

INSTRUCTION MANUAL

TECO INVERTER

200V class

IP20 3 Phase 3.7~132KW
5~175HP

400V class

IP20 3 Phase 3.7~315KW
5~425HP

IP55 3 Phase 3.7~75KW
5~100HP



TECO INVERTER

F510 Series

Table of Contents

Preface	0-1
Chapter 1 Safety Precautions	1-1
1.1 Before Supplying Power to the Inverter	1-1
1.2 Wiring.....	1-2
1.3 Before Operation	1-3
1.4 Parameters Setting	1-3
1.5 Operation	1-4
1.6 Maintenance, Inspection and Replacement.....	1-5
1.7 Disposal of the Inverter	1-5
Chapter 2 Model Description	2-1
2.1 Nameplate Data.....	2-1
2.2 Inverter Models-Motor Power Rating	2-1
Chapter 3 Environment and Installation	3-1
3.1 Environment.....	3-1
3.2 Installation.....	3-2
3.2.1 Installation Spaces	3-2
3.2.2 External View.....	3-3
3.2.2.1 External View (IP00/ IP20).....	3-3
3.2.2.2 External View (IP55).....	3-6
3.2.3 Warning Labels.....	3-7
3.2.4 Removing the Front Cover and Keypad.....	3-8
3.2.4.1 Standard Type (IP00/IP20).....	3-9
3.2.4.2 Built-in Filter Type (IP20/IP00).....	3-15
3.2.4.3 Built-in Filter Type (IP55).....	3-16
3.3 Inverter Wiring	3-18
3.3.1 Wire Gauges and Tightening Torque.....	3-18
3.3.2 Wiring Peripheral Power Devices	3-19
3.3.3 General Wiring Diagram	3-21
3.3.4 Single/ Multi- Pump Dedicated Wiring Diagram.....	3-22
3.3.5 Wiring for Control Circuit Terminals.....	3-25
3.3.6 Wiring for Main Circuit Terminals	3-28
3.3.7 Wiring Precautions	3-37
3.3.8 Input Power and Cable Length	3-39
3.4 Inverter Specifications.....	3-40
3.5 Inverter Derating Based on Carrier Frequency	3-43
3.6 Inverter Derating Based on Temperature.....	3-47
3.7 Inverter Dimensions.....	3-48
3.7.1 Standard Type (IP00/IP20).....	3-48
3.7.2 Models with Built-in Filter (IP00/IP20).....	3-56
3.7.3 Models with Built-in Filter (IP55)	3-58
Chapter 4 Keypad and Programming Functions	4-1
4.1 LED Keypad.....	4-1
4.1.1 Keypad Display and Keys.....	4-1
4.1.2 Seven Segment Display Description.....	4-3
4.1.3 LED Indicator Description	4-5
4.1.4 Power-up Monitor	4-7

4.1.5	Modifying Parameters/ Set Frequency Reference	4-8
4.1.6	Operation Control	4-10
4.2	LCD keypad	4-11
4.2.1	Keypad Display and Keys	4-11
4.2.2	Keypad Menu Structure	4-13
4.3	Parameters	4-17
4.4	Description of Parameters	4-62
4.5	Built-in PLC Function	4-253
4.5.1	Basic Command	4-253
4.5.2	Basic Command Function	4-254
4.5.3	Application Functions	4-255
4.6	Modbus Protocol Descriptions	4-262
4.6.1	Communication Connection and Data Frame	4-262
4.6.2	Register and Data Format	4-266
4.7	BacNET Protocol Descriptions	4-285
4.7.1	BACnet Services	4-285
4.7.2	BACnet Protocol Structure	4-286
4.7.3	BACnet Specifications	4-287
4.7.4	BACnet Object Properties	4-288
4.8	MetaSys N2 Communication Protocol	4-291
4.8.1	Introduction and Setting	4-291
4.8.2	MetaSys N2 Specification	4-291
4.8.3	Definition of MetaSys N2 Communication Protocol	4-292
4.8.4	MetaSys N2 Communication Protocol in F510 Model	4-293
Chapter 5 Check Motor Rotation and Direction		5-1
Chapter 6 Speed Reference Command Configuration		6-1
6.1	Reference from Keypad	6-1
6.2	Reference from External Analog Signal (0-10V / 4-20mA)	6-2
6.3	Reference from Serial Communication RS485 (00-05=3)	6-4
6.4	Reference from two Analog Inputs	6-6
6.5	Change Frequency Unit from Hz to rpm	6-6
Chapter 7 Operation Method Configuration (Run / Stop)		7-1
7.1	Run/Stop from the Keypad (00-02=0) – Default Setting	7-1
7.2	Run/Stop from External Switch / Contact or Pushbutton (00-02=1)	7-2
7.3	Run/Stop from Serial Communication RS485 (00-02=3)	7-3
Chapter 8 Motor and Application Specific Settings		8-1
8.1	Set Motor Nameplate Data (02-01, 02-05)	8-1
8.2	Acceleration and Deceleration Time (00-14, 00-15)	8-2
8.3	Torque Compensation Gain (01-10)	8-3
8.4	Automatic Energy Savings Function (11-19)	8-4
8.5	Emergency Stop	8-6
8.6	Direct / Unattended Startup	8-7
8.7	Analog Output Setup	8-8
Chapter 9 Using PID Control for Constant Flow / Pressure Applications		9-1
9.1	What is PID Control?	9-1

9.2 Connect Transducer Feedback Signal (10-01)	9-3
9.3 Engineering Units	9-4
9.4 Sleep / Wakeup Function	9-5
Chapter 10 Troubleshooting and Fault Diagnostics	10-1
10.1 General	10-1
10.2 Fault Detection Function	10-1
10.3 Warning / Self-diagnosis Detection Function	10-5
10.4 Auto-tuning Error	10-12
10.5 PM Motor Auto-tuning Error	10-13
Chapter 11 Inverter Peripheral devices and Options	11-1
11.1 Braking Resistors and Braking Units	11-1
11.2 AC Line Reactors	11-4
11.2.1 200V Class AC Reactor Dimensions	11-5
11.2.2 400V Class AC Reactor Dimensions	11-6
11.3 Input Noise Filters	11-7
11.4 Input Current and Fuse Specifications	11-9
11.5 Other options	11-11
11.6 Communication options	11-16
11.7 Profibus Communication Option Card	11-17
11.7.1 Introduction	11-17
11.7.2 Specification of JN5-CM-PBUS	11-17
11.7.3 Wiring Diagram of JN5-CM-PBUS	11-18
11.7.4 Installation	11-18
11.7.5 Descriptions of Terminals, LEDs and DIP switch	11-21
11.7.6 Related Parameters for Communication	11-22
11.7.7 Profibus I/O List	11-22
11.7.8 Error Message	11-26
11.7.9 GSD File	11-26
11.8 Protective Cover	11-28
Appendix-A Instructions for UL	A-1

Preface

The F510 product is an inverter designed to control a three-phase induction motor. Please read this manual carefully to ensure correct operation, safety and to become familiar with the inverter functions.

The F510 inverter is an electrical / electronic product and must be installed and handled by qualified service personnel.

Improper handling may result in incorrect operation, shorter life cycle, or failure of this product as well as the motor.

All F510 documentation is subject to change without notice. Be sure to obtain the latest editions for use or visit our website at <http://globalsa.teco.com.tw>.



Available Documentation:

1. F510 Start-up and Installation Manual
2. F510 Instruction Manual

Read this instruction manual thoroughly before proceeding with installation, connections (wiring), operation, or maintenance and inspection.

Ensure you have sound knowledge of the inverter and familiarize yourself with all safety information and precautions before proceeding to operate the inverter.

Please pay close attention to the safety precautions indicated by the warning  and caution  symbol.

 Warning	Failure to ignore the information indicated by the warning symbol may result in death or serious injury.
 Caution	Failure to ignore the information indicated by the caution symbol may result in minor or moderate injury and/or substantial property damage.

Chapter 1 Safety Precautions

1.1 Before Supplying Power to the Inverter



Warning

- The main circuit must be correctly wired. For single phase supply use input terminals (R/L1, T/L3) and for three phase supply use input terminals (R/L1, S/L2, T/L3). Terminals U/T1, V/T2, W/T3 must only be used to connect the motor. Connecting the input supply to any of the U/T1, V/T2 or W/T3 terminals will cause damage to the inverter.



Caution

- To avoid the front cover from disengaging or other physical damage, do not carry the inverter by its cover. Support the unit by its heat sink when transporting. Improper handling can damage the inverter or injure personnel, and should be avoided.
- To avoid the risk of fire, do not install the inverter on or near flammable objects. Install on nonflammable objects such as metal surfaces.
- If several inverters are placed inside the same control panel, provide adequate ventilation to maintain the temperature below 40°C/104°F (50°C/122°F without a dust cover) to avoid overheating or fire.
- When removing or installing the digital operator, turn off the power first, and then follow the instructions in this manual to avoid operator error or loss of display caused by faulty connections.



Warning

- This product is sold subject to IEC 61800-3. In a domestic environment this product may cause radio interference in which case the user may need to apply corrective measures.
- Over temperature protection function on motor is disabled.

1.2 Wiring



Warning

- Always turn OFF the power supply before attempting inverter installation and wiring of the user terminals.
- Wiring must be performed by a qualified personnel / certified electrician.
- Make sure the inverter is properly grounded. (200V Class: Grounding impedance shall be less than 100Ω. 400V Class: Grounding impedance shall be less than 10Ω.) It is required to disconnect the ground wire in the control board to avoid the sudden surge causing damage on electronic parts if it is improperly grounded.
- Please check and test emergency stop circuits after wiring. (Installer is responsible for the correct wiring.)
- Never touch any of the input or output power lines directly or allow any input or output power lines to come in contact with the inverter case.
- Do not perform a dielectric voltage withstand test (megger) on the inverter or this will result in inverter damage to the semiconductor components.



Caution

- The line voltage applied must comply with the inverter's specified input voltage. (See product nameplate section 2.1)
- Connect braking resistor and braking unit to the designated terminals. (See section 3.3.5)
- Do not connect a braking resistor directly to the DC terminals P(+) and N(-), otherwise fire may result.
- Use wire gauge recommendations and torque specifications. (See Wire Gauge and Torque Specification section 3.3.1) °
- Never connect input power to the inverter output terminals U/T1, V/T2, W/T3.
- Do not connect a contactor or switch in series with the inverter and the motor.
- Do not connect a power factor correction capacitor or surge suppressor to the inverter output °
- Ensure the interference generated by the inverter and motor does not affect peripheral devices.

1.3 Before Operation



Warning

- Make sure the inverter capacity matches the parameters 13-00 before supplying power.
- Reduce the carrier frequency (parameter 11-01) if the cable from the inverter to the motor is over 80 ft (25m). A high-frequency current can be generated by stray capacitance between the cables and result in an overcurrent trip of the inverter, an increase in leakage current, or an inaccurate current readout.
- Be sure to install all covers before turning on power. Do not remove any of the covers while power to the inverter is on, otherwise electric shock may occur.
- Do not operate switches with wet hands, otherwise electric shock may result.
- Do not touch inverter terminals when energized even if inverter has stopped, otherwise electric shock may result.

1.4 Parameter Setting



Caution

- Do not connect a load to the motor while performing an auto-tune.
- Make sure the motor can freely run and there is sufficient space around the motor when performing a rotational auto-tune.

1.5 Operation




Warning

- Be sure to install all covers before turning on power. Do not remove any of the covers while power to the inverter is on, otherwise electric shock may occur.
- Do not connect or disconnect the motor during operation. This will cause the inverter to trip and may cause damage to the inverter.
- Operations may start suddenly if an alarm or fault is reset with a run command active. Confirm that no run command is active upon resetting the alarm or fault, otherwise accidents may occur.
- Do not operate switches with wet hands, otherwise electric shock may result.
- An external emergency stop switch is enabled when parameter 08-30 is set for the run permissive function.
- It provides an independent external hardware emergency switch, which emergently shuts down the inverter output in the case of danger.
- If automatic restart after power recovery (parameter 07-00) is enabled, the inverter will start automatically after power is restored.
- Make sure it is safe to operate the inverter and motor before performing a rotational auto-tune.
- Do not touch inverter terminals when energized even if inverter has stopped, otherwise electric shock may result.
- Do not check signals on circuit boards while the inverter is running.
- After the power is turned off, the cooling fan may continue to run for some time.



Caution

- Do not touch heat-generating components such as heat sinks and braking resistors.

- Carefully check the performance of motor or machine before operating at high speed, otherwise Injury may result.
- Note the parameter settings related to the braking unit when applicable.
- Do not use the inverter braking function for mechanical holding, otherwise injury may result.
- Do not check signals on circuit boards while the inverter is running.

1.6 Maintenance, Inspection and Replacement



Warning

- Wait a minimum of 5 minutes after power has been turned OFF before starting an inspection. Also confirm that the charge light is OFF and that the DC bus voltage has dropped below 25Vdc. Wait a minimum of 15 minutes while inverter is over 20HP.
- Never touch high voltage terminals in the inverter.
- Make sure power to the inverter is disconnected before disassembling the inverter.
- Only authorized personnel should perform maintenance, inspection, and replacement operations. (Take off metal jewelry such as watches and rings and use insulated tools.)



Caution

- The Inverter can be used in an environment with a temperature range from 14° -104°F (-10-40°C) and relative humidity of 95% non-condensing.
- The inverter must be operated in a dust, gas, mist and moisture free environment.

1.7 Disposal of the Inverter



Caution

- Please dispose of this unit with care as an industrial waste and according to your required local regulations.
- The capacitors of inverter main circuit and printed circuit board are considered as hazardous waste and must not be burned.
- The Plastic enclosure and parts of the inverter such as the top cover board will release harmful gases if burned.


Chapter 2 Model Description

2.1 Nameplate Data


It is essential to verify the F510 inverter nameplate and make sure that the F510 inverter has the correct rating so it can be used in your application with the proper sized AC motor.

Unpack the F510 inverter and check the following:

- (1) The F510 inverter and quick setting guide are contained in the package.
- (2) The F510 inverter has not been damaged during transportation there should be no dents or parts missing.
- (3) The F510 inverter is the type you ordered. You can check the type and specifications on the main nameplate.
- (4) Check that the input voltage range meets the input power requirements.
- (5) Ensure that the motor HP matches the motor rating of the inverter.



2.2 Model Identification



Inverter Models – Motor Power Rating :

200V Class

Voltage (Vac) & Frequency (Hz)	F510 Model	Motor Power (Hp)	Applied Motor (kW)	Filter		Operator		Protection Class (IP55)
				with	without	LED	LCD	
3ph 200~240V +10%/-15% 50/60Hz	F510-2005-H3	5	3.7		⊙	⊙		
	F510-2005-C3	5	3.7		⊙		⊙	
	F510-2008-H3	7.5	5.5		⊙	⊙		
	F510-2008-C3	7.5	5.5		⊙		⊙	
	F510-2010-H3	10	7.5		⊙	⊙		
	F510-2010-C3	10	7.5		⊙		⊙	
	F510-2015-H3	15	11		⊙	⊙		
	F510-2015-C3	15	11		⊙		⊙	
	F510-2020-H3	20	15		⊙	⊙		
	F510-2020-C3	20	15		⊙		⊙	
	F510-2025-H3	25	18.5		⊙	⊙		
	F510-2025-C3	25	18.5		⊙		⊙	
	F510-2030-H3	30	22		⊙	⊙		
	F510-2030-C3	30	22		⊙		⊙	
	F510-2040-H3	40	30		⊙	⊙		
	F510-2040-C3	40	30		⊙		⊙	
	F510-2050-H3	50	37		⊙	⊙		
	F510-2050-C3	50	37		⊙		⊙	
	F510-2060-H3	60	45		⊙	⊙		
	F510-2060-C3	60	45		⊙		⊙	
	F510-2075-H3	75	55		⊙	⊙		
	F510-2075-C3	75	55		⊙		⊙	
	F510-2100-H3	100	75		⊙	⊙		
	F510-2100-C3	100	75		⊙		⊙	
	F510-2125-H3	125	94		⊙	⊙		
	F510-2125-C3	125	94		⊙		⊙	
F510-2150-H3	150	112		⊙	⊙			
F510-2150-C3	150	112		⊙		⊙		
F510-2175-H3	175	130		⊙	⊙			
F510-2175-C3	175	130		⊙		⊙		

Note:

- Short Circuit Rating: 200V Class: 5KA.

400V Class

Voltage (Vac) & Frequency (Hz)	F510 Model	Motor Power (Hp)	Applied Motor (kW)	Filter		Operator		Protection Class (IP55)
				with	without	LED	LCD	
3ph 380~480V +10%/-15% 50/60Hz	F510-4005-H3	5	3.7		⊙	⊙		
	F510-4005-H3F	5	3.7	⊙		⊙		
	F510-4005-C3	5	3.7		⊙		⊙	
	F510-4005-C3F	5	3.7	⊙			⊙	
	F510-4005-C3FN4	5	3.7	⊙			⊙	⊙
	F510-4008-H3	7.5	5.5		⊙	⊙		
	F510-4008-H3F	7.5	5.5	⊙		⊙		
	F510-4008-C3	7.5	5.5		⊙		⊙	
	F510-4008-C3F	7.5	5.5	⊙			⊙	
	F510-4008-C3FN4	7.5	5.5	⊙			⊙	⊙
	F510-4010-H3	10	7.5		⊙	⊙		
	F510-4010-H3F	10	7.5	⊙		⊙		
	F510-4010-C3	10	7.5		⊙		⊙	
	F510-4010-C3F	10	7.5	⊙			⊙	
	F510-4010-C3FN4	10	7.5	⊙			⊙	⊙
	F510-4015-H3	15	11		⊙	⊙		
	F510-4015-H3F	15	11	⊙		⊙		
	F510-4015-C3	15	11		⊙		⊙	
	F510-4015-C3F	15	11	⊙			⊙	
	F510-4015-C3FN4	15	11	⊙			⊙	⊙
	F510-4020-H3	20	15		⊙	⊙		
	F510-4020-H3F	20	15	⊙		⊙		
	F510-4020-C3	20	15		⊙		⊙	
	F510-4020-C3F	20	15	⊙			⊙	
	F510-4020-C3FN4	20	15	⊙			⊙	⊙
	F510-4025-H3	25	18.5		⊙	⊙		
	F510-4025-H3F	25	18.5	⊙		⊙		
	F510-4025-C3	25	18.5		⊙		⊙	
	F510-4025-C3F	25	18.5	⊙			⊙	
	F510-4025-C3FN4	25	18.5	⊙			⊙	⊙
	F510-4030-H3	30	22		⊙	⊙		
	F510-4030-H3F	30	22	⊙		⊙		
F510-4030-C3	30	22		⊙		⊙		
F510-4030-C3F	30	22	⊙			⊙		
F510-4030-C3FN4	30	22	⊙			⊙	⊙	
F510-4040-H3	40	30		⊙	⊙			
F510-4040-H3F	40	30	⊙		⊙			
F510-4040-C3	40	30		⊙		⊙		
F510-4040-C3F	40	30	⊙			⊙		
F510-4040-C3FN4	40	30	⊙			⊙	⊙	

Voltage (Vac) & Frequency (Hz)	F510 Model	Motor Power (Hp)	Applied Motor (kW)	Filter		Operator		Protection Class (IP55)
				with	without	LED	LCD	
3ph 380~480V +10%/-15% 50/60Hz	F510-4050-H3	50	37		○	○		
	F510-4050-H3F	50	37	○		○		
	F510-4050-C3	50	37		○		○	
	F510-4050-C3F	50	37	○			○	
	F510-4050-C3FN4	50	37	○			○	○
	F510-4060-H3	60	45		○	○		
	F510-4060-H3F	60	45	○		○		
	F510-4060-C3	60	45		○		○	
	F510-4060-C3F	60	45	○			○	
	F510-4060-C3FN4	60	45	○			○	○
	F510-4075-H3	75	55		○	○		
	F510-4075-H3F	75	55	○		○		
	F510-4075-C3	75	55		○		○	
	F510-4075-C3F	75	55	○			○	
	F510-4075-C3N4	75	55		○		○	○
	F510-4100-H3	100	75		○	○		
	F510-4100-C3	100	75		○		○	
	F510-4100-C3N4	100	75		○		○	○
	F510-4125-H3	125	94		○	○		
	F510-4125-C3	125	94		○		○	
	F510-4150-H3	150	112		○	○		
	F510-4150-C3	150	112		○		○	
	F510-4175-H3	175	130		○	○		
	F510-4175-C3	175	130		○		○	
	F510-4215-H3	215	160		○	○		
	F510-4215-C3	215	160		○		○	
	F510-4250-H3	250	185		○	○		
	F510-4250-C3	250	185		○		○	
	F510-4300-H3	300	220		○	○		
	F510-4300-C3	300	220		○		○	
	F510-4375-H3	375	280		○	○		
	F510-4375-C3	375	280		○		○	
F510-4425-H3	425	317		○	○			
F510-4425-C3	425	317		○		○		
F510-4535-H3	535	400		○	○			
F510-4535-C3	535	400		○		○		
F510-4670-H3	670	500		○	○			
F510-4670-C3	670	500		○		○		
F510-4800-H3	800	600		○	○			
F510-4800-C3	800	600		○		○		

Note:

- Short Circuit Rating: 400V Class: 5KA.

Chapter 3 Environment and Installation

3.1 Environment

The environment will directly affect the proper operation and the life span of the inverter. To ensure that the inverter will give maximum service life, please comply with the following environmental conditions:

Protection	
Protection Class	IP20/ NEMA 1, IP00
	IP55/ NEMA 12
Ambient Environment	
Operating Temperature	Ambient Temperature: -10°C - +40°C (14 -104 °F)
	Without Cover: -10°C - +50°C (14-122 °F)
	If several inverters are placed in the same control panel, provide a heat removal means to maintain ambient temperatures below 40°C
Storage Temperature	-20°C - +70°C (-4 -158 °F)
Humidity	95% non-condensing Relative humidity 5% to 95%, free of moisture. (Follow IEC60068-2-78 standard)
Altitude	< 1000m (3,281 ft.)
Installation Site	Avoid direct sunlight.
	Avoid exposure to rain or moisture.
	Avoid oil mist and salinity.
	Avoid corrosive liquid and gas.
	Avoid dust, lint fibers, and small metal filings.
	Avoid electromagnetic interference (soldering machines, power machines).
	Keep away from radioactive and flammable materials.
	Avoid vibration (stamping, punching machines etc.). Add a vibration-proof pad if the situation cannot be avoided.
Shock	Maximum acceleration: 1.2G (12m/s ²), from 49.84 to 150 Hz Displacement amplitude : 0.3mm (peak value), from 10 to 49.84 Hz (Follow IEC60068-2-6 standard)

3.2 Installation

3.2.1 Installation Spaces

- When installing the inverter, ensure that inverter is installed in upright position (vertical direction) and there is adequate space around the unit to allow normal heat dissipation as per the following Fig. 3.2.1




Fig 3.2.1: F510 Installation space

$X = 1.18''$ (30mm) for inverter ratings up to 18.5kW


$X = 1.96''$ (50mm) for inverter ratings 22kW or higher

- **Important Note:** The inverter heatsink temperature can reach up to 90°C/ 194°F during operation; make sure to use insulation material rated for this temperature.


3.2.2 External View

3.2.2.1 External View (IP00/ IP20)

(a) 200V 5-7.5HP/ 400V 5-10HP



(Wall-mounted type, IEC IP00)




(Wall-mounted type, IEC IP20, NEMA1)

(b) 200V 10-30HP/ 400V 15-40HP




(Wall-mounted type, IEC IP00)




(Wall-mounted type, IEC IP20, NEMA1)

(c) 200V 40-50HP/ 400V 50-75HP



(Wall-mounted type, IEC IP20, NEMA1)

(d) 200V 60-125HP/ 400V 100-250HP




(Wall-mounted type, IEC IP00)




(Wall-mounted type, IEC IP20, NEMA1)

(e) 200V 150-175HP/ 400V 300-425HP




(Wall-mounted type, IEC IP00)




(Wall-mounted type, IEC IP20)

(f) 400V 535-800HP




(Wall-mounted type, IEC IP00)




(Wall-mounted type, IEC IP20)

3.2.2.2 External View (IP55)

(a) 400V 5-25HP



(b) 400V 30-100HP



(Wall-mounted type, IEC IP55)



(Wall-mounted type, IEC IP55)

Information provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk



3.2.3 Warning Labels

Important:

Warning information located on the front cover must be read upon installation of the inverter.

 **WARNING**
 Risk of electrical shock. Shut off main power and wait for 5 minutes before servicing.
 Hot surface. Risk of burn.
 **CAUTION**
See manual before operation.




(a) 200V: 5-7.5HP/ 400V: 5-10HP (IP20)

 **WARNING**
 Risk of electrical shock. Shut off main power and wait for 5 minutes before servicing.
 **CAUTION**
See manual before operation.

(b) 200V: 10-15HP/ 400V: 15-20HP (IP20)

 **WARNING**
 Risk of electrical shock. Shut off main power and wait for 15 minutes before servicing.
 **CAUTION**
See manual before operation.

(c) 200V: 20-175HP/ 400V: 25-800HP(IP20)

 **WARNING**
 Risk of electrical shock. Shut off main power and wait for 5 minutes before servicing.
 **CAUTION**
See manual before operation.

(d) 400V : 5-100HP (IP55)

3.2.4 Removing the Front Cover and Keypad


- Before making any wiring connections to the inverter, the front cover needs to be removed.

IP00/ IP20 Type



- It is not required to remove the digital operator before making any wiring connections.
- Models 200V, 5 – 30 HP and 400V, 5 – 40 HP have a plastic cover. Loosen the screws and remove the cover to gain access to the terminals and make wiring connections. Place the plastic cover back and fasten screws when wiring connections have been made.
- Models 200V, 40 - 175HP and 400V, 50 - 800HP have a metal cover. Loosen the screws and remove the cover to gain access to the terminals and make wiring connections. Place the metal cover back and fasten screws when wiring connections have been made.


IP55 Type




- It is essential to remove the digital operator before making any wiring connections.
- Model 400V, 5 – 25 HP has a plastic cover. Loosen the screws and remove the cover to gain access to the terminals and make wiring connections. Place the plastic cover back and fasten screws when wiring connections have been made.
- Models 400V, 30 - 100HP has a metal cover. Loosen the screws and remove the cover to gain access to the terminals and make wiring connections. Place the metal cover back and fasten screws when wiring connections have been made.

3.2.4.1 Standard Type (IP00/ IP20)


(a) 200V 5-7.5HP/ 400V 5-10HP




Step 1: Unscrew



Step 2: Remove cover




Step 3: Make wire connections and place cover back




Step 4: Fasten screw


(b) 200V 10-30HP/ 400V 15-40HP




Step 1: Unscrew



Step 2: Remove cover




Step 3: Make wire connections and place cover back




Step 4: Fasten screw


(c) 200V 40-50HP/ 400V 50-75HP




Step 1: Unscrew cover



Step 2: Remove cover




Step 3: Make wire connections and place cover back




Step 4: Fasten screw


(d) 200V 60-125HP/ 400V 100-250HP




Step 1: Unscrew cover



Step 2: Remove cover




Step 3: Make wire connections and place cover back




Step 4: Fasten screw


(e) 200V 150-175HP/ 400V 300-425HP




Step 1: Unscrew cover



Step 2: Remove cover




Step 3: Make wire connections and place cover back




Step 4: Fasten screw


(f) 400V 535-800HP




Step 1: Unscrew cover



Step 2: Remove cover




Step 3: Make wire connections and place cover back




Step 4: Fasten screw

3.2.4.2 Built-in Filter Type (IP20/ IP00)


400V 5-75HP




Step 1: Unscrew cover




Step 2: Remove cover




Step 3: Unscrew filter section



Step 4: Remove filter cover




Step 5: Make connections and place filter cover back




Step 6: Fasten screw

3.2.4.3 Built-in Filter Type (IP55)


(a) 400V 5-25HP




Step 1: Unscrew operator




Step 2: Remove operator



Step 3: Pull out operator and remove power line




Step 4: Unscrew cover




Step 5: Check the inside waterproof gasket is not pulled away from cover while opening the cover


(b) 400V 30-100HP




Step 1: Unscrew operator



Step 2: Remove operator



Step 3: Pull out operator and remove power line



Step 4: Unscrew cover and remove it

3.3 Inverter Wiring

3.3.1 Wire Gauges and Tightening Torque

To comply with UL standards, use UL approved copper wires (rated 75° C) and round crimp terminals (UL Listed products) as shown in table below when connecting to the main circuit terminals. Teco recommends using crimp terminals manufactured by NICHIFU Terminal Industry Co., Ltd and the terminal crimping tool recommended by the manufacturer for crimping terminals and the insulating sleeve.

Table 3.3.1.1 Wire gauges and tightening torque terminal screw size

Wire size mm ² (AWG)	Terminal Screw size	Model of round crimp terminal	Tightening torque kgf.cm (in.lbs)	Model of insulating sleeve	Model of crimp tool
0.75 (18)	M3.5	R1.25-3.5	8.2 to 10 (7.1 to 8.7)	TIC 1.25	NH 1
	M4	R1.25-4	12.2 to 14 (10.4 to 12.1)	TIC 1.25	NH 1
1.25 (16)	M3.5	R1.25-3.5	8.2 to 10 (7.1 to 8.7)	TIC 1.25	NH 1
	M4	R1.25-4	12.2 to 14 (10.4 to 12.1)	TIC 1.25	NH 1
2 (14)	M3.5	R2-3.5	8.2 to 10 (7.1 to 8.7)	TIC 2	NH 1 / 9
	M4	R2-4	12.2 to 14 (10.4 to 12.1)	TIC 2	NH 1 / 9
	M5	R2-5	22.1 to 24 (17.7 to 20.8)	TIC 2	NH 1 / 9
	M6	R2-6	25.5 to 30.0 (22.1 to 26.0)	TIC 2	NH 1 / 9
3.5/5.5 (12/10)	M4	R5.5-4	12.2 to 14 (10.4 to 12.1)	TIC 3.5/5.5	NH 1 / 9
	M5	R5.5-5	20.4 to 24 (17.7 to 20.8)	TIC 3.5/5.5	NH 1 / 9
	M6	R5.5-6	25.5 to 30.0 (22.1 to 26.0)	TIC 3.5/5.5	NH 1 / 9
	M8	R5.5-8	61.2 to 66.0 (53.0 to 57.2)	TIC 3.5/5.5	NH 1 / 9
8 (8)	M4	R8-4	12.2 to 14 (10.4 to 12.1)	TIC 8	NOP 60
	M5	R8-5	20.4 to 24 (17.7 to 20.8)	TIC 8	NOP 60
	M6	R8-6	25.5 to 30.0 (22.1 to 26.0)	TIC 8	NOP 60
	M8	R8-8	61.2 to 66.0 (53.0 to 57.2)	TIC 8	NOP 60
14 (6)	M4	R14-4	12.2 to 14 (10.4 to 12.1)	TIC 14	NH 1 / 9
	M5	R14-5	20.4 to 24 (17.7 to 20.8)	TIC 14	NH 1 / 9
	M6	R14-6	25.5 to 30.0 (22.1 to 26.0)	TIC 14	NH 1 / 9
	M8	R14-8	61.2 to 66.0 (53.0 to 57.2)	TIC 14	NH 1 / 9
22 (4)	M6	R22-6	25.5 to 30.0 (22.1 to 26.0)	TIC 22	NOP 60/ 150H
	M8	R22-8	61.2 to 66.0 (53.0 to 57.2)	TIC 22	NOP 60/ 150H
30/38 (3 / 2)	M6	R38-6	25.5 to 30.0 (22.1 to 26.0)	TIC 38	NOP 60/ 150H
	M8	R38-8	61.2 to 66.0 (53.0 to 57.2)	TIC 38	NOP 60/ 150H
50/ 60 (1/ 1/ 0)	M8	R60-8	61.2 to 66.0 (53.0 to 57.2)	TIC 60	NOP 60/ 150H
	M10	R60-10	102 to 120 (88.5 to 104)	TIC 60	NOP 150H
70 (2/0)	M8	R70-8	61.2 to 66.0 (53.0 to 57.2)	TIC 60	NOP 150H
	M10	R70-10	102 to 120 (88.5 to 104)	TIC 60	NOP 150H
80 (3/0)	M10	R80-10	102 to 120 (88.5 to 104)	TIC 80	NOP 150H
	M16	R80-16	255 to 280 (221 to 243)	TIC 80	NOP 150H
100 (4/0)	M10	R100-10	102 to 120 (88.5 to 104)	TIC 100	NOP 150H
	M12	R100-12	143 to 157 (124 to 136)	TIC 100	NOP 150H
	M16	R80-16	255 to 280 (221 to 243)	TIC 80	NOP 150H

3.3.2 Wiring Peripheral Power Devices



Caution

- After power is shut off to the inverter, the capacitors will slowly discharge. Do NOT touch the inverter circuitry or replace any components until the “CHARGE” indicator is off.
- Do NOT wire or connect/disconnect internal connectors of the inverter when the inverter is powered up or when powered off and the “CHARGE” indicator is on.
- Do NOT connect inverter output U, V and W to the supply power. This will result in damage to the inverter.
- The inverter must be properly grounded. Use terminal E to connect earth ground and comply with local standards.
- It is required to disconnect the grounded wire in the control board when the inverter is not grounded or floating ground power system.
- Do NOT perform a dielectric voltage withstand test (megger) on the inverter this will result in inverter damage to the semiconductor components.
- Do NOT touch any of the components on the inverter control board to prevent damage to the inverter by static electricity.




Caution

- Refer to the recommended wire size table for the appropriate wire to use. The voltage between the power supply and the input of the inverter may not exceed 2%.


$$\text{Phase-to-phase voltage drop (V)} = \sqrt{3} \times \text{resistance of wire } (\Omega/\text{km}) \times \text{length of line (m)} \times \text{current} \times 10^{-3}.$$

(km=3280 x feet) / (m=3.28 x feet)

- Reduce the carrier frequency (parameter 11-01) if the cable from the inverter to the motor is greater than 25m (82ft). A high-frequency current can be generated by stray capacitance between the cables and result in an overcurrent trip of the inverter, an increase in leakage current, or an inaccurate current readout.
- To protect peripheral equipment, install fast acting fuses on the input side of the inverter. Refer to section 11.4 for additional information.




Power supply:


-  Make sure the correct voltage is applied to avoid damaging the inverter.

Molded-case circuit breaker (MCCB) or fused disconnect:

- A molded-case circuit breaker or fused disconnect must be installed between the AC source and the inverter that conforms to the rated voltage and current of the inverter to control the power and protect the inverter.

-  Do not use the circuit breaker as the run/stop switch for the inverter.

Ground fault detector / breaker:

-  Install a ground fault breaker to prevent problems caused by current leakage and to protect personnel. Select current range up to 200mA, and action time up to 0.1 second to prevent high frequency failure.

Magnetic contactor:

- Normal operations do not need a magnetic contactor. When performing functions such as external control and auto restart after power failure, or when using a brake controller, install a magnetic contactor.

-  Do not use the magnetic contactor as the run/stop switch for the inverter.

AC line reactor for power quality:

- When inverters are supplied by a high capacity power source (> 600KVA), an AC reactor can be connected to improve the power factor.

Install Fast Acting Fuse:


- To protect peripheral equipment, install fast acting fuses in accordance with the specifications in section 11.4 for peripheral devices.


Input Noise filter:

- A filter must be installed when there are inductive loads affecting the inverter. The inverter meets EN55011 Class A, category C3 when the TECO special filter is used. See section 11.3 for peripheral devices.

Inverter:

- Output terminals T1, T2, and T3 are connected to U, V, and W terminals of the motor. If the motor runs in reverse while the inverter is set to run forward, swap any two terminals connections for T1, T2, and T3.

-  To avoid damaging the inverter, do not connect the output terminals T1, T2, and T3 to AC input power.

-  Connect the ground terminal properly. (200V series: $R_g < 100\Omega$; 400V series: $R_g < 10\Omega$.)

Output Noise filter:


- An output noise filter may reduce system interference and induced noise.

Motor:

- If the inverter drives multiple motors the output rated current of the inverter must be greater than the total current of all the motors.

3.3.3 General Wiring Diagram


The following is the standard wiring diagram for the F510 inverter (⊙ indicates main circuit terminals and ○ indicates control circuit terminals). Locations and symbols of the wiring terminal block might be different due to different models of F510. The description of control circuit terminals and main circuit terminals can be referred to Table 3.3.5.1, 3.3.6.1 and 3.3.6.2




3.3.4 Single/ Multi- Pump Dedicated Wiring Diagram

■ PUMP Wiring Diagram for Pressure Sensor of Voltage Type

Single Pump:




Multi-Pump:




■ PUMP Wiring Diagram for Pressure Sensor of Current Type

Single Pump:



Multi-Pump:



Notes: 1. The position of dip switch requires being correct (SW2, SW3).

2. It is required to reconnect after setting Master/ Slave.

3. 24VG and GND require short circuit.
4. When the communication modes is selected to be multiple pumps in parallel connection (09-01=3), the baud rate settings (09-02) of Master and Slave are required to be consistent. Refer to parameter 23-31 for the actions in parallel connection modes.
5. In the wiring of multi-pump current type pressure sensor, it is required to adjust Slave to be 04-07(AI2 Gain) =252.0% and 04-08(AI1 Bias) =25.0%.

Information
provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk

3.3.5 Wiring for Control Circuit Terminals

■ Control circuit terminals identification

◆ IP20 type

- 200V: 5HP~50HP , 400V: 5HP~75HP

S(+)	S(-)	S1	S3	S5	24V	+10V	MT	GND	GND	AI1	AI2
E	24VG	S2	S4	S6	F1	F2	PO	P I	AO1	AO2	E

R1A	R1B	R1C	
R2A	R2C	R3A	R3C

- 200V: 60HP~125HP , 400V: 100HP~800HP

S(+)	S(-)	S1	S3	S5	24V	+10V	MT	GND	GND	AI1	AI2
E	24VG	S2	S4	S6	F1	F2	PO	P I	AO1	AO2	E

R1A	R1B	R1C	R2A	R2C	R3A	R3C
-----	-----	-----	-----	-----	-----	-----

◆ IP55 type

- 400V: 5HP~100HP

S(+)	S(-)	S1	S3	S5	24V	+10V	MT	GND	GND	AI1	AI2
E	24VG	S2	S4	S6	F1	F2	PO	P I	AO1	AO2	E

R1A	R1B	R1C	
R2A	R2C	R3A	R3C

Table 3.3.5.1 Description of control circuit terminals

Type	Terminal	Terminal function	Signal level/ information
Digital input signal	S1	2-wire forward rotation/ stop command (default), multi-function input terminals * 1	Signal Level 24 VDC (opto-isolated) Maximum current: 8mA Maximum voltage: 30 Vdc Input impedance: 4.22kΩ
	S2	2-wire reversal rotation/ stop command (default), multi-function input terminals * 1	
	S3	Multi-speed/ position setting command 1 (default), multi-function input terminals * 1	
	S4	Multi-speed/ position setting command 2 (default), multi-function input terminals * 1	
	S5	Multi-speed/ position setting command 3 (default), multi-function input terminal* 1	
	S6	Fault reset (default), multi-function input terminal * 1	
24V Power supply	24V	Digital signal SOURCE point (SW3 switched to SOURCE)	±15%, Max. output current: 250mA (The sum of all loads connected)
	24VG	Common terminal of Digital signals Common point of digital signal SINK (SW3 switched to SINK)	
Analog input signal	+10V	Power for external speed potentiometer	±5% (Max. current: 20mA)
	MT	Motor temperature detector of externally connecting PTC	1330Ω movement, 550Ω return
	AI1	Multi-function analog input for speed reference (0-10V input)	From 0 to +10V Input impedance: 20KΩ Resolution: 12bit
	AI2	Multi-function analog input terminals *2, can use SW2 to switch voltage or current input (0~10V)/(4-20mA)	From 0 to +10V Input impedance: 20KΩ From 4 to 20 mA Input impedance: 250Ω Resolution: 12bit
	GND	Analog signal ground terminal	----
	E	Shielding wire's connecting terminal (Ground)	----
Analog output signal	AO1	Multi-function analog output terminals *3 (0~10V/ 4-20mA output)	From 0 to 10V Max. current: 2mA From 4 to 20 mA
	AO2	Multi-function analog output terminals *3 (0~10V/ 4-20mA output)	
	GND	Analog signals ground terminal	
Pulse output signal	PO	Pulse output, Band width 32KHz	Max. Frequency: 32KHz Open Collector output Load: 2.2 KΩ
	GND	Analog signals ground terminal	----
Pulse input signal	PI	Pulse command input, frequency width of 32KHz	L: from 0.0 to 0.5V H: from 4.0 to 13.2V Max. Frequency: 0 - 32KHz Impedance: 3.89 KΩ
	GND	Analog signals ground terminal	----

Table 3.3.5.1 Description of control circuit terminals (Continued)

Type	Terminal	Terminal function	Signal level/ information
Relay output	R1A- R1B- R1C	Relay A contact (multi-function output terminal) Relay B contact (multi-function output terminal) Relay contact common terminal, please refer to parameter group 03 in this manual for more functional descriptions.	Rating: 250Vac: 10 mA ~ 1A 30Vdc: 10 mA ~ 1A
	R2A-R2C	With the same functions as R1A/R1B/R1C	Rating: 250Vac: 10 mA ~ 1A 30Vdc: 10 mA ~ 1A
	R3A-R3C	With the same functions as R1A/R1B/R1C	
Safety input	F1	On: normal operation. Off: emergency stop. (Jumper wired has to be removed to use external safety function to stop.)	24Vdc, 8mA, pull-high
	F2	Safety command common terminal	24V Ground
RS-485 port	S (+)	RS485/MODBUS	differential input and output
	S (-)		
Grounding	E (G)	Grounding to earth Shield the connecting terminal	----

Notes:

- *1: Multi-function digital input can be referred to in this manual.
 - Group 03: External Terminals Digital Input / Output Function Group.
- *2: Multi-function analog input can be referred to in this manual.
 - Group 04 - External Terminal Analog Signal Input (Output) Function Group.
- *3: Multi-function analog output can be referred to in this manual.
 - Group 04 - External Terminal Analog Signal Input (Output) Function Group.



Caution

- Maximum output current capacity for terminal 10V is 20mA.
- Multi-function analog output AO1 and AO2 are for use for an analog output meter. Do not use these output for feedback control.
- Control board's 24V and 10V are to be used for internal control only. Do not use the internal power-supply to power external devices.

3.3.6 Wiring for Main Circuit Terminals

Table 3.3.6.1 Description of main circuit terminals (IP00/IP20 Type)

Terminal	200V : 5~30HP 400V : 5~40HP	200V: 40~175HP 400V: 50~800HP
	R/L1	Input Power Supply
S/L2		
T/L3		
B1/P	<ul style="list-style-type: none"> • B1/P – ⊖ : DC power supply • B1/P – B2 : external braking resistor 	-
B2		
⊖		<ul style="list-style-type: none"> • ⊕ - ⊖ : DC power supply or connect braking module
⊕	-	
U/T1	Inverter output	
V/T2		
W/T3		
E	Ground terminal	

Table 3.3.6.2 Description of main circuit terminals (IP55 Type)

Terminal	400V
	5 - 100HP
R/L1, S/L2, T/L3	Input Power Supply
U/T1, V/T2, W/T3	Inverter output
B1, B2	Braking resistor connecting terminal *1
⊕1, ⊕2	DC reactor connecting terminal *2
B1, B2, ⊖	DC power supply (DC+, DC-) Braking module connecting terminal
⊕ (PE)	Ground terminal


*1. The model of 400V 25HP (18.5KW) or below is built-in braking transistor.

*2. Before connecting DC reactor, please remove short circuit between terminal ⊕1 and ⊕2.

■ Main circuit terminals identification and screw size


◆ IP20 Type

- 200V: 5-7.5HP/ 400V: 5-10HP




Terminal screw size	
T	⊖
M4	M4

- 200V: 10-15HP/ 400V: 15- 20HP




Terminal screw size	
T	⊖
M4	M4

- 200V: 20-30HP/ 400V: 25-40HP




Terminal screw size	
T	⊖
M6	M6

- 200V: 40-50HP/ 400V: 50-75HP




Terminal screw size	
T	⊖
M8	M8

- 200V: 60-75HP/ 400V: 100-125HP




Terminal screw size		
Power supply	T	⊕
400V 100HP	M8	M10
200V 60-75HP/ 400V 125HP	M10	M10

- 200V: 100-125HP/ 400V: 150-250HP




Terminal screw size	
T	⊕
M10	M10

- 200V: 150-175HP/ 400V: 300-425HP



Terminal screw size	
T	⊕
M12	M10


- 400V: 530-800HP




Terminal screw size	
T	⊕
M10	M10

IP55 Type


- 400V: 5-7.5HP




- 400V: 10-15HP




- 400V: 20-25HP



- 400V: 30-50HP




- 400V: 60-75HP



Terminal screw size	
T1	
M8	M8

- 400V : 100HP




Terminal screw size		
T1	T2	
M8	M10	M8


■ Input / Output Power Section Block Diagram

The following diagrams show the basic configuration of the power sections for the range of horsepower and input voltages. This is shown for reference only and is not a detailed depiction.


◆ IP00/IP20 Type



7. IP20 400V: 300~425HP




8. IP20 400V: 535~800HP




◆ IP55 Type


1. IP55 400V: 5~15HP



2. IP55 400V: 20~25HP




3. IP55 400V: 30~100HP




■ Cooling Fan Supply Voltage Selection (400V class)

The inverter input voltage range of the F510 400V class models ranges from 380 to 460Vac. In these models the cooling fan is directly powered from the power supply. Inverter models F510-4125/ 4150/ 4175/ 4215/ 4250/ 4300/ 4375/ 4425/ 4535/ 4670/ 4800-H3 requires the user to select the correct jumper position based on the inverter input voltage ("440V" is the default position for these models). Please select the correct position according to the input voltage. If the voltage setting is too low, the cooling fan will not provide adequate cooling for the inverter resulting in an over-heat error. If the input voltage is greater than 460Vac, select the "460V" position.

(1) 400V : 150HP~250HP



(2) 400V : 300HP~800HP



■ Power Input Wire Size, NFB and MCB Part Numbers

The following table shows the recommended wire size, molded case circuit breakers and magnetic contactors for each of the F510 models. It depends on the application whether or not to install a circuit breaker. The NFB must be installed between the input power supply and the inverter input (R/L1, S/L2, T/L3).

Note: When using a ground protection, make sure the current setting is above 200mA and trip delay time is 0.1 sec of higher.

Table 3.3.6.3 Wiring Instrument for 200V/400V class (IP00/IP20 type)

Power supply	F510 Model			Wire size (mm ²)			NFB ^{*3}	MC ^{*3}
	Horse power (HP)	Rated KVA	Rated current (A)	Main circuit ^{*1}	Grounding E(G)	Control line ^{*2}		
200V 3 ∅	5HP	5.5	14.5	3.5~5.5	3.5~5.5	0.5~2	TO-50EC(30A)	CU-16
	7.5HP	8.0	22	5.5	5.5	0.5~2	TO-50EC(30A)	CU-16
	10HP	11.4	30	8	5.5~8	0.5~2	TO-100S(50A)	CU-18
	15HP	15	42	8	5.5~8	0.5~2	TO-100S(50A)	CU-25
	20HP	21	56	14	8	0.5~2	TO-100S(100A)	CU-50
	25HP	26	69	22	8	0.5~2	TO-100S(100A)	CU-65
	30HP	30	79	22	14	0.5~2	TO-225S(100A)	CU-80
	40HP	42	110	38	14	0.5~2	TO-225S(150A)	CN-100
	50HP	53	138	60	22	0.5~2	TO-225S(175A)	CN-125
	60HP	64	169	80	22	0.5~2	TO-225S(200A)	CN-150
	75HP	76	200	100	22	0.5~2	TO-225S(225A)	CN-180
	100HP	95	250	150	22	0.5~2	TO-400S(300A)	CN-300
	125HP	119	312	200	38	0.5~2	TO-400S(400A)	CN-300
	150HP	137	400	300	38	0.5~2	TO-600S(600A)	S-K400
175HP	172	450	250*2P	50	0.5~2	TO-800S(800A)	S-K600	
400V 3 ∅	5HP	7.0	9.2	2~5.5	3.5~5.5	0.5~2	TO-50EC(15A)	CU-18
	7.5HP	8.5	12.1	2~5.5	3.5~5.5	0.5~2	TO-50EC(15A)	CU-18
	10HP	13.3	17.5	3~5.5	3.5~5.5	0.5~2	TO-50EC(20A)	CU-18
	15HP	18	23	5.5	5.5	0.5~2	TO-50EC(30A)	CU-25
	20HP	24	31	8	8	0.5~2	TO-100S(50A)	CU-25
	25HP	29	38	8	8	0.5~2	TO-100S(50A)	CU-35
	30HP	34	44	8	8	0.5~2	TO-100S(50A)	CU-50
	40HP	41	54	14	8	0.5~2	TO-100S(75A)	CU-50
	50HP	55	73	22	8	0.5~2	TO-100S(100A)	CU-65
	60HP	67	88	22	14	0.5~2	TO-100S(100A)	CN-80
	75HP	79	103	38	14	0.5~2	TO-225S(150A)	CN-100
	100HP	111	145	60	22	0.5~2	TO-225S(175A)	CN-150
	125HP	126	168	80	22	0.5~2	TO-225S(225A)	CN-150
	150HP	159	208	150	22	0.5~2	TO-400S(300A)	CN-300
	175HP	191	250	150	22	0.5~2	TO-400S(300A)	CN-300
	215HP	226	296	200	30	0.5~2	TO-400S(400A)	CN-300
	250HP	250	328	250	30	0.5~2	TO-400S(400A)	S-K400
	300HP	332	435	300	38	0.5~2	TO-600S(600A)	S-K600
375HP	393	515	250*2P	50	0.5~2	TO-800S(800A)	S-K600	
425HP	457	585	250*2P	50	0.5~2	TE-1000(1000A)	S-K600	
535HP	526	700	300*2P	50	0.5~2	1000	800	
670HP	640	875	300*2P	50	0.5~2	1200	1000	
800HP	732	960	300*2P	50	0.5~2	1200	1000	

*1. The main circuit terminals: R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, B1/P, B2, ⊖, ⊕.

*2. Control line is the terminal wire on the control board.

*3. The NFB and MCB listed in the table are of TECO product numbers, products with same rated specification of other brands may be used. To reduce electrical noise interference, ensure that a RC surge absorber (R: 10Ω/ 5W, C: 0.1μf/1000VDC) is added to both sides of MCB coil.

Table 3.3.6.4 Wiring Instrument for 400V class (IP55 type)

Power supply	F510 Model			Wire size(mm ²)			NFB ^{*3}	MC ^{*3}
	Horse power (HP)	Rated KVA	Rated current (A)	Main circuit ^{*1}	Grounding E(G)	Control line ^{*2}		
400V 3 ∅	5HP	7.0	9.2	2~5.5	3.5~5.5	0.5~2	TO-50EC(15A)	CU-18
	7.5HP	8.5	12.1	2~5.5	3.5~5.5	0.5~2	TO-50EC(15A)	CU-18
	10HP	13.3	17.5	3~5.5	3.5~5.5	0.5~2	TO-50EC(20A)	CU-18
	15HP	18	23	5.5	5.5	0.5~2	TO-50EC(30A)	CU-25
	20HP	24	31	8	8	0.5~2	TO-100S(50A)	CU-25
	25HP	29	38	8	8	0.5~2	TO-100S(50A)	CU-35
	30HP	34	44	8	8	0.5~2	TO-100S(50A)	CU-50
	40HP	41	54	14	8	0.5~2	TO-100S(75A)	CU-50
	50HP	55	73	22	8	0.5~2	TO-100S(100A)	CU-65
	60HP	67	88	22	14	0.5~2	TO-100S(100A)	CN-80
	75HP	79	103	38	14	0.5~2	TO-225S(150A)	CN-100
100HP	111	145	60	22	0.5~2	TO-225S(175A)	CN-150	

*1. The main circuit terminals: R(L1), S(L2), T(L3), ⊖, ⊕1, ⊕2, U(T1), V(T2), W(T3), B1, B2 (Polyethylene power line of 600V is recommended to be used.)

*2. Control line is the terminal wire on the control board.

*3. The NFB and MCB listed in the table are of TECO product numbers, products with same rated specification of other brands may be used. To reduce electrical noise interference, ensure that a RC surge absorber (R: 10Ω/ 5W, C: 0.1μf/1000VDC) is added to both sides of MCB coil.

3.3.7 Wiring Precautions

! Danger	<ul style="list-style-type: none">• Do NOT remove any protective covers or attempt any wiring while input power is applied. Connect all wiring before applying input power. When making wiring changes after power up, remove input power and wait a minimum of five minutes after power has been turned off before starting. Also confirm that the charge lamp is off and that DC voltage between terminals B1/P or (+) and (-) does not exceed 25V, otherwise electric shock may result.• Only authorized personnel should work on the equipment. (Take off metal jewelry such as watches and rings and use insulated tools.), otherwise electric shock or injury may result.
-----------------	---

(A) Wiring for control circuit:

- (1) Separate the wiring for control circuit terminals from main circuit wiring for terminals (R/L1, S/L2, T/L3, U/T1, V/T2, and W/T3).
- (2) Separate the wiring for control circuit terminals (R1A, R1B, R1C / R2A, R2C /R3A, R3C) from wiring for terminals S1~S6, A01, A02, GND, +10V-, AI1, AI2, and GND wiring.
- (3) Use shielded twisted-pair cables (#24 - #14 AWG / 0.5 -2 mm²) shown in Fig. 3.3.7.1 for control circuits to minimize noise problems. The maximum wiring distance should not exceed 50m (165 ft).



Figure 3.3.7.1 Shielded Twisted-Pair

(B) Wiring for main circuit:

- (1) The Input power supply voltage can be connected in any phase sequence to power input terminals R/L1, S/L2, or T/L3 on the terminal block.
- (2) DO NOT connect the AC input power source to the output terminals U/T1, V/T2 and. W/T3.
- (3) Connect the output terminals U/T1, V/T2, W/T3 to motor lead wires U/T1, V/T2, and W/T3, respectively.
- (4) Check that the motor rotates forward with the forward run source. If it does not, swap any 2 of the output cables to change motor direction.
- (5) DO NOT connect phase correcting capacitors or LC/RC noise filter to the output circuit.

(C) Grounding:

- (1) Connect the ground terminal (E) to ground having a resistance of less than 100Ω.
- (2) Do not share the ground wire with other devices, such as welding machines or power tools.
- (3) Always use a ground wire that complies with the local codes and standards for electrical equipment and minimize the length of ground wire.
- (4) When using more than one inverter, be careful not to loop the ground wire, as shown below in Fig. 3.3.7.2.




Figure 3.3.7.2 F510 Inverter Grounding

3.3.8 Input Power and Cable Length

■ Cable size

The length of the cables between the input power source and /or the motor and inverter can cause a significant phase to phase voltage reduction due to the voltage drop across the cables. The wire size shown in Tables 3.3.6.3 & 3.3.6.4 is based on a maximum voltage drop of 2%. If this value is exceeded, a wire size having larger diameter may be needed. To calculate phase to phase voltage drop, apply the following formula:

$$\text{Phase-to-phase voltage drop (V)} = \sqrt{3} \times \text{resistance of wire } (\Omega/\text{km}) \times \text{length of line (m)} \times \text{current} \times 10^{-3}$$

(km=3280 x feet)

(m=3.28 x feet)

■ Cable length vs. Carrier frequency

The allowable setting of the PWM carrier frequency is also determined by motor cable length and is specified in the following Table 3.3.8.1.

Table 3.3.8.1 Cable Length vs. Carrier Frequency

Cable length between the inverter and Motor in m (ft.).	< 30 (100)	30 – 50 (100 – 165)	50 – 100 (166 - 328)	≥ 100 (329)
Recommended carrier frequency allowed Parameter 11-01	16kHz (max)	10 kHz (max)	5 kHz (max)	2 kHz (max)

■ Installing an AC line reactor

If the inverter is connected to a large-capacity power source (600kVA or more), install an optional AC reactor on the input side of the inverter. This also improves the power factor on the power supply side.

3.4 Inverter Specifications

■ Basic Specifications

(a) 200V class

Inverter capacity (HP)		5	7.5	10	15	20	25	30	40	50	60	75	100	125	150	175	
Output Rated	Rated Output Capacity (KVA)	5.5	8	11.4	15.2	21.3	26.2	30	41.9	52.5	64.3	76.2	95.2	118.8	152.4	171.4	
	Rated Output Current (A)	14.5	22	30	42	56	69	79	110	138	169	200	250	312	400	450	
	Maximum Applicable Motor ^{*1} HP (KW)	5 (3.7)	7.5 (5.5)	10 (7.5)	15 (11)	20 (15)	25 (18.5)	30 (22)	40 (30)	50 (37)	60 (45)	75 (55)	100 (75)	125 (90)	150 (110)	175 (130)	
	Maximum Output Voltage (V)	3-phase 200V~240V															
	Maximum Output Frequency (Hz)	Based on parameter setting 0.1~400.0 Hz															
Power supply	Rated Voltage, Frequency	3-phase 200V~240V, 50/60Hz															
	Allowable Voltage Fluctuation	-15% ~ +10%															
	Allowable Frequency Fluctuation	±5%															

(b) 400V class

Inverter capacity (HP)		5	7.5	10	15	20	25	30	40	50	60	75	100	125	150	175	215	250	300	375	
Output Rated	Rated Output Capacity (KVA)	7.0	8.4	13.3	17.5	23.6	28.9	33.5	41.1	54.8	67	78.4	110	125	158	190	225	250	331	392	
	Rated Output Current (A)	9.2	12.1	17.5	23	31	38	44	54	73	88	103	145	168	208	250	296	328	435	515	
	Maximum Applicable Motor ^{*1} HP (KW)	5 (3.7)	7.5 (5.5)	10 (7.5)	15 (11)	20 (15)	25 (18.5)	30 (22)	40 (30)	50 (37)	60 (45)	75 (55)	100 (75)	125 (90)	150 (110)	175 (132)	215 (160)	250 (185)	300 (220)	375 (280)	
	Maximum Output Voltage (V)	3-phase 380V~480V																			
	Maximum Output Frequency (Hz)	Based on parameter setting 0.1~400.0 Hz																			
Power supply	Rated Voltage, Frequency	3-phase 380V ~ 480V, 50/60Hz																			
	Allowable Voltage Fluctuation	-15% ~ +10%																			
	Allowable Frequency Fluctuation	±5%																			

Inverter capacity (HP)		425	535	670	800
Output Rated	Rated Output Capacity (KVA)	445	525	640	731
	Rated Output Current (A)	585	700	875	960
	Maximum Applicable Motor ^{*1} HP (KW)	425 (315)	535 (400)	670 (500)	800 (600)
	Maximum Output Voltage (V)	3-phase 380V~480V			
	Maximum Output Frequency (Hz)	Based on parameter setting 0.1~400.0 Hz			
Power supply	Rated Voltage, Frequency	3-phase 380V ~ 480V, 50/60Hz			
	Allowable Voltage Fluctuation	-15% ~ +10%			
	Allowable Frequency Fluctuation	±5%			

*1: Take standard 4-pole induction motor as the base.

*2: F510 model is designed to be used in normal duty (ND), whose overload capability is 120% for 1 min.

*3: If it is greater than default carrier frequency, you need to adjust the load current based on the de-rating curve.

200V class	Carrier freq. default setting	Carrier freq. range	400V class	Carrier freq. default setting	Carrier freq. range
5~25HP	2KHz	2~16KHz	5~30HP	4KHz	2~16KHz
30HP	2KHz	2~12KHz	40HP	2KHz	2~16KHz
40~50HP	2KHz	2~12KHz (*4)	50~60HP	4KHz	2~12KHz (*4)
60~125HP	2KHz	2~10KHz (*4)	75~215HP	4KHz	2~10KHz (*4)
-	-	-	250HP	2KHz	2~8KHz
150~175HP	2KHz	2~5KHz	300~375HP	4KHz	2~5KHz
-	-	-	425HP	2KHz	2~5KHz
-	-	-	535~800HP	4KHz	2~5KHz

*4: If control mode is set to SLV mode and maximum frequency (01-02) is larger than 80 Hz, the carrier frequency range is 2~8Hz.

The following table shows the maximum output frequency for each control mode.

Control mode	Other settings	Maximum output frequency
V/F	Unlimited	400Hz
SLV	200V 5~15HP, 400V 5~20HP	150Hz
	200V 20~30HP, 400V 25HP	110Hz
	400V 30~40HP	100Hz
	200V 40~125HP, 400V 50~215HP, carrier (11-01) is set as 8K or below 8K.	100Hz
	200V 40~125HP, 400V 50~215HP, carrier (11-01) is set as above 8K.	80Hz
PMSLV	Unlimited	400Hz

■ General Specifications

Control Characteristics	Operation Modes	LED keypad with seven-segment display *5 and LCD keypad (Optional HOA LCD keypad); all LCD keypad with parameter copy function
	Control Modes	V/F, SLV, PMSLV with space vector PWM mode
	Frequency Control Range	0.1Hz~400.0Hz
	Frequency Accuracy (Temperature change)	Digital references: $\pm 0.01\%$ (-10 to +40°C), Analog references: $\pm 0.1\%$ (25°C $\pm 10^\circ\text{C}$)
	Speed Control Accuracy	$\pm 0.5\%$ (Sensorless Vector Control Mode) ^{*1}
	Frequency Setting Resolution	Digital references: 0.01Hz, Analog references: 0.06Hz/60Hz
	Output Frequency Resolution	0.01Hz
	Inverter Overload	120%/1 min
	Frequency Setting Signal	DC 0~+10V / 0~20mA or 4~20mA
	Acceleration/ Deceleration Time	0.0~6000.0 seconds (separately set acceleration and deceleration time)
	Voltage, Frequency Characteristics	Custom V/F curve based on parameters
	Braking Torque	About 20%
	Main Control Functions	Auto tuning, Soft-PWM, Over voltage protection, Dynamic braking, Speed search, Restart upon momentary power loss, 2 sets of PID control, Slip Compensation, RS-485 communication standard, Simple PLC function, 2 sets of analog outputs, Safety switch
Other Functions		
Protection Function	Stall Prevention	Current level can be setting (It can be set separately in acceleration or constant speed; it can be set with or without protection in deceleration)
	Instantaneous Over Current (OC) and Output Short-Circuit (SC) Protection	Inverter stops when the output current exceeds 160% of the inverter rated current
	Inverter Overload Protection (OL2)	If inverter rated current 120%/1min is exceeded, inverter stops. The factory default carrier frequency is 2~4KHZ ^{*2}
	Motor Overload Protection (OL1)	Electrical overload protection curve
	Over voltage (OV) Protection	If the main circuit DC voltage rises over 410V (200V class)/ 820V (400V class), the motor stops running.
	Under voltage (UV) Protection	If the main circuit DC voltage falls below 190V (200V class)/ 380V (400V class), the motor stops running.
	Auto-Restart after Momentary Power Loss	Power loss exceeds 15ms. Auto-restart function available after momentary power loss in 2 sec.
	Overheat(OH) Protection	Use temperature sensor for protection.
	Ground Fault (GF) Protection	Use current sensor for protection.
	DC Bus Charge Indicator	When main circuit DC voltage $\geq 50\text{V}$, the CHARGE LED turns on.
	Output Phase Loss (OPL) Protection	If the OPL is detected, the motor stops automatically.
	Environment Specifications	Installation Location
Ambient Temperature		-10~+40°C (14°F~104°F) (IP20/NEMA1 or IP55/NEMA12), -10~+50°C (14°F~122°F) (IP00) without de-rating; with de-rating, its maximum operation temperature is 60°C (140°F).
Storage Temperature		-20~+70°C (-4°F~+158°F)
Humidity		95%RH or less (no condensation)
Altitude and Vibration		Altitude of 1000m (3181ft) or below, below 5.9m/s ² (0.6G)
Communication Function		Built-in RS-485 as standard (Modbus protocol with RJ45/ BACnet/ Metasys N2)
PLC Function		Built-in
EMI Protection		The built-in noise filter complies with EN61800-3 available for inverters 400V 75HP or below (IP20) / 400V 60HP or below (IP55)
EMS Protection		in compliance with EN61800-3
Safety Certification	CE Declaration	in compliance with EN61800-3 (CE & RE) and EN61800-5-1 (LVD, Low-Voltage Directive)
	UL Certification	UL508C
Accessories		1 to 8 Pump card, HOA LCD keypad, Profibus card




*1: Speed control accuracy will be different from the installation conditions and motor types.

*2: The factory default carrier frequency is different from models.




3.5 Inverter Derating Based on Carrier Frequency




Note: Derating curve current of carrier frequency means inverter rated current.



(a) 200V Models



(b) 400V Models








3.6 Inverter Derating Based on Temperature

Note: User needs to adjust the inverter rated current for ambient temperature to ensure the appropriate industrial application.




Information provided by **EMAG**
Tel: 01902 601403
www.emag-ltd.co.uk

3.7 Inverter Dimensions


3.7.1 Standard Type (IP00/IP20)

(a) 200V: 5-7.5HP/ 400V: 5-10HP




Inverter Model	Dimensions in mm (inch)							NW in kg(lbs)
	W	H	D	W1	H1	t	d	
F510-2005-H3	140 (5.51)	279 (10.98)	177 (6.97)	122 (4.80)	267 (10.51)	7 (0.28)	M6	3.8 (8.38)
F510-2008-H3	140 (5.51)	279 (10.98)	177 (6.97)	122 (4.80)	267 (10.51)	7 (0.28)	M6	3.8 (8.38)
F510-4005-H3	140 (5.51)	279 (10.98)	177 (6.97)	122 (4.80)	267 (10.51)	7 (0.28)	M6	3.8 (8.38)
F510-4008-H3	140 (5.51)	279 (10.98)	177 (6.97)	122 (4.80)	267 (10.51)	7 (0.28)	M6	3.8 (8.38)
F510-4010-H3	140 (5.51)	279 (10.98)	177 (6.97)	122 (4.80)	267 (10.51)	7 (0.28)	M6	3.8 (8.38)

(b) 200V: 10-30HP/ 400V: 15-40HP




Inverter Model	Dimensions in mm (inch)						d	NW in kg(lbs)
	W	H	D	W1	H1	t		
F510-2010-H3	210 (8.27)	300 (11.81)	215 (8.46)	192 (7.56)	286 (11.26)	1.6 (0.06)	M6	6.2 (13.67)
F510-2015-H3	210 (8.27)	300 (11.81)	215 (8.46)	192 (7.56)	286 (11.26)	1.6 (0.06)	M6	6.2 (13.67)
F510-2020-H3	265 (10.43)	360 (14.17)	225 (8.86)	245 (9.65)	340 (13.39)	1.6 (0.06)	M8	10 (22.05)
F510-2025-H3	265 (10.43)	360 (14.17)	225 (8.86)	245 (9.65)	340 (13.39)	1.6 (0.06)	M8	10 (22.05)
F510-2030-H3	265 (10.43)	360 (14.17)	225 (8.86)	245 (9.65)	340 (13.39)	1.6 (0.06)	M8	10 (22.05)
F510-4015-H3	210 (8.27)	300 (11.81)	215 (8.46)	192 (7.56)	286 (11.26)	1.6 (0.06)	M6	6.2 (13.67)
F510-4020-H3	210 (8.27)	300 (11.81)	215 (8.46)	192 (7.56)	286 (11.26)	1.6 (0.06)	M6	6.2 (13.67)
F510-4025-H3	265 (10.43)	360 (14.17)	225 (8.86)	245 (9.65)	340 (13.39)	1.6 (0.06)	M8	10 (22.05)
F510-4030-H3	265 (10.43)	360 (14.17)	225 (8.86)	245 (9.65)	340 (13.39)	1.6 (0.06)	M8	10 (22.05)
F510-4040-H3	265 (10.43)	360 (14.17)	225 (8.86)	245 (9.65)	340 (13.39)	1.6 (0.06)	M8	10 (22.05)

(c) 200V: 40-50HP/ 400V: 50-75HP




Inverter Model	Dimensions in mm (inch)						d	NW in kg(lbs)
	W	H	D	W1	H1	t		
F510-2040-H3	284 (11.18)	525 (20.67)	252 (9.92)	220 (8.66)	505 (19.88)	1.6 (0.06)	M8	30 (66.14)
F510-2050-H3	284 (11.18)	525 (20.67)	252 (9.92)	220 (8.66)	505 (19.88)	1.6 (0.06)	M8	30 (66.14)
F510-4050-H3	284 (11.18)	525 (20.67)	252 (9.92)	220 (8.66)	505 (19.88)	1.6 (0.06)	M8	30 (66.14)
F510-4060-H3	284 (11.18)	525 (20.67)	252 (9.92)	220 (8.66)	505 (19.88)	1.6 (0.06)	M8	30 (66.14)
F510-4075-H3	284 (11.18)	525 (20.67)	252 (9.92)	220 (8.66)	505 (19.88)	1.6 (0.06)	M8	30 (66.14)

(d) 200V: 60-125HP/ 400V: 100-250HP (IP00)




Inverter Model	Dimensions in mm (inch)							NW in kg(lbs)
	W	H	D	W1	H1	t	d	
F510-2060-H3	344 (13.54)	580 (22.83)	300 (11.81)	250 (9.84)	560 (22.05)	1.6 (0.06)	M10	40.5 (89.29)
F510-2075-H3	344 (13.54)	580 (22.83)	300 (11.81)	250 (9.84)	560 (22.05)	1.6 (0.06)	M10	40.5 (89.29)
F510-2100-H3	459 (18.07)	790 (31.10)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	74 (163.14)
F510-2125-H3	459 (18.07)	790 (31.10)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	74 (163.14)
F510-4100-H3	344 (13.54)	580 (22.83)	300 (11.81)	250 (9.84)	560 (22.05)	1.6 (0.06)	M10	40.5 (89.29)
F510-4125-H3	344 (13.54)	580 (22.83)	300 (11.81)	250 (9.84)	560 (22.05)	1.6 (0.06)	M10	40.5 (89.29)
F510-4150-H3	459 (18.07)	790 (31.10)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	74 (163.14)
F510-4175-H3	459 (18.07)	790 (31.10)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	74 (163.14)
F510-4215-H3	459 (18.07)	790 (31.10)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	74 (163.14)
F510-4250-H3	459 (18.07)	790 (31.10)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	74 (163.14)

(e) 200V: 60-125HP/ 400V: 100-250HP (IP20)




Inverter Model	Dimensions in mm (inch)						d	NW in kg(lbs)
	W	H	D	W1	H1	t		
F510-2060-H3	348.5 (13.72)	740 (29.13)	300 (11.81)	250 (9.84)	560 (22.05)	1.6 (0.06)	M10	44 (97.00)
F510-2075-H3	348.5 (13.72)	740 (29.13)	300 (11.81)	250 (9.84)	560 (22.05)	1.6 (0.06)	M10	44 (97.00)
F510-2100-H3	463.5 (18.25)	1105 (43.50)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	81 (178.57)
F510-2125-H3	463.5 (18.25)	1105 (43.50)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	81 (178.57)
F510-4100-H3	348.5 (13.72)	740 (29.13)	300 (11.81)	250 (9.84)	560 (22.05)	1.6 (0.06)	M10	44 (97.00)
F510-4125-H3	348.5 (13.72)	740 (29.13)	300 (11.81)	250 (9.84)	560 (22.05)	1.6 (0.06)	M10	44 (97.00)
F510-4150-H3	463.5 (18.25)	1105 (43.50)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	81 (178.57)
F510-4175-H3	463.5 (18.25)	1105 (43.50)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	81 (178.57)
F510-4215-H3	463.5 (18.25)	1105 (43.50)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	81 (178.57)
F510-4250-H3	463.5 (18.25)	1105 (43.50)	324.5 (12.78)	320 (12.60)	760 (29.92)	1.6 (0.06)	M10	81 (178.57)

(f) 200V: 150-175HP/ 400V: 300-425HP (IP00)




Inverter Model	Dimensions in mm (inch)								NW in kg(lbs)
	W	H	D	W1	W2	H1	t	d	
F510-2150-H3	690 (27.17)	1000 (39.37)	410 (16.14)	530 (20.87)	265 (10.43)	960 (37.80)	1.6 (0.06)	M12	184 (405.65)
F510-2175-H3	690 (27.17)	1000 (39.37)	410 (16.14)	530 (20.87)	265 (10.43)	960 (37.80)	1.6 (0.06)	M12	184 (405.65)
F510-4300-H3	690 (27.17)	1000 (39.37)	410 (16.14)	530 (20.87)	265 (10.43)	960 (37.80)	1.6 (0.06)	M12	184 (405.65)
F510-4375-H3	690 (27.17)	1000 (39.37)	410 (16.14)	530 (20.87)	265 (10.43)	960 (37.80)	1.6 (0.06)	M12	184 (405.65)
F510-4425-H3	690 (27.17)	1000 (39.37)	410 (16.14)	530 (20.87)	265 (10.43)	960 (37.80)	1.6 (0.06)	M12	184 (405.65)

(g) 200V: 150-175HP/ 400V: 300-425HP (IP20)




Inverter Model	Dimensions in mm (inch)							d	NW in kg(lbs)
	W	H	D	W1	W2	H1	t		
F510-2150-H3	690 (27.17)	1313 (51.69)	410 (16.14)	530 (20.87)	265 (10.43)	960 (37.80)	1.6 (0.06)	M12	194 (427.70)
F510-2175-H3	690 (27.17)	1313 (51.69)	410 (16.14)	530 (20.87)	265 (10.43)	960 (37.80)	1.6 (0.06)	M12	194 (427.70)
F510-4300-H3	690 (27.17)	1313 (51.69)	410 (16.14)	530 (20.87)	265 (10.43)	960 (37.80)	1.6 (0.06)	M12	194 (427.70)
F510-4375-H3	690 (27.17)	1313 (51.69)	410 (16.14)	530 (20.87)	265 (10.43)	960 (37.80)	1.6 (0.06)	M12	194 (427.70)
F510-4425-H3	690 (27.17)	1313 (51.69)	410 (16.14)	530 (20.87)	265 (10.43)	960 (37.80)	1.6 (0.06)	M12	194 (427.70)

(h) 400V: 535-800HP (IP00)



Inverter Model	Dimensions in mm (inch)											NW in kg(lbs)
	W	H	D	W1	W2	W3	H1	H2	H3	t	d	
F510-4535-H3	958 (37.72)	1356 (53.38)	507 (19.96)	916 (36.06)	158 (6.22)	600 (23.62)	1200 (47.24)	300 (11.81)	63.5 (2.50)	6.2 (0.24)	M12	335 (739)
F510-4670-H3	958 (37.72)	1356 (53.38)	507 (19.96)	916 (36.06)	158 (6.22)	600 (23.62)	1200 (47.24)	300 (11.81)	63.5 (2.50)	6.2 (0.24)	M12	335 (739)
F510-4800-H3	958 (37.72)	1356 (53.38)	507 (19.96)	916 (36.06)	158 (6.22)	600 (23.62)	1200 (47.24)	300 (11.81)	63.5 (2.50)	6.2 (0.24)	M12	335 (739)


(i) 400V: 535-800HP (IP20)



Inverter Model	Dimensions in mm (inch)										d	NW in kg(lbs)
	W	H	D	W1	W2	W3	H1	H2	H3	t		
F510-4535-H3	958 (37.72)	1756 (69.13)	507 (19.96)	916 (36.06)	158 (6.22)	600 (23.62)	1200 (47.24)	300 (11.81)	63.5 (2.50)	6.2 (0.24)	M12	350 (772)
F510-4670-H3	958 (37.72)	1756 (69.13)	507 (19.96)	916 (36.06)	158 (6.22)	600 (23.62)	1200 (47.24)	300 (11.81)	63.5 (2.50)	6.2 (0.24)	M12	350 (772)
F510-4800-H3	958 (37.72)	1756 (69.13)	507 (19.96)	916 (36.06)	158 (6.22)	600 (23.62)	1200 (47.24)	300 (11.81)	63.5 (2.50)	6.2 (0.24)	M12	350 (772)


3.7.2 Models with Built-in Filter (IP00/IP20)

(a) 400V: 5-10HP




Inverter Model	Dimensions in mm (inch)							d	NW in kg(lbs)
	W	H	D	W1	H1	H2	t		
F510-4005-H3F	140 (5.51)	385 (15.16)	177 (6.97)	122 (4.80)	267 (10.51)	279 (10.98)	7 (0.28)	M6	5.5 (12.13)
F510-4008-H3F	140 (5.51)	385 (15.16)	177 (6.97)	122 (4.80)	267 (10.51)	279 (10.98)	7 (0.28)	M6	5.5 (12.13)
F510-4010-H3F	140 (5.51)	385 (15.16)	177 (6.97)	122 (4.80)	267 (10.51)	279 (10.98)	7 (0.28)	M6	5.5 (12.13)

(b) 400V: 15-40HP



Inverter Model	Dimensions in mm (inch)							d	NW in kg(lbs)
	W	H	D	W1	H1	H2	t		
F510-4015-H3F	210 (8.27)	416.5 (16.40)	215 (8.46)	192 (7.56)	286 (11.26)	300 (11.81)	1.6 (0.06)	M6	8.0 (17.64)
F510-4020-H3F	210 (8.27)	416.5 (16.40)	215 (8.46)	192 (7.56)	286 (11.26)	300 (11.81)	1.6 (0.06)	M6	8.0 (17.64)
F510-4025-H3F	265 (10.43)	500 (19.69)	225 (8.86)	245 (9.65)	340 (13.39)	360 (14.17)	1.6 (0.06)	M8	12.5 (27.56)
F510-4030-H3F	265 (10.43)	500 (19.69)	225 (8.86)	245 (9.65)	340 (13.39)	360 (14.17)	1.6 (0.06)	M8	12.5 (27.56)
F510-4040-H3F	265 (10.43)	500 (19.69)	225 (8.86)	245 (9.65)	340 (13.39)	360 (14.17)	1.6 (0.06)	M8	12.5 (27.56)


(c) 400V: 50-75HP



Inverter Model	Dimensions in mm (inch)							d	NW in kg(lbs)
	W	H	D	W1	H1	H2	t		
F510-4050-H3F	284 (11.18)	679 (26.73)	252 (9.92)	220 (8.66)	505 (19.88)	525 (20.67)	1.6 (0.06)	M8	32.5 (71.65)
F510-4060-H3F	284 (11.18)	679 (26.73)	252 (9.92)	220 (8.66)	505 (19.88)	525 (20.67)	1.6 (0.06)	M8	32.5 (71.65)
F510-4075-H3F	284 (11.18)	679 (26.73)	252 (9.92)	220 (8.66)	505 (19.88)	525 (20.67)	1.6 (0.06)	M8	32.5 (71.65)


3.7.3 Models with Built-in Filter (IP55)

(a) 400V: 5-25HP



Inverter Model	Dimensions in mm (inch)						d	NW in kg(lbs)
	W	H	D	W1	H1	t		
F510-4005-C3FN4	189 (7.44)	284 (11.18)	186 (7.32)	171 (6.73)	266 (10.47)	1.2 (0.05)	M5	7 (15.43)
F510-4008-C3FN4	189 (7.44)	284 (11.18)	186 (7.32)	171 (6.73)	266 (10.47)	1.2 (0.05)	M5	7 (15.43)
F510-4010-C3FN4	230 (9.06)	320 (12.60)	210 (8.27)	210 (8.27)	305 (12.01)	2 (0.08)	M5	10.5 (23.15)
F510-4015-C3FN4	230 (9.06)	320 (12.60)	210 (8.27)	210 (8.27)	305 (12.01)	2 (0.08)	M5	10.5 (23.15)
F510-4020-C3FN4	265 (10.43)	396 (15.59)	227 (8.94)	249 (9.80)	380 (14.96)	2 (0.08)	M5	17 (37.48)
F510-4025-C3FN4	265 (10.43)	396 (15.59)	227 (8.94)	249 (9.80)	380 (14.96)	2 (0.08)	M5	17 (37.48)

(b) 400V: 30-60HP (Models of 75~100HP without built-in filter)



Inverter Model	Dimensions in mm (inch)							d	NW in kg(lbs)
	W	H	D	W1	H1	t			
F510-4030-C3FN4	224 (8.82)	527 (20.75)	311 (12.24)	180 (7.09)	505 (19.88)	2 (0.08)	M10	32.5 (71.65)	
F510-4040-C3FN4	224 (8.82)	527 (20.75)	311 (12.24)	180 (7.09)	505 (19.88)	2 (0.08)	M10	32.5 (71.65)	
F510-4050-C3FN4	224 (8.82)	527 (20.75)	311 (12.24)	180 (7.09)	505 (19.88)	2 (0.08)	M10	32.5 (71.65)	
F510-4060-C3FN4	326 (12.83)	695 (27.36)	343 (13.50)	276 (10.87)	671 (26.42)	2.3 (0.09)	M10	55 (121.25)	
F510-4075-C3N4	326 (12.83)	695 (27.36)	343 (13.50)	276 (10.87)	671 (26.42)	2.3 (0.09)	M10	55 (121.25)	
F510-4100-C3N4	326 (12.83)	695 (27.36)	343 (13.50)	276 (10.87)	671 (26.42)	2.3 (0.09)	M10	55 (121.25)	

Chapter 4 Keypad and Programming Functions

4.1 LED Keypad

4.1.1 Keypad Display and Keys



DISPLAY	Description
5 Digit LED Display	Monitor inverter signals, view / edit parameters, fault / alarm display.
LED INDICATORS	
FAULT	LED ON when a fault or alarm is active.
FWD	LED ON when inverter is running in forward direction, flashing when stopping.
REV	LED On when inverter is running in reverse direction, flashing when stopping.
SEQ	LED ON when RUN command is from the external control terminals or from serial communication.
REF	LED ON when Frequency Reference command is from the external control terminals or from serial communication.




KEYS (8)	Description
RUN	RUN inverter
STOP	STOP inverter
▲	Parameter navigation Up, Increase parameter or reference value
▼	Parameter navigation down, decrease parameter or reference value
LOC/REM	Used to switch between Local Mode and Remote Mode REMOTE Mode: Set by parameters, controlled by control circuit terminals, communication or other ways. LOCAL Mode: Controlled by operator. It displays REMOTE Mode at power-up. Users can switch between LOCAL and REMOTE Mode if they press LOC/ REM keys when the inverter stops. Parameter of 23-41 can determine if LOC/REM keys are enabled or not.
DSP/FUN	Used to scroll to next screen Frequency screen → Function selection → Monitor parameter
◀ / RESET	Selects active seven segment digit for editing with the ▲ ▼ keys Used to reset fault condition.
READ / ENTER	Used to read and save the value of the active parameter.

Auto-Repeat Keys

Holding the ▲UP or ▼DOWN key for a longer period of time will initiate the auto-repeat function resulting in the value of the selected digit to automatically increase or decrease.

4.1.2 Seven Segment Display Description











Actual	LED Display	Actual	LED Display	Actual	LED Display	Actual	LED Display
0	0	A	A	L	L	Y	Y
1	1	B	b	n	n	-	-
2	2	C	C	o	o	°	°
3	3	D	d	P	P	-	-
4	4	E	E	q	q	.	.
5	5	F	F	r	r		
6	6	G	G	S	S		
7	7	H	H	t	t		
8	8	I	I	u	u		
9	9	J	J	v	v		

Display output frequency	Frequency Reference	Set Frequency Reference
LED lights on	LED flashes	Flashing digit
		

- ◆ At power-up, the display will show the frequency reference setting and all LEDs are flashing. Press the ▲ (UP) or ▼ (DOWN) key to enter the frequency reference edit mode, use the ◀/RESET key to select which digit to edit (flashing). Use the ▲ (UP) or ▼ (DOWN) key to modify the value and press the READ / ENTER key to save the frequency reference and switch back to the frequency reference display mode.
- ◆ During run operation, the display will show the output frequency.



Note: When in edit mode and the READ / ENTER is not pressed within 5 sec, the inverter will switch back to the frequency reference display mode.

LED Display Examples




Seven Segment Display	Description
	1. Displays the frequency reference at power-up. 2. Displays the actual output frequency during run operation.
	Displays parameter code.
	Displays the setting value of parameter.
	Displays input voltage.
	Displays inverter current.
	Displays DC Bus Voltage.
	Displays temperature.
	Displays PID feedback value; The displayed digit is set by 12-01.
	Error display; refer to chapter 5 Troubleshooting and Maintenance.
	Displays AI1/ AI2 input (0~100%)

4.1.3 LED Indicator Description




- **Fault LED**

State	Description	FAULT LED
Off	No Fault Active	
Illuminated	Fault Active	




- **Forward LED**

State	Description	FWD LED
Off	Inverter in reverse direction	
Illuminated	Inverter is running in forward direction	
Flashing	Forward direction active, no run command	



- **Reverse LED**

State	Description	REV LED
Off	Inverter in forward direction	
Illuminated	Inverter is running in reverse direction	
Flashing	Reverse direction active, no run command	



- **RUN LED**

State	Description	RUN LED
Off	Inverter stopped	
Illuminated	Inverter running	
Flashing	Inverter stopped or stopping	


● **SEQ LED**

State	Description	SEQ LED
Off	Sequence controlled from keypad	
Illuminated	Sequence set from external source	

● **REF LED**


State	Description	REF LED
Off	Frequency reference set from keypad	
Illuminated	Frequency reference set from external source	

Run / Stop Status Indicators



4.1.4 Power-up Monitor


◆ Power-up




◆ Changing Monitor at Power-up

12- 00	Display Selection							
Range	Highest bit -> <u>0</u> <u>0</u> <u>0</u> <u>0</u> <u>0</u> <- Lowest bit The setting range for each bit is 0 ~ 7 from the highest bit to the lowest bit.							
	<table border="0"> <tr> <td>0: No display</td> <td>4: Temperature</td> </tr> <tr> <td>1: Output current</td> <td>5: PID feedback</td> </tr> <tr> <td>2: Output voltage</td> <td>6: AI1 value</td> </tr> <tr> <td>3: DC voltage</td> <td>7: AI2 value</td> </tr> </table>	0: No display	4: Temperature	1: Output current	5: PID feedback	2: Output voltage	6: AI1 value	3: DC voltage
0: No display	4: Temperature							
1: Output current	5: PID feedback							
2: Output voltage	6: AI1 value							
3: DC voltage	7: AI2 value							

Example: 12- 00= 【10000】




Example: 12- 00= 【12345】




4.1.5 Modifying Parameters/ Set Frequency Reference

Example: Modifying Parameters




Example: Set Frequency Reference




Note: When upper or lower limit is reached during editing of the frequency reference, the edit value will automatically rollover from the lower limit to the upper limit or from the upper limit to the lower limit.

4.1.6 Operation Control



4.2 LCD keypad

4.2.1 Keypad Display and Keys



DISPLAY	Description
LCD Display	Monitor inverter signals, view / edit parameters, fault / alarm display.
LED INDICATORS	
FAULT	LED ON when a fault or alarm is active.
FWD	LED ON when inverter is running in forward direction, flashing when stopping.
REV	LED On when inverter is running in reverse direction, flashing when stopping.
SEQ	LED ON when RUN command is from the external control terminals or from serial communication.
REF	LED ON when Frequency Reference command is from the external control terminals or from serial communication.

KEYS (8)	Description
RUN	RUN inverter
STOP	STOP inverter
▲	Parameter navigation Up, Increase parameter or reference value
▼	Parameter navigation down, decrease parameter or reference value
LOC/REM	Used to switch between Local Mode and Remote Mode REMOTE Mode: Set by parameters, controlled by control circuit terminals, communication or other ways. LOCAL Mode: Controlled by operator. It displays REMOTE Mode at power-up. Users can switch between LOCAL and REMOTE Mode if they press LOC/ REM keys when the inverter stops. Parameter of 23-41 can determine if LOC/REM keys are enabled or not.
DSP/FUN	Used to scroll to next screen Frequency screen → Function selection → Monitor parameter
◀ / RESET	Selects active seven segment digit for editing with the ▲ ▼ keys Used to reset fault condition.
READ / ENTER	Used to read and save the value of the active parameter.

Auto-Repeat Keys


Holding the ▲UP or ▼DOWN key for a longer period of time will initiate the auto-repeat function resulting in the value of the selected digit to automatically increase or decrease.

Note: HOA LCD keypad is available with an optional accessory.

4.2.2 Keypad Menu Structure

◆ Main Menu

The F510 inverter main menu consists of two main groups (modes). The DSP/FUN key is used to switch between the monitor mode and the parameter group mode. Refer to Figure 4.2.2.1.



Mode	Description
Monitor Mode	View inverter status, signals and fault data.
Parameter Group Mode	Access to available parameter groups.

All the available parameter groups are listed in the Parameter Group Mode. Use the up and down keys to select a group and press READ/ ENTER to access its parameters.




Fig. 4.2.2.1 Parameter Group Structure

Notes:

- Always perform auto-tune on the motor before operating the inverter in vector control (sensorless vector or flux vector). Auto-tuning mode will not be displayed when the inverter is running or when a fault is active.
- To scroll through the available modes, parameter groups or parameter list press and hold the up or down key.

◆ **Monitor Mode**

In monitor mode inverter signals can be monitored such as output frequency, output current and output voltage, etc...) as well as fault information and fault trace. See Fig 4.2.2.2 for keypad navigation.




Fig 4.2.2.2 Monitor Mode

◆ Programming Mode

In programming mode inverter parameters can be read or changed. See Fig 4.2.2.3 for keypad navigation.




Fig 4.2.2.3 Programming Mode

Notes:

- The parameters values can be changed from the data set/read screen with the ▲ (up) or ▼ (down) and < / RESET shift key.
- To save a parameter press the READ/ENTER key. Return to the previous sub-menu screen press DSP/FUN key.
- Press the ▲ (up) or ▼ (down) key to scroll parameter groups or parameter list. When pressing DSP/FUN in the parameter edit mode, it will return to the previous screen of parameter group mode; when pressing DSP/FUN in the parameter group mode, it will return to the previous screen of parameter group selection mode.
- Refer to section 4.4 for parameter details.




Fig 4.2.2.4 Parameter Group Selection Mode Screen

Information
 provided by
EMAG
 Tel: 01902 601403
 www.emag-ltd.co.uk

4.3 Parameters

Parameter Group	Name
Group 00	Basic Parameters
Group 01	V/F Control Parameters
Group 02	IM Motor Parameters
Group 03	External Digital Input and Output Parameters
Group 04	External Analog Input and Output Parameters
Group 05	Multi-Speed Parameters
Group 06	Automatic Program Operation Parameters
Group 07	Start/ Stop Parameters
Group 08	Protection Parameters
Group 09	Communication Parameters
Group 10	PID Parameters
Group 11	Auxiliary Parameters
Group 12	Monitoring Parameters
Group 13	Maintenance Parameters
Group 14	PLC Setting Parameters
Group 15	PLC Monitoring Parameters
Group 16	LCD Parameters
Group 17	IM Motor Automatic Tuning Parameters
Group 18	Slip Compensation Parameters
Group 19	Reserved
Group 20	Speed Control Parameters
Group 21	Torque Control Parameters
Group 22	PM Motor Parameters
Group 23	Pump & HVAC
Group 24	1 to 8 Pump Card Function Group

Parameter Attribute	
*1	Parameters can be changed during run operation.
*2	Read-only parameters for communication.
*3	Parameter will not reset to default during a factory reset
*4	Read-only parameter
*5	Only displayed in using LED keypad
*6	Refer to the supplementation 1 if software V1.3 is used.
*7	New added parameters in software V1.4
*8	Refer to the supplementation 2 if software V1.5 is used.
*9	New added parameters in software V1.5

Supplementation 1 Setting range and default value in software V1.3			
Code	Parameter Name	Setting Range	Default Value
01-02	Maximum Output Frequency	10.0~400.0	the same as that in V1.4
02-07	Poles	2~8 (even)	the same as that in V1.4
03-02	Multi-function Terminal Function Setting-S3	the same as that in V1.4	8
03-03	Multi-function Terminal Function Setting-S4	the same as that in V1.4	9
03-04	Multi-function Terminal Function Setting-S5	the same as that in V1.4	2
03-11	Relay (R1A-R1C) Output	0~36	1
03-12	Relay (R2A-R2C) Output	0~36	20
03-39	Relay (R3A-R32C) Output	0~36	0
07-15	Pre-excitation Level	100~200	the same as that in V1.4
09-02	Baud-Rate Setting (bps)	the same as that in V1.4	3
10-35	PID Unit	0~21	the same as that in V1.4
16-01	Sub-screen Monitoring 1	5~76	the same as that in V1.4
16-02	Sub-screen Monitoring 2	5~76	the same as that in V1.4
16-03	Sub-screen Monitoring 3	5~76	the same as that in V1.4
16-04	Selection of Engineering Unit	0~21	the same as that in V1.4
17-06	Pole Number of Motor	2~8 (even)	the same as that in V1.4
23-00	Function Selection	0~2	the same as that in V1.4
23-02	Operation Pressure Setting	0.01 ~ 25.50	the same as that in V1.4
23-03	Maximum Pressure Setting	0.01 ~ 25.50	the same as that in V1.4
23-09	Tolerance Range of Contact Pressure	0.10 ~ 25.50	the same as that in V1.4
23-12	Maximum Pressure Limit	0.10 ~ 25.50	the same as that in V1.4
23-15	Minimum Pressure Limit	0.10 ~ 25.50	the same as that in V1.4
23-24	Range of Water Pressure Detection	0.10 ~ 2.50	the same as that in V1.4

Parameter 16-06 in inverter software V1.3 has been transferred to parameter 11-13 in V1.4.

Supplementation 2 Setting range and default value in software V1.5			
Code	Paramter Name	Setting Range	Default Value
00-05	Main Frequency Command Source Selection	0: Keypad	the same as that in V1.4
		1: External Terminal (Analog)	
		2: Terminal Command UP/DOWN	
		3: Communication Control (RS-485)	
		4: Reserved	
		5: PID Given	
		6: RTC	
00-06	Alternative Frequency Command Source Selection	0: Keypad	the same as that in V1.4
		1: External Terminal (Analog)	
		2: Terminal Command UP/DOWN	
		3: Communication Control (RS-485)	
		4: Reserved	
		5: PID Given	
		6: RTC	
23-02	Operation Pressure Setting	0.01 ~ 650.00(23-20=0)	the same as that in V1.4 (23-20=0) 20% (23-20=1)
		0~100%(23-20=1)	
23-09	Tolerance Range of Constant Pressure	0.01 ~ 650.00(23-20=0)	the same as that in V1.4 (23-20=0) 5% (23-20=1)
		0~100%(23-20=1)	
23-12	Maxium Pressure Limit	0.01 ~ 650.00(23-20=0)	the same as that in V1.4 (23-20=0) 50% (23-20=1)
		0~100%(23-20=1)	
23-15	Minimum Pressure Limit	0.01 ~ 650.00(23-20=0)	the same as that in V1.4 (23-20=0) 5% (23-20=1)
		0~100%(23-20=1)	
23-24	Range of Water Pressure Detection	0.01 ~ 650.00(23-20=0)	the same as that in V1.4 (23-20=0) 1% (23-20=1)
		0~100%(23-20=1)	
23-38	Pressure Change Range of Leak Detection Restart	0.01 ~ 650.00(23-20=0)	the same as that in V1.4 (23-20=0) 1% (23-20=1)
		0~100%(23-20=1)	
23-39	Tolerance Range of Leak Detection Restart	0.01~ 650.00(23-20=0)	the same as that in V1.4 (23-20=0) 5% (23-20=1)
		0~100%(23-20=1)	

Group 00 Basic Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
00-00	Control Mode Selection	0: V/F	0	-	0	0	0	*3
		1: Reserved						
		2: SLV						
		3~4: Reserved						
		5: PM SLV						
00-01	Motor's Rotation Direction	0: Forward	0	-	0	0	0	*1
		1: Reverse						
00-02	Main Run Command Source Selection	0: Keypad	0 ^{*note1}	-	0	0	0	
		1: External Terminal (Control Circuit)						
		2: Communication Control (RS-485)						
		3: PLC						
		4: RTC						
00-03	Alternative Run Command Source Selection	0: Keypad	2	-	0	0	0	
		1: External Terminal (Control Circuit)						
		2: Communication Control (RS-485)						
		3: PLC						
		4: RTC						
00-04	Language Selection	0: English	0	-	0	0	0	
		1: Simple Chinese						
		2: Traditional Chinese						
00-05	Main Frequency Command Source Selection	0: Keypad	0 ^{*note1}	-	0	0	0	
		1: External Terminal (Analog AI1)						
		2: Terminal Command UP/ DOWN						
		3: Communication Control (RS-485)						
		4: Reserved						
		5: PID given						
		6: RTC						
		7: AI2 Auxiliary Frequency *7						
00-06	Alternative Frequency Command Source Selection	0: Keypad	3	-	0	0	0	
		1: External Terminal (Analog)						
		2: Terminal Command UP/ DOWN						
		3: Communication Control (RS-485)						
		4: Reserved						
		5: PID						
		6: RTC						
		7: AI2 Auxiliary Frequency *7						
00-07	Main and Alternative Frequency Command Modes	0: Main Frequency	0	-	0	0	0	
		1: Main Frequency + Alternative Frequency						
00-08	Communication Frequency Command Range	0.00-400.00	0.00	Hz	0	0	0	
00-09	Communication Frequency Command Memory Selection	0: Do not save when power is off.	0	-	0	0	0	
		1: Save when power is off.						
00-10 ~ 00-11	Reserved							
00-12	Upper Limit Frequency	0.1~109.0	100.0	%	0	0	0	

Group 00 Basic Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
00-13	Lower Limit Frequency	0.0~109.0	0.0	%	○	○	○	
00-14	Acceleration Time 1	0.1~6000.0	-	s	○	○	○	*1
00-15	Deceleration Time 1	0.1~6000.0	-	s	○	○	○	*1
00-16	Acceleration Time 2	0.1~6000.0	-	s	○	○	○	*1
00-17	Deceleration Time 2	0.1~6000.0	-	s	○	○	○	*1
00-18	Jog Frequency	0.00~400.00	6.00	Hz	○	○	○	*1
00-19	Jog Acceleration Time	0.1~0600.0	-	s	○	○	○	*1
00-20	Jog Deceleration Time	0.1~0600.0	-	s	○	○	○	*1
00-21	Acceleration Time 3	0.1~6000.0	-	s	○	○	○	*1
00-22	Deceleration Time 3	0.1~6000.0	-	s	○	○	○	*1
00-23	Acceleration Time 4	0.1~6000.0	-	s	○	○	○	*1
00-24	Deceleration Time 4	0.1~6000.0	-	s	○	○	○	*1
00-25	Switch-Over Frequency of Acc/Dec Time 1 and Time 4	0.0~400.0	0.0	Hz	○	○	○	
00-26	Emergency Stop Time	0.1~6000.0	5.0	s	○	○	○	
00-27	Reserved							
00-28	Main Frequency Command Characteristic Selection	0: Positive Characteristic (0~10V/4~20mA is corresponding to 0~100%)	0	-	○	○	○	
		1: Negative Characteristic (0~10V/4~20mA is corresponding to 100~0%)						
00-29 ~ 00-31	Reserved							
00-32	Application Selection Presets	0: Default Value	0	-	○	○	○	
		1: Water Supply Pump						
		2: Conveyor *7						
		3: Exhaust fan						
		4: HVAC						
		5: Compressor *7						
		6: Hoist *7						
7: Crane *7								
00-33	Modified Parameters	0: Enable	0	-	○	○	○	
		1: Disable						
00-34 ~ 00-40	Reserved							
00-41	User Parameter 0	Set 13-06 = 1, and enable user parameter. Setting Range: 01-00 ~24-06 (only used in LCD keypad)	-		○	○	○	
00-42	User Parameter 1		-		○	○	○	
00-43	User Parameter 2		-		○	○	○	
00-44	User Parameter 3		-		○	○	○	
00-45	User Parameter 4		-		○	○	○	
00-46	User Parameter 5		-		○	○	○	
00-47	User Parameter 6		-		○	○	○	
00-48	User Parameter 7		-		○	○	○	
00-49	User Parameter 8		-		○	○	○	
00-50	User Parameter 9		-		○	○	○	
00-51	User Parameter 10		-		○	○	○	
00-52	User Parameter 11		-		○	○	○	
00-53	User Parameter 12		-		○	○	○	
00-54	User Parameter 13		-		○	○	○	

Group 00 Basic Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
00-55	User Parameter 14		-		○	○	○	
00-56	User Parameter 15		-		○	○	○	

*note1: Default value is 1 in software V1.1 or the previous (external control); Default value is 0 in software V1.2 or the following (keypad).

Group 01 V/F Control Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
01-00	V/F Curve Selection	0~FF	6	-	○	×	×	*3
01-01	Reserved							
01-02	Maximum Output Frequency	20.0~400.0	60.0	Hz	○	○	○	*6
01-03	Maximum Output Voltage	200V: 0.1~255.0	220.0	V	○	×	×	
		400V: 0.2~510.0	440.0					
01-04	Middle Output Frequency 2	0.0~400.0	0.0	Hz	○	×	×	
01-05	Middle Output Voltage 2	200V: 0.0~255.0	0.0	V	○	×	×	
		400V: 0.0~510.0						
01-06	Middle Output Frequency 1	0.0~400.0	30.0	Hz	○	×	×	
01-07	Middle Output Voltage 1	200V: 0.0~255.0	38.5	V	○	×	×	
		400V: 0.0~510.0	77.0					
01-08	Minimum Output Frequency	0.0~400.0	1.5	Hz	○	○	○	
01-09	Minimum Output Voltage	200V: 0.0~255.0	6.6	V	○	×	×	
		400V: 0.0~510.0	13.2					
01-10	Torque Compensation Gain	0.0~2.0	0.5	-	○	×	×	*1
01-11	Reserved							
01-12	Base Frequency	10.0~400.0	60.0	Hz	○	○	○	
01-13	Base Output Voltage	200V: 0.0~255.0	220.0	V	○	×	×	
		400V: 0.0~510.0	440.0					
01-14	Input Voltage Setting	200V: 155.0~255.0	220.0	V	○	○	○	
		400V: 310.0~510.0	440.0					
01-15	Torque Compensation Time	0~10000	200	ms	○	×	×	

Group 02 IM Motor Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
02-00	No-Load Current	0.01~600.00	KVA	A	○	×	×	
02-01	Rated Current	V/F mode is 10%~200% of inverter's rated current; SLV mode is 25%~200% of inverter's rated current.	KVA	A	○	○	×	
02-02	Reserved							
02-03	Rated Rotation Speed	0~60000	KVA	Rpm	○	○	×	
02-04	Rated Voltage	200V: 50.0~240.0	220.0	V	○	○	×	
		400V: 100.0~480.0	440.0					
02-05	Rated Power	0.01~600.00	KVA	kW	○	○	×	
02-06	Rated Frequency	10.0~400.0	60.0	Hz	○	○	×	
02-07	Poles	2~16 (Even)	4	-	○	○	×	*6
02-08	Reserved							
02-09	Excitation Current	15.0~70.0	KVA	%	×	○	×	

Group 02 IM Motor Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
02-10	Core Saturation Coefficient 1	0~100	KVA	%	X	O	X	
02-11	Core Saturation Coefficient 2	0~100	KVA	%	X	O	X	
02-12	Core Saturation Coefficient 3	80~300	KVA	%	X	O	X	
02-13	Core Loss	0.0~15.0	KVA	%	O	X	X	
02-14	Reserved							
02-15	Resistance between Wires	0.001~60.000	KVA	Ω	O	O	X	
02-16	Rotor Resistance	0.001~60.000	KVA	Ω	X	O	X	
02-17	Leakage Inductance	0.01~200.00	KVA	mH	X	O	X	
02-18	Mutual Inductance	0.1~6553.5	KVA	mH	X	O	X	
02-19	No-Load Voltage	200V: 50~240	KVA	V	X	O	X	
		400V: 100~480						
02-20 ~ 02-32	Reserved							
02-33	Leakage Inductance Ratio	0.1~15.0	KVA	%	X	O	X	
02-34	Slip Frequency	0.10~20.00	KVA	Hz	X	O	X	

Group 03 External Digital Input and Output Parameters											
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute			
					V/F	SLV	PM SLV				
03-00	Multi-function Terminal Function Setting-S1	0: 2-Wire Sequence (ON: Forward Run Command)	0	-	O	O	O				
		1: 2-Wire Sequence (ON: Reverse Run Command)									
		2: Multi-Speed Setting Command 1	1						O	O	O
		3: Multi-Speed Setting Command 2							O	O	O
		4: Multi-Speed Setting Command 3							O	O	O
5: Multi-Speed Setting Command 4	2	O	O	O	*6						
6: Forward Jog Run Command		O	O	O							
03-01	Multi-function Terminal Function Setting-S2	7: Reverse Jog Run Command	3	-	O	O	O	*6			
		8: UP Frequency Increasing Command									
		9: DOWN Frequency Decreasing Command	4						O	O	O
		10: Acceleration/ Deceleration Setting Command 1							O	O	O
		11: Inhibit Acceleration/ Deceleration Command							O	O	O
12: Main/Alternative Run command Switching	17	-	O	O	O						
13: Main/Alternative Frequency Command Switching											
14: Emergency Stop (Decelerate to Zero and Stop)											
03-02	Multi-function Terminal Function Setting-S3	15: External Baseblock Command (Rotation freely to Stop)	-	-	O	O	O				
		16: PID Control Disable									
		17: Fault Reset (RESET)									

Group 03 External Digital Input and Output Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		18: Reserved		-	-	-	-	
		19: Speed Search 1(from the maximum frequency)		-	O	O	X	
03-03	Multi-function Terminal Function Setting-S4	20: Manual Energy Saving Function	17	-	O	X	X	
		21: PID Integral Reset		-	O	O	O	
		22~23: Reserved		-	-	-	-	
		24: PLC Input						
		25: External Fault						
		26: 3-Wire Sequence (Forward/ Reverse Command)						
		27: Local/ Remote Selection		-	O	O	O	
		28: Remote Mode Selection						
		29: Jog Frequency Selection						
		30: Acceleration/ Deceleration Setting Command 2						
		31: Inverter Overheating Warning						
		32: Reserved		-	-	-	-	
		33: DC Braking		-	O	X	X	
		34: Speed Search 2 (from Frequency Command)		-	O	X	O	
35: Timing Function Input	-	O	O	O				
36: PID Soft Start Disable								
03-04	Multi-function Terminal Function Setting-S5	37~40: Reserved		-	-	-	-	
		41: PID Sleep		-	O	O	O	
		42~46: Reserved		-	-	-	-	
		47: Fire Mode (Forced to Run Mode)	-	O	O	O		
		48: KEB Acceleration	-	O	X	X		
		49: Parameters Writing Allowable	-	O	O	O		
		50: Unattended Start Protection (USP)	-	O	O	O		
51~52: Reserved	-	-	-	-				
03-05	Multi-function Terminal Function Setting-S6	53: 2-Wire Self Holding Mode (Stop Command)						
		54: Switch PID1 and PID2						
		55: RTC Time Enable	-	O	O	O		
		56: RTC Offset Enable						
		57: Forced Frequency Run						
		58: Run Permissive Function						
03-06 ~ 03-07	Reserved							
03-08	(S1~S6) DI Scan Time	0: Scan Time 4ms 1: Scan Time 8ms	1	-	O	O	O	
03-09	Multi-Function Terminal (S1-S4 Selection)	xxx0b:S1 A Contact	0000b	-	O	O	O	
		xxx1b:S1 B Contact						
		xx0xb:S2 A Contact						
		xx1xb:S2 B Contact						
		x0xxb:S3 A Contact						
x1xxb:S3 B Contact								
		0xxb:S4 A Contact						
		1xxb:S4 B Contact						

Group 03 External Digital Input and Output Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute	
					V/F	SLV	PM SLV		
03-10	Multi-Function Terminal (S5-S6 Selection)	xxx0b:S5 A Contact	0000b	-	O	O	O		
		xxx1b:S5 B Contact							
		xx0xb:S6 A Contact							
		xx1xb:S6 B Contact							
		x0xxb: Reserved							
x1xxb: Reserved									
03-11	Relay (R1A-R1C) Output	0: During Running	0	-	O	O	O	*6	
		1: Fault Contact Output							
		2: Frequency Agree							
		3: Setting Frequency Agree (03-13 ± 03-14)							
		4: Frequency Detection 1 (> 03-13, Hysteresis interval 03-14)							
		5: Frequency Detection 2 (< 03-13, Hysteresis interval 03-14)							
		6: Automatic Restart							
		7~8: Reserved							
		9: Baseblock							
		10~11: Reserved							
		12: Over-Torque Detection							
		13: Current Agree *7							
		14~17: Reserved							
		18: PLC Status							
19: PLC Control									
20: Zero Speed									
21: Inverter Ready									
22: Undervoltage Detection									
23: Source of Operation Command									
24: Source of Frequency Command									
25: Low Torque Detection									
26: Frequency Reference Missing									
27: Timing Function Output									
28~31: Reserved									
32: Communication Control Contacts									
33: RTC Timer 1									
34: RTC Timer 2									
35: RTC Timer 3									
36: RTC Timer 4									
37: Detection Output of PID Feedback Loss *7									
38: Brake Release *7									
03-12	Relay (R2A-R2C) Output		1	-	O	O	O	*6	
03-13	Frequency Detection Level	0.0~400.0	0.0	Hz	O	O	O		
03-14	Frequency Detection Width	0.1~25.5	2.0	Hz	O	O	O		
03-15	Current Agree Level	0.1~999.9	0.1	A	O	O	O	*7	
03-16	Delay Time of Current Agree Detection	0.1~10.0	0.1	s	X	O	X	*7	
03-17 ~ 03-18	Reserved								

Group 03 External Digital Input and Output Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
03-19	Relay(R1A-R3C)Type	xxx0b: R1 A Contact xxx1b: R1 B Contact	0000b	-	O	O	O	
		xx0xb: R2 A Contact xx1xb: R2 B Contact						
		x0xxb: R3 A Contact x1xxb: R3 B Contact						
03-20 ~ 03-26	Reserved							
03-27	UP/DOWN Frequency Hold/ Adjust Selection	0: Keep UP/DOWN frequency when stopping.	0	-	O	O	O	
		1: Clear UP/DOWN frequency when stopping.						
		2: Allow frequency UP/DOWN when stopping.						
		3: Refresh frequency at acceleration.						
03-28 ~ 03-29	Reserved							
03-30	Pulse Input Selection	0: Common Pulse Input	0	-	O	O	O	*7
		1: PWM (Pulse Width Modulation)						
03-31	Pulse Input Scaling	50~32000	1000	Hz	O	O	O	*1
03-32	Pulse input gain	0.0~1000.0	100	%	O	O	O	*1
03-33	Pulse input bias	-100.0~100.0	0.0	%	O	O	O	*1
03-34	Pulse input filter time	0.00~2.00	0.1	Sec	O	O	O	*1
03-35 ~ 03-36	Reserved							
03-37	Timer ON Delay (DI/DO)	0.0~6000.0	0.0	s	O	O	O	
03-38	Timer OFF Delay (DI/DO)	0.0~6000.0	0.0	s	O	O	O	
03-39	Relay (R3A-R3C) Output	Setting range and definition are the same as those of 03-11 and 03-12.	20	-	O	O	O	
03-40	Up/down Frequency Width Setting	0.00~5.00	0.00	Hz	O	O	O	*7
03-41	Torque Detection Level	0~300	10	%	X	O	X	*7
03-42	Delay Time of Braking Action	0.00~65.00	0.00	s	X	O	X	*7

Group 04 External Analog Input and Output Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
04-00	AI Input Signal Type	0: AI2: 0~10V/ 0~20mA 1: AI2: 4~20mA/ 2~10V	1	-	O	O	O	
04-01	AI1 Signal Scanning and Filtering Time	0.00~2.00	0.03	s	O	O	O	
04-02	AI1 Gain	0.0~1000.0	100.0	%	O	O	O	*1
04-03	AI1 Bias	-100.0~100.0	0	%	O	O	O	*1
04-04	Reserved							
04-05	AI2 Function Setting	0: Auxiliary Frequency	0	-	O	O	O	
		1: Frequency Reference Gain			O	O	O	
		2: Frequency Reference Bias			O	O	O	
		3: Output Voltage Bias			O	X	O	
		4: Coefficient of Acceleration and Deceleration Reduction			O	O	O	
		5: DC Braking Current			O	O	X	
		6: Over-Torque Detection Level			O	O	O	
		7: Stall Prevention Level During Running			O	X	X	
		8: Frequency Lower Limit			O	O	O	
		9: Jump Frequency 4			O	O	O	
		10: Added to AI1			O	O	O	
		11: Positive Torque Limit			X	O	O	
		12: Negative Torque Limit			X	O	O	
		13: Regenerative Torque Limit			X	O	O	
		14: Positive / Negative Torque Limit			X	O	O	
		15: Reserved			-	-	-	
		16: Torque Compensation			X	O	X	
17: Reserved	-	-	-					
04-06	AI2 Signal Scanning and Filtering Time	0.00~2.00	0.03	s	O	O	O	
04-07	AI2 Gain	0.0~1000.0	100.0	%	O	O	O	*1
04-08	AI2 Bias	-100.0~100.0	0	%	O	O	O	*1
04-09 ~ 04-10	Reserved							
04-11	AO1 Function Setting	0: Output Frequency	0	-	O	O	O	
		1: Frequency Command			O	O	O	
		2: Output Voltage			O	O	O	
		3: DC Voltage			O	O	O	
		4: Output Current			O	O	O	
		5: Output Power			O	O	O	
		6: Motor Speed			O	O	O	
		7: Output Power Factor			O	O	O	
		8: AI1 Input			O	O	O	
		9: AI2 Input			O	O	O	
		10: Torque Command			X	O	O	

Group 04 External Analog Input and Output Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		11: q-axis Current			X	O	O	
		12: d-axis Current			X	O	O	
		13: Speed deviation			X	X	O	
		14: Reserved			-	-	-	
		15: ASR Output			X	X	O	
		16: Reserved			-	-	-	
		17: q-axis Voltage			X	O	O	
		18: d-axis Voltage			X	O	O	
		19~20: Reserved			-	-	-	
		21: PID Input			O	O	O	
		22: PID Output			O	O	O	
		23: PID Target Value			O	O	O	
		24: PID Feedback Value			O	O	O	
		25: Output Frequency of the Soft Starter			O	O	O	
		26: PG feedback			-	-	-	
		27: PG compensation			-	-	-	
		28: Communication Control *6			O	O	O	
04-12	AO1 Gain	0.0~1000.0	100.0	%	O	O	O	*1
04-13	AO1 Bias	-100.0~100.0	0	%	O	O	O	*1
04-14 ~ 04-15	Reserved							
04-16	AO2 Function Setting	Setting range and definition are the same as 04-11	3	-	O	O	O	
04-17	AO2 Gain	0.0~1000.0	100.0	%	O	O	O	*1
04-18	AO2 Bias	-100.0~100.0	0	%	O	O	O	*1
04-19	AO Output Signal Type	0: AO1:0~10V AO2:0~10V	0		O	O	O	
		1: AO1:0~10V AO2:4~20mA						
		2: AO1:4~20mA AO2:0~10V						
		3: AO1:4~20mA AO2: 4~20mA						
04-20	Filter Time of AO Signal Scan	0.00~0.50	0.00	s	O	O	O	*1 *7

Group 05 Multi-Speed Function Group

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
05-00	Acceleration and Deceleration Selection of Multi-Speed	0: Acceleration and deceleration time are set by 00-14 ~ 00-24	0	-	O	O	O	
		1: Acceleration and Deceleration Time are set by 05-17 ~ 05-48						
05-01	Frequency Setting of Speed-Stage 0	0.00~400.00	5.00	Hz	O	O	O	*1
05-02	Frequency Setting of Speed-Stage 1	0.00~400.00	5.00	Hz	O	O	O	*7
05-03	Frequency Setting of Speed-Stage 2	0.00~400.00	10.00	Hz	O	O	O	*7
05-04	Frequency Setting of Speed-Stage 3	0.00~400.00	20.00	Hz	O	O	O	*7
05-05	Frequency Setting of Speed-Stage 4	0.00~400.00	30.00	Hz	O	O	O	*7
05-06	Frequency Setting of Speed-Stage 5	0.00~400.00	40.00	Hz	O	O	O	*7
05-07	Frequency Setting of Speed-Stage 6	0.00~400.00	50.00	Hz	O	O	O	*7
05-08	Frequency Setting of Speed-Stage 7	0.00~400.00	50.00	Hz	O	O	O	*7
05-09	Frequency Setting of Speed-Stage 8	0.00~400.00	5.00	Hz	O	O	O	*7
05-10	Frequency Setting of Speed-Stage 9	0.00~400.00	5.00	Hz	O	O	O	*7
05-11	Frequency Setting of Speed-Stage 10	0.00~400.00	5.00	Hz	O	O	O	*7
05-12	Frequency Setting of Speed-Stage 11	0.00~400.00	5.00	Hz	O	O	O	*7
05-13	Frequency Setting of Speed-Stage 12	0.00~400.00	5.00	Hz	O	O	O	*7
05-14	Frequency Setting of Speed-Stage 13	0.00~400.00	5.00	Hz	O	O	O	*7
05-15	Frequency Setting of Speed-Stage 14	0.00~400.00	5.00	Hz	O	O	O	*7
05-16	Frequency Setting of Speed-Stage 15	0.00~400.00	5.00	Hz	O	O	O	*7
05-17	Acceleration Time Setting of Multi Speed 0	0.1~6000.0	10.0	s	O	O	O	
05-18	Deceleration Time Setting of Multi Speed 0	0.1~6000.0	10.0	s	O	O	O	
05-19	Acceleration Time Setting of Multi Speed 1	0.1~6000.0	10.0	s	O	O	O	
05-20	Deceleration Time Setting of Multi Speed 1	0.1~6000.0	10.0	s	O	O	O	
05-21	Acceleration Time Setting of Multi Speed 2	0.1~6000.0	10.0	s	O	O	O	

Group 05 Multi-Speed Function Group

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
05-22	Deceleration Time Setting of Multi Speed 2	0.1~6000.0	10.0	s	O	O	O	
05-23	Acceleration Time Setting of Multi Speed 3	0.1~6000.0	10.0	s	O	O	O	
05-24	Deceleration Time Setting of Multi Speed 3	0.1~6000.0	10.0	s	O	O	O	
05-25	Acceleration Time Setting of Multi Speed 4	0.1~6000.0	10.0	s	O	O	O	
05-26	Deceleration Time Setting of Multi Speed 4	0.1~6000.0	10.0	s	O	O	O	
05-27	Acceleration Time Setting of Multi Speed 5	0.1~6000.0	10.0	s	O	O	O	
05-28	Deceleration Time Setting of Multi Speed 5	0.1~6000.0	10.0	s	O	O	O	
05-29	Acceleration Time Setting of Multi Speed 6	0.1~6000.0	10.0	s	O	O	O	
05-30	Deceleration Time Setting of Multi Speed 6	0.1~6000.0	10.0	s	O	O	O	
05-31	Acceleration Time Setting of Multi Speed 7	0.1~6000.0	10.0	s	O	O	O	
05-32	Deceleration Time Setting of Multi Speed 7	0.1~6000.0	10.0	s	O	O	O	
05-33	Acceleration Time Setting of Multi Speed 8	0.1~6000.0	10.0	s	O	O	O	
05-34	Deceleration Time Setting of Multi Speed 8	0.1~6000.0	10.0	s	O	O	O	
05-35	Acceleration Time Setting of Multi Speed 9	0.1~6000.0	10.0	s	O	O	O	
05-36	Deceleration Time Setting of Multi Speed 9	0.1~6000.0	10.0	s	O	O	O	
05-37	Acceleration Time Setting of Multi Speed 10	0.1~6000.0	10.0	s	O	O	O	
05-38	Deceleration Time Setting of Multi Speed 10	0.1~6000.0	10.0	s	O	O	O	
05-39	Acceleration Time Setting of Multi Speed 11	0.1~6000.0	10.0	s	O	O	O	
05-40	Deceleration Time Setting of Multi Speed 11	0.1~6000.0	10.0	s	O	O	O	
05-41	Acceleration Time Setting of Multi Speed 12	0.1~6000.0	10.0	s	O	O	O	
05-42	Deceleration Time Setting of Multi Speed 12	0.1~6000.0	10.0	s	O	O	O	
05-43	Acceleration Time Setting of Multi Speed 13	0.1~6000.0	10.0	s	O	O	O	
05-44	Deceleration Time Setting of Multi Speed 13	0.1~6000.0	10.0	s	O	O	O	
05-45	Acceleration Time Setting of	0.1~6000.0	10.0	s	O	O	O	

Group 05 Multi-Speed Function Group								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
	Multi Speed 14							
05-46	Deceleration Time Setting of Multi Speed 14	0.1~6000.0	10.0	s	O	O	O	
05-47	Acceleration Time Setting of Multi Speed 15	0.1~6000.0	10.0	s	O	O	O	
05-48	Deceleration Time Setting of Multi Speed 15	0.1~6000.0	10.0	s	O	O	O	

Group 06 Automatic Program Operation Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
06-00	Automatic Operation Mode Selection	0: Disable 1: Execute a single cycle operation mode. Restart speed is based on the previous stopped speed. 2: Execute continuous cycle operation mode. Restart speed is based on the previous stopped speed. 3: After the completion of a single cycle, the on-going operation speed is based on the speed of the last stage. Restart speed is based on the previous stopped speed. 4: Execute a single cycle operation mode. Restart speed will be based on the speed of stage 1. 5: Execute continuous cycle operation mode. Restart speed will be based on the speed of stage 1. 6: After the completion of a single cycle, the on-going operation speed is based on the speed of the last stage. Restart speed is based on the previous stopped speed.	0	-	O	O	X	
06-01	Frequency Setting of Operation-Stage 1	0.00~400.00	5.00	Hz	O	O	O	*1
06-02	Frequency Setting of Operation -Stage 2	0.00~400.00	10.00	Hz	O	O	O	*1
06-03	Frequency Setting of Operation -Stage 3	0.00~400.00	20.00	Hz	O	O	O	*1
06-04	Frequency Setting of Operation -Stage 4	0.00~400.00	30.00	Hz	O	O	O	*1

Group 06 Automatic Program Operation Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
06-05	Frequency Setting of Operation -Stage 5	0.00~400.00	40.00	Hz	O	O	O	*1
06-06	Frequency Setting of Operation -Stage 6	0.00~400.00	50.00	Hz	O	O	O	*1
06-07	Frequency Setting of Operation -Stage 7	0.00~400.00	50.00	Hz	O	O	O	*1
06-08	Frequency Setting of Operation -Stage 8	0.00~400.00	5.00	Hz	O	O	O	*1
06-09	Frequency Setting of Operation -Stage 9	0.00~400.00	5.00	Hz	O	O	O	*1
06-10	Frequency Setting of Operation -Stage 10	0.00~400.00	5.00	Hz	O	O	O	*1
06-11	Frequency Setting of Operation -Stage 11	0.00~400.00	5.00	Hz	O	O	O	*1
06-12	Frequency Setting of Operation -Stage 12	0.00~400.00	5.00	Hz	O	O	O	*1
06-13	Frequency Setting of Operation -Stage 13	0.00~400.00	5.00	Hz	O	O	O	*1
06-14	Frequency Setting of Operation -Stage 14	0.00~400.00	5.00	Hz	O	O	O	*1
06-15	Frequency Setting of Operation -Stage 15	0.00~400.00	5.00	Hz	O	O	O	*1
06-16	Time Setting of Operation -Stage 0	0.0~6000.0	0.0	s	O	O	X	*1
06-17	Time Setting of Operation -Stage 1	0.0~6000.0	0.0	s	O	O	X	*1
06-18	Time Setting of Operation -Stage 2	0.0~6000.0	0.0	s	O	O	X	*1
06-19	Time Setting of Operation -Stage 3	0.0~6000.0	0.0	s	O	O	X	*1
06-20	Time Setting of Operation -Stage 4	0.0~6000.0	0.0	s	O	O	X	*1
06-21	Time Setting of Operation -Stage 5	0.0~6000.0	0.0	s	O	O	X	*1
06-22	Time Setting of Operation -Stage 6	0.0~6000.0	0.0	s	O	O	X	*1
06-23	Time Setting of Operation -Stage 7	0.0~6000.0	0.0	s	O	O	X	*1
06-24	Time Setting of Operation -Stage 8	0.0~6000.0	0.0	s	O	O	X	*1
06-25	Time Setting of Operation -Stage 9	0.0~6000.0	0.0	s	O	O	X	*1
06-26	Time Setting of Operation -Stage 10	0.0~6000.0	0.0	s	O	O	X	*1
06-27	Time Setting of Operation -Stage 11	0.0~6000.0	0.0	s	O	O	X	*1

Group 06 Automatic Program Operation Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
06-28	Time Setting of Operation -Stage 12	0.0~6000.0	0.0	s	O	O	X	*1
06-29	Time Setting of Operation -Stage 13	0.0~6000.0	0.0	s	O	O	X	*1
06-30	Time Setting of Operation -Stage 14	0.0~6000.0	0.0	s	O	O	X	*1
06-31	Time Setting of Operation -Stage 15	0.0~6000.0	0.0	s	O	O	X	*1
06-32	Direction Selection of Operation -Stage 0	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-33	Direction Selection of Operation -Stage 1	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-34	Direction Selection of Operation -Stage 2	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-35	Direction Selection of Operation -Stage 3	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-36	Direction Selection of Operation -Stage 4	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-37	Direction Selection of Operation -Stage 5	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-38	Direction Selection of Operation -Stage 6	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-39	Direction Selection of Operation -Stage 7	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-40	Direction Selection of Operation -Stage 8	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-41	Direction Selection of Operation -Stage 9	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-42	Direction Selection of Operation -Stage 10	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-43	Direction Selection of Operation -Stage 11	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-44	Direction Selection of Operation -Stage 12	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-45	Direction Selection of Operation -Stage 13	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-46	Direction Selection of Operation -Stage 14	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	
06-47	Direction Selection of Operation -Stage 15	0: Stop 1: Forward 2: Reverse	0	-	O	O	X	

Group 07: Start /Stop Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
07-00	Momentary Power Loss/ Fault Restart Selection	0: Disable	0	-	O	O	O	
		1: Enable						
07-01	Fault Auto-Restart Time	0~7200	0	s	O	O	O	
07-02	Number of Fault Auto-Restart Attempts	0~10	0	-	O	O	O	
07-03	Reserved							
07-04	DC injection braking starting frequency	0: DC injection braking is enabled at power up when external run command issues.	1	-	O	O	O	
		1: DC injection braking is disabled at power up when external run command issues.						
07-05	Automatic start delay at power up	1.0~300.0	1.5	Sec	O	O	O	
07-06	DC Injection Braking Start Frequency	0.0~10.0	0.5	Hz	O	O	X	
07-07	DC Injection Braking Current	0~100	50	%	O	O	X	
07-08	DC Injection Braking Time at Stop	0.00~10.00	0.50	s	O	O	X	
07-09	Stop Mode Selection	0: Deceleration to Stop	0	-	O	O	O	
		1: Coast to Stop						
		2: DC Braking Stop						
		3: Coast to Stop with Timer						
07-10 ~ 07-12	Reserved							
07-13	Low Voltage Detection Level	200V: 150~300	190	V	O	O	O	
		400V: 300~600	380					
07-14	Pre-excitation Time	0.00~10.00	2.00	s	X	O	X	
07-15	Pre-excitation Level	50~200	100	%	X	O	X	*6
07-16	DC Injection Braking Time at Start	0.00~100.00	0.00	s	O	O	X	
07-17	Reserved							
07-18	Minimum Base block Time	0.1~5.0	-	Sec	O	O	O	
07-19	Direction-Detection Speed Search Operating Current	0~100	50	%	O	O	X	
07-20	Speed Search Operating Current	0~100	20	%	O	O	X	
07-21	Integral Time of Speed Searching	0.1~10.0	2.0	Sec	O	O	X	
07-22	Delay Time of Speed Search	0.0~20.0	0.2	Sec	O	O	X	
07-23	Voltage Recovery Time	0.1~5.0	2.0	Sec	O	O	X	
07-24	Direction-Detection Speed Search Selection	0: Disable	0	-	O	O	X	
		1: Enable						
07-25	Low voltage Detection Time	0.00~1.00	0.00	Sec	O	O	O	
07-26	SLV Speed Search Function	0: Enable	0	-	X	O	X	
		1: Disable						

Group 07: Start /Stop Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
07-27	Start Selection after Fault during SLV Mode	0: Speed search start	0	-	X	O	O	
		1: Normal Start						
07-28	Start Selection after External Base Block	0: Speed search start	0	-	O	O	X	
		1: Normal Start						

Group 08 Protection Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
08-00	Stall Prevention Function	xxx0b: Stall prevention is enabled in acceleration.	0000b	-	O	O	O	
		xxx1b: Stall prevention is disabled in acceleration.						
		xx0xb: Stall prevention is enabled in deceleration.						
		xx1xb: Stall prevention is disabled in deceleration.						
		x0xxb: Stall prevention is enabled in operation						
		x1xxb: Stall prevention is disabled in operation						
		0xxxb: Stall prevention in operation decelerates based on deceleration time 1						
		1xxxb: Stall prevention in operation decelerates based on deceleration time 2						
08-01	Stall Prevention Level in Acceleration	30~200	120	%	O	O	O	
08-02	Stall Prevention Level in Deceleration	200V: 330~410	395	V	O	O	O	
		400V: 660~820	790					
08-03	Stall Prevention Level in Operation	30~200	120	%	O	O	O	
08-04	Reserved							
08-05	Selection for Motor Overload Protection (OL1)	xxx0b: Motor Overload Protection is disabled	0001b	-	O	O	O	
		xxx1b: Motor Overload Protection is enabled						
		xx0xb: Cold Start of Motor Overload						
		xx1xb: Hot Start of Motor Overload						
		x0xxb: Standard Motor						
		x1xxb: Special motor						
		0xxxb: Reserved						
1xxxb: Reserved								

Group 08 Protection Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
08-06	Start-up Mode of Overload Protection Operation (OL1)	0: Stop Output after Overload Protection	0	-	○	○	○	
		1: Continuous Operation after Overload Protection.						
08-07	Reserved							
08-08	Automatic Voltage Regulation (AVR)	0: Enable	0	-	○	○	○	
		1: Disable						
08-09	Selection of Input Phase Loss Protection	0: Disable	0	-	○	○	○	
		1: Enable						
08-10	Selection of Output Phase Loss Protection	0: Disable	0	-	○	○	○	
		1: Enable						
08-11 ~ 08-12	Reserved							
08-13	Selection of Over-Torque Detection	0: Over-Torque Detection is Disabled.	0	-	○	○	○	
		1: Start to Detect when Reaching the Set Frequency.						
		2: Start to Detect when the Operation is Begun.						
08-14	Selection of Over-Torque Operation	0: Deceleration to Stop when Over-Torque is Detected.	0	-	○	○	○	
		1: Display Warning when Over-Torque is Detected. Go on Operation.						
		2: Coast to Stop when Over Torque is Detected						
08-15	Level of Over-Torque Detection	0~300	150	%	○	○	○	
08-16	Time of Over-Torque Detection	0.0~10.0	0.1	Sec	○	○	○	
08-17	Selection of Low-Torque Detection	0: Low-Torque Detection is Disabled.	0	-	○	○	○	
		1: Start to Detect when Reaching the Set Frequency.						
		2: Start to Detect when the Operation is Begun.						
08-18	Selection of Low-Torque Operation	0: Deceleration to Stop when Low-Torque is Detected.	0	-	○	○	○	
		1: Display Warning when Low-Torque is Detected. Go on Operation.						
		2: Coast to Stop when Low-Torque is Detected						
08-19	Level of Low-Torque Detection	0~300	30	%	○	○	○	
08-20	Time of Low-Torque Detection	0.0~10.0	0.1	Sec	○	○	○	
08-21	Limit of Stall Prevention in Acc	0~100	50	%	○	○	○	

Group 08 Protection Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
	over Base Speed							
08-22	Stall Prevention Detection Time in Operation	2~100	100	ms	○	○	○	
08-23	Ground Fault (GF) Selection	0: Disable 1: Enable	0	-	○	○	○	
08-24	Operation Selection of External Fault	0: Deceleration to Stop 1: Coast to Stop 2: Continuous Operation	0	-	○	○	○	
08-25	Detection selection of External Fault	0: Immediately Detect when the Power is Supplied. 1: Start to Detect during Operation	0	-	○	○	○	
08-26 ~ 08-29	Reserved							
08-30	Selection of Run Permissive Function	0: Deceleration to Stop 1: Coast to Stop	0	-	○	○	○	
08-31 ~ 08-34	Reserved							
08-35	Fault Selection of Motor Overheat	0: Disable 1: Deceleration to Stop 2: Coast to Stop	0	-	○	○	○	
08-36	Time Coefficient of PTC Input Filter	0.00 ~ 5.00	0.20	Sec	○	○	○	
08-37	Fan Control Function	0: Start at Operation 1: Permanent Start 2: Start at High Temperature*	0	-	○	○	○	
08-38	Delay Time of Fan Off	0~600	60	Sec	○	○	○	
08-39	Delay Time of Motor Overheat Protection	1~300	60	Sec	○	○	○	

* Models of inverter ratings above 2040 and 4050 in IP20 enclosure do not have this function.

Group 09: Communication Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
09-00	INV Communication Station Address	1~31	1	-	○	○	○	*2
09-01	Communication Mode Selection	0: MODBUS 1: BACNET 2: METASYS 3: PUMP in Parallel Connection 4: PROFIBUS	0	-	○	○	○	
09-02	Baud Rate Setting (bps)	0:1200 1:2400 2:4800 3:9600 4:19200	3	-	○	○	○	*2

Group 09: Communication Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		5:38400						
09-03	Stop Bit Selection	0: 1 Stop Bit 1: 2 Stop Bit	0	-	0	0	0	*2
09-04	Parity Selection	0: No Parity 1: Even Bit 2: Odd Bit	0	-	0	0	0	*2
09-05	Reserved							
09-06	Communication Error Detection Time	0.0~25.5	0.0	S	0	0	0	
09-07	Fault Stop Selection	0: Deceleration to Stop Based on Deceleration Time 1 when Communication Fault Occurs. 1: Coast to Stop when Communication Fault Occurs. 2: Deceleration to Stop Based on Deceleration Time 2 when Communication Fault Occurs. 3: Keep Operating when Communication Fault Occurs.	3	-	0	0	0	
09-08	Comm. Fault Tolerance Count	1~20	1	-	0	0	0	
09-09	Waiting Time	5~65	5	ms	0	0	0	
09-10	Device Instance Number	1 ~ 254	1	-	0	0	0	

Group 10: PID Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
10-00	PID Target Value Source Setting	0: Keypad (for PUMP or HVAC mode) 1: AI1 Given 2: AI2 Given 3: Reserved 4: 10-02 Given 5: Reserved	1	-	0	0	0	
10-01	PID Feedback Value Source Setting	1: AI1 Given 2: AI2 Given 3: Reserved	2	-	0	0	0	
10-02	PID Target Value	0.0~100.0	0.0	%	0	0	0	
10-03	PID Control Mode	xxx0b: PID Disable xxx1b: PID Enable xx0xb: PID Positive Characteristic xx1xb: PID Negative Characteristic x0xxb: PID Error Value of D Control x1xxb: PID Feedback Value of D Control 0xxb: PID Output	0000b	-	0	0	0	

Group 10: PID Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		1xxx: PID Output + Target Value						
10-04	Feedback Gain	0.01~10.00	1.00	-	O	O	O	*1
10-05	Proportional Gain (P)	0.00~10.00	3.00	-	O	O	O	*1
10-06	Integral Time (I)	0.00~100.00	0.50	s	O	O	O	*1
10-07	Differential Time (D)	0.00~10.00	0.00	s	O	O	O	*1
10-08	Reserved							
10-09	PID Bias	-100.0~100.0	0	%	O	O	O	*1
10-10	PID Primary Delay Time	0.00~10.00	0.00	s	O	O	O	*1
10-11	PID Feedback Loss Detection Selection	0: Disable	0	-	O	O	O	
		1: Warning						
		2: Fault						
10-12	PID Feedback Loss Detection Level	0~100	0	%	O	O	O	
10-13	PID Feedback Loss Detection Time	0.0~10.0	1.0	s	O	O	O	
10-14	PID Integral Limit	0.0~100.0	100.0	%	O	O	O	*1
10-15 ~ 10-16	Reserved							
10-17	Start Frequency of PID Sleep	0.00~180.00	30.00	Hz	O	O	O	
10-18	Delay Time of PID Sleep	0.0~255.5	0.0	s	O	O	O	
10-19	Frequency of PID Waking up	0.00~180.00	0.00	Hz	O	O	O	
10-20	Delay Time of PID Waking up	0.0~255.5	0.0	s	O	O	O	
10-21 ~ 10-22	Reserved							
10-23	PID Limit	0.00~100.0	100.0	%	O	O	O	*1
10-24	PID Output Gain	0.0~25.0	1.0	-	O	O	O	
10-25	PID Reversal Output Selection	0: Do not Allow Reversal Output	0	-	O	O	O	
		1: Allow Reversal Output						
10-26	PID Target Acceleration/Deceleration Time	0.0~25.5	0.0	s	O	O	O	
10-27	PID Feedback Display Bias	-99.99~99.99	0.00	-	O	O	O	
10-28	PID Feedback Display Gain	0.00~100.00	100.00	-	O	O	O	
10-29	PID Sleep Selection	0: Disable	1	-	O	O	O	
		1: Enable						
		2: Set by DI						
10-30	Upper Limit of PID Target	0.0 ~ 100.0	100.0	%	O	O	O	
10-31	Lower Limit of PID Target	0.0 ~ 100.0	0.0	%	O	O	O	
10-32	PID Switching Function	0: PID1	0		O	O	O	
		1: PID2						
		2: Set by DI						
		3: Switch to PID2 when RTC Timer Enables						
10-33	PID Maximum Feedback Value	1~10000	999	-	O	O	O	
10-34	PID Decimal Width	0~4	1	-	O	O	O	
10-35	PID Unit	0: %	0	-	O	O	O	*6

Group 10: PID Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		1: FPM						
		2: CFM						
		3: PSI						
		4: GPH						
		5: GPM						
		6: IN						
		7: FT						
		8: /s						
		9: /m						
		10: /h						
		11: °F						
		12: inW						
		13: HP						
		14: m/s						
		15: MPM						
		16: CMM						
		17: W						
		18: KW						
		19: m						
		20: °C						
		21: RPM						
		22: Bar						
		23: Pa						
10-36	PID2 Proportional Gain (P)	0.00~10.00	3.00	-	O	O	O	*1
10-37	PID2 Integral Time (I)	0.0~100.0	0.50	s	O	O	O	*1
10-38	PID2 Differential Time (D)	0.00~10.00	0.00	s	O	O	O	*1
10-39	PID Output Frequency Setting during disconnection	00.00~400.00	30.00	Hz	O	O	O	*6

Group 11: Auxiliary Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
11-00	Direction Lock Selection	0: Allow Forward and Reverse Rotation	1	-	O	O	O	
		1: Only Allow Forward Rotation						
		2: Only Allow Reverse Rotation						
11-01	Carrier Frequency	0: Carrier Output Frequency Tuning	Inverter KVA ^{*a}	-	O	O	X	
		1: 1.5KHz						
		2~16: 2~16KHz						
11-02	Soft PWM Function Selection	0: Disable	1 ^{*b}	-	O	O	O	
		1: Enable						
11-03	Automatic carrier lowering selection	0: Disable	0	-	O	X	X	
		1: Enable						

Group 11: Auxiliary Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
11-04	S-curve Time Setting at the Start of Acceleration	0.00~2.50	0.20	s	O	O	O	
11-05	S-curve Time Setting at the End of Acceleration	0.00~2.50	0.20	s	O	O	O	
11-06	S-curve Time Setting at the Start of Deceleration	0.00~2.50	0.20	s	O	O	O	
11-07	S-curve Time Setting at the End of Deceleration	0.00~2.50	0.20	s	O	O	O	
11-08	Jump Frequency 1	0.0~400.0	0.0	Hz	O	O	O	
11-09	Jump Frequency 2	0.0~400.0	0.0	Hz	O	O	O	
11-10	Jump Frequency 3	0.0~400.0	0.0	Hz	O	O	O	
11-11	Jump Frequency Width	0.0~25.5	1.0	Hz	O	O	O	
11-12	Manual Energy Saving Gain	0~100	80	%	O	X	X	
11-13	Automatic Return Time	0~120	60	Sec	O	O	O	*6
11-14 ~ 11-17	Reserved							
11-18	Manual Energy Saving Frequency	0.00~400.00	0.00	Hz	O	X	X	
11-19	Automatic Energy Saving Function	0: Automatic Energy Saving is Disabled	0	-	O	X	X	
		1: Automatic Energy Saving is Enabled						
11-20	Filter Time of Automatic Energy Saving	0~200	140	ms	O	X	X	
11-21	Voltage Upper Limit of Energy Saving Tuning	0~100	100	%	O	X	X	
11-22	Adjustment Time of Automatic Energy Saving	0~5000	20	ms	O	X	X	*1
11-23	Detection Level of Automatic Energy Saving	0~100	10	%	O	X	X	
11-24	Coefficient of Automatic Energy Saving	0.00~655.35	KVA ^a	-	O	X	X	
11-25 ~ 11-28	Reserved							
11-29	Auto De-rating Selection	0: Disable	0	-	O	X	X	
		1: Enable						
11-30	Variable Carrier Frequency Max. Limit	2~16	KVA ^a	KHz	O	X	X	
11-31	Variable Carrier Frequency Min. Limit	2~16	KVA ^a	KHz	O	X	X	
11-32	Variable Carrier Frequency Proportional Gain	00~99	00	-	O	X	X	
11-33 ~ 11-40	Reserved							
11-41	Reference Frequency Loss Detection	0: Deceleration to Stop when Reference Frequency Disappears	0	-	O	O	O	

Group 11: Auxiliary Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		1: Operation is Set by 11-42 when Reference Frequency Disappears						
11-42	Reference Frequency Loss Level	0.0~100.0	80.0	%	O	O	O	
11-43	Hold Frequency at Start	0.0~400.0	0.0	Hz	O	O	O	
11-44	Frequency Hold Time at Start	0.0~10.0	0.0	s	O	O	O	
11-45	Hold Frequency at Stop	0.0~400.0	0.0	Hz	O	O	O	
11-46	Frequency Hold Time at Stop	0.0~10.0	0.0	s	O	O	O	
11-47	EB Deceleration Time	0.0~25.5	0.0	s	O	X	X	*1
11-48	KEB Detection Level	200V: 190~210	200	V	O	X	X	
		400V: 380~420	400					
11-49 ~ 11-50	Reserved							
11-51	Braking Selection of Zero Speed	0: Disable	0	-	O	X	X	
		1: Enable						
11-52 ~ 11-53	Reserved							
11-54	Initialization of Cumulative Energy	0: Do not Clear Cumulative Energy	0	-	O	O	O	*1
		1: Clear Cumulative Energy						
11-55	STOP Key Selection	0: Stop Key is Disabled when the Operation Command is not Provided by Keypad.	1	-	O	O	O	
		1: Stop Key is Enabled when the Operation Command is not Provided by Keypad.						
11-56	UP/DOWN Selection	0: When UP/DOWN in Keypad is Disabled, it will be Enabled if Press ENTER after Frequency Modification.	0	-	O	O	O	
		1: When UP/DOWN in Keypad is Enabled, it will be Enabled after Frequency Modification.						
11-57	Reserved							
11-58	Record Reference Frequency	0: Disable	0	-	O	O	O	*1
		1: Enable						
11-59	Prevention of Oscillation Gain	0.01~2.50	0.01		O	X	X	*7
11-60	Prevention of Oscillation Upper Limit	0~100	30	%	O	X	X	*7
11-61	Prevention of Oscillation Time Parameters	0~100	0		O	X	X	*7
11-62	Prevention of Oscillation Selection	0: Mode 1 1: Mode 2	1		O	X	X	*7

*a: KVA means the default value of this parameter will be changed by different capacities of inverter.

*b: Default value is 1 only for V/F mode.

Group 12: Monitoring Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
12-00	Display Screen Selection	00000~77777 From the leftmost bit, it displays the screen when press DSP key in order. 0: No display 1: Output Current 2: Output Voltage 3: DC Bus Voltage 4: Heatsink Temperature 5: PID Feedback 6: A11 Value 7: A12 Value	00000	-	0	0	0	*5
12-01	PID Feedback Display Mode	0: Display the Feedback Value by Integer (xxx) 1: Display the Feedback Value by the Value with First Decimal Place (xx.x) 2: Display the Feedback Value by the Value with Second Decimal Place (x.xx)	0		0	0	0	*5
12-02	PID Feedback Display Unit Setting	0: xxxxx (no unit) 1: xxxPb (pressure) 2: xxxFL (flow)	0		0	0	0	*5
12-03	Line Speed Display (LED)	0~65535	0	RPM	0	0	0	*5
12-04	Line Speed Display Mode (LED)	0: Display Inverter Output Frequency 1: Line Speed Display at Integer.(xxxxx) 2: Line Speed Display at One Decimal Place.(xxxx.x) 3: Line Speed Display at Two Decimal Places.(xxx.xx) 4: Line Speed Display at Three Decimal Places.(xx.xxx)	0		0	0	0	*5
12-05	Status display of digital input terminal (LED / LCD)	LED display is shown as below no input  correspondences to input and output	-	-	0	0	0	

Group 12: Monitoring Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		 <p>LCD display is shown as below</p> <p>0 : OPEN 1 : CLOSE</p> <p>Input Terminal(S6) Input Terminal(S5) Input Terminal(S4) Input Terminal(S3) Input Terminal(S2) Input Terminal(S1) Output Terminal(R3) Output Terminal(R2) Output Terminal(R1)</p>						
12-06 ~ 12-10	Reserved							
12-11	Output Current of Current Fault	Display the output current of current fault	-	A	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-12	Output Voltage of Current Fault	Display the output voltage of current fault	-	V	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-13	Output Frequency of Current Fault	Display the output frequency of current fault	-	Hz	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-14	DC Voltage of Current Fault	Display the DC voltage of current fault	-	V	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-15	Frequency Command of Current Fault	Display the frequency command of current fault	-	Hz	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-16	Frequency Command	If LED enters this parameter, it only allows monitoring frequency command.	-	Hz	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-17	Output Frequency	Display the current output frequency	-	Hz	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-18	Output Current	Display the current output current	-	A	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-19	Output Voltage	Display the current output voltage	-	V	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-20	DC Voltage	Display the current DC voltage	-	V	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-21	Output Power	Display the current output power	-	kW	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-22	Motor's Rotation Speed	Display motor's current rotation speed in VF/SLV mode Motor's rotation speed = output power x(120/motor's pole number) In PG/SV mode, motor's rotation speed is calculated by feedback frequency. Max limit is 65535	-	rpm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
12-23	Output Power Factor	Display the current output power	-	-	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

Group 12: Monitoring Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		factor						
12-24	Control Mode	Display control mode 0 : VF 2 : SLV 5 : PM SLV	-	-	O	O	O	
12-25	AI1 Input	Display the current AI1 input (0V corresponds to 0%, 10V corresponds to 100%,)	-	%	O	O	O	
12-26	AI2 Input	Display the current AI2 input (0V or 4mA corresponds to 0%, 10V or 20mA corresponds to 100%)	-	%	O	O	O	
12-27	Torque Command	Display the current torque command (100% corresponds to motor torque)	-	%	X	O	O	
12-28	Motor Torque Current (Iq)	Display the current q-axis current	-	%	X	O	O	
12-29	Motor Excitation Current (Id)	Display the current d-axis current	-	%	X	O	O	
12-30 ~ 12-35	Reserved							
12-36	PID Input	Display input error of the PID controller (PID target value - PID feedback) (100% corresponds to the maximum frequency set by 01-02 or 01-16)	0.01	%	O	O	O	
12-37	PID Output	Display output of the PID controller (100% corresponds to the maximum frequency set by 01-02 or 01-16)	-	%	O	O	O	
12-38	PID Setting	Display the target value of the PID controller (100% corresponds to the maximum frequency set by 01-02 or 01-16)	-	%	O	O	O	
12-39	PID Feedback	Display the feedback value of the PID controller (100% corresponds to the maximum frequency set by 01-02 or 01-16)	-	%	O	O	O	
12-40	Reserved							
12-41	Heatsink Temperature	Display the heatsink temperature of IGBT temperature.	-	°C	O	O	O	
12-42	RS-485 Error Code		-	-	O	O	O	*7

Group 12: Monitoring Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
12-43	Inverter Status		101B	-	0	0	0	
12-44	Reserved							
12-45	Recent Fault Message	Display current fault message	-	-	0	0	0	
12-46	Previous Fault Message	Display previous fault message	-	-	0	0	0	
12-47	Previous Two Fault Messages	Display previous two fault messages	-	-	0	0	0	
12-48	Previous Three Fault Messages	Display previous three fault messages	-	-	0	0	0	
12-49	Previous Four Fault Messages	Display previous four fault messages	-	-	0	0	0	
12-50	DIO Status of Current Fault	Display the DI/DO status of current fault Description is similar to 12-05	-	-	0	0	0	
12-51	Inverter Status of Current Fault	Display the inverter status of current fault Description is similar to 12-43	-	-	0	0	0	
12-52	Trip Time 1 of Current Fault	Display the operation time of current fault, 12-53 is the days, while 12-52 is the ahemeral hours.	-	Hr	0	0	0	
12-53	Trip Time 2 of Current Fault	Display the operation time of current fault, 12-53 is the days, while 12-52 is the ahemeral hours.	-	day	0	0	0	
12-54	Frequency Command of Previous Fault	Display frequency command of previous fault	-	Hz	0	0	0	
12-55	Output Frequency of Previous Fault	Display output frequency of previous fault	-	Hz	0	0	0	
12-56	Output Current of Previous Fault	Display output current of previous fault	-	A	0	0	0	
12-57	Output Voltage of Previous Fault	Display output voltage of previous fault	-	V	0	0	0	
12-58	DC Voltage of Previous Fault	Display DC voltage of previous fault	-	V	0	0	0	
12-59	DIO Status of Previous Fault	Display DI/DO status of previous fault Description is similar to 12-05	-	-	0	0	0	
12-60	Inverter Status of Previous Fault	Display inverter status of previous fault Description is similar to 12-43	-	-	0	0	0	
12-61	Trip time 1 of last fault	Display the operation time of last time's fault, 12-62 is the days, while 12-61 is the ahemeral hours .	-	Hr	0	0	0	
12-62	Trip time 2 of last fault		-	day	0	0	0	
12-63	Recent warning messages	Display the recent warning messages	-	-	0	0	0	
12-64	Previous warning message	Display the previous warning message	-	-	0	0	0	

Group 12: Monitoring Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
12-65 ~ 12-66	Reserved							
12-67	Accumulative Energy (kWHr)	0.0 ~ 999.9		kWHr	O	O	O	
12-68	Accumulative Energy (MWHr)	0 ~ 60000		MWHr	O	O	O	
12-69	Accumulative Electricity Price (\$)	0 ~ 9999		\$	O	O	O	
12-70	Accumulative Electricity Price (10000\$)	0 ~ 60000		\$	O	O	O	
12-71	Flow Meter Feedback	1 ~ 50000		GP M	O	O	O	
12-72	RTC Date	12.01.01 ~ 99.12.31	12.01.01		O	O	O	
12-73	RTC Time	00:00 ~ 23:59	00:00		O	O	O	
12-74	Operating Pressure Setting	0.01 ~ 25.50	2.00	PSI	O	X	X	
12-75	Pressure Feedback Value	0.01 ~ 25.50	-	PSI	O	X	X	
12-76	Non-Load Voltage	0.0 ~ 600.0	-	V	X	O	X	
12-77	Flow Meter Target Setting	1 ~ 50000	-	GP M	O	O	O	*7
12-78	Reserved							
12-79	Pulse Input Percetage	0.0~100.0	-	%	O	O	O	*7

* Models of inverter ratings above 200V 50HP (including 50HP) and 400V 75HP (including 75HP) in IP20 enclosure do not support functions of heatsink temperature display. All models in IP55 enclosure support functions of heatsink temperature display.

* Maximum upper limit in motor speed (rpm) of parameter 12-22 is 65535.

Group 13 Maintenance Function Group								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
13-00	Inverter Rating Selection	00H~FFH	-	-	O	O	O	*4
13-01	Software Version	0.0-9.9	-	-	O	O	O	*4
13-02	Reserved							
13-03	Cumulative Operation Hours 1	0~23	-	hr	O	O	O	*4
13-04	Cumulative Operation Hours 2	0~65535	-	day	O	O	O	*4
13-05	Selection of Accumulative Operation Time	0: Accumulative time in power on						
		1: Accumulative time in operation						
13-06	Parameters Locked	0: Parameters out of 13-06 are read-only.						
		1: Only user parameter is enabled.						
		2: All parameters are writable.						
13-07	Parameter Password Function	0~9999	0	-	O	O	O	
13-08	Restore Factory Setting	0: No Initialization	0	-	O	O	O	
		2: 2 wire Initialization (200/400V, 60Hz)						

Group 13 Maintenance Function Group								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		3: 3 wire Initialization (200/400V, 60Hz)						
		4: 2 wire Initialization (200/400V, 50Hz)						
		5: 3 wire Initialization (200/400V, 50Hz)						
		6: 2 wire Initialization (200/400V, 50Hz)						
		7: 3 wire Initialization (200/400V, 50Hz)						
		8: PLC Initialization						
		9: 2 Wire Initialization (230V/460V, 60Hz)						
		10: 3 Wire Initialization (230V/460V, 60Hz)						
		Others: Reserved						
13-09	Fault History Clearance Function	0: Do not Clear Fault History 1: Clear Fault History	0	-	○	○	○	*1
13-10	Password Function 2	0 ~ 9999	0		○	○	○	
13-11	C/B CPLD Ver.	0.00~9.99	0.00		○	○	○	*7
13-12	Option Card Id	0~255	0		○	○	○	*7
13-13	Option Card CPLD Ver.	0.00~9.99	0.00		○	○	○	*7

Group 14: PLC Setting Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
14-00	T1 Set Value 1	0~9999	0	-	○	○	○	
14-01	T1 Set Value 2 (Mode 7)	0~9999	0	-	○	○	○	
14-02	T2 Set Value 1	0~9999	0	-	○	○	○	
14-03	T2 Set Value 2 (Mode 7)	0~9999	0	-	○	○	○	
14-04	T3 Set Value 1	0~9999	0	-	○	○	○	
14-05	T3 Set Value 2 (Mode 7)	0~9999	0	-	○	○	○	
14-06	T4 Set Value 1	0~9999	0	-	○	○	○	
14-07	T4 Set Value 2 (Mode 7)	0~9999	0	-	○	○	○	
14-08	T5 Set Value 1	0~9999	0	-	○	○	○	
14-09	T5 Set Value 2 (Mode 7)	0~9999	0	-	○	○	○	
14-10	T6 Set Value 1	0~9999	0	-	○	○	○	
14-11	T6 Set Value 2 (Mode 7)	0~9999	0	-	○	○	○	
14-12	T7 Set Value 1	0~9999	0	-	○	○	○	
14-13	T7 Set Value 2 (Mode 7)	0~9999	0	-	○	○	○	
14-14	T8 Set Value 1	0~9999	0	-	○	○	○	
14-15	T8 Set Value 2 (Mode 7)	0~9999	0	-	○	○	○	
14-16	C1 Set Value	0~65535	0	-	○	○	○	
14-17	C2 Set Value	0~65535	0	-	○	○	○	

Group 14: PLC Setting Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
14-18	C3 Set Value	0~65535	0	-	0	0	0	
14-19	C4 Set Value	0~65535	0	-	0	0	0	
14-20	C5 Set Value	0~65535	0	-	0	0	0	
14-21	C6 Set Value	0~65535	0	-	0	0	0	
14-22	C7 Set Value	0~65535	0	-	0	0	0	
14-23	C8 Set Value	0~65535	0	-	0	0	0	
14-24	AS1 Set Value 1	0~65535	0	-	0	0	0	
14-25	AS1 Set Value 2	0~65535	0	-	0	0	0	
14-26	AS1 Set Value 3	0~65535	0	-	0	0	0	
14-27	AS2 Set Value 1	0~65535	0	-	0	0	0	
14-28	AS2 Set Value 2	0~65535	0	-	0	0	0	
14-29	AS2 Set Value 3	0~65535	0	-	0	0	0	
14-30	AS3 Set Value 1	0~65535	0	-	0	0	0	
14-31	AS3 Set Value 2	0~65535	0	-	0	0	0	
14-32	AS3 Set Value 3	0~65535	0	-	0	0	0	
14-33	AS4 Set Value 1	0~65535	0	-	0	0	0	
14-34	AS4 Set Value 2	0~65535	0	-	0	0	0	
14-35	AS4 Set Value 3	0~65535	0	-	0	0	0	
14-36	MD1 Set Value 1	0~65535	1	-	0	0	0	
14-37	MD1 Set Value 2	0~65535	1	-	0	0	0	
14-38	MD1 Set Value 3	0~65535	1	-	0	0	0	
14-39	MD2 Set Value 1	0~65535	1	-	0	0	0	
14-40	MD2 Set Value 2	0~65535	1	-	0	0	0	
14-41	MD2 Set Value 3	0~65535	1	-	0	0	0	
14-42	MD3 Set Value 1	0~65535	1	-	0	0	0	
14-43	MD3 Set Value 2	0~65535	1	-	0	0	0	
14-44	MD3 Set Value 3	0~65535	1	-	0	0	0	
14-45	MD4 Set Value 1	0~65535	1	-	0	0	0	
14-46	MD4 Set Value 2	0~65535	1	-	0	0	0	
14-47	MD4 Set Value 3	0~65535	1	-	0	0	0	

Group 15: PLC Monitoring Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
15-00	T1 Current Value 1	0~9999	0	-	0	0	0	
15-01	T1 Current Value 2 (Mode 7)	0~9999	0	-	0	0	0	
15-02	T2 Current Value 1	0~9999	0	-	0	0	0	
15-03	T2 Current Value 2 (Mode 7)	0~9999	0	-	0	0	0	
15-04	T3 Current Value 1	0~9999	0	-	0	0	0	
15-05	T3 Current Value 2 (Mode 7)	0~9999	0	-	0	0	0	
15-06	T4 Current Value 1	0~9999	0	-	0	0	0	
15-07	T4 Current Value 2 (Mode 7)	0~9999	0	-	0	0	0	
15-08	T5 Current Value 1	0~9999	0	-	0	0	0	
15-09	T5 Current Value 2 (Mode 7)	0~9999	0	-	0	0	0	
15-10	T6 Current Value 1	0~9999	0	-	0	0	0	
15-11	T6 Current Value 2 (Mode 7)	0~9999	0	-	0	0	0	
15-12	T7 Current Value 1	0~9999	0	-	0	0	0	
15-13	T7 Current Value 2 (Mode 7)	0~9999	0	-	0	0	0	
15-14	T8 Current Value 1	0~9999	0	-	0	0	0	
15-15	T8 Current Value 2 (Mode 7)	0~9999	0	-	0	0	0	
15-16	C1 Current Value	0~65535	0	-	0	0	0	
15-17	C2 Current Value	0~65535	0	-	0	0	0	
15-18	C3 Current Value	0~65535	0	-	0	0	0	
15-19	C4 Current Value	0~65535	0	-	0	0	0	
15-20	C5 Current Value	0~65535	0	-	0	0	0	
15-21	C6 Current Value	0~65535	0	-	0	0	0	
15-22	C7 Current Value	0~65535	0	-	0	0	0	
15-23	C8 Current Value	0~65535	0	-	0	0	0	
15-24	AS1 Results	0~65535	0	-	0	0	0	
15-25	AS2 Results	0~65535	0	-	0	0	0	
15-26	AS3 Results	0~65535	0	-	0	0	0	
15-27	AS4 Results	0~65535	0	-	0	0	0	
15-28	MD1 Results	0~65535	0	-	0	0	0	
15-29	MD2 Results	0~65535	0	-	0	0	0	
15-30	MD3 Results	0~65535	0	-	0	0	0	
15-31	MD4 Results	0~65535	0	-	0	0	0	
15-32	TD Current Value	0~65535	0	-	0	0	0	

Group 16: LCD Function Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
16-00	Main Screen Monitoring	5~79 When using LCD to operate, the monitored item displays in the first line. (default is frequency command)	16	-	O	O	O	*1 *6
16-01	Sub-Screen Monitoring 1	5~79 (Parameter 12-05~12-79) When using LCD to operate, the monitored item displays in the second line. (default is output frequency)	17	-	O	O	O	*1 *6
16-02	Sub-Screen Monitoring 2	5~76(Parameter 12-05~12-79) when using LCD to operate, the monitored item displays in the third line. (default is output current)	18	-	O	O	O	*1 *6
16-03	Selection of Display Unit	0~39999: Determine the display way and unit of frequency command 0: Frequency display unit is 0.01Hz 1: Frequency display unit 0.01% 2: Rpm display; motor rotation speed is set by the control modes to select IM (02-07)/ PM (22-03) motor poles to calculate. 40~9999: Users specify the format, Input 0XXXX represents the display of XXXX at 100%. 10001~19999: Users specify the format; Input 1XXXX represents the display of XXX.X at 100%. 20001~29999: Users specify the format, Input 2XXXX represents the display of XX.XX at 100%. 30001~39999: Users specify the format, Input 3XXXX represents the display of X.XXX at 100%.	0	-	O	O	O	
16-04	Selection of Engineering Unit	0: No Unit 1: FPM 2: CFM 3: PSI 4: GPH 5: GPM 6: IN 7: FT 8: /s 9: /m 10: /h	0	-	O	O	O	*6

Group 16: LCD Function Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		11: °F						
		12: inW						
		13: HP						
		14: m/s						
		15: MPM						
		16: CMM						
		17: W						
		18: KW						
		19: m						
		20: °C						
		21: RPM						
		22: Bar						
		23: Pa						
16-05	LCD Backlight	0~7	5	-	0	0	0	*1
16-06	Reserved							
16-07	Copy Function Selection	0: Do not copy parameters	0	-	0	0	0	
		1: Read inverter parameters and save to the operator.						
		2: Write the operator parameters to inverter.						
		3: Compare parameters of inverter and operator.						
16-08	Selection of Allowing Reading	0: Do not allow to read inverter parameters and save to the operator.	0	-	0	0	0	
		1: Allow to read inverter parameters and save to the operator.						
16-09	Selection of Operator Removed (LCD)	0: Keep operating when LCD operator is removed.	0	-	0	0	0	*1
		1: Display fault to stop when LCD operator is removed						
16-10	RTC Time Display Setting	0: Hide	0		0	0	0	
		1: Display						
16-11	RTC Date Setting	12.01.01 ~ 99.12.31	12.01.01		0	0	0	
16-12	RTC Time Setting	00:00 ~ 23:59	00:00		0	0	0	
16-13	RTC Timer Function	0: Disable	0		0	0	0	
		1: Enable						
		2: Set by DI						
16-14	P1 Start Time	00:00 ~ 23:59	08:00		0	0	0	
16-15	P1 Stop Time	00:00 ~ 23:59	18:00		0	0	0	
16-16	P1 Start Date	1:Mon, 2:Tue, 3:Wed,	1		0	0	0	
16-17	P1 Stop Date	4:Thu,;5:Fri,;6:Sat, 7:Sun	5		0	0	0	
16-18	P2 Start Time	00:00 ~ 23:59	08:00		0	0	0	
16-19	P2 Stop Time	00:00 ~ 23:59	18:00		0	0	0	

Group 16: LCD Function Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
16-20	P2 Start Date	1:Mon,2:Tue,3:Wed,	1		O	O	O	
16-21	P2 Stop Date	4:Thu,5:Fri,6:Sat, 7:Sun	5		O	O	O	
16-22	P3 Start Time	00:00 ~ 23:59	08:00		O	O	O	
16-23	P3 Stop Time	00:00 ~ 23:59	18:00		O	O	O	
16-24	P3 Start Date	1:Mon,2:Tue,3:Wed,	1		O	O	O	
16-25	P3 Stop Date	4:Thu,5:Fri,6:Sat, 7:Sun	5		O	O	O	
16-26	P4 Start Time	00:00 ~ 23:59	08:00		O	O	O	
16-27	P4 Stop Time	00:00 ~ 23:59	18:00		O	O	O	
16-28	P4 Start Date	1:Mon, 2:Tue, 3:Wed,	1		O	O	O	
16-29	P4 Stop Date	4:Thu, 5:Fri, 6:Sat, 7:Sun	5		O	O	O	
16-30	Selection of RTC Offset	0: Disable	0		O	O	O	
		1: Enable						
		2: Set by DI						
16-31	RTC Offset Time Setting	00:00 ~ 23:59	00:00	-	O	O	O	
16-32	Source of Timer 1	0: None,1:P1,	1		O	O	O	
16-33	Source of Timer 2	2:P2,3:P1+P2	2		O	O	O	
16-34	Source of Timer 3	4:P3,5:P1+P3, 6:P2+P3,7:P1+P2+P3, 8:P4,9:P1+P4, 10:P2+P4, 11:P1+P2+P4 12:P3+P4 13:P1+P3+P4, 14:P2+P3+P4 15:P1+P2+P3+P4, 16:Off,17:Off+P1 18:Off+P2, 19:Off+P1+P2 20:Off+P3, 21:Off+P1+P3 22:Off+P2+P3 23:Off+P1+P2+P3 24:Off+P4 25:Off+P1+P4 26:Off+P2+P4 27:Off+P1+P2+P4 28:Off+P3+P4 29:Off+P3+P4 30:Off+P2+P3+P4 31:Off+P1+P2+P3+P4	4		O	O	O	
16-35	Source of Timer 4	0: Off	8		O	O	O	
16-36	Selection of RTC Speed	0: Off	0		O	O	O	
		1: By Timer 1						
		2: By Timer 2						
		3: By Timer 3						
		4: By Timer 4						

Group 16: LCD Function Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		5: By Timer 1+2						
16-37	Selection of RTC Rotation Direction	xxx0b: RTC Run1 Forward Rotation			O	O	O	
		xxx1b: RTC Run1 Reverse Rotation						
		xx0xb: RTC Run2 Forward Rotation						
		xx1xb: RTC Run2 Reverse Rotation						
		x0xxb: RTC Run3 Forward Rotation						
		x1xxb: RTC Run3 Reverse Rotation						
		0xxxb: RTC Run4 Forward Rotation						
		1xxxb: RTC Run4 Reverse Rotation						

Group 17: IM Motor Automatic Tuning Parameters								
Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
17-00	Mode Selection of Automatic Tuning	0: Rotation Auto-tune	2 ^{°c}	-	O	O	X	
		1: Static Auto-tune						
		2: Stator Resistance Measurement						
		3: Reserved						
		4: Loop Tuning						
17-01	Motor Rated Output Power	0.00~600.00	-	KW	O	O	X	
17-02	Motor Rated Current	0.1~1200.0	-	A	O	O	X	
17-03	Motor Rated Voltage	200V: 0.0~255.0	220	V	O	O	X	
		400V:0.0~510.0	440					
17-04	Motor Rated Frequency	10.0~400.0	60.0	Hz	O	O	X	
17-05	Motor Rated Speed	0~24000	KVA ^{*a}	rpm	O	O	X	
17-06	Pole Number of Motor	2~16 (Even)	4	Pole	O	O	X	*6
17-07	Reserved							
17-08	Motor No-load Voltage	200V: 50~240	KVA ^{*a}	V	O	O	X	
		400V:100~480						
17-09	Motor Excitation Current	0.01~600.00 (15%~70% motor rated current)	KVA ^{*a}	A	O	O	X	
17-10	Automatic Tuning Start	0: Disable	0	-	O	O	X	
		1: Enable						
17-11	Error History of Automatic Tuning	0: No Error	0	-	O	O	X	
		1: Motor Data Error						
		2: Stator Resistance Tuning Error						
		3: Leakage Induction Tuning Error						
		4: Rotor Resistance Tuning Error						

Group 17: IM Motor Automatic Tuning Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
		5. Mutual Induction Tuning Error						
		6. Reserved						
		7. DT Error						
		8. Motor Acceleration Error						
		9. Warning						
17-12	Leakage Inductance Ratio	0.1 ~ 15.0	3.4	%	X	O	X	
17-13	Slip Frequency	0.10 ~ 20.00	1.00	Hz	X	O	X	

*c: Default value is 2 in V/F mode while it is 0 in SLV mode.

*a: KVA means the default value of this parameter will be changed by different capacities of inverter.

Group 18: Slip Compensation Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
18-00	Slip Compensation Gain at Low Speed	0.00~2.50	0.00 ^{*d}	-	O	O	X	*1
18-01	Slip Compensation Gain at High Speed	-1.00~1.00	0.0	-	O	O	X	*1
18-02	Slip Compensation Limit	0~250	200	%	O	X	X	
18-03	Slip Compensation Filter Time	0.0~10.0	1.0	Sec	O	X	X	
18-04	Regenerative Slip Compensation Selection	0: Disable	0	-	O	X	X	
		1: Enable						
18-05	FOC Delay Time	1~1000	100	ms	X	O	X	
18-06	FOC Gain	0.00~2.00	0.1	-	X	O	X	

*d: Default value is 0.00 in V/F mode while it is 1.0 in SLV mode.

Group 19 Reserved

Group 20 Speed Control Parameters*

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
20-00	ASR Gain 1	0.00~250.00	3.00	-	X	O	O	*1
20-01	ASR Integral Time 1	0.001~10.000	SLV: 0.500 PMSLV :0.08,	Sec	X	O	O	*1
20-02	ASR Gain 2	0.00~250.00	3.00	-	X	O	O	*1
20-03	ASR Integral Time 2	0.001~10.000	SLV: 0.500 PMSLV :0.08,	Sec	X	O	O	*1
20-04	ASR Integral Time Limit	0~300	200	%	X	O	O	
20-05	Reserved							

Group 20 Speed Control Parameters*

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
~ 20-06	Reserved							
20-07	Selection of Acceleration and Deceleration of P/PI	0: PI speed control will be enabled only in constant speed. For accel/ decal, only use P control. 1: Speed control is enabled either in constant speed or accel/decal.	1	-	X	O	X	
20-08	ASR Delay Time	0.000~0.500	0.004	Sec	X	O	X	
20-09	Speed Observer Proportional (P) Gain 1	0.00~2.55	0.61	-	X	O	X	*1
20-10	Speed Observer Integral(I) Time 1	0.01~10.00	0.05	Sec	X	O	X	*1
20-11	Speed Observer Proportional (P) Gain 2	0.00~2.55	0.61	-	X	O	X	*1
20-12	Speed Observer Integral(I) Time 2	0.01~10.00	0.06	Sec	X	O	X	*1
20-13	Low-pass Filter Time Constant of Speed Feedback 1	1~1000	4	ms	X	O	X	
20-14	Low-pass Filter Time Constant of Speed Feedback 2	1~1000	30	ms	X	O	X	
20-15	ASR Gain Change Frequency 1	0.0~400.0	4.0	Hz	X	O	X	
20-16	ASR Gain Change Frequency 2	0.0~400.0	8.0	Hz	X	O	X	
20-17	Torque Compensation Gain at Low Speed	0.00~2.50	1.00	-	X	O	X	*1
20-18	Torque Compensation Gain at High Speed	-10~10	0	%	X	O	X	*1
20-19 ~ 20-32	Reserved							
20-33	Constant Speed Detection Level	0.1~5.0	1.0		X	O	O	*7
20-34	Derating of Compensation Gain	0~25600	0		X	O	X	*7
20-35	Derating of Compensation Time	0~30000	100	ms	X	O	X	*7

*: This parameter group is enabled in SLV and PMSLV modes.

Group 21 Torque Control Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
21-00 ~ 21-04	Reserved							
21-05	Positive Torque Limit	0~160	160	%	X	O	O	
21-06	Negative Torque Limit	0~160	160	%	X	O	O	
21-07	Forward Regenerative Torque Limit	0~160	160	%	X	O	O	
21-08	Reversal Regenerative Torque	0~160	160	%	X	O	O	

Group 21 Torque Control Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
	Limit							

Group 22: PM Motor Parameters- only available when PM Control Mode is selected

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
22-00	Rated Power of PM Motor	0.00~600.00	KVA	kW	X	X	O	
22-01	Rated Voltage of PM Motor	200V: 50.0~240.0	220.0	V	X	X	O	
		400V: 100.0~480.0	440.0					
22-02	Rated Current of PM Motor	0.1~999.9	KVA	A	X	X	O	
22-03	Pole Number of PM Motor	2~96	6	pole s	X	X	O	
22-04	Rated Rotation Speed of PM Motor	1~60000 (22-04, 22-06, only need to set one of them, the program will calculate the other.)	1500	rpm	X	X	O	
22-05	Maximum Rotation Speed of PM Motor	1~60000	1500	rpm	X	X	O	
22-06	PM Motor Rated Frequency	0.0~400.0	75.0	Hz	X	X	O	
22-07 ~ 22-09	Reserved							
22-10	PM SLV Start Current	0 ~ 120% Motor Rated Current	50	%	X	X	O	
22-11	DC Injection Current	0 ~ 100% Motor Rated Current	40	%	X	X	O	
22-12	Speed Estimation kp Value	1~10000	2000	-	X	X	O	*7
22-13	Speed Estimation ki Value	1~1024	40	-	X	X	O	*6
22-14	PM Motor Armature Resistance	0.001 ~ 32.767	1.000	Ω	X	X	O	
22-15	PM Motor D-axis Inductance	0.001 ~ 32.767	1.024	mH	X	X	O	
22-16	PM Motor Q-axis Inductance	0.001 ~ 32.767	1.024	mH	X	X	O	
22-17 ~ 22-20	Reserved							
22-21	SLV PM Motor Tuning	0: Disable	0	-	X	X	O	
		1: Enable						
22-22	Fault History of SLV PM Motor Tuning	0. No Error	0	--	X	X	O	*4
		1~4: Reserved						
		5: Circuit tuning time out.						
		6: Reserved						
		7: Other motor tuning errors						
		8: Reserved						
		9: Current Abnormity Occurs while Loop Adjustment.						
		10: Reserved						
		11: Stator Resistance Measurement Timeout						
		12: Reserved						

Group 23 Pump & HVAC Function Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
23-00	Function Selection	0: Disable	0	-	O	O	O	
		1: Pump						
		2: HVAC						
		3: Compressor *7						
23-01	Setting of Single & Multiple Pumps and Master & Slave Machines	0: Single Pump	0		O	X	X	
		1: Master						
		2: Slave 1						
		3: Slave 2						
		4: Slave 3						
23-02	Operation Pressure Setting	0.01 ~ 650.00	2.00	PSI	O	X	X	*6 *8
23-03	Maximum Pressure Setting	0.01 ~ 650.00	10.00	PSI	O	X	X	*6
23-04	Pump Pressure Command Source	0: Set by 23-02	0	0	O	X	X	
		1: Set by AI						
23-05	Display Mode Selection	0: Display of Target and Pressure Feedback *	0	%	O	X	X	
		1: Only Display Target Pressure						
		2: Only Display Feedback Pressure						
23-06	Proportion Gain (P)	0.00~10.00	3.00	-	O	X	X	
23-07	Integral Time (I)	0.0~100.0	0.5	Sec	O	X	X	
23-08	Differential Time (D)	0.00~10.00	0.00	Sec	O	X	X	
23-09	Tolerance Range of Constant Pressure	0.10 ~ 650.00	0.50	PSI	O	X	X	*6 *8
23-10	Sleep Frequency of Constant Pressure	0.00 ~ 180.00	30.00	Hz	O	X	X	
23-11	Sleep Time of Constant Pressure	0.0 ~ 255.5	0.0	Sec	O	X	X	
23-12	Maximum Pressure Limit	0.00 ~ 650.00	5.00	PSI	O	X	X	*6 *8
23-13	Warning Time of High Pressure	0.0 ~ 600.0	10.0	Sec	O	X	X	
23-14	Stop Time of High Pressure	0.0 ~ 600.0	20.0	Sec	O	X	X	
23-15	Minimum Pressure Limit	0.00 ~ 650.00	0.50	PSI	O	X	X	*6 *8
23-16	Warning Time of Low Pressure	0.0 ~ 600.0	10.0	Sec	O	X	X	
23-17	Fault Stop Time of Low Pressure	0.0 ~ 600.0	20.0	Sec	O	X	X	
23-18	Detection Time of Loss Pressure	0.0 ~ 600.0	0.0	Sec	O	X	X	
23-19	Detection Proportion of Loss Pressure	0 ~ 100	0	%	O	X	X	
23-20	Percentage of Pressure Level	0: Pressure Unit Setting	0		O	X	X	*9
		1: Pressure Percentage Setting						
23-21 ~ 23-22	Reserved							
23-23	Direction of Water Pressure Detection	0: Upward Detection	1	-	O	X	X	
		1: Downward Detection						
23-24	Range of Water Pressure	0.0 ~ 65.00	0.1	PSI	O	X	X	*6

Group 23 Pump & HVAC Function Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
	Detection							*8
23-25	Period of Water Pressure Detection	0.0 ~ 200.0	20.0	Sec	O	X	X	
23-26	Acceleration Time of Water Pressure Detection	0.1 ~ 6000.0	KVA	Sec	O	X	X	
23-27	Deceleration Time of Water Pressure Detection	0.1 ~ 6000.0	KVA	Sec	O	X	X	
23-28	Forced Run Command	0.0 ~ 200	0.0	Hz-	O	X	X	
23-29	Switching Time of Multiple Pumps in Parallel	0 ~ 240	3	Hr	O	X	X	
23-30	Detection Time of Multiple Pumps in Parallel Running Start	0.0 ~ 30.0	5.0	Sec	O	X	X	
23-31	Synchronous Selection of Multiple Pumps in Parallel	0: Disable	0		O	X	X	
		1: Pressure Setting and Run/Stop						
		2: Pressure Setting						
		3: Run/Stop						
23-32 ~ 23-36	Reserved							
23-37	Leakage Detection Time	0.0~100.0	0.0	Sec	O	X	X	*7
23-38	Pressure Variation of Leakage Detection Restart	0.01~65.00	0.1	PSI	O	X	X	*7
23-39	Pressure Tolerance Range of Leakage Detection Restart	0.01~65.00	0.5	PSI	O	X	X	*7
23-40	Reserved							
23-41	Local/ Remote Key	0: Disable	1		O	O	O	
		1: Enable						
23-42	Energy Recalculating	0: Disable (Energy Accumulating)	0		O	O	O	
		1: Enable						
23-43	Electricity Price per kWh	0.000 ~ 5.000	0.000	\$	O	O	O	
23-44	Selection of Accumulative Electricity Pulse Output Unit	0: Disable	0		O	O	O	
		1: Unit for 0.1kWh						
		2: Unit for 1kWh						
		3: Unit for 10kWh						
		4: Unit for 100kWh						
5: Unit for 1000kWh								
23-45	Given Modes of Flow Meters Feedback	0: Disable	1		O	O	O	
		1: Analog Input						
		2: Pulse Input						
23-46	Maximum Value of Flow Meters	1 ~ 50000	10000	GPM	O	O	O	
23-47	Target Value of Flow Meters	1 ~ 50000	5000	GPM	O	O	O	
23-48	Maximum Flow Value of Feedback	0.01 ~ 99.00	80.00	%	O	O	O	
23-49	Maximum Flow Warning Time of Feedback	0.0 ~ 255.0	3.0	Sec	O	O	O	
23-50	Maximum Flow Stop Time of	0.0 ~ 255.0	6.0	Sec	O	O	O	

Group 23 Pump & HVAC Function Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
	Feedback							
23-51	Minimum Flow Value of Feedback	0.01 ~ 99.00	10.00	%	O	O	O	
23-52	Minimum Flow Warning Time of Feedback	0.0 ~ 255.0	3.0	Sec	O	O	O	
23-53	Minimum Flow Stop Time of Feedback	0.0 ~ 255.0	6.0	Sec	O	O	O	
23-54	Detection Function of Low Suction	0: Disable	0		O	O	O	
		1: PID Error Value						
		2: Current						
		3: Current and PID Error Value						
23-55	Detection Time of Low Suction	0 ~ 30.0	10.0	Sec	O	O	O	
23-56	PID Error Level of Low Suction	0 ~ 30	10	%	O	O	O	
23-57	Current Level of Low Suction(Motor Rated Current)	0 ~ 100	10	%	O	O	O	
23-58	Reaction of Low Suction	0: Disable	0		O	O	O	
		1: Warning						
		2: Fault						
		3: Fault & Restart						
23-59	Source of HVAC Pressure Command	0: Set by 23-47	0		O	O	O	
		1: Set by AI						
23-60 ~ 23-65	Reserved							
23-66	Derating of Current Level	10~200	110	%	O	X	X	
23-67	Derating of Delay Time	1.0~20.0	10.0	Sec	O	X	X	
23-68	Derating of Frequency Gain	1~100	90	%	O	X	X	
23-69	OL4 Current Level	10~200	120	%	O	X	X	
23-70	OL4 Delay Time	0~20.0	5.0	Sec	O	X	X	

***Note: With LED keypad, setting of 23-03 needs to be lower than 9.9 PSI in the pump modes; 10-33 is lower than 1000 and 10-34=1 in the PID modes.**

Group 24 Pump Control Function Parameters

Code	Parameter Name	Setting Range	Default	Unit	Control Mode			Attribute
					V/F	SLV	PM SLV	
24-00	Selection of Pump Control Function	0: Function of 1 to 8 Pump Card is Disabled	0	-	0	0	0	
		1: Fixed Modes of Inverter Pump: First on and Last off; then Stop All.						
		2: Fixed Modes of Inverter Pump: Only Stop Inverter Pump.						
		3: Fixed Modes of Inverter Pump: First on and First Off; then Stop All.						
		4: Cycle Modes of Inverter Pump: First on and First Off; then Stop All.						
		5: Cycle Modes of Inverter Pump: Only Stop Inverter Pump.						
		6: 1 to 3 Relay of Cycle Modes of Inverter Pump: First on and First off; then Stop All						
24-01	Selection of Relay 2-4 Function	xxx0b: Reserved	0000b		0	0	0	
		xxx1b: Reserved						
		xx0xb: Realy 2 Disable						
		xx1xb: Realy 2 Enable						
		x0xxb: Realy 3 Disable						
		x1xxb: Realy 3 Enable						
		0xxxb: Realy 4 Disable						
		1xxxb: Realy 4 Enable						
24-02	Selection of Relay 5-8 Function	xxx0b: Realy 5 Disable	0000b		0	0	0	
		xxx1b: Realy 5 Enable						
		xx0xb: Realy 6 Disable						
		xx1xb: Realy 6 Enable						
		x0xxb: Realy 7 Disable						
		x1xxb: Realy 7 Enable						
		0xxxb: Realy 8 Disable						
		1xxxb: Realy 8 Enable						
24-03	Duration of Upper Limit Frequency	1.0 ~ 600.0	300.0	Sec	0	0	0	*1
24-04	Duration of Lower Limit Frequency	1.0 ~ 600.0	300.0	Sec	0	0	0	*1
24-05	Switching Time of Magnetic Contactor	0.1 ~ 20.0	1.00	Sec	0	0	0	*1
24-06	Allowable Bias of Pump Switch	0.0 ~ 20.0	0.0	%	0	0	0	*1
24-07	Pump Control Source Selection	0: 1 to 8 pump card	0		0	0	0	
		1: Built-in 1 to 3 control mode						

4.4 Description of Parameters

Group 00-Basic Parameters

00- 00	Control Mode Selection
Range	【0】 : V/F 【1】 : Reserved 【2】 : SLV 【3】 : Reserved 【4】 : Reserved 【5】 : PMSLV

The inverter offers the following control modes:

00-00=0: V/F Mode

Select the required V/F curve (01-00) based on your motor and application. Perform a stationary auto-tune (17-00=2). If the motor cable length is longer than 50m (165ft), see parameter 17-00 for details.

00-00=2: Sensorless Vector Control

Verify the inverter rating matches the motor rating. Perform rotational auto-tune to measure and store motor parameters for higher performance operation. Perform non-rotational auto-tune if it's not possible to rotate the motor during auto-tune. Refer to parameter group 17 for details on auto-tuning.

00-00=5: PM Sensorless Vector Control

Verify the inverter rating matches the motor rating. Set PM motor data in parameters 22-00 to 22-06. Refer to parameter 22-17 for details on PM Motor tuning.

Braking Resistor

Choose a braking resistor based on application and drive model used. A braking module is required for Inverters ratings 200V 30HP, 400V/40HP or greater.

Note: Parameter 00-00 is excluded from initialization.

00- 01	Motor's Rotation Direction
Range	【0】 : Forward 【1】 : Reverse

Use the FWD/REV key to change motor direction when Run Command Selection (00-02 = 0) is set to keypad control. In keypad control operation the direction is stored in 00-01. Direction of this function will be limited to the motor direction lock selection of parameter 11-00.

00- 02	Main Run Command Source Selection
Range	【0】 : Keypad control 【1】 : External terminal control 【2】 : Communication control 【3】 : PLC 【4】 : RTC

00-02=0: Keypad Control

Use the keypad to start and stop the inverter and set direction with the forward / reverse key. Refer to section 4-1 for details on the keypad.

00-02=1: External Terminal Control

External terminals are used to start and stop the inverter and select motor direction.

The inverter can be operated in 2-wire and 3-wire mode.

00- 03	Alternative Run Command Source Selection
Range	<p>【0】 : Keypad control</p> <p>【1】 : External terminal control</p> <p>【2】 : Communication control</p> <p>【3】 : PLC</p> <p>【4】 : RTC</p>

00-03=0: Keypad Control

Use the keys (Stop/ Run or FWD/ REV) in the keypad via the setting of 00-03=0 to run the inverter (please refer to section 4.1 for details on the keypad).

00-03=1: External Terminal Control

External terminals are used to start and stop the inverter and select motor direction via the setting of 00-03=1.

Note: It is required to switch the command via the setting of multi-function digital input terminals (03-00~03-05) to 12 (Main/Alternative Run command Switching).

■ **2-wire operation**

For 2-wire operation, set 03-00 (S1 terminal selection) to 0 and 03-01 (S2 terminal selection) to 0.

Terminal S1	Terminal S2	Operation
Open	Open	Stop Inverter
Closed	Open	Run Forward
Open	Closed	Run Reverse
Closed	Closed	Stop Inverter, Display EF9 Alarm after 500ms

Parameter 13-08 to 2, 4 or 6 for 2-wire program initialization, multi-function input terminal S1 is set to forward , operation/ stop, and S2 is set for reverse, operation / stop.




Figure 4.4.1 Wiring example of 2-wire

■ 3-wire operation

For 3-wire operation set any of parameters 03-02 to 03-05 (terminal S3 ~ S6) to 26 to enable 3-wire operation in combination with S1 and S2 terminals set to operation command and stop command.

Parameter 13-08 to 3, 5 or 7 for 3-wire program initialization, multi-function input terminal S1 is set to run operation, S2 for stop operation and S5 for forward/reverse command.

Note: Terminal S1 must be closed for a minimum of 50ms to activate operation.




Figure 4.4.2 Wiring example of 3-wire





Figure 4.4.3 3-wire operation


■ **2-wire operation with hold function**

To enable 2-wire operation with hold function, set any of parameters 03-02 to 03-05 (terminal S1 ~ S6) to 53. When this mode is enabled set terminal S1 (03-00=0) to forward and S2 (03-01=1) to reverse run command.



Note: Terminal S1, S2 and S5 must be closed for a minimum of 50ms to activate operation.

Note: The inverter will display SE2 error when input terminals S1-S6 is set to 53 and 26 simultaneously.



00-03=2: Communication control

The inverter is controlled by the RS-485 port. Refer to parameter group 9 for communication setup.

00-03=3: PLC control

The inverter is controlled by the inverter built-in PLC logic. Refer to section 4.4.

00-03=4: RTC control

The inverter is controlled by RTC timer when run command is set to RTC.

00- 04	Language Selection
Range	【0】 : English 【1】 : Simple Chinese 【2】 : Traditional Chinese

It is only for LCD keypad to select. This parameter is allowed not to be modified when 13-08 (restore

factory setting) is active but it is still initialized in inverter software V1.3).

00-04=0: English Display

00-04=1: Simple Chinese Display

00-04 = 2: Traditional Chinese Display

00- 05	Main Frequency Command Source Selection
00- 06	Alternative Frequency Source Selection
Range	<p>【0】 : Keypad 【1】 : External control (analog AI1) 【2】 : Terminal UP / DOWN 【3】 : Communication control 【4】 : Reserved 【5】 : PID 【6】 : RTC 【7】 : AI2 Auxiliary frequency</p>

*1

***1: It is new added in inverter software V1.4.**

00-05/00-06= 0: Keypad

Use the keypad to enter frequency reference or to set parameter 05-01 (frequency reference 1) as alternative frequency reference source. Refer to section 4.1.4 for details.

If alternative frequency setting is set to the keypad control (00-06=0)

00-05/00-06= 1: External control (Analog Input)

When 04-05=0, give frequency reference command from control circuit terminal AI1 (voltage input). If auxiliary frequency is used, refer to p4-91 for descriptions of multi-speed functions.

When frequency reference command AI1 & AI2 is controlled independently, setting procedures are as follows:

- ① 00-05/ 00-06 are set individually to be 1 and 7.
- ② Set 04-00 depending on input signal type selection of AI1 & AI2.
- ③ Set 04-05=0 (Auxiliary frequency setting).
- ④ Set multi-function terminal to be 13, then frequency reference command can be switched to AI1 control or AI2 control.

When 04-05=1, give frequency reference command from control circuit terminal AI1 (voltage input) or AI2 (current input, set by 04-00).

Use AI1 terminal when voltage input signal is the main frequency reference command.

Use AI2 terminal when current input signal (4-20mA) is the main frequency reference command.

Use analog reference from analog input AI1 or AI2 to set the frequency reference (as shown in Figure 4.4.4). Refer to parameter 04-00 to select the signal type.

	Voltage input	Current input	04-00 Setting (Default = 1)	Dipswitch SW2 (Default 'V')	Remark Default 04-05="10"
AI1 – Analog Input 1	0 ~ 10V	-----	-----	-----	-----
AI2 – Analog Input 2	0 ~ 10V	-----	0: AI2 0~10V	Set to 'V'	Set 04-05="10" (Note)
	-----	4 ~ 20mA	1: AI2 4~20mA	Set to "I"	

Note: Set parameter 04-05 to 10 to add frequency reference AI2 to AI1.




Figure 4.4.4 Analog input as main frequency reference command

00-05/00-06= 2: Terminal UP / DOWN

The inverter accelerates with the UP command closed and decelerates with the DOWN command closed. Please refer to parameter 03-00 ~ 03-05 for additional information.

Note: To use this function both the UP and DOWN command have to be selected to any of the input terminals.

00-05/00-06= 3: Communication Control

The frequency reference command is set via the RS-485 communication port using the MODBUS RTU/ BacNet/ MetaSys protocol.

Refer to parameter group 9 for additional information.

00-05/00-06= 5: PID

- Enables PID control, reference frequency is controlled by the PID function. Refer to parameter group 10 for PID setup.
- When 00-05/00-06=5, PID control mode 10-03=xxx1b is automatically set to enable PID. (**Note:** It is new added in inverter software V1.4.)

00-05/00-06= 6: RTC

Enables RTC control, reference frequency is controlled by the RTC function, Refer to parameter group 16 for RTC setup.

00-05/00-06=7: AI2 Auxiliary frequency^{*1}

When 04-05 is set to 0 (auxiliary frequency), frequency command is set by multi-function analog input AI2. Maximum output frequency (01-02, Fmax) =100%; if 04-05 is not set to 0, the frequency is 0. Refer to p4-94 for descriptions of multi-speed functions.

00- 07	Main and Alternative Frequency Command Modes
Range	[0] : Main reference frequency [1] : Main frequency + alternative frequency

When set to 0 the reference frequency is set by the main reference frequency selection of parameter 00-05. When set to 1 the reference frequency is sum of the main reference frequency (00-05) and alternative frequency (00-06).

Note: The inverter will display the SE1 error when 00-07 = 1 and parameter 00-05 and 00-06 are set to the same selection.

When parameter 00-06 is set to 0 (Keypad) the alternative frequency reference is set by parameter 05-01 (Frequency setting of speed-stage 0).

00- 08	Communication Frequency Command – READ ONLY
Range	【0.00~400.00】 Hz

Display the frequency reference when 00-05 or 00-06 is set to communication control (3).

00- 09	Communication Frequency Command Memory
Range	【0】 : Do not store the communication frequency command at power down 【1】 : Store communication frequency reference at power down

Note: This parameter is only effective in communication mode.

00-12	Upper Limit Frequency
Range	【0.1~109.0】 %

Set the maximum frequency reference as a percentage of the maximum output frequency. Maximum output frequency depends on motor selection.

Motor 1: Maximum frequency parameter 01-02.

Motor 2: Maximum frequency parameter 01-16.

00-13	Lower Limit Frequency
Range	【0.0~109.0】 %

Set the minimum frequency reference as a percentage of the maximum output frequency. Maximum output frequency depends on motor selection. Motor 1: Maximum frequency is set by parameter 01-02 and Motor 2 Maximum frequency is set by parameter 01-16.

Notes:

- When the frequency lower limit is set to a value greater than 0 and the inverter is started the output frequency will accelerate to the frequency lower limit with a minimum frequency defined by parameter 01-08 for motor 1 and parameter 01-22 for motor 2.
- Frequency upper limit has to greater or equal to the frequency lower limit otherwise the inverter will display a SE01 (Set range error).
- Frequency upper and lower limit is active for all frequency reference modes.




Figure 4.4.5 Frequency reference upper and lower limits

00-14	Acceleration Time 1
Range	【0.1~6000.0】 Sec
00-15	Deceleration Time 1
Range	【0.1~6000.0】 Sec
00-16	Acceleration Time 2
Range	【0.1~6000.0】 Sec
00-17	Deceleration Time 2
Range	【0.1~6000.0】 Sec
00-21	Acceleration Time 3
Range	【0.1~6000.0】 Sec
00-22	Deceleration Time 3
Range	【0.1~6000.0】 Sec
00-23	Acceleration Time 4
Range	【0.1~6000.0】 Sec
00-24	Deceleration Time 4
Range	【0.1~6000.0】 Sec
00-25	Switching Frequency of Acceleration and Deceleration
Range	【0.00~400.00】 Hz 【0.0~1200.0】 Hz (When 00-31 = 1)

Acceleration time is the time required to accelerate from 0 to 100% of maximum output frequency. Deceleration time is the time required to decelerate from 100 to 0% of maximum output frequency. Motor 1: Maximum frequency is set by parameter 01-02 and Motor 2 Maximum frequency is set by parameter 01-16.

Note: Actual acceleration and deceleration times can be affected by the inverter driven load.

The default values for the acceleration, deceleration times are dependent on the inverter size.

Size		Acceleration / Deceleration Default Value
200V Class	400V Class	
5~15HP	5~20HP	10s
20~30HP	25~40HP	15s
40~175HP	50~800HP	20s

A: Select acceleration and deceleration time via the digital input terminals

The following table shows the acceleration / deceleration selected when the digital input function Accel/Decel time 1 (#10) and Accel/Decel time 2 1(#30) are used.

Table 4.4.1 Acceleration / deceleration time selection

Accel/decel time 2 (Set 03-00 ~ 03-05 = 30)	Accel/decel time 1 (Set 03-00 to 03-05 = 10)	Acceleration time	Deceleration time
0	0	Tacc1 (00-14)	Tdec1 (00-15)
0	1	Tacc2 (00-16)	Tdec2 (00-17)
1	0	Tacc3 (00-21)	Tdec3 (00-22)
1	1	Tacc4 (00-23)	Tdec4 (00-24)

0: OFF, 1: ON




Figure 4.4.6: Terminal S5 switch between Tacc1/Tacc2 and Tdec1/Tdec2

B. Automatically acceleration / deceleration time switch-over based on output frequency

Set acceleration / deceleration switch over frequency parameter 00-25 to a value greater than 0 to automatically switch between Tacc1 (00-14) / Tdec1 (00-23) and Tacc4 (00-24) / Tdec4 (00-15).

Tacc1 (00-14) / Tdec1 (00-23) are active when the output frequency < 00-25 and Tacc4 (00-24) / Tdec4 (00-15) are active when the output frequency >= 00-25. Refer to the Figure 4.4.7 for details.

Note: Multi-function input function #10 (Accel/Decel time 1) and #30 (Accel/Decel time 2) have a higher priority than switch over frequency parameter 00-25.




Figure 4.4.7 Automatic acceleration / deceleration time switch-over based on output frequency

00-18	Jog Frequency
Range	【0.00~400.00】 Hz 【0.0~1200.0】 Hz (When 00-31 = 1)
00-19	Jog Acceleration Time
Range	【0.1~0600.0】 Sec
00-20	Jog Deceleration Time
Range	【0.1~0600.0】 Sec

Jog acceleration time (00-19) is the time required to accelerate from 0 to 100% of maximum output frequency. Jog deceleration time (00-20) is the time required to decelerate from 100 to 0% of maximum output frequency. Motor 1: Maximum frequency is set by parameter 01-02 and Motor 2 Maximum frequency is set by parameter 01-16.

The inverter uses the Jog frequency (00-18, default 6.0 Hz) as its frequency reference when jog is active.

00- 26	Emergency Stop Time
Range	【0.0~6000.0】 Sec

The emergency stop time is used in combination with multi-function digital input function #14 (Emergency stop). When emergency stop input is activated the inverter will decelerate to a stop using the Emergency stop time (00-26) and display the [EM STOP] condition on the keypad.

Note: To cancel the emergency stop condition the run command has to be removed and emergency stop input deactivated.

Multi-function digital input terminals (03-00 ~ 03-05) are set to 14: When the emergency stop input is activated the inverter will decelerate to a stop using the time set in parameter 00-26.

Note: After an emergency stop command the run command and emergency stop command have to be removed before the inverter can be restarted. Please refer to Figure 4.4.8. The emergency stop function can be used to stop inverter in case of an external event.

Multi-function digital input terminals (03-00 ~ 03-05) set to 15: When the base block input is activated the inverter output will turn off and the motor will coast to a stop.




Figure 4.4.8 Emergency stop example

00- 28	Selection of Main Frequency Command Characteristic
Range	【0】 : Positive characteristic (0~10V/4~20mA = 0~100%) 【1】 : Negative / inverse characteristic (0~10V/4~20mA = 100~0%)

00-28= 0: Positive reference curve, 0 – 10V / 4 – 20mA = 0 – 100% main frequency reference.

00-28= 1: Negative reference curve, 0 – 10V / 4 – 20mA = 100 – 0% main frequency reference.

Note: Selection applies to analog input AI1 and AI2.




Figure 4.4.9 Positive/negative analog input as main frequency reference command.

00- 32	Application	
Range	【0】 : Default Value	
	【1】 : Water supply pump	*1
	【2】 : Conveyor	
	【3】 : Exhaust fan	
	【4】 : HVAC	
	【5】 : Compressor	*1
	【6】 : Hoist	*1
【7】 : Crane	*1	

*1: It is new added in inverter software V1.4.

(1) Water supply pump

Parameter	Name	Value
00-00	Control mode selection	0 : V/F
11-00	Direction lock selection	1 : Forward direction only
01-00	V/F curve selection	6 (60Hz) 4 (50Hz)
07-00	Momentary stop and restart selection	1 : Enable
08-00	Stall prevention function	xx0xb : Stall prevention is enabled during deceleration
23-00	Function Selection	1: Pump

(2) Conveyor

Parameter	Name	Value
00-00	Control mode selection	0: V/F
00-14	Acceleration time 1	3.0 sec
00-15	Deceleration time 1	3.0 sec
00-27	HD/ND selection	0: HD
08-00	Stall prevention function	xx0xb: Stall prevention is enabled during deceleration

(3) Exhaust fan

Parameter	Name	Value
00-00	Control mode selection	0 : V/F
11-00	Direction lock selection	1 : Forward direction only
01-00	V/F curve selection	F
01-04	Middle output frequency 2	30.0 Hz
01-05	Middle output voltage 2	50.0 V
07-00	Momentary stop and restart selection	1 : Enable
08-00	Stall prevention function	xx0xb : Stall prevention is enabled during deceleration

(4) HVAC

Parameter	Name	Value
00-00	Control mode selection	0 : V/F
11-00	Direction lock selection	1 : Forward direction only
11-01	Carrier frequency	8.0kHz

Parameter	Name	Value
07-00	Momentary stop and restart selection	1 : Enable
11-03	Automatic carrier frequency reduction	1 : Enable
01-00	V/F curve selection	6 (60Hz) 4 (50Hz)
23-00	Function Selection	2: HVAC

(5) Compressor

Parameter	Name	Value
00-00	Control mode selection	0: V/F
11-00	Direction lock selection	1: Forward direction only
00-14	Acceleration time 1	5.0 sec
00-15	Deceleration time 1	5.0 sec
00-27	HD/ND selection	0: HD
01-00	V/F curve selection	F
01-07	Middle Output Voltage 1	Half of the maximum voltage
07-00	Momentary stop and restart selection	1: Enable
08-00	Stall prevention function	xx0xb: Stall prevention during deceleration
23-00	Function Selection	3: Compressor

(6) Hoist

Parameter	Name	Value
00-00	Control mode selection	2: SLV
00-05	Main Frequency command source selection	0: keypad
11-43	Hold Frequency at start	3.0 Hz
11-44	Frequency hold Time at start	0.3 sec
00-14	Acceleration time 1	3.0 sec
00-15	Deceleration time 1	3.0 sec
00-27	HD/ND selection	0 : HD
11-01	Carrier frequency	5.0kHz
05-01	Frequency setting of speed-stage 0	6.0 Hz
06-01	Frequency setting of speed-stage 1	30.0 Hz
06-02	Frequency setting of speed-stage 2	60.0 Hz
01-00	V/F curve selection	F
03-39	Relay output (R3A-R3C)	5 : frequency detection 2
07-18	Minimum baseblock time	0.3 sec
08-00	Stall prevention function	xx1xb: Stall prevention is disabled in deceleration.
03-13	Frequency detection level	2.0 Hz
03-14	Frequency detection width	0.0 Hz
08-18	Selection of low-torque operation	0: Deceleration to stop when low- torque is detected.
08-19	Level of low-torque detection	2 %
08-20	Time of low-torque detection	0.5 sec
08-09	Selection of input phase loss protection	1 : Enable
08-10	Selection of output phase loss protection	1 : Enable
11-03	Selection of reducing carrier automatically	1 : Enable

(7) Crane

Parameter	Name	Value
00-00	Control mode selection	0: V/F
00-05	Main Frequency Command Source Selection	0: keypad
00-14	Acceleration time 1	3.0 sec
00-15	Deceleration time 1	3.0 sec
00-27	HD/ND Mode selection	0: HD
11-01	Carrier frequency	5.0kHz
05-01	Frequency setting of speed-stage 0	6.0 Hz
06-01	Frequency setting of speed-stage 1	30.0 Hz
06-02	Frequency setting of speed-stage 2	60.0 Hz
03-04	Multi-function terminal Function setting-S5	2: Multi-Speed Setting Command 1
03-05	Multi-function terminal Function setting-S6	3: Multi-Speed Setting Command 2
03-39	Relay output (R3A-R3C)	23 : Frequency command source
08-00	Stall prevention function	xx1xb : Stall prevention is disabled in deceleration
08-09	Selection of input phase loss protection	1: Enable
08-10	Selection of output phase loss protection	1: Enable

00-33	Modified Parameters
Range	【0】 : Disable 【1】 : Enable

This parameter automatically lists all the adjusted parameters. When the default value is adjusted and 00-33=1, it will list all the parameters different from default values in the advanced modes and these parameters can be edited directly. The adjusted parameters list displays only when 00-33 is set from 0 to 1 or 00-33=1 at start up.

If user wants to restore to the original editing interface, it is only required to set parameter 00-33=0.

This function can display 250 adjusted parameters. If they are more than 250 parameters, it will list the adjusted parameters before 250.

Example: set 00-03 (Alternative Run Command Source Selection) to be different default value.

Steps	LCD Display	Descriptions
1	Group 00 Basic Func. 01 V/F Pattern 02 Motor Parameter	The starting parameter group (00) in the setting modes of ▲ (Up)/ ▼ (Down) selection groups.
2	PARA 00 -01. Motor Direction -02. RUN Source -03. Sub RUN Source	Press READ/ ENTER key and ▲ (Up)/ ▼ (Down) to select alternative run command source (00-03).
3	Edit 00-00 Sub RUN Source Terminal (0 ~4) <2>	Press READ/ ENTER key and adjust the value. The selected setting value will flash.
4	PARA 00 -33. Modify parameter -41. User P1 -42. User P2	Press DSP/ FUN to the menu of modified parameters (00-33).
5	Edit 00-33 Modify parameter Enable (0 ~1) <0>	Press READ/ ENTER key to adjust the value to 1 (The modified parameter is enabled.) The selected setting value will flash.
6	Modify 00 00-03. Sub RUN Source 00-33. Modify parameter	Press DSP/ FUN back to the advanced modes.

■ User Parameter Setting (00-41 ~ 00-56) (only for LCD)

00- 41	User Parameter 0 Function Setting
00- 42	User Parameter 1 Function Setting
00- 43	User Parameter 2 Function Setting
00- 44	User Parameter 3 Function Setting
00- 45	User Parameter 4 Function Setting
00- 46	User Parameter 5 Function Setting
00- 47	User Parameter 6 Function Setting
00- 48	User Parameter 7 Function Setting
00- 48	User Parameter 8 Function Setting
00- 50	User Parameter 9 Function Setting
00- 51	User Parameter 10 Function Setting
00- 52	User Parameter 11 Function Setting
00- 53	User Parameter 12 Function Setting
00- 54	User Parameter 13 Function Setting
00- 55	User Parameter 14 Function Setting
00- 56	User Parameter 15 Function Setting

- User parameter (00-41 ~ 00-56) can select 16 sets of parameters (01-00 group ~ 24-06 group) and put them into the list to do the fast access setting.
- When the access setting of parameter 13-06 is set to 1, user parameter 00-41 ~ 00-56 can be displayed and changed.
- User parameter 00-41 ~ 00-56 can be changed in the advanced modes, exclusive of being in operation.
- Set value in the parameter of 00-41 ~ 00-56 and set 13-06 to 1.
- When 13-06=1, only parameter of 00-00 ~ 00-56 can be set or read in the advanced modes. 13-06=1 is enabled in the parameter setting of 00-41~00-56.
- When user would like to leave the screen of user parameters, press RESET key and then DSP/FUN key to select parameter Group 13.
-

Example 1: Set 03-00 (Multi-function terminal Function Setting-S1) to user parameter 0 (00-41)

Steps	LCD Display	Descriptions
1	Group 00 Basic Func. 01 V/F Pattern 02 Motor Parameter	Select the start parameter group (00) in the advanced modes.
2	PARA 00 -41. User P0 -42. User P1 -43. User P2	Press (READ/ ENTER) key and ▲ (Up) / ▼ (Down) to select user parameter 0 (00-41).
3	Edit 00-41 User P0=00-41 00-41 User P0 <00-01 - 24-07>	Press (READ/ ENTER) key to the screen of data setting/ read. * The selected setting value will flash.
4	Edit 00-41 User P0=00-41 03-00 S1 Function Sel <00-01 - 24-07>	Press ◀ (Left) / ▶ (Right) and ▲ (Up) / ▼ (Down) key to set the value to 03-00 (Multi-function terminal Function Setting-S1)
5	Edit 00-41 User P0= 03-00 03-00 S1 Function Sel <00-01 - 24-07>	Press (READ/ ENTER) key to save 03-00 and the digit stops flashing and the screen displays User P0 = 03-00 ; 03-00 (Multi-function terminal Function Setting-S1) has been defined as 00-41. Few seconds later, the selected digit will flash again.
6	Monitor Freq Ref 12-16=000.00Hz ----- 12-17=000.00Hz 12-18=0000.0A	Press (DSP/ FUN) key to the display of main screen. * If users do not press BACK key in one minute, the screen will automatically display the monitor mode shown as the left figure. The automatically return time can be set via 16-06.


Example 2: After one or more parameters in 00-41 ~ 00-56 are set, user parameters settings are as follows.

Step	LCD Display	Descriptions
1	Group 13 Driver Status 14 PLC Setting 15 PLC Monitor	Select the start parameter group (03) in the advanced modes.
2	PARA 13 -06. Access Level -07. Password 1 -08. Initialize	Press (READ/ ENTER) and ▲ (Up) / ▼ (Down) key to enter the access level of parameter (13-06).
3	Edit 13-06 Access Level ----- 1 User Level (0~2) < 2 >	Press (READ/ ENTER) key to enter the screen of the data setting/ read. * The selected setting value will flash.
4	—ADV— G01-02 Access Level 1 User Level (0-2) < 2 >	Press ▲ (Up) / ▼ (Down) key to change setting value to 1 (13-06=1, user level) and Press (READ/ ENTER) key to save the setting value (03-00). Then, the digit stops flashing and the screen displays the setting value. Few seconds later, the selected digit will flash again. User level (13-06=1) can be set by one or more parameters in the user parameters of 00-41 ~ 00-56. If users do not set user parameters, 13-06 will not be set in the user level (setting value=1).
5	PARA 13 -06. Access Level	Press (DSP/FUN) key to the display of subdirectory.
6	Group 00.User Function	Press (DSP/FUN) key to the display of group directory. It is required to press ▲ (Up) key to select Group 00 User Function.
7	Monitor Freq Ref 12-16=000.00Hz ----- 12-17=000.00Hz ----- 12-18=0000.0A	Press (DSP/ FUN) key to enter the main screen. If user would like to leave the screen of user parameters, press RESET key and then DSP/FUN key to select parameter Group 13. Hotkeys are only enabled in inverter software V1.4.
8	Group 00. User Function00 U 13.Driver Status	13-06 can be selected to be adjusted so leave parameters or enter parameter group 00 to edit user parameters is allowable.
9	PARA 00 -41. S1 Function Sel	Press (READ/ ENTER) key and ▲ (Up) / ▼ (Down) key to select user parameter 0 (00-41) display.
10	Edit 00-41 S1 Function Sel 00 2-Wire (FWD-RUN) (00~57) < 00 > < 03-00 >	Press (READ/ ENTER) key to enter the screen of data setting/ read. *The selected setting value will flash. In this example, 03-00 (Multi-function terminal Function Setting-S1) has been defined as user parameters (00-41). The right bottom location displays the original parameter group.

Step	LCD Display	Descriptions
11	Edit 00-41 S1 Function Sel	Press ▲ (Up) / ▼ (Down) key to change the setting value to 2. Use (READ/ ENTER) key to save the setting value. When the selected setting value does not flash again, the setting value will be saved to 00-41 and 03-00 simultaneously.
	06 FJOG (00~57) < 00 > < 03-00 >	
12	Monitor Freq Ref	Press (DSP/FUN) key to the display of main screen. * If users do not press (DSP/ FUN) key in one minute, the screen will automatically display the monitor mode shown as the left figure. The automatically return time can be set via 16-06.
	12-16=000.00Hz	
	12-17=000.00Hz	
	12-18=0000.0A	

User Parameter Run Mode Structures

- A. Define Parameter Group 0~24 as user parameters except parameter 00-00 and 00-41~00-56.




Note: User level (13-06=1) can be set by one or more parameters in the user parameters of 00-41 ~ 00-56.

[Main Screen]

[Main Menu]

[Subdirectory]

[READ/ ENTER]



Information
provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk

Group 01-V/F Control Parameters

01- 00	V/F Curve Selection
Range	【0~FF】

The V/F curve selection is enabled for V/F mode. Make sure to set the inverter input voltage parameter 01-14.

There are three ways to set V/F curve:

- (1) 01-00 = 0 to E: choose any of the 15 predefined curves (0 to E).
- (2) 01-00 = 0F, use 01-02~01-09 and 01-12 ~ 01-13, with voltage limit.
- (3) 01-00 = FF: use 01-02~01-09 and 01-12 ~ 01-13, without voltage limit.

The default parameters (01-02 ~ 01-09 and 01-12 ~ 01-13) are the same when 01-00 is set to F (default) and 01-00 is set to 1.

Parameters 01-02 ~ 01-13 are automatically set when any of the predefined V/F curves are selected.

This parameter will be affected to reset by the initialization parameter (13-08).

Consider the following items as the conditions for selecting a V/F pattern.

- (1) The voltage and frequency characteristic of motor.
- (2) The maximum speed of motor.

Information
provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk

Table 4.4.2 5 - 30HP V/F curve selection

Type	Specification	01-00	V/F curve ^{*1}	Type	Specification	01-00	V/F ^{*1}		
General purpose	50Hz	0		High Starting Torque [‡]	Low Starting Torque	8			
			High Starting Torque					9	
	60Hz	60Hz Saturation	1			60Hz	Low Starting Torque	A	
		50Hz Saturation	2				High Starting Torque	B	
Variable Torque Characteristic	72Hz	3		Constant-power torque(Reducer)	90Hz	C			
								50Hz	Variable Torque 1
	Variable Torque 2	5	180Hz		E				
	60Hz	Variable Torque 3					6 (Def. Val.)		
		Variable Torque 4	7						

Type	Specification	01-00	V/F curve ^{*1}
Rated Horsepower Torque (Reducer)	1200Hz	F	

*1. Values shown are for 200V class inverters; double values for 400V class inverters.

‡: Select high starting torque only for the following conditions.

- (1) The power cable length is > 50m (492ft).
- (2) Voltage drop at startup is high.
- (3) An AC reactor is used on the input side or output side of the inverter.
- (4) Motor power is lower than the inverter rated power.

Table 4.4.3 40HP and above V/F curve selection

Type	Specification	01-00	V/F curve ^{*1}	Type	Specification	01-00	V/F curve ^{*1}				
General purpose	50Hz	0		High Starting Torque [‡]	50Hz	8					
			60Hz				2		60Hz	A	
	60Hz	1			F	60Hz		B			
			60Hz				2		60Hz	B	
Variable Torque Characteristic	72Hz	3			Constant-power torque (Reducer)	90Hz		C			
			50Hz	4			5		120Hz	D	
	60Hz	7	60Hz	E							
							60Hz	Variable Torque 1	4	5	120Hz
	60Hz	Variable Torque 2	5	120Hz		D					
60Hz					Variable Torque 3		6 (Def. Val.)	7	180Hz	E	
	60Hz	Variable Torque 4	7	180Hz		E					

*1. Values shown are for 200V class inverters; double values for 400V class inverters.

‡: Select high starting torque only for the following conditions.

- (1) The power cable length is > 50m (492ft).
- (2) Voltage drop at startup is high.
- (3) An AC reactor is used on the input side or output side of the inverter.
- (4) Motor power lower than the inverter rated power.

01- 02	Maximum Output Frequency
Range	【20.0~400.0】 Hz^{*1}
01- 03	Maximum Output Voltage
Range	200V: 【0.1~255.0】 V 400V: 【0.2~510.0】 V
01- 04	Middle output frequency 2
Range	【0.0~400.0】 Hz
01- 05	Middle Output Voltage 2
Range	200V: 【0.0~255.0】 V 400V: 【0.0~510.0】 V
01- 06	Middle Output Frequency 1
Range	【0.0~400.0】 Hz
01- 07	Middle Output Voltage 1
Range	200V: 【0.0~255.0】 V 400V: 【0.0~510.0】 V
01- 08	Minimum Output Frequency
Range	【0.0~400.0】 Hz
01- 09	Minimum Output Voltage
Range	200V: 【0.0~255.0】 V 400V: 【0.0~510.0】 V
01- 12	Base Frequency
Range	【10.0~400.0】 Hz
01- 13	Base Output Voltage
Range	200V: 【0.0~255.0】 V 400V: 【0.0~510.0】 V

*1: The setting range of 01-02 in inverter software V1.3 is **【40.0~400.0】**

V/F curve setting (01-02 ~ 01-09 and 01-12 ~ 01-13)

Select any of the predefined V/F curves setting '0' to 'E' that best matches your application and the load characteristic of your motor, choose a custom curve setting 'F' or 'FF' to set a custom curve.

Important:

Improper V/F curve selection can result in low motor torque or increased current due to excitation.

For low torque or high speed applications, the motor may overheat. Make sure to provide adequate cooling when operating the motor under these conditions for a longer period of time.

If the automatic torque boost function is enabled (parameter 01-10), the applied motor voltage will automatically change to provide adequate motor torque during start or operating at low frequency.

Custom V/F Curve Setting:

A custom curve selection allows users to set parameters 01-02 ~ 01-13 whereas a predefined curve selection does not.




Figure 4.4.10 Custom V/F curve

When setting the frequency related parameters for a custom V/F curve values make sure that:

$$F_{\max} > F_{\text{base}} > F_{\text{mid2}} > F_{\text{mid1}} > F_{\min}$$

(01-02) (01-12) (01-04) (01-06) (01-08)

The 'SE03' V/F curve tuning error is displayed when the frequency values are set incorrectly.

When 01-04 and 01-05 (or 01-18 and 01-09) are set to 0, the inverter ignores the set values of Fmid2 and Vmid2.

When the control mode is changed parameter 00-00, 01-08 (F_{\min}) and 01-09 (V_{\min}) will automatically be changed to the default setting of the selected control mode.

SLV (Sensorless vector control)

Enter the motor data in parameter group 17 for SV and SLV control mode (00-00) and perform auto-tuning.

In the SLV mode the V/F curve normally does not have to be re-adjusted after a successful auto-tune.

The maximum output frequency setting 01-02 (F_{\max}), base frequency 01-12 (F_{base}) or minimum output frequency 01-08 (F_{\min}) can be adjusted but the voltage is automatically adjusted by the internal current controller.

Set the base frequency (01-12, F_{base}) to the motor rated frequency on the motor nameplate.

Perform the auto-tuning procedure after adjusting parameters 02-19 or 17-04 to reduce the voltage at no-load operation.

Motor jitter can be reduced by lowering the no-load voltage. Please note that lowering the no-load voltage increases the current at no-load.

01-10	Torque Compensation Gain
Range	【0.0~2.0】

In V/F mode the inverter automatically adjusts the output voltage to adjust the output torque during start or during load changes based on the calculated loss of motor voltage.

The rate of adjustment can be changed with the torque compensation gain parameter.

Refer to the torque compensation gain adjustment shown in Figure 4.4.11.




Figure 4.4.11 Torque compensation gain to increase/decrease output torque

Increase value when:

- The wiring between the inverter and the motor is too long
- The motor size is smaller than the inverter size

Note: Gradually increase the torque compensation value and make sure the output current does not exceed inverter rated current.

Reduce value when:

- When experiencing motor vibration

Important:

Confirm that the output current at low speed does not exceed the rated output current of the inverter.

01-14	Input Voltage Setting
Range	200V: 【155.0~255.0】 V 400V: 【310.0~510.0】 V

Set the inverter input voltage (E.g. 200V / 208V / 230V / 240V or 380V / 415V / 440V / 460V / 480V).

This parameter is used as a reference for predefined V/F curve calculation (01-00 = 0 to E), over-voltage protection level, stall prevention, etc...

01-15	Torque Compensation Time
Range	【0~10000】 ms

Set the torque compensation delay time in milliseconds.

Only adjust in the following situations:

Increase value when:

- When experiencing motor vibration

Decrease value when:

- When motor torque response is too slow

Group 02-IM Motor Parameter

02- 00	No-load Current
Range	【0.01~600.00】 A
02- 01	Rated Current
Range	V/F mode is 10%~200% of inverter's rated current. SLV mode is 25%~200% of inverter's rated current.
02-03	Rated Rotation Speed
Range	【0~60000】 rpm
02- 04	Rated Voltage
Range	200V: 【50.0~240.0】 V 400V: 【100.0~480.0】 V
02- 05	Rated Power
Range	【0.01~600.00】 KW
02-06	Rated Frequency
Range	【10.0~400.0】 Hz
02-07	Poles
Range	【2~16】 (Even) ^{*1}
02-09	Excitation Current
Range	【15.0~70.0】 %
02-10	Core Saturation Coefficient 1
Range	【0~100】 %
02-11	Core Saturation Coefficient 2
Range	【0~100】 %
02-12	Core Saturation Coefficient 3
Range	【80~300】 %
02-13	Core Loss
Range	【0.0~15.0】 %
02-15	Resistance between Wires
Range	【0.001~60.000】 Ω
02-16	Rotor Resistance
Range	【0.001~60.000】 Ω
02-17	Leakage Inductance
Range	【0.01~200.00】 mH
02-18	Mutual Inductance
Range	【0.1~6553.5】 mH
02-19	No-Load Voltage
Range	200V: 【50~240】 V 400V: 【100~480】 V
02-33	Leakage Inductance Ratio
Range	【0.1~15.0】 %
02-34	Slip Frequency
Range	【0.1~20.0】 Hz

*1: The setting range of 02-07 in inverter software V1.3 is 【2~8】 (Even).

In most case no adjustment is required after performing an auto-tune except when using the inverter in special applications (e.g. machine tool, positioning, etc...).

Please refer to parameter group 22 for permanent magnet motor parameters.

- (1) Number of motor poles (02-07)
Set the number of motor pole according to the motor nameplate.
- (2) Motor rated power (02-05)
Set the motor power according to the motor nameplate.
- (3) Motor rated current (02-01)
Set the motor rated current according to the motor nameplate.
- (4) Motor rated voltage (02-04)
Set the motor rated voltage according to the motor nameplate.
- (5) Rated frequency of motor (02-06)
Set the motor rated frequency according to the motor nameplate.
- (6) Rated rotation speed of motor (02-03)
Set the motor rpm according to the motor nameplate.
- (7) No-load motor voltage (02-19)

Parameter determines the rated flux during motor's rated rotation in SLV control mode. Set the value of this parameter to the same value as parameter 17-08 (02-19 for motor 2). A value of 10~50V below the input voltage level ensures that the motor is capable of providing adequate torque performance when operating at nominal speed (or higher speed). Setting the value to small can result in a reduction in no-load current, weakened motor flux and an increase in motor current while the motor is loaded.

- (8) Motor excitation current (02-09)
 - This parameter is automatically set via auto-tuning. It required manual adjustment without auto-tuning.
 - Start tunig from 33% when doing manual adjustment. If the output value of no-load voltage (12-67) is higher than the setting value of no-load voltage (17-08), the motor excitation current is adjusted downward; if the value (12-67) is lower than the value (17-08), the motor excitation current is adjusted upward.
 - Adjust the value of motor excitation current (02-09) will change the value of the motor leakage inductance (02-17) and motor mutual inductance (02-18).
- (9) Setting of motor core saturation coefficients 1, 2 and 3 (02-10, 02-11, 02-12)

These parameters are automatically set during auto-tune. No adjustment required. Parameters are set to 50% for 02-10, 75% for 02-11 and 137.5% for 02-12 to reduce the impact of core saturation. The motor core's saturation coefficient is defined as a percentage of the motor excitation current. When the motor flux reaches 137.5% level, the core's saturation coefficient shall be greater than 137.5%. When the motor flux is 50% or 75%, the core's saturation coefficient is required to be less than 50% and 75%.




Figure 4.4.12-a Y-equivalent model of an induction motor

(10) Motor core loss (02-13)

Set motor core loss as the percentage of the motor rated power.

$$\% W_{\text{core}} (02-13) = \frac{3 \times \text{Motor core loss (watt)}}{\text{Motor rated power (watts, 02-05)}} \times 100\%$$

Note: In V/F mode motor core loss (02-13) is used to for torque compensation.

(11) Motor line to line resistance (02-15)

(12) Motor rotor resistance R2 (02-16)

(13) Motor leakage inductance (02-17)

(14) Motor mutual inductance (02-18)

(15) Motor no-load current (02-00).

Value is calculated based on the motor rated frequency (17-05) and motor rated current (17-03).

In V / F control mode, the output current is greater than the no-load current with slip compensation is enabled.

Note: The value of 02-01 needs to be greater than the value set in parameter 02-00, otherwise warning message "SE01" out of range error will be displayed.




Figure 4.4.12-b Y-equivalent model of an induction motor

(16) Motor Leakage Inductance Ratio (02-33)

- This parameter is set by the conversion of manual adjustment function. This adjustment does not have the magnetic function. Normally, it does not require adjustment.
- Definition of leakage inductance ratio is the ratio of leakage inductance to rotor inductance. If default setting is 3.4%, adjust this ratio changes the parameter of motor leakage inductance. The formula of this ratio is as follows:

$$\xi = \frac{LlKg}{Lr}$$

- When the ratio of leakage inductance is too high or too low, it may cause the motor jittering with different sound and without operation. The general setting range is 3.0%~5.0% and 4.0% is the relatively common value for motor operation normally. The ratio of leakage inductance is adjusted depending on different motor types.

(17) Motor Slip Frequency (02-34)

- This parameter is set by the conversion of manual adjustment function. This adjustment does not have the magnetic function. Normally, it does not require adjustment.
- The default setting is 1Hz and the value of motor slip frequency is obtained from motor nameplate. Take 4-pole motor with 60Hz for example,

Synchronous speed is $N = \frac{120 \times \text{Frequency}}{\text{Pole}} = \frac{120 \times 60}{4} = 1800 \text{ rpm}$ and the rated speed in the

motor nameplate is 1700 rpm, then $\text{Slip} = \frac{1800 - 1700}{60} = 1.67 \text{ Hz}$.

Note: Adjusting the motor slip frequency changes the parameter of rotor resistance and the value of slip frequency is adjusted depending on different motor types.

Group 03- External Digital Input and Output Parameters

03- 00	Multi-function terminal function setting – S1
03- 01	Multi-function terminal function setting – S2
03- 02	Multi-function terminal function setting – S3
03- 03	Multi-function terminal function setting – S4
03- 04	Multi-function terminal function setting – S5
03-05	Multi-function terminal function setting – S6
Range	<p> 【0】 : 2-Wire Sequence (ON: Forward Run Command) 【1】 : 2-Wire Sequence (ON: Reverse Run Command) 【2】 : Multi-Speed Setting Command 1 【3】 : Multi-Speed Setting Command 2 【4】 : Multi-Speed Setting Command 3 【5】 : Multi-Speed Setting Command 4 【6】 : Forward Jog Run Command 【7】 : Reverse Jog Run Command 【8】 : UP Frequency Increasing Command 【9】 : DOWN Frequency Decreasing Command 【10】 : Acceleration/ Deceleration Setting Command 1 【11】 : Inhibit Acceleration/ Deceleration Command 【12】 : Main/Alternative Run command Switching 【13】 : Main/Alternative Frequency Command Switching 【14】 : Emergency Stop (Decelerate to Zero and Stop) 【15】 : External Baseblock Command (Rotation freely to Stop)*¹ 【16】 : PID Control Disable 【17】 : Fault Reset (RESET) 【18】 : Reserved 【19】 : Speed Search 1(from the maximum frequency)*¹ 【20】 : Manual Energy Saving Function 【21】 : PID Integral Reset 【22】 ~ 【23】 : Reserved 【24】 : PLC Input 【25】 : External Fault 【26】 : 3-Wire Sequence (Forward/ Reverse Command) 【27】 : Local/ Remote Selection 【28】 : Remote Mode Selection 【29】 : Jog Frequency Selection 【30】 : Acceleration/ Deceleration Setting Command 2 【31】 : Inverter Overheating Warning 【32】 : Reserved 【33】 : DC Braking*¹ 【34】 : Speed Search 2 (from Frequency Command)*¹ 【35】 : Timing Function Input 【36】 : PID Soft Start Disable 【37】 ~ 【40】 : Reserved 【41】 : PID Sleep 【42】 ~ 【46】 : Reserved 【47】 : Fire Mode (Forced to Run Mode) 【48】 : KEB Acceleration </p>

<p> 【49】 : Parameters Writing Allowable 【50】 : Unattended Start Protection (USP) 【51】 ~ 【52】 : Reserved 【53】 : 2-Wire Self Holding Mode (Stop Command) 【54】 : Switch PID1 and PID2 【55】 : RTC Time Enable 【56】 : RTC Offset Enable 【57】 : Forcing Frequency Run 【58】 : Run Permissive Function </p>
--

*1: It can not be selected on the items 15, 19, 33, and 34 while using the permanent magnetic (PM) motor.

Refer to the multi-function digital input and related parameters in the following Fig. 4.4.13




Figure 4.4.13 Multi-function digital input and related parameters

Table 4.4.4 Multi-function digital input setting (03-00 ~ 03-05) (“O”: Enable, “X”: Disable)

Value	Function		Description	Control mode		
	Name	LCD Display		V/F	SLV	PM SLV
0	2-wire type (Forward operation)	2-Wire (FWD-RUN)	2- wire (ON : Forward operation command).	0	0	0
1	2-wire type (Reverse operation)	2-Wire (REV-RUN)	2- wire (ON : Reverse operation command).	0	0	0
2	Multi-Speed Setting Command 1	Muti-Spd Ref 1	Multi-Speed Reference 1	0	0	0
3	Multi-Speed Setting Command 2	Muti-Spd Ref 2	Multi-Speed Reference 2	0	0	0
4	Multi-Speed Setting Command 3	Muti-Spd Ref 3	Multi-speed Reference 3	0	0	0
5	Multi-Speed Setting Command 4	Muti-Spd Ref 4	Multi-speed Reference 4	0	0	0
6	Forward Jog Run Command	FJOG	ON: Forward operation in jog mode (00-18)	0	0	0
7	Reverse Jog Run Command	RJOG	ON: Reverse operation in jog mode (00-18)	0	0	0
8	UP Frequency Increasing Command	UP command	ON: Command of output frequency increasing (only used by support of DOWN command).	0	0	0
9	DOWN Frequency Decreasing Command	DOWN command	ON: Command of output frequency decreasing (only used by support of UP command).	0	0	0
10	Acceleration/Deceleration Setting Command 1	Acc/Decel Time Selection 1	Acceleration/deceleration time selection command1	0	0	0
11	Inhibit Acceleration/Deceleration Command	ACC/DEC Inhibit	ON: Acceleration/deceleration prohibition	0	0	0
12	Main/Alternative Run command Switching	Run Change Sel	Run command source is set by alternative run command (00-03).	0	0	0
13	Main/Alternative Frequency Command Switching	Freq Change Sel	Frequency command source is set by alternative frequency command (00- 06).	0	0	0
14	Emergency Stop (Decelerate to Zero and Stop)	E-Stop	ON: Emergency stop input	0	0	0
15	External Baseblock Command (Rotation freely to Stop)	Ext. BB	ON: Inverter base interdiction	0	0	0
16	PID Control Disable	PID Disable	ON: PID control disable	0	0	0
17	Fault Reset	Fault Reset	Fault reset	0	0	0
18	Reserved	Reserved	Reserved	-	-	-
19	Speed Search 1(from the maximum frequency)	Speed Search 1	ON: Search the speed from the maximum output frequency	0	0	0

Value	Function		Description	Control mode		
	Name	LCD Display		V/F	SLV	PM SLV
20	Manual Energy Saving Function	Energy saving	ON: Manual energy saving control is based on the settings of 11-12 and 11-18.	0	X	0
21	PID Integral Reset	PID I-Reset	ON: PID integral value reset	0	0	0
22~23	Reserved	Reserved	Reserved	-	-	-
24	PLC input	PLC Input	ON: Digital PLC input	0	0	0
25	External fault	Ext. Fault	ON: External fault alarm	0	0	0
26	3-Wire Sequence (Forward/ Reverse Command)	3-Wire (FWD/REV)	3-wire control (forward/reverse command). ON: Reverse; OFF: Forward. When the parameter is set to 26 , terminal S1 and terminal will become operation command and stop command respectively, and their original functions will be closed.	0	0	0
27	Local/ Remote Selection	Local/Remote	ON: Local mode (via the digital operator) OFF: Frequency command and operation command will be determined according to the setting of parameter (00-02 and 00-05)	0	0	0
28	Remote Mode Selection	Remote Mode Sel	ON: RS-485 communication OFF: Control circuit terminal	0	0	0
29	Jog Frequency Selection	JOG Freq Ref	ON: Selection jog frequency command	0	0	0
30	Acceleration/ Deceleration Setting Command 2	Acc/Decel Time Selection 2	Acceleration/deceleration time selection command2	0	0	0
31	Inverter Overheating Warning (OH2)	Overheat Alarm	ON: Inverter overheat alarm (OH2) input(will display OH2)	0	0	0
32	Reserved	Reserved	Reserved	-	-	-
33	DC Braking	DC Brake Command	ON: Perform DC braking	0	0	0
34	Speed Search 2 (from Frequency Command)	Speed Search 2	ON: Search speed from set frequency	0	0	0
35	Timing Function Input	Timer Input	.Set the time function at 03-33, 03-34 .Set the time function output at 03-11, 03-12	0	0	0
36	PID Soft Start Disable	PID SFS Disable	ON: PID slow-start off	0	0	0
37~40	Reserved	Reserved	Reserved	-	-	-
41	PID Sleep	PID Sleep	ON: PID Sleep	0	0	0
42~46	Reserved	Reserved	Reserved	-	-	-
47	Fire Mode (Forced to Run Mode)	Fire Mode	ON: Turn off hardware and software fault or alarm protection (a special application of HVAC)	0	0	0
48	KEB Acceleration	KEB Accel.	ON: KEB acceleration start	0	X	X
49	Parameters Write-in Allowed	Write Enabled	ON: All parameters are writable. OFF: Except reference frequency (00-05) all parameters are write-protected.	0	0	0
50	Unattended Start Protection (USP)	USP	ON: After power is input , the inverter ignores the operation command OFF: After power is input , the inverter will return the operation status before power is cut off.	0	0	0
51~52	Reserved	Reserved	Reserved	-	-	-

Value	Function		Description	Control mode		
	Name	LCD Display		V/F	SLV	PM SLV
53	2-Wire Self Holding Mode (Stop Command)	2-Wire (STOP)	2-Wire Self Holding Mode (ON: Stop Command).	○	○	○
54	Switch PID1 and PID2	PID 2 Enable	ON: PID1 enabled OFF: PID2 enabled	○	○	○
55	RTC Time Enable	RTC Timer Switch	ON:RTC Time Function Enabled	○	○	○
56	RTC Offset Enable	Offset Time Switch	ON:RTC Offset Enabled	○	○	○
57	Forcing Frequency Run	Force Freq Cmd	ON: Run on Forcing Frequency (23-28) OFF: Determine frequency reference and run command depending on the setting of parameter (00-02 and 00-05)	○	○	○
58	Run Permissive Function	Safety Function	ON: Stop on the setting of 08-30	○	○	○

03-0X =00: 2-wire control: forward operation

03-0X =01: 2-wire control: reverse operation. Refer to the 2-wire operation mode in Figure 4.3.1.

03-0X =02: Multi-speed setting command 1.

03-0X =03: Multi-speed setting command 2.

03-0X =04: Multi-speed setting command 3.

03-0X =05: Multi-speed setting command 4.

03-0X =29: Jog frequency selection (setting =29).

Select frequency reference using the multi-function digital input.

Table 4.4.5 Multi-speed operation selection

Speed	Multi-function digital input (S1 ~ S6) ^{*3}					Frequency selection
	Jog frequency reference	Multi-speed frequency 4	Multi-speed frequency 3	Multi-speed frequency 2	Multi-speed frequency 1	
1	0	0	0	0	0	Frequency command 1 (05-01) or main speed frequency ^{*2}
2	0	0	0	0	1	Auxiliary speed frequency or frequency reference 2 (06-01)
3	0	0	0	1	0	Frequency command 3 (06-02)
4	0	0	0	1	1	Frequency command 4 (06-03)
5	0	0	1	0	0	Frequency command 5 (06-04)
6	0	0	1	0	1	Frequency command 6 (06-05)
7	0	0	1	1	0	Frequency command 7 (06-06)
8	0	0	1	1	1	Frequency command 8 (06-07)
9	0	1	0	0	0	Frequency command 9 (06-08)
10	0	1	0	0	1	Frequency command 10 (06-09)
11	0	1	0	1	0	Frequency command 11(06-10)
12	0	1	0	1	1	Frequency command 12 (06-11)
13	0	1	1	0	0	Frequency command 13 (06-12)
14	0	1	1	0	1	Frequency command 14(06-13)
15	0	1	1	1	0	Frequency command 15 (06-14)
16	0	1	1	1	1	Frequency command 16 (06-15)
17	1 ^{*1}	—	—	—	—	Jog frequency command (00-18)

0: OFF, 1: ON, —: Ignore

*1. Jog frequency terminal has a higher priority than multi-speed reference 1 to 4.

*2. When parameter 00-05=0 (frequency reference input = digital operator), multi-speed frequency 1 will be set by 05-01 frequency reference setting1). When parameter 00-05=1 (frequency reference input=control circuit terminal), multi-speed frequency command 1 is input through analog command terminal AI1 or AI2).

*3. Multi-speed operation is disabled when PID is enabled.

Wiring Example: Fig. 4.4.14 and 4.4.15 show an example of a 9-speed operation selection.




Figure 4.4.14 Control Terminal Wiring Example




Figure 4.4.15 9-speed timing diagram

*1. When 00-05=1, multi-speed frequency reference is set by analog input AI1 or AI2.

03-0X =06: Forward jog run command, uses jog frequency parameter 00-18.

Notes:

- Jog command has a higher priority than other frequency reference commands.
- Jog command uses stop mode set in parameter 07-09 when Jog command is active > 500ms.

03-0X =07: Reverse jog run command, uses jog frequency parameter 00-18.

Notes:

- Jog command has a higher priority than other frequency reference commands.
- Jog command uses stop mode set in parameter 07-09 when Jog command is active > 500ms.

03-0X =08: UP frequency command; set parameter 00-05 Frequency command to 2 to activate. Refer to parameter 11-56 for UP/DOWN mode.

03-0X =09: Down frequency command; set parameter 00-05 Frequency command to 2 to activate. Refer to parameter 11-56 for UP/DOWN mode.

Note: UP/DOWN frequency command follows standard acceleration and deceleration times Tacc1 / Tdec1 (00-14, 00-15) or Tacc2 / Tdec 2 (00-16, 00-17) and requires both UP and DOWN functions 08 and 09 to be programmed to the digital input terminals.

Note: SE02 DI terminal Error will be displayed when:

- When only the UP or DOWN command function is programmed to the digital inputs.
- When both UP and DOWN command are activated simultaneously.

For the examples of UP/DOWN control wiring and operation, please refer to Figure 4.4.16 and 4.4.17.




Figure 4.4.16 UP/DOWN wiring and operation example




Figure 4.4.17 Up / Down command timing diagram

UP / DOWN Command Operation

When the Forward Run command is active and the UP or Down command is momentarily activated the inverter will accelerate the motor up to the lower limit of the frequency reference (00-13).

When using the UP / Down command, the output frequency is limited to the upper limit of frequency reference (00-12) and the lower limit of frequency reference (00-13).

The UP / DOWN command uses acceleration 1 or 2 / deceleration time 1 or 2 for normal operation Tacc1 / Tdec1 (00-14, 00-15) or Tacc2 / Tdec 2 (00-16, 00-17).

Refer to 03-40 UP/ DOWN frequency width setting for using other functions of UP/ DOWN. (It is enabled in inverter software V1.4)

Frequency reference retention is active when parameter 11-58 is set to 1 and the frequency reference is saved when power is lost and retrieved when power is restored.

- (1). When 11-58 = 1 and the operation command is active, the output frequency will accelerate to the previously stored frequency command.

(2). When 11-58 = 0 and the operation command is active, the output frequency will accelerate to the lower limit of frequency reference (00-13).

03-0X =10: Acceleration/deceleration 1 selection

03-0X =30: Acceleration/deceleration 2 selection

Refer to the "multi-function digital input terminals select acceleration/ deceleration time" in Table 4.4.1 and Figure 4.4.6.

03-0X =11: Inhibit acceleration/deceleration command (hold command)

When activated suspends the acceleration / deceleration operation and maintains the output frequency at current level.

If 11-58 = 1, the frequency reference value is saved when the acceleration/deceleration inhibit command is active. Deactivating the acceleration / deceleration inhibit command resumes acceleration / deceleration.

If 11-58 = 0, the frequency reference value is saved when the acceleration/deceleration inhibit command is active and even when powering down the inverter.

Refer to Fig.4.4.18. as an example.




Figure 4.4.18 Inhibit acceleration / deceleration command operation

*1. When 11-58 = 1, and acceleration / deceleration inhibit command is activated, the frequency reference is stored even when powering down the inverter. When a run command is given (e.g. run forward) and the acceleration / deceleration inhibit command is active, the inverter will accelerate to the previously stored frequency reference.

*2. When 11-58 = 0, and a run command is and the acceleration / deceleration inhibit command is active, the frequency reference and output frequency will remain at zero.

03-0X =12: Main/Alternative Run command Switching

Run command source is set by alternative run command (00-03) when function terminal is active. When function terminal is set to 27 (Local/ Remote control selection), the priority will higher than the switch of main/ alternative run command.

03-0X =13: Main/Alternative Frequency Command Switching

Frequency command source is set by alternative frequency command (00- 06) when function terminal is

active. When function terminal is set to 27 (Local/ Remote control selection), the priority will higher than the switch of main/ alternative frequency command.

03-0X =14: Emergency stop (decelerate to zero and stop)

Refer to the "deceleration time of emergency stop" of parameter 00-26.

03-0X =15: External Baseblock Command (coast to stop)

Execute the base block command by the use of ON / OFF way of multi-function digital input terminal, and prohibit the inverter output.

During run: When an external base block command is activated, the keypad displays "BBn BaseBlock (Sn)", indicating the inverter output is turned off (n indicates the digital input number 1 – 6). Upon removing the base block signal, the motor will run at the frequency reference. If speed search from frequency reference is active the inverter output frequency starts from the frequency reference and searches for the coasting motor speed and continue to operate. If speed search is not active the output frequency starts at 0Hz.

During deceleration: When an external base block command is activated, the keypad displays "BBn BaseBlock (Sn)", indicating the inverter output is turned off (n indicates the digital input number 1 – 6). Upon removing the base block signal, the motor is stopped or will coast to a stop and the inverter will remains in the stop condition.

During acceleration: When an external base block command is activated, the keypad displays "BBn BaseBlock (Sn)", indicating the inverter output is turned off (n indicates the digital input number 1 – 6). Upon removing the base block signal, the motor will run at the frequency reference. If speed search from frequency reference is active the inverter output frequency starts from the frequency reference and searches for the coasting motor speed and continue to operate. If speed search is not active the output frequency starts at 0Hz.




Figure 4.4.19 External base block operation

03-0X =16: PID control disable.

03-0X =17: Fault reset

The output becomes active when the inverter trips on a fault. Upon an inverter fault the inverter output will turn off (base block) and the keypad displays the dedicated fault message.

When fault occurs, the following actions can be used to reset the fault:

1. Program one of the multi-function digital inputs (03-00 to 03-05) to 17 (reset fault) and active input.*
2. Press the reset key of the digital operator (RESET).*
3. Recycle power to the inverter. **Important Note:** If a run command is active during power-up, the

inverter will start running automatically.

* To reset an active fault the run command has to be removed.

03-0X =19: Speed Search 1 (from the maximum frequency).

03-0X =34: Speed Search 2 (from the frequency command).

Refer to the "speed search" function in the parameter group 7 (start/ stop control function).

03-0X =20: Energy saving enabled

Manual energy savings function is set with parameters 11-12 and 11-18.

For the manual energy saving operation refer to Figure 4.3.78.

03-0X =21: PID integral reset

03-0X =25: External fault

Activating the external fault input will turn off the inverter output and the motor will coast to a stop. The keypad displays the external fault message "EFn Ext. Fault (Sn)", where n is the input terminal number.

03-0X =27: Local / Remote selection.

Switch the inverter frequency reference source between Local (keypad) or Remote (control circuit terminals or RS485). Use parameter 00-05 (Main frequency command source selection) and 00-02 (Run command selection) to select the remote source.

Note: In 3-wire operation terminal S1 and S2 are reserved for run/stop operation and the Local / Remote function can only be set to digital input terminals S3 to S6 (03-02 to 03-05).

Note: To switch between local and remote the inverter has to be stopped.

Input	Mode	Frequency Reference / Run/Stop Command Source
ON	Local	- Frequency reference and Run-Stop from keypad. - LEDs SEQ and REF are off.
OFF	Remote	- Frequency reference source selected by parameter 00-05 and Run-Stop source selected by parameter 00-02. - LEDs SEQ and REF are on.

03-0X =28: Remote mode selection

Switch between terminal source and communication (RS-422/RS-485) source for frequency reference and operation command.

In Remote mode, indicators of SEQ and REF are on; you can use terminals AI1 and AI2 to control the frequency command, and use terminals S1, S2 or communication terminal RS-485 to control the operation command.

Input	Mode	Frequency Reference / Run/Stop Command Source
ON	Communication	- Frequency reference and run/stop command control via communication (RS-422/RS-485).
OFF	Terminal	- Frequency reference source from AI1 / AI2 input (00-05=1) and Run-Stop command from terminals S1 / S2 (00-02=1).




Figure 4.4.20 Remote mode operation selection

To switch the frequency reference and operation command input between communication RS-485 and control terminals the following parameters have to be set:

1. 00-05=1 (use control terminal AI1 or AI2 as reference frequency source)
2. 00-02=1 (use control terminal S1 or S2 for operation command)
3. Set one of the digital input terminals (03-02 to 03-05) to 28 (Operation selection of remote mode)

03-0X =24: PLC Input

It is required to match Drive Link program. Ladder diagram is edited in the PLC program. When the message output is conducted, this message will be sent to the inverter.

03-0X =26: 3-Wire Sequence (Forward/ Reverse Command)

When the digital input terminals (S3~S6) is set to 26, terminal S1 and S2 will become the run command and stop command. Refer to Fig.4.4.2.

03-0X =29: Jog Frequency Selection

When 00-18 (Jog Frequency) is set up, the inverter depends on this frequency for command when it is ON.

03-0X =30: Acceleration/ Deceleration Setting Command 2

When it is ON, the inverter will be active depends on the acceleration time 2 of 00-16 and deceleration time 2 of 00-17.

03-0X =31: Inverter overheat warning

When input is active the inverter displays warning message "OH2" and continues operation. Deactivating the input reverts back to the original display. Warning message does not require resetting the inverter.

03-0X =33: DC braking

When input is active DC-Injection braking is enabled during start and stopping of the inverter. DC Injection braking is disabled when a run or jog command is active. Refer to the DC braking time diagram in Fig.4.4.21.




Figure 4.4.21 DC braking timing diagram

03-0X =35: Timing function

Refer to the "time function" parameter 03-37 and 03-38.

03-0X =36: PID Soft start disable

Refer to the "PID Control" function of PID function parameter group 10.

03-0X =47: Fire mode (Forced to operation mode)

When input is active disables all inverter warning and hardware (exclusive of SC) protections. This function is commonly used in commercial applications where the inverter controls an exhaust fan and needs run to destruction in case of a fire.

03-0X =48: KEB acceleration

When input is active enables KEB (Kinetic Energy Braking) during acceleration. Refer to the parameter description of 11-47 and 11-48. Note: To enable set parameter 11-47 to a value greater than 0.

03-0X =49: Parameters write-in allowed

When input is active allows parameter to be changed.

Note: When none of the digital input terminals are set to function 49, parameter write-in protection is controlled by parameter 13-06.

Input	Parameter Save
ON	Parameters Write Enabled
OFF	Parameters Write Protected

03-0X =50: Unattended Start Protection (USP)

When input is active prevents inverter from starting automatically when a run command is present at time of power-up. Please refer to Fig.4.4.21a for more details.




Figure 4.4.21a Unattended Start Protection

03-0X =53: 2-Wire Self Holding Mode (Stop Command).

Refer to the “2-wire operation with hold function” of parameter 00-02.

03-0X =54: Switch PID1 and PID2

It will switch PID1 to PID2 when PID2 is ON.

03-0X =55: RTC Time Enable

When 16-13 (RTC timer function) = 2 (DI setting) and RTC Time Enable is ON, RTC timer function is enabled.

03-0X =56: RTC Offset Enable

When 16-30 (Selection of RTC Offset) = 2 (DI setting) and RTC Offset Enable is ON, the inverter will run depending on RTC offset time setting (16-31).

03-0X =57: Forced Frequency Run

This function enables with the corresponding of parameter of 23-28 and the source of frequency command of parameter 00-05 set to the value of 5 (PID given, namely the parameter of 10-03 needs to be active).

When any one of the multi-function digital input terminal (S1~S6) is set to the value of 16 (the interdiction of PID function), pump will not depend on feedback to do any PID output adjustment; simultaneously another one is set to the value of 57 (forced frequency run) and inverter will have the frequency run setting depending on the parameter of 23-28. Inverter will stop output when digital input terminals (S1~S6) are removed.

This function is applied to inverter output being controlled by external pressure sensor (eg. differential pressure switch) when pressure sensor disconnects.

03-0X =58: Run Permissive Function

When digital input terminal enables, inverter will stop via the set of parameter 08-30 after Run Permissive Function function is active.

03- 08	(S1~S6) DI Scan Time
Range	【0】 Scan Time 4ms 【1】 Scan Time 8ms

Set the digital input CPU scan time. The digital input signal needs to be present for the minimum scan time to qualify as an enabled command.

Note: For noisy environments select scan time of 8ms (results in a slower response time).

03- 09	Multi-function Terminal S1-S4 Type Selection
Range	【xxx0b】 : S1 A contact 【xx1b】 : S1 B contact 【xx0xb】 : S2 A contact 【xx1xb】 : S2 B contact 【x0xxb】 : S3 A contact 【x1xxb】 : S3 B contact 【0xxxb】 : S4 A contact 【1xxxb】 : S4 B contact

03- 10	Multi-function Terminal S5-S6 Type Selection
Range	【xxx0b】 : S5 A contact 【xx1b】 : S5 B contact 【xx0xb】 : S6 A contact 【xx1xb】 : S6 B contact

Parameter 03-09 and 03-10 selects the digital input type between a normally open and a normally closed switch/contact.

Each bit of 03-09/03-10 presents an input :

03-09= 0 0 0 0 0 : normally open switch
 s4 s3 s2 s1 1 : normally closed switch

03-10= x x 0 0 0 : normally open switch
 s6 s5 1 : normally closed switch

Example: S1 and S2 wired to a normally closed contact / switch set 03-09=0011.



Do not set the operation command parameter 00-02 to terminal control before setting the digital input type. Failure to comply may cause death or serious injury.

03-11	Relay (R1A-R1C) Output	
03-12	Relay (R2A-R2C) Output	
03-39	Relay (R3A-R3C) Output	
Range	<p> 【0】 : During Running 【1】 : Fault Contact Output 【2】 : Frequency Agree 【3】 : Setting Frequency Agree (03-13±03-14) 【4】 : Frequency Detection 1 (> 03-13, Hysteresis interval is the setting value of 03-14) 【5】 : Frequency Detection 2 (< 03-13, Hysteresis interval is the setting value of 03-14) 【6】 : Automatic Restart 【7】 ~ 【8】 : Reserved 【9】 : Baseblock 【10】 ~ 【11】 : Reserved 【12】 : Over-Torque Detection 【13】 : Current Agree 【14】 ~ 【17】 : Reserved 【18】 : PLC Status 【19】 : PLC Control 【20】 : Zero Speed 【21】 : Inverter Ready 【22】 : Undervoltage Detection 【23】 : Source of Operation Command 【24】 : Source of Frequency Command 【25】 : Low Torque Detection 【26】 : Frequency Reference Missing 【27】 : Timing Function Output 【28】 ~ 【31】 : Reserved 【32】 : Communication Control Contacts 【33】 : RTC Timer 1 【34】 : RTC Timer 2 【35】 : RTC Timer 3 【36】 : RTC Timer 4 【37】 : Detection Output of PID Feedback Loss 【38】 : Brake Release </p>	<p>*1</p> <p>*1</p> <p>*1</p>

*1: It is new added in inverter software V1.4.




Figure 4.4.22 Multi-function digital output and related parameters

Table 4.4.6 Description of multi-function digital output

Value	Function		Description	Control Mode		
	Name	LCD Display		V/F	SLV	PM SLV
0	During Running	Running	ON: During running (Run Command is ON)	○	○	○
1	Fault Contact Output	Fault	ON: Fault contact output (except CF00 and CF01)	○	○	○
2	Frequency Agree	Freq. Agree	ON: Frequency agree (frequency agree width detection is set by 03-14)	○	○	○
3	Setting Frequency Agree	Setting Freq Agree	ON: Output frequency = allowed frequency detection level (03-13) ± frequency bandwidth (03-14)	○	○	○
4	Frequency Detection 1	Freq. Detect 1	ON: Output frequency > 03-13, Hysteresis interval is the setting value of 03-14 ON: Output frequency > 03-13, Hysteresis interval is the setting value of 03-14	○	○	○
5	Frequency Detection 2	Freq. Detect 2	OFF: During acceleration: Output frequency ≥ 03-13 + 03-14 ON: During deceleration: Output frequency < 03-13	○	○	○
6	Automatic Restart	Auto Restart	ON: the period of automatic restart	○	○	○
7~8	Reserved	Reserved	Reserved	-	-	-
9	Baseblock	Baseblock	ON: During baseblock	○	○	○
10~11	Reserved	Reserved	Reserved	-	-	-
12	Over-Torque Detection	Over Torque	ON: Over torque detection is ON	○	○	○
13	Current Agree	Current Agree	ON: Output current > 03-15	○	○	○
14~17	Reserved	Reserved	Reserved	-	-	-
18	PLC Status	PLC statement	ON: when 00-02 is set to 3 (PLC operation command source)	○	○	○
19	PLC Control	Control From PLC	ON: Control from PLC	○	○	○
20	Zero Speed	Zero Speed	ON: Output frequency < Minimum output frequency (Fmin)	○	○	○
21	Inverter Ready	Ready	ON: Inverter ready (after power on, no faults)	○	○	○
22	Undervoltage Detection	Low Volt Detected	ON: DC bus voltage = < Low-voltage warning detection level (07-13)	○	○	○

Value	Function		Description	Control Mode		
	Name	LCD Display		V/F	SLV	PM SLV
23	Source of Operation Command	Run Cmd Status	ON: Operation command from LED digital operator (local mode)	○	○	○
24	Source of Frequency Command	Freq Ref Status	ON: Reference frequency from LED digital operator (local mode)	○	○	○
25	Low Torque Detection	Under Torque	ON: Low-torque detection is ON	○	○	○
26	Frequency Reference Missing	Ref. Loss.	ON: Reference frequency loss	○	○	○
27	Timing Function Output	Timer Output	Set time function parameter to 03-33 and 03-34 , and the time function input is set by parameter from 03-00 and 03-05	○	○	○
28~31	Reserved	Reserved	Reserved	-	-	-
32	Communication Control Contacts	Control From Comm	ON: DO is set by communication control.	○	○	○
33	RTC Timer 1	RTC Timer 1	ON: 16-36 (RTC Speed Selection) selects Timer 1 and 16-32 (Source of Timer 1) is active in the set time.	○	○	○
34	RTC Timer 2	RTC Timer 2	ON: 16-36 (RTC Speed Selection) selects Timer 2 and 16-33 (Source of Timer 2) is active in the set time.	○	○	○
35	RTC Timer 3	RTC Timer 3	ON: 16-36 (RTC Speed Selection) selects Timer 3 and 16-34 (Source of Timer 3) is active in the set time.	○	○	○
36	RTC Timer 4	RTC Timer 4	ON: 16-36 (RTC Speed Selection) selects Timer 4 and 16-35 (Source of Timer 4) is active in the set time.	○	○	○
37	Detection Output of PID Feedback Loss	PID Fbk Loss	ON: PID Feedback Loss	○	○	○
38	Brake Release	Brake Release	ON: Brake Release	X	○	X

03-1X=0: During Running

OFF	Run command is OFF and the inverter is stopped.
ON	Run command is ON or output frequency is greater than 0.

03-1X=1: Fault contact output

Output is active during fault condition.

Note: Communication error (CF00, CF01) do not activate the fault contact.

03-1X=2: Frequency Agree

Output is active when the output frequency falls within the frequency reference minus the frequency detection width (03-14).

03-1X=3: Setting Frequency Agree

Output is active when the output frequency falls within the frequency detection width (03-14) of the set frequency detection level (03-13).

03-1X=4: Frequency detected 1

Output is active when the output frequency rises above the frequency detection level (03-13) + frequency detection width (03-14) and deactivates when the output frequency falls below frequency detection level (03-13).

03-1X=5: Frequency detected 2

Output is active when the output frequency is below the frequency detection level (03-13) + frequency detection width (03-14) and turns off when the output frequency falls below frequency detection level.

03-1X=6: Automatic restart.

Output is active during an auto-restart operation.

03-1X=9: Baseblock (B.B.)

Output is active when the inverter output is turned off during a Baseblock command.

03-1X=12: Over torque detected (Normally Open)

Output is active during an over torque detection see parameters 08-13 ~ 08-16.

03-1X=25: Low torque detected (Normally Open)

Output is active during low torque detection see parameters 08-17 ~ 08-20.

03-1X=13: Current Agree

When the output current is larger than that in 03-15 and its duration is higher than that in 03-16, this function will be ON.

03-1X=18: PLC status (setting =18)

Output is active when operation command parameter (00-02) is set to 3: PLC Control.

03-1X=19: PLC control contact

Output is controlled by the PLC logic

03-1X=20: Zero-speed

Output is active during zero-speed

Active	Output frequency \geq minimum output frequency (01-08, Fmin)
Off	Output frequency is \leq the minimum output frequency




Figure 4.4.23 Zero-speed operation

03-1X=21: Inverter Ready

Output is active when no faults are active and the inverter is ready for operation.

03-1X=22: Undervoltage Detection

Output is active when the DC bus voltage falls below the low voltage detection level (07-13).

03-1X=23: Source of operation command

Output is active in local operation command.

OFF	Remote mode: 00-02 = 1 or 2, or any one of the multi-function digital input terminals (S1 to S6) set to function 5 (LOCAL / REMOTE control) is OFF. SEQ LED of the keypad is ON.
ON	Local mode: 00-02 = 0, or any one of the multi-function digital input terminals (S1 to S6) set to function 5 (LOCAL / REMOTE control) is active. SEQ LED of the keypad is OFF.

03-1X=24: Source of frequency command

Output is active in local frequency command.

OFF	Remote mode: 00-05 = 1 or 2, or any one of the multi-function digital input terminals (S1 to S6) set to function 5 (LOCAL / REMOTE control) is OFF. REF LED of the keypad is ON.
ON	Local mode: 00-05 = 0, or any one of the multi-function digital input terminals (S1 to S6) set to function 5 (LOCAL / REMOTE control) is active. REF LED of the keypad is OFF.

03-1X=26: Frequency reference missing

Output is active when the frequency reference is lost. When parameter 11-41 is set to 0 the inverter will decelerate to a stop. When parameter 11-41 is set to 1 operation will continue at the value of parameter 11-42 times the last know frequency reference.

03-1X=27: Time function output

Output is controlled by timer function see parameter 03-37 and 03-38.

03-1X=32: Communication control contacts

Output is active when communication control is active.

03-1X=37: Detection Output of PID Feedback Loss

When PID feedback loss occurs (refer to parameters setting 10-11~10-13), this function will be ON.

03-1X=38: Brake Release

When this function is ON, Break release is enabled. Refer to parameters descriptions of 03-41~03-42.

03-13	Frequency Detection Level
Range	【0.0~400.0】 Hz 【0.0~1200.0】 Hz (when 00-31 = 1)
03-14	Frequency Detection Width
Range	【0.1~25.5】 Hz

Frequency Detection Level: set the multi-function output terminals R1A-R1C, R2A-R2C or R3A-R3C to the desired detection level and bandwidth for use with multi-function output functions 2 to 5.

The time charts for the Frequency Agree Detection operation are shown in the following Table 4.4.7.

Table 4.4.7 Frequency Detection Operation

Function	Detection operation of frequency confirmation	Description
Frequency agree		<ul style="list-style-type: none"> If output frequency is higher than the value of Frequency Detection Level (03-13) + Frequency Detection Width (03-14), the signal of output frequency detection 1 is ON. If output frequency is lower than Frequency Detection Level (03-13), the signal of output frequency detection 1 is OFF. If output frequency falls the value between (03-13) and (03-13) + (03-14), the signal of output frequency detection 1 is the same as the previous value. Any of the digital outputs function (03-11, 03-12 or 03-39) can be set to 4 (Output Frequency Detection 1).
Set frequency agree		<ul style="list-style-type: none"> If output frequency is higher than the value of Frequency Detection Level Width (03-13) + Frequency Detection Width (03-14), the signal of output frequency detection 1 is OFF. If output frequency is lower than Frequency Detection Level (03-13), the signal of output frequency detection 1 is ON. If output frequency falls the value between (03-13) and (03-13) + (03-14), the signal of output frequency detection 2 is the same as the previous value. Any of the digital outputs function (03-11, 03-12 or 03-39) can be set to 5 (Output Frequency Detection 2).
Output frequency detection 1		<ul style="list-style-type: none"> Output is active when the output frequency rises above the frequency detection level (03-13) + frequency detection width (03-14) and deactivates when the output frequency falls below frequency detection level (03-13). Any of the digital outputs function (03-11, 03-12 or 03-39) can be set to 4 (Output frequency detection 1).


Function	Detection operation of frequency confirmation	Description
Output frequency detection 2		<ul style="list-style-type: none"> Output is active when the output frequency is below the frequency detection level (03-13) + frequency detection width (03-14) and turns off when the output frequency falls below frequency detection level. Any of the digital outputs function (03-11, 03-12 or 03-39) can be set to 5 (Output frequency detection 2).

03-15	Current Agree Level	*1
Range	【0.1~999.9】 A	
03-16	Delay Time of Current Agree Detection	*1
Range	【0.1~10.0】 Sec	

*1: It is new added in inverter software V1.4.

- **03-11=13** : Relay is active when output current is larger than that in 03-15.
- **03-15** : The setting value (**0.1~15.0**) depends on motor rated current.
- **03-16** : The unit of the setting value (**0.1~10.0**) is second. The delay time of relay signal from ON to OFF is 100ms (constant).

Timing Diagram:



03-19	Relay (R1A-R3C) Type	
Range	【xxx0b】 : R1 A contact	【xxx1b】 : R1 B contact
	【xx0xb】 : R2 A contact	【xx1xb】 : R2 B contact
	【x0xxb】 : R3 A contact	【xx1xb】 : R3 B contact

Parameter 03-19 selects the digital output type between a normally open and a normally closed contact.
Each bit of 03-19 presents an output :

03-19= 0 0 0 0 **0**: normally open contact
 R3 **R2** **R1** **1**: normally close contact

Example: R1 normally closed and R2 normally open contact set 03-19=xx001.

03- 27	UP/DOWN Frequency Hold/ Adjust Selection
Range	【0】 : Keep UP/DOWN frequency when stopping. 【1】 : Clear UP/DOWN frequency when stopping. 【2】 : Allow frequency UP/DOWN when stopping. 【3】 : Refresh frequency at acceleration.

03-27=0: When the run command is removed the UP/DOWN frequency reference before deceleration is stored. The next time the run command is applied the output frequency will ramp up to the previously stored frequency reference.

03-27=1: When the run command is removed the UP/DOWN frequency reference command is cleared (set to 0). The next time the run command is applied the output frequency will start at 0.

03-27=2: UP/DOWN command is active when run command is not active.

03-27=3: Keep the state of frequency command not to be cleared. When Run Command re-sends, press UP/DOWN key before the run frequency reaches the frequency command, press UP/ DOWN key, then:

- When 03-40 = 0, Frequency Command is set by Run Frequency.
- When 03-40 ≠ 0, Frequency Command is set by the values of Run Frequency plus the setting frequency of 03-40.

03- 30	Pulse Input Selection	*1
Range	【0】 : Common Pulse Input 【1】 : PWM (Pulse Width Modulation)	

*1: It is new added in inverter software V1.4.

There are two modes in pulse input selection:

03-30=0: Common Pulse Input

Pulse Input (PI) = the selected frequency divided by pulse input scaling (set by 03-31), corresponding to the maximum output frequency of motor 1 (01-02).

Note: Monitor parameter 12-79 (pulse input percentage) displays the proportional relationship between input signal and 03-31 (pulse input scaling).

03-30=1: PWM (Pulse Width Modulation)


It is required to input the correct frequency.

PWM= posedge pulse time divided by previous pulse time period, corresponding to the maximum output frequency of motor 1 (01-02).


Note: Monitor parameter 12-79 (pulse input percentage) displays the proportional relationship between the positive edge of input signal and time period.

Note: Tolerance range of pulse time period in PWM modes is ±12.5%. If it is over than the range, it is inactive.

Diagram of pulse input selection:



$$\text{Pulse Input Command} = \frac{\text{Frequency}}{\text{Scaling factor (using 03-31)}} \times 100\%(01-02)$$



$$\text{Pulse Input Command} = \frac{T1:\text{Period}}{T:\text{Period}} \times 100\%(01-02)$$

03-31	Pulse Input Scaling
Range	【50~32000】 Hz

Pulse input scaling, 100% = Maximum pulse frequency.

03-32	Pulse Input Gain
Range	【0.0~1000.0】 %

Target value (03-03) in % = Pulse input frequency scaled to 100% based on maximum pulse frequency (03-31) times the gain (03-32) + bias (03-33).

03-33	Pulse Input Bias
Range	【-100.0~100.0】 %

Target value (03-03) in % = Pulse input frequency scaled to 100% based on maximum pulse frequency (03-31) times the gain (03-32) + bias (03-33).

03-34	Pulse Input Filter Time
Range	【0.00~2.00】 Sec

* Refer to Fig.4.4.24 for the pulse input specification.




Figure 4.4.24 Pulse input adjustment

Set Pulse Input Setup as Flow Meters Input

Set parameter 23-45 (Given Modes of Flow Meters Feedback) to 2 (Pulse Input) to use the pulse input terminal PI as the flow meters input. Refer to the description of parameter group 23 for details. Next set the pulse input scaling (03-31), enter the pulse input frequency to match the maximum output frequency. Adjust the pulse input filter time (03-34) in case interference or noise is encountered.

03- 37	Timer ON Delay (DI/DO)
Range	【0.0~6000.0】 Sec
03-38	Timer OFF Delay (DI/DO)
Range	【0.0~6000.0】 Sec


Enable the timer function by setting one of multi-function input parameters 03-00~03-05 (S1 to S6) to 35 (timer function input) and one of multi-function output parameters 03-11, 03-12, 03-39 (R1A-R1C to R3A-R3C) to 27 (timer function output).

The timer function can be used to implement a timer relay. Use timing parameter 03-37 and 03-38 to set the timer ON / OFF delay.

Timer output is turned ON when the multi-function timer input is ON for the time specified in parameter 03-37.

Timer output is turned OFF after the multi-function timer input is OFF for the time specified in parameter 03-38.

Timing example:




03- 40	Up/down Frequency Width Setting	*1
Range	【0.00~5.00】 Hz	

*1: It is new added in inverter software V1.4.


For example: Set terminal S1 : 03- 00= **【8】** (Up Frequency Increasing Command), S2 : 03- 01= **【9】** (DOWN Frequency Decreasing Command) and 03- 39= **【Δ】** Hz.

Mode1: When 03-39 is set to 0Hz, it will maintain the original **up/down** function, shown as Fig. 4.4.20.

Mode2: When 03-39 is not set to 0Hz and terminal conduction time is lower than 2 sec, conducting one time leading to frequency variation Δ Hz (setting frequency by 03-40) ◦



Mode3: When 03-39 is not set to 0Hz and terminal conduction time is larger than 2 sec, frequency variation depends on acceleration/ deceleration.



Notes:

△H1: setting frequency increment in acceleration, t1: terminal conduction time in acceleration,
 △H2: setting frequency increment in deceleration, t2: terminal conduction time in deceleration.

$$\Delta H1 = \frac{\text{Upper Limit Frequency}}{\text{Acceleration Time 2}} \times \text{Terminal Conduction Time (t1)}$$

$$\Delta H2 = \frac{\text{Lower Limit Frequency}}{\text{Deceleration Time 2}} \times \text{Terminal Conduction Time (t2)}$$


03- 41	Torque Detection Level	*1
Range	【0~300】 %	
03-42	Delay Time of Braking Action	*1
Range	【0.00~65.00】 Sec	

*1: It is new added in inverter software V1.4.


Function of Brake Release:

It requires function of frquecny agree to use, shown as the following figure.

When output frequency is larger than frequency detection level (03-13) and output torque is larger than torque detection level (03-41) during Inverter operation, it will delay braking action delay time (03-42) and then release brake.



It is also recommended to be with the use of start and stop frequency locked function (11-43~11-46), shown as the following figure:



Group 04 External Analog Input and Output Parameters

04- 00	AI Input Signal Type
Range	【0】 : AI2 0~10V/0~20mA 【1】 : AI2 4~20mA/ 2~10V
04- 01	AI1 Signal Scanning and Filtering Time
Range	【0.00~2.00】 Sec
04- 02	AI1 Gain
Range	【0.0~1000.0】 %
04- 03	AI1 Bias
Range	【-100~100.0】 %
04- 05	AI2 Function Setting
Range	【0】 : Auxiliary Frequency 【1】 : Frequency Reference Gain 【2】 : Frequency Reference Bias 【3】 : Output Voltage Bias 【4】 : Coefficient of Acceleration and Deceleration Reduction 【5】 : DC Braking Current* 【6】 : Over-Torque Detection Level 【7】 : Stall Prevention Level During Running 【8】 : Frequency Lower Limit 【9】 : Jump Frequency 4 【10】 : Added to AI1 【11】 : Positive Torque Limit 【12】 : Negative Torque Limit 【13】 : Regenerative Torque Limit 【14】 : Positive / Negative Torque Limit 【15】 : Reserved 【16】 : Torque Compensation 【17】 : Reserved
04- 06	AI2 Signal Scanning and Filtering Time
Range	【0.00~2.00】 Sec
04- 07	AI2 Gain
Range	【0.0~1000.0】 %
04- 08	AI2 Bias
Range	【-100.0~100.0】 %

Refer to the followings for the details of parameter 04-00 (AI input signal type)

- ① AI2=0~10V, Set 04-00=0, tune SW2 on the control board to V.
- ② AI2=0~20mA, Set 04-00=0, tune SW2 on the control board to I.
- ③ AI2=4~20mA, Set 04-00=1, tune SW2 on the control board to I.
- ④ AI2=2~10V, Set 04-00=1 or 3, tune SW2 on the control board to V.

(1) Analog Input Level Adjustment AI1, AI2 (04-02, 04-03, 04-07, 04-08)

Each analog input AI1 and AI2 has a separate gain and bias parameter associated with it.

Analog input signal AI1 can be adjusted with parameter 04-02 and 04-03; Analog input signal AI2 can be adjusted with parameter 04-07 and 04-08. Refer to Fig.4.4.25.




Figure 4.4.25 Analog inputs and related parameters

Gain setting: Sets the level in % that corresponds to a 10V or 20mA signal at the analog input.

Bias setting: Sets the level in % that corresponds to a 0V or 4mA signal at the analog input.

Use both gain and bias setting to scale the input signal.




Figure 4.4.26 Gain and bias operations (for frequency reference signal)

(2) AI1 signal filtering time (04-01)

(3) AI2 signal filtering time (04-06)

All analog inputs (AI1, AI2) have a 1st order programmable input filter that can be adjusted when noise is present on each of the incoming analog signal to prevent erratic drive control.

The filter time constant (range: 0.00 to 2.00 seconds) is defined as the time that the input step signal reaches 63% of its final value.

Note: Increasing the filter time causes the drive operation to become more stable but less responsive to change to the analog input.




Figure 4.4.27 Filter time constant

(4) AI2 function setting (04-05)

AI2 is multi-function analog input terminal function selection. Refer to Table 4.4.8 for function overview

Table 4.4.8 Multi-function analog input list (04-05 setting)

Value	Function		Description	Control mode		
	Name	LCD Display		V/F	SLV	PM SLV
0	Auxiliary Frequency	AUX.Freq Ref	Max Output Frequency (01-02, Fmax) =100%	○	○	○
1	Frequency Reference Gain (FGAIN)	Freq Ref Gain	Aggregated gain = AI1 = 04-02 * FGAIN	○	○	○
2	Frequency Reference Bias (FBIAS)	Freq Ref Bias	Aggregated bias = AI1 = 04-03 * FBIAS	○	○	○
3	Output Voltage Bias (VBIAS)	Output Volt Bias	Aggregate output voltage = V/F curve voltage + VBIAS	○	X	○
4	Coefficient of Acceleration and Deceleration Reduction (K)	Tacc/Tdec Scaling	Actual acceleration and deceleration time = accel. and decal. time / K	○	○	○
5	DC Braking Current*	DC Inj Current	Adjust the DC braking current (0 ~ 100%) based on analog input. When the inverter rated current = 100%, DC braking current 07-07 is disabled.	○	○	○
6	Over-Torque Detection Level	Over Tq Level	Change over-torque detection level based on over-torque detection level, at this time, 08-15 is disabled.	○	○	○
7	Stall Prevention Level During Running	Run Stall Level	Adjust the action level (30% ~ 200%) of stall prevention in operation based on analog input. The inverter rated current =100%	○	X	○
8	Frequency Lower Limit	Ref. Low Bound	Adjust the lower limit (0 ~ 100%) of frequency command based on analog input, the maximum output = 100%. The lower limit of frequency command is the greater one of the actual frequency command's lower limit 00-13 or the multi-function analog input.	○	○	○
9	Jump Frequency 4	Jump Freq 4	Jump frequency 4. 100% = maximum output frequency	○	○	○

Value	Function		Description	Control mode		
	Name	LCD Display		V/F	SLV	PM SLV
10	Added to AI1	Add to AI1	Added to AI1. 100% = maximum output frequency	0	0	0
11	Positive Torque Limit	Positive Tq Limit	100% = Motor's rated torque	X	0	0
12	Negative Torque Limit	Negative Tq Limit	100% = Motor's rated torque	X	0	0
13	Regenerative Torque Limit	Regen. Tq Limit	100% = Motor's rated torque	X	0	0
14	Positive / Negative Torque Limit	+/- Tq Limit	100% = Motor's rated torque	X	0	0
15	Torque Limit	Tq Limit	100% = Motor's rated torque	X	X	X
16	Torque Compensation	Tq Compensation	100% = Motor's rated torque	X	0	X
17	Reserved	No Function	Reserved	0	0	0

04-05=0: Auxiliary frequency

When parameter 00-05 = 1 (main frequency from external control) the auxiliary speed reference frequency can be activated via the multi-speed input commands (see table 4.4.5). The auxiliary frequency command can be set via AI2. The maximum output frequency is set by 01-02, $F_{max} = 100\%$.

04-05=1: Frequency Reference Gain (FGAIN)

Multi-function analog input AI2 can be used to adjust the frequency reference gain of analog input AI1. The total frequency reference gain of terminal AI1 is the internal gain set by parameter 04-02 times FGAIN. The maximum frequency reference for AI1 is 100%.




Figure 4.4.28 Frequency gain adjustment

Example:

When the internal gain of AI1 (04-02) is set to 100% and AI2 to 5V (for example $FGAIN = 50\%$), the reference frequency of terminal AI1 will be 50%, as shown in Fig. 4.4.29.




Figure 4.4.29 Frequency reference gain adjustment (example)

04-05=2: Frequency Reference bias (FBIAS)

Multi-function analog input terminal AI2 can be used to adjust the frequency reference bias of AI1. The total frequency reference bias of terminal AI1 is the sum of internal bias set by parameter 04-03 and FBIAS. The maximum frequency reference for AI1 is 100%.




Figure 4.4.30 Bias adjustment

Example:

Terminal AI1 input is 0V, 04-02 = 100% (AI1 gain), 04-03 = 0% (AI1 bias) and terminal AI2 input is 3V. The reference frequency will be 30% as shown in Fig.4.4.31.




Figure 4.4.31 Frequency Reference bias adjustment (example)

04-05=3: Output Voltage Bias (VBIAS)

Multi-function analog input AI2 can be used to adjust the output voltage. The total output voltage of inverter is the sum of output voltage based on the selected V/F curve and VBIAS. The maximum output voltage is set by 01-03, $V_{max} = 100\%$.




Figure 4.4.32 Bias adjustment

04-05=4: Acceleration and deceleration coefficient (K)

Multi-function analog input AI2 can be used to adjust the acceleration and deceleration time coefficient. The actual acceleration and deceleration time is calculated as follows:

$$\text{Actual accel /decel time} = \frac{\text{Acceleration / Deceleration time (00-14 ~ 00-17, 00-21~ 00-24)}}{K}$$

Acceleration/ Deceleration time setting is 100% (00-14~00-17, 00-21~00-24).




Figure 4.4.33 Acceleration / deceleration time reduction coefficient

04-05=5: DC braking current

Multi-function analog input AI2 can be used to adjust the DC Injection braking current. DC braking current parameter 07-07 setting should be set to 0% to use this function. The inverter rated current = 100%

Note: When using the permanent magnet (PM) motor, there will be no options of setting 5.




Figure 4.4.34 DC braking current adjustment

04-05=6: Over-torque detection level

Multi-function analog input AI2 can be used to adjust the over-torque detection level.

100% of inverter rated current (V/F control mode)

100% motor rated torque (SLV control mode)

If the multi-function analog input is used to adjust the over-torque level, the internal over-torque detection level (08-15) is disabled.




Figure 4.4.35 Over-torque/less torque detection level adjustment

4-05=7: Stall prevention level during running

Multi-function analog input AI2 can be used to adjust the stall prevention level during operation. Inverter rated current = 100%. When AI2 is set to control stall prevention level (04-05 = 7) and parameter 08-03 (Stall prevention level during operation) is used, then the lesser of the two value becomes the active stall prevention level during operation.

Example: If the motor power is less than that of the inverter, the operation and the stall prevention of the motor will be based on the factory settings, multi-function analog input AI2 can be used to reduce the stall prevention level during operation.




Figure 4.4.36 Stall prevention level adjustment during operation

04-05=8: Frequency lower limit

Multi-function analog input AI2 can be used to adjust the lower limit of frequency reference. Maximum output frequency (F_{max} , 01-02) = 100%. The actual lower limit is determined by the maximum value of 00-13 (frequency lower limit) and level of the multi-function analog input AI2.




Figure 4.4.37 Adjustment of lower limit of frequency reference

04-05=9: Jump frequency 4

Multi-function analog input AI2 can be used to adjust Jump frequency 4.

Maximum output frequency (01-02, Fmax) = 100%. Setting 11-08 ~ 11-10 to 0.0Hz turns of the Jump frequency function.




Figure 4.4.38 Jump frequency 4 setting operation

04-05=10: Added to AI1

Multi-function analog input AI2 can be used as a bias level for analog input AI1.




Figure 4.4.39 Added to AI1 as a bias operation

Example:

04-02 (AI1 gain) = 100%, 04-03 (AI2 gain) = 0%, and terminal AI2 level is 2V. If input terminal AI1 is 0V, the internal reference frequency of terminal AI1 will be 20 %

04-05=11: Positive torque limit

Multi-function analog input AI2 can be used to adjust the positive torque limit.

04-05=12: Negative torque limit

Multi-function analog input AI2 can be used to adjust the negative torque limit.

04-05=13: Regenerative torque limit

Multi-function analog input AI2 can be used to adjust the regenerative torque limit.

04-05=14: Positive / negative torque limits

Multi-function analog input AI2 can be used to adjust both the positive and negative torque limit.

For more details on torque limits, please refer to parameter group 21 - torque control group.

04-05=15: Torque limit of speed control

Multi-function analog input AI2 can be used to adjust the torque limit in closed loop vector mode.

04-05=16: Torque compensation of speed control

Multi-function analog input AI2 can be used to adjust the torque compensation in closed loop vector mode.

For more details on the torque control functions, please refer to parameter group 21 - torque control group.

04-11	AO1 Function Setting
Range	<p> 【0】 : Output Frequency 【1】 : Frequency Command 【2】 : Output Voltage 【3】 : DC Voltage 【4】 : Output Current 【5】 : Output Power 【6】 : Motor Speed 【7】 : Output Power Factor 【8】 : AI1 Input 【9】 : AI2 Input 【10】 : Torque Command 【11】 : q-axis Current 【12】 : d-axis Current 【13】 : Speed Deviation 【14】 : Reserved 【15】 : ASR Output 【16】 : Reserved 【17】 : q-axis Voltage 【18】 : d-axis Voltage 【19】 ~ 【20】 : Reserved 【21】 : PID Input 【22】 : PID Output 【23】 : PID Target Value 【24】 : PID Feedback Value 【25】 : Output Frequency of the Soft Starter 【26】 : PG feedback 【27】 : PG compensation 【28】 : Communication Control </p>
04-12	AO1 Gain
Range	【0.0~1000.0】 %
04-13	AO1 Bias
Range	【-100.0~100.0】 %
04-16	AO2 Function Setting
Range	Setting range and definition are the same as those of 04-11.
04-17	AO2 Gain
Range	【0.0~1000.0】 %
04-18	AO2 Bias

Range	【-100.0~100.0】 %	
04-19	AO Output Signal Type	
Range	【0】 : AO1 0~10V	AO2 0~10V
	【1】 : AO1 0~10V	AO2 4~20mA
	【2】 : AO1 4~20mA	AO2 0~10V
	【3】 : AO1 4~20mA	AO2 4~20mA

For the analog output and related parameters, refer to Fig.4.4.40.




Figure 4.4.40 Analog outputs and related parameters

Analog output AO1 and AO2 adjustment (04-12, 04-13 and 04-17, 04-18)

Signal: Use parameter 04-11 to select the analog output signal for AO1 and parameter 04-16 to select the analog output signal for AO2.

Gain: Use parameter 04-12 to adjust the gain for AO1 and parameter 04-17 to adjust the gain for AO2. Adjust the gain so that the analog output (10V/20mA) matches 100% of the selected analog output signal (04-11 for AO1 and 04-16 for AO2).

Bias: Use parameter 04-13 to adjust the bias for AO1 and parameter 04-18 to adjust the bias for AO2. Adjust the bias so that the analog output (0V/4mA) matches 0% of the selected analog output signal (04-11 for AO1 and 04-16 for AO2).




Figure 4.4.41 Analog output level adjustment

Table 4.4.9 Selection of analog output terminals function (04-11 and 04-16)

04-11, 04-16 Parameter setting	Function (Keypad display)	Monitoring Parameters Group 12	Control Mode		
			VF	SLV	PM SLV
0	Output Freq	12-17	O	O	O
1	Freq Ref	12-16	O	O	O
2	Output Voltage	12-19	O	O	O
3	DC Voltage	12-20	O	O	O
4	Output Current	12-18	O	O	O
5	Output KW	12-21	O	O	O
6	Motor Speed	12-22	O	O	O
7	Output PF	12-23	O	O	O
8	AI1 Input	12-25	O	O	O
9	AI2 Input	12-26	O	O	O
10	Torque Ref	12-27	X	O	O
11	Current Iq	12-28	X	O	O
12	Current Id	12-29	X	O	O
13	Speed Deviation	12-30	X	O	O
14	Reserved	-	X	X	X
15	ASR Output	12-32	X	X	X
16	Reserved	-	X	X	X
17	Voltage Ref Vq	-	X	O	O
18	Voltage Ref Vd	-	X	O	O
19~20	Reserved	-	X	X	X
21	PID Input	12-36	O	O	O
22	PID Output	12-37	O	O	O
23	PID Setpoint	12-38	O	O	O
24	PID Feedback	12-39	O	O	O
25	Output Freq (SFS)	-	O	O	O
26~27	Reserved	-	X	X	X
28	Comm Control	-	O	O	O

04-20	Filter Time of AO Signal Scan	*1
Range	【0.00~0.50】 Sec	

***1: It is new added in inverter software V1.4.**

This function is used for filtering out momentary change of analog output signal.

Note: When this function is added, it will decrease the system reaction but increase interference protection.

Group 05 Multi-Speed Parameters

05- 00	Acceleration and Deceleration Selection of Multi-Speed
Range	【0】 : Acceleration and deceleration time are set by 00-14 ~ 00-24 【1】 : Acceleration and Deceleration Time are set by 05-17 ~ 05-48

05-00=0: Standard Acceleration and deceleration times parameters 00-14 ~ 00-17 / 00-21 ~ 00-24 are used for multi-speed 0 ~ 15.

05-00=1: Each multi-speed uses a dedicated acceleration and deceleration time parameters 05-17 ~ 05-48. There are two different modes for acceleration / deceleration timing when 05-00 is set to 1, see time example on the next page.

Acceleration time calculation formula

$$\text{Time it takes to reach set frequency} = \frac{\text{Acceleration time} \times (\text{set frequency} - \text{output frequency})}{\text{Maximum output frequency}}$$

Deceleration time calculation formula

$$\text{Time it takes to reach set frequency} = \frac{\text{Deceleration time} \times (\text{output frequency} - \text{set frequency})}{\text{Maximum output frequency}}$$

Maximum output frequency: Parameter 01-00=F, maximum output frequency set by 01-02, 01-00 ≠ F, maximum output frequency determined by V/F curve selected (50.0 / 60.0 / 90.0 / 120.0 / 180.0).

Example : 01-00=01 (50Hz (maximum output frequency), 05-02=10 Hz (multi-step speed 0), 05-17=5.0s (Acceleration time), 05-18=20.0 sec. (Deceleration time).

Acceleration time calculation formula

$$\text{Time it takes to reach set frequency} = \frac{5.0 \times 10 \text{ Hz}}{50 \text{ Hz}} = 1.0 \text{ sec.}$$

Deceleration time calculation formula

$$\text{Time it takes to reach set frequency} = \frac{20.0 \times 10 \text{ Hz}}{50 \text{ Hz}} = 4.0 \text{ sec.}$$


Example: Acceleration / deceleration timing when 05-00 is set to 1. In this example the following parameters are set:

- 00-02=1** (External Terminal Operation)
- 03-00=0** (Terminal S1: Forward /Stop)
- 03-01=1** (Terminal S2: Reversal /Stop)
- 03-02=2** (Terminal S3: Speed 1)
- 03-03=3** (Terminal S4: Speed 2)
- 03-03=4** (Terminal S5: Speed 3)

*Speed 1 is required to confirm if AI2 function setting (04-05) is set to 0 (Auxiliary frequency). If 04-05=0, it will make the frequency of speed 1 set to AI2 auxiliary frequency and the value is determined by AI2. If function of speed 1 is generally used, set AI2 to other functions except 0 (the recommended value: set 10 ADD to AI1.)

Acceleration / Deceleration Calculation Mode 1:

If the run command is cycled on and off, acceleration and deceleration time (a ~ f) is calculated based on the active speed command as follows:




$$a = \frac{(05-17) \times (05-01)}{(01-02)} \quad b = \frac{(05-18) \times (05-01)}{(01-02)} \quad c = \frac{(05-19) \times (05-02)}{(01-02)} \quad \text{in sec.}$$

$$d = \frac{(05-20) \times (05-02)}{(01-02)} \quad e = \frac{(05-21) \times (05-03)}{(01-02)} \quad f = \frac{(05-22) \times (05-03)}{(01-02)} \quad \text{in sec.}$$

Acceleration / Deceleration Calculation Mode 2:

If the run command remains on, acceleration and deceleration time (a ~ f) is calculated based on the active speed command as follows:



$$a = \frac{(05-17) \times (05-01)}{(01-02)} \quad b = \frac{(05-19) \times [(05-02) - (05-01)]}{(01-02)} \quad c = \frac{(05-21) \times [(05-03) - (05-02)]}{(01-02)} \quad \text{in sec.}$$

$$d = \frac{(05-24) \times [(05-03) - (05-04)]}{(01-02)} \quad e = \frac{(05-26) \times (05-04)}{(01-02)} \quad f = \frac{(05-25) \times (05-05)}{(01-02)} \quad \text{in sec.}$$

$$g = \frac{(05-27) \times (05-05)}{(01-02)} \quad h = \frac{(05-27) \times (05-06)}{(01-02)} \quad i = \frac{(05-19) \times (05-06)}{(01-02)} \quad \text{in sec.}$$

05- 01	Frequency Setting of Speed-Stage 0
Range	【0.0~400.00】 Hz

05-02	Frequency Setting of Speed- Stage 1	*1
Range	【0.0~400.00】 Hz	

05-03	Frequency Setting of Speed- Stage 2	*1
Range	【0.0~400.00】 Hz	

05-04	Frequency Setting of Speed- Stage 3	*1
Range	【0.0~400.00】 Hz	

05-05	Frequency Setting of Speed- Stage 4	*1
Range	【0.0~400.00】 Hz	

05-06	Frequency Setting of Speed- Stage 5	*1
Range	【0.0~400.00】 Hz	

05-07	Frequency Setting of Speed- Stage 6	*1
Range	【0.0~400.00】 Hz	

05-08	Frequency Setting of Speed- Stage 7	*1
Range	【0.0~400.00】 Hz	

05-09	Frequency Setting of Speed- Stage 8	*1
Range	【0.0~400.00】 Hz	

05-10	Frequency Setting of Speed- Stage 9	*1
Range	【0.0~400.00】 Hz	

05-11	Frequency Setting of Speed- Stage 10	*1
Range	【0.0~400.00】 Hz	

05-12	Frequency Setting of Speed- Stage 11	*1
Range	【0.0~400.00】 Hz	

05-13	Frequency Setting of Speed- Stage 12	*1
Range	【0.0~400.00】 Hz	

05-14	Frequency Setting of Speed- Stage 13	*1
Range	【0.0~400.00】 Hz	

05-15	Frequency Setting of Speed- Stage 14	*1
Range	【0.0~400.00】 Hz	

05-16	Frequency Setting of Speed- Stage 15	*1
Range	【0.0~400.00】 Hz	

*1: It is new added in inverter software V1.4. Parameters 05-02~05-16 is required to set the frequency in parameters 06-01~06-15 in inverter software V1.3.

05-17	Acceleration time setting for multi speed 0	
Range	【0.1~6000.0】 Sec	

05-18	Deceleration time setting for multi speed 0	
Range	【0.1~6000.0】 Sec	

05-19	Acceleration time setting for multi speed 1	
Range	【0.1~6000.0】 Sec	

05-20	Deceleration time setting for multi speed 1
Range	【0.1~6000.0】 Sec
05-21	Acceleration time setting for multi speed 2
Range	【0.1~6000.0】 Sec
05-22	Deceleration time setting for multi speed 2
Range	【0.1~6000.0】 Sec
05-23	Acceleration time setting for multi speed 3
Range	【0.1~6000.0】 Sec
05-24	Deceleration time setting for multi speed 3
Range	【0.1~6000.0】 Sec
05-25	Acceleration time setting for multi speed 4
Range	【0.1~6000.0】 Sec
05-26	Deceleration time setting for multi speed 4
Range	【0.1~6000.0】 Sec
05-27	Acceleration time setting for multi speed 5
Range	【0.1~6000.0】 Sec
05-28	Deceleration time setting for multi speed 5
Range	【0.1~6000.0】 Sec
05-29	Acceleration time setting for multi speed 6
Range	【0.1~6000.0】 Sec
05-30	Deceleration time setting for multi speed 6
Range	【0.1~6000.0】 Sec
05-31	Acceleration time setting for multi speed 7
Range	【0.1~6000.0】 Sec
05-32	Deceleration time setting for multi speed 7
Range	【0.1~6000.0】 Sec
05-33	Acceleration time setting for multi speed 8
Range	【0.1~6000.0】 Sec
05-34	Deceleration time setting for multi speed 8
Range	【0.1~6000.0】 Sec
05-35	Acceleration time setting for multi speed 9
Range	【0.1~6000.0】 Sec
05-36	Deceleration time setting for multi speed 9
Range	【0.1~6000.0】 Sec

05-37	Acceleration time setting for multi speed 10
Range	【0.1~6000.0】 Sec
05-38	Deceleration time setting for multi speed 10
Range	【0.1~6000.0】 Sec
05-39	Acceleration time setting for multi speed 11
Range	【0.1~6000.0】 Sec
05-40	Deceleration time setting for multi speed 11
Range	【0.1~6000.0】 Sec
05-41	Acceleration time setting for multi speed 12
Range	【0.1~6000.0】 Sec
05-42	Deceleration time setting for multi speed 12
Range	【0.1~6000.0】 Sec
05-43	Acceleration time setting for multi speed 13
Range	【0.1~6000.0】 Sec
05-44	Deceleration time setting for multi speed 13
Range	【0.1~6000.0】 Sec
05-45	Acceleration time setting for multi speed 14
Range	【0.1~6000.0】 Sec
05-46	Deceleration time setting for multi speed 14
Range	【0.1~6000.0】 Sec
05-47	Acceleration time setting for multi speed 15
Range	【0.1~6000.0】 Sec
05-48	Deceleration time setting for multi speed 15
Range	【0.1~6000.0】 Sec

Group 06 Automatic Program Operation Parameters

06- 00	Automatic Operation Mode Selection
Range	<p>【0】 : Disable</p> <p>【1, 4】 : Execute a single cycle operation. Restart speed is based on the previous stopped speed.</p> <p>【2, 5】 : Execute continuous cycle operation. Restart speed is based on the previous cycle stop speed.</p> <p>【3, 6】 : After completion of a single cycle, the on-going operation speed is based on the speed of the last stage. Restart speed is based on the previous stopped speed</p> <p>1 to 3: After a stop the inverter will start with the incomplete step when the run command is re-applied.</p> <p>4 to 6: After a stop the inverter will start with the first step of the cycle when the run command is re-applied.</p>

Automatic operation mode uses frequency reference parameters 05-01, 06-01~06-15, operation time parameters 06-16 ~ 06-31 and direction of operation parameters 06-32~06-47.

Note: The automatic operation mode is disabled when any of the following functions are enabled:

- Frequency wobbling function
- PID function
- Parameters 06-16 to 06-31 are set to 0.

Notes:

- When automatic operation mode is enabled multi-step speed reference command 1~4 (03-00~03-07=2~5) is disabled.
- Frequency of multi-step speed 0 is set by 05-01.
- Acceleration/deceleration time is set by parameter 00-14 and 00-15 in automatic operation mode.

Automatic operation frequency reference settings		
06-01	Frequency Setting of Operation-Stage 1	*1
06-02	Frequency Setting of Operation -Stage 2	*1
06-03	Frequency Setting of Operation -Stage 3	*1
06-04	Frequency Setting of Operation -Stage 4	*1
06-05	Frequency Setting of Operation -Stage 5	*1
06-06	Frequency Setting of Operation -Stage 6	*1
06-07	Frequency Setting of Operation -Stage 7	*1
06-08	Frequency Setting of Operation -Stage 8	*1
06-09	Frequency Setting of Operation -Stage 9	*1
06-10	Frequency Setting of Operation -Stage 10	*1
06-11	Frequency Setting of Operation -Stage 11	*1
06-12	Frequency Setting of Operation -Stage 12	*1
06-13	Frequency Setting of Operation -Stage 13	*1
06-14	Frequency Setting of Operation -Stage 14	*1
06-15	Frequency Setting of Operation -Stage 15	*1
Range	0.00~400.00 Hz	

*1: It is operation frequency in inverter software V1.4.

Automatic operation time settings	
06-16	Time Setting of Operation -Stage 0
06-17	Time Setting of Operation -Stage 1
06-18	Time Setting of Operation -Stage 2
06-19	Time Setting of Operation -Stage 3
06-20	Time Setting of Operation -Stage 4
06-21	Time Setting of Operation -Stage 5
06-22	Time Setting of Operation -Stage 6
06-23	Time Setting of Operation -Stage 7
06-24	Time Setting of Operation -Stage 8
06-25	Time Setting of Operation -Stage 9
06-26	Time Setting of Operation -Stage 10
06-27	Time Setting of Operation -Stage 11
06-28	Time Setting of Operation -Stage 12
06-29	Time Setting of Operation -Stage 13
06-30	Time Setting of Operation -Stage 14
06-31	Time Setting of Operation -Stage 15
Range	0.0~6000.0 Sec

Automatic operation direction settings	
06-32	Direction Selection of Operation -Stage 0
06-33	Direction Selection of Operation -Stage 1
06-34	Direction Selection of Operation -Stage 2
06-35	Direction Selection of Operation -Stage 3
06-36	Direction Selection of Operation -Stage 4
06-37	Direction Selection of Operation -Stage 5
06-38	Direction Selection of Operation -Stage 6
06-39	Direction Selection of Operation -Stage 7
06-40	Direction Selection of Operation -Stage 8
06-41	Direction Selection of Operation -Stage 9
06-42	Direction Selection of Operation -Stage 10
06-43	Direction Selection of Operation -Stage 11
06-44	Direction Selection of Operation -Stage 12
06-45	Direction Selection of Operation -Stage 13
06-46	Direction Selection of Operation -Stage 14
06-47	Direction Selection of Operation -Stage 15
Range	0: Stop, 1: Forward, 2: Reversal

Example 1: Automatic operation mode – Single cycle

In this example the inverter executes a single cycle and then stops.

Parameter Settings:

06-00 = 1 (Single cycle operation)
06-32~06-34 = 1 (Forward for operation stage 0 - 2)
06-47 = 2 (Reversal for operation stage 15)
06-35~06-46 = 0 (Stop for operation frequency stage 3 - 14)
05-01 = 15 Hz (Operation frequency stage 0: 15 Hz)
06-01 = 30 Hz (Operation frequency stage 1: 30 Hz)
06-02 = 50 Hz (Operation frequency stage 2: 50 Hz)
06-15 = 20 Hz (Operation frequency stage 15: 20 Hz)
06-16 = 20 sec (Operation time stage 0: 20 sec)
06-17 = 25 sec (Operation time stage 1: 25 sec)
06-18 = 30 sec (Operation time stage 2: 30 sec)
06-31 = 40 sec (Operation time stage 15 :40 sec)




Figure 4.4.42 Single cycle automatic operation (stop)

Example 2: Automatic operation mode – Continuous cycle

In this example the inverter repeats the same cycle.

Parameter Settings:

06-00 = 2 or 5 (Continuous cycle operation)
06-01~06-47=Enter same setting as that of Example 1.




Figure 4.4.43 Periodic automatic operation

Example 3: Automatic operation mode – Single cycle and continue running at last speed of the cycle
 In this example the inverter executes a single cycle and continue running at last speed of the cycle.





Figure 4.4.44 Single cycle automatic operation (continuous)

06-00= 1 to 3:

After a stop the inverter will start with the incomplete step when the run command is re-applied.

06-00= 4 to 6:

After a stop the inverter will start with the first step of the cycle when the run command is re-applied.



Notes:

- Acceleration/ deceleration time is set with parameters 00-14 and 00-15 in automatic operation mode.
- If the setting value of parameters 06-16~06-31 is 0, automatic operation mode is not active.

Group 07: Start /Stop Parameters

07- 00	Momentary Power Loss/Fault Restart Selection
Range	【0】 : Disable 【1】 : Enable

07-00=0: Inverter trips on “UV” fault if power loss time is greater than 8ms.

07-00=1: Inverter restarts after restarting the power at the momentary power loss.

Note: When 07-00=1, inverter restore automatically the motor rotation after restarting the power even if momentary power loss occurs.

07- 01	Fault Auto-Restart Time
Range	【0~7200】 Sec

07-01 = 0 sec.: Automatic restart time interval is set by minimum baseblock time (07-18).

07-01 <07-18: Automatic restart time interval is set by minimum baseblock time (07-18).

07-01 > 07-18: Automatic restart time interval is set by fault reset time (07-01).

Note:

Automatic restart time interval is time of 07-18 plus 07-01 and delay time of peed search (07-22).

Refer to Fig.4.4.45 for setting automatic restart interval.




Figure 4.4.45 Automatic restart operation

07- 02	Number of Fault Auto-Restart Attempts
Range	【0~10】

When the automatic restart function is enabled the internal automatic restart attempt counter is reset based on the following actions:

- a) No fault occurs in 10 minutes or longer after the automatic restart
- b) Reset command to clear fault via input terminal or using the keypad (ex: press reset/ ◀ key)
- c) Power to the inverter is turned off and back on again

Note:

Multi-function digital output R1A-R1C, R2A-R2C, R3A-R3C can be programmed to activate during an automatic reset attempt, refer to parameter 03-11, 03-12 and 03-39.

Automatic restart operation:

- a) Fault is detected. The inverter turn off the output, displays the fault on the keypad and waits for the minimum baseblock time parameter 07-18 to expire before accepting another run / automatic restart command.
- b) After the minimum baseblock time (07-18) has expired, the active fault is reset and a speed search operation is performed. The time between each fault restart attempt is set by parameter 07-01.
- c) When the total numbers of restart attempts exceed the number of automatic restart attempts set in parameter 07-02, the inverter will turn off the output and the fault contact is activated.

Please refer to Figure 4.4.46 for the automatic restart operation.




Figure 4.4.46 Auto-restart operation

The automatic restart function is active for the following faults. Please note that when the fault is not listed in the table the inverter will not attempt an automatic restart.

Parameter Name	Faults		Numbers of Restart
07-00	UV (under voltage)		Unlimited
07-01	OC (over current) OL1 (motor overload) UT (Under torque detection)	OV (overvoltage) OL2 (Inverter overload) OT (Over-torque detection)	Depend on parameter 07-02
07-02	IPL (input phase loss) GF (ground failure)	OPL (Output phase loss)	

Notes:

1. Fault restart function contains momentary power loss restart and auto reset restart.
2. Refer to chapter 10 for the details of troubleshooting and fault diagnostics.
3. Refer to speed search function (07-19~07-24) for the selection of speed search modes.

Note:

Automatic restart function is only active in the state of no harm to the safety or to the application devices.

Warning - Excessively use of the automatic restart function will damage the inverter.

07- 04	Automatic start at power up
Range	[0] : Automatic start at power up when external run command is enabled [1] : Without automatic start at power up when external run command is enabled

07- 04 = 0:

If the running switch is in conducting state when power supply is on, the inverter will start automatically.

07- 04 =1:

If the running switch is not in conducting state when power supply is on , the inverter will not start automatically and STP1 will flash. It is required to switch off the running switch and make it be in conducting state so as to start the inverter.

07- 05	Automatic start delay at power up
Range	【1.0~300.0】 Sec

When 07- 04 = 0, if power supply is on, the inverter automatically start at power up and it will count the delay time set by 07–05. The inverter starts running only when the delay time ends.

! Warning:

- When **07- 04 = 0** and run command source is set to external control (**00- 02/00- 03 = 1**), if running switch is in conducting state and the inverter starts automatically when power supply is on, customers are suggested to switch off the power supply and running switch at power loss to prevent from the damage to the inverter and user when reconnecting.
- When **07- 04 = 1** and run command source is set to external control (**00- 02/00- 03 = 1**), if running switch is not in conducting state when power supply is on, the inverter will not start automatically and STP1 will flash. It is required to switch off the running switch and then make it be in conducting state and start the inverter after the delay time of automatic start at power up ends.

07- 06	DC Injection Braking Start Frequency
Range	【0.0~10.0】 Hz

DC injection braking start frequency is the level the output frequency has to reach before DC braking injection function is activated.

07- 07	DC Injection Braking Current
Range	【0~100】 %

DC Injection braking current as percentage of the inverter rated current. Increasing this level will increase the amount of heat generated by the motor windings. Do not set this parameter higher than the level necessary to hold the motor shaft.

07- 08	DC Injection Braking Time at Stop
Range	【0.00~10.00】 Sec

Duration of DC injection braking is during a stop operation. DC injection braking at stop is disabled when parameter 07-08 is set to 0 sec.

07- 16	DC Injection Braking Time at Start
Range	【0.00~100.00】 Sec

Duration of DC injection braking is during a start operation. DC injection braking at start is disabled when parameter 07-16 is set to 0 sec.

DC Injection Braking Operation

When DC Injection braking is active DC voltage is applied to the motor, increasing the braking current and resulting in an increase in the strength of the magnetic field trying to lock the motor shaft.

To enable DC injection braking during a start operation set the DC injection braking current (07-07) and the DC injection braking time (07-16) at start to a value greater than 0. DC injection braking at start can be used to prevent “wind milling effect” in fan applications.

To enable DC injection braking during a stop operation set the DC injection braking current (07-07) and the DC injection braking time at stop (07-08) to a value greater than 0.

Notes:

- When parameter 07-16 is set to 0 sec. the inverter will start from the minimum output frequency.
- Increasing the DC braking time (07-08, 07-16) can reduce the motor stop time.
- Increasing the DC braking current (07-07) can reduce the motor stop time.
- During stop operation: If the DC braking start frequency < minimum output frequency (01-08), DC braking is activated when the output frequency reaches the minimum output frequency level.
- DC Injection braking cannot be used in sensor vector control (SV).




Figure 4.4.47 DC braking operation

DC braking operation can be controlled via any one of the multi-function input terminals (03-00 to 05) function 33. Refer to Fig. 4.4.47 for DC braking operation.

DC braking current can be controlled via the multi-function analog input (04-05) function 5. Refer to Fig. 4.4.34.

07- 09	Stop Mode Selection
Range	[0] : Deceleration to Stop
	[1] : Coast to Stop
	[2] : DC Braking Stop
	[3] : Coast to Stop with Timer

When a stop command is issued the inverter stops according to the stop mode selected. There are four types of stop modes,

Note: When using the permanent magnet motor, only the option of deceleration to stop mode is available.


07-09=0: Deceleration to stop

When a stop command is issued, the motor will decelerate to the minimum output frequency (01-08) Fmin and then stop. Deceleration rate depends on the deceleration time (factory default: 00-15).

When the output frequency reaches the DC braking stop frequency (07-06) or the minimum output frequency (01-08), DC injection braking is activated and the motor stops.

$$\text{Deceleration time} = \frac{\text{Output frequency when stop command is issued}}{\text{Maximum output frequency } F_{\max} \text{ (01-02)}} \times \text{deceleration time setting}$$

Note: S curve setting will add to the overall stop time



T: DC Braking Time at stop (07-08)

Figure 4.4.48 Deceleration to stop

07-09=1: Coast to stop

When a stop command is issued, the motor will coast to a stop. Stop time depends on motor load and friction of the system.

The inverter waits for the time set in the minimum baseblock time (07-18) before accepting the next run command.

In SLV mode (00-00=2) the speed search function is automatically enabled upon the next run command.

Note: When using a mechanical brake set parameter 07-26 to 1.




Figure 4.4.49 Coast to stop

07-09=2: DC braking to stop

When a stop command is issued, the inverter will turn off the output (Baseblock) and after the minimum Baseblock time (07-18) has expired activate DC braking (07-07). Refer to Fig.4.4.50.

The DC braking time (t_{DCDB}) of Figure 4.4.50 is determined by the value of 07-08 (DC Braking start time) and the output frequency at the time the stop command was issued.

$$t_{DCDB} = \frac{(07-08) \times 10 \times \text{output frequency}}{1000}$$

Note: Increase the minimum Baseblock time (07-18) in case an Overcurrent trip occurs during the DC braking.




Figure 4.4.50 DC braking to stop

07-09=3: Coast to stop with timer

When a stop command is issued the motor will coast to a stop after the minimum Baseblock time (07-18) has expired. The inverter ignores the run command until the total time of the timer has expired.

The total time of the timer is determined by the deceleration time (00-15, 17, 22 or 24) and the output frequency upon stop. Refer to Fig.4.4.51




Figure 4.4.51 Coast to stop with timer

07- 13	Low Voltage Detection Level
Range	【200V】 : 150~300V 【400V】 : 300~600V
07- 25	Low voltage Detection Time
Range	【0.00~1.00】 Sec

Adjust the 07-13 voltage level from 150 to 300 Vdc (200V series) or from 300 to 600 Vdc (400V series).

When the AC input voltage is lower than the 07-13 value (07-13/ 1.414 = AC voltage detection level) for the time specified in 07-25 the low-voltage error "UV" will displayed. If 07-25 = 0.00 sec., the UV error will be displayed immediately.

Set preventive measures:

- The inverter input voltage will limit the output voltage. If the input voltage drops excessively, or if the load is too big, the motor may stall.
- If the input voltage drops below the value set in 07-13 then the output is turned off momentarily. The inverter will not automatically start when power is restored.

07- 14	Pre-excitation Time
Range	【0.00~10.00】 Sec
07- 15	Pre-excitation Level
Range	【50~200】 %

If a high starting torque is required for the application, especially for a large horsepower motors, the pre-excitation operation can be used to pre-flux (magnetize) the motor.

07-14: Pre-excitation time

When an operation command (forward or reverse) is activated, the inverter will automatically start pre-excitation based on the time set in parameter 07-14.

The time for the flux to reach 100% is a function value of motor's electrical time constant (See figure 4.4.52).

Electrical time constant (quadratic by-pass circuit time constant) can be calculated by motor parameter setting (group 02)

$$\text{Electrical time constant } T_2 = \frac{\text{Motor leakage inductance (02-17)} + \text{motor mutual inductance (02-18)}}{\text{Motor rotor resistance (02-16)}}$$

Set the pre-excitation time (07-14) based on the electrical time constant T_2

07-15: Pre-excitation initial level

Use the pre-excitation initial level (07-15) to provide a higher excitation current during the pre-excitation time (07-14), which will increase the speed and stability for motors.

In order to quickly magnetize the motor, reduce the pre-excitation time (07-14) and set the pre-excitation level (07-15) to a high level.

If 07-15 is set greater than 100%, providing a high excitation current during the pre-excitation time (07-14), motor's magnetization time is shorted. When the setting reaches 200%, magnetization is reduced by roughly half.

A high pre-excitation level (07-15) might result in excessive motor sound during pre-excitation.

When the flux reaches 100%, pre-excitation current reverts back to 100% and pre-excitation is completed.




Figure 4.4.52 Pre-excitation operation

07- 18	Minimum Base block Time
Range	【0.1~5.0】 Sec

In case of a momentary power failure, the inverter continues to operate after the power has been restored when parameter 07-00 is set to 1. Once the momentary power failure is detected; the inverter will automatically shut down the output and maintain B.B for a set time (07-18).

It is expected that after the minimum base block time has expired the residual voltage to be almost zero.

When the momentary power failure time exceeds the minimum base block time (07-18), the inverter will automatically perform a speed search upon return of power. Refer to the following figure 4.4.53.




Figure 4.4.53 Minimum B.B time and momentary power loss time

Minimum base block time (07-18) is also used to for the DC braking function in combination with speed search as follows:

- Set the minimum base block time required (07-18).
- Execute speed search or DC braking function.
- Increase minimum Baseblock time if over-current "OC" condition occurs.
- After speed search is completed, normal operation continues.

07- 19	Direction-Detection Speed Search Operating Current
Range	【0~100】 %
07- 20	Speed Search Operating Current
Range	【0~100】 %
07- 21	Integral Time of Speed Searching
Range	【0.1~10.0】 Sec
07- 22	Delay Time of Speed Search
Range	【0.0~20.0】 Sec
07-23	Voltage Recovery Time
Range	【0.1~5.0】 Sec
07- 24	Direction-Detection Speed Search Selection
Range	【0】 : Disable 【1】 : Enable
07- 26	SLV Speed Search Function
Range	【0】 : Enable 【1】 : Disable
07- 27	Start Selection after Fault during SLV Mode
Range	【0】 : Speed search start 【1】 : Normal Start
07- 28	Start after External Base Block
Range	【0】 : Speed search start 【1】 : Normal Start

Speed search function is used to find the speed of a coasting motor and continue operation from that point. The speed search function is active after a momentary power loss.

Speed Search from Multi-function digital inputs

Set the multi-function digital input to external speed search command 1 or 2. External speed search command 1 (value = 19) and 2 (value = 34) cannot be set at the same time, otherwise "SE02" (digital input terminal error) warning occurs.

Speed search function must be enabled before applying the run command to ensure proper operation. See relay logic in Fig. 4.4.54.




Figure 4.4.54 Speed search and operation commands

Notes: Speed Search Operation

- The speed search cannot be used when the motor rated power is greater than the inverter rated power.
- The speed search cannot be used when the motor rated power is two inverter sizes smaller than the inverter currently used.
- The speed search cannot be used in combination with a high-speed motor.
- In V / F mode, it is necessary to perform a static auto-tune.
- In SLV mode, it is necessary to perform a rotational auto-tune. Perform a static auto-tune when using long motor leads.

Speed search uses current detecting. Use parameter 07-24 to select detection direction.

07-19: Speed Direction Search Operating Current

- Used in bidirectional speed search only (07-24 = 1).
- Set bidirectional current level.
- Increase value if speed search is not successful at low speeds (above 5Hz)

Note: If value is too high may cause DC braking effect.

07-20: Speed Search Operating Current

- Can be used for bidirectional (07-24 = 1) or unidirectional (07-24 = 0) speed search.
- Sets speed search current Level.
- The set value must be lower than the excitation current (02-09) and must equal to the no-load current. If the no-load current is unknown it is recommended to set value at 20%.
- Excessive speed search current will cause inverter output to saturate.
- It is recommended to use speed search in case of a momentary power loss. Increase the minimum base block time (07-18) in case of an over-current condition.

07-21: Integral time of speed searching

- Can be used for bidirectional (07-24 = 1) or unidirectional (07-24 = 0) speed search.
- Set the integral time during speed search.
- If OV occurs, increase the set value to increase the speed search time. Decrease the value if a quick start is required

07-22: Delay time of speed search

- Use delay time when using a contactor on the inverter output side.
- The inverter speed search starts after the delay time expires.
- Speed search delay time is disabled when set to 0.0 sec. (07-22 = 0.0)

07-23: Voltage recovery time

- Sets the voltage recovery time.
- Sets the time for the inverter to restore the output voltage from 0V to the specified V/f level after speed search function is completed.

07-24: Direction-Detection Speed Search Selection

07-24=0: Disable Direction-Detection Speed Search

Speed search is executed using speed search operating current defined in parameter 07-20. In case speed search is not successful (e.g. motor speed is too low) a speed search time-out warning is displayed. Set 07-19 to value greater than 0 to enable DC braking at speed search if a time-out occurs frequently.

07-24=1: Enable Direction-Detection Speed Search

At start the current controller will send a step current to the motor (07-19) to determine the motor direction. Once direction is determined the current controller will perform a speed search using speed search operating current defined in parameter 07-20. Speed search is executed after a momentary power loss (external speed search command 2, 03-00 to 03-05 = 34) or from max. frequency (external speed search command 1, 03-00 to 03-05 = 19). Speed search direction will follow the speed command.

07-26: SLV Speed Search Function

- In SLV mode (00-00 = 2) set the stop mode to the coast stop (07-09 = 1) or to the coast to stop with timer (07-09 = 3). After a stop command is issued (coast to stop or coast to stop with times) the speed search function is automatically activated for the next start.

07-26=0: Enable (No mechanical brake is installed)

07-26=1: Disable (Mechanical brake is installed)

07-27: Start Selection after fault during SLV mode

07-27=0: Speed search start: Speed search is executed after a fault in SLV mode.

07-27=1: Normal start: Speed search is not enabled.

Note: Set the parameter to 1 (normal start) after a fault has occurred and a mechanical brake is used to stop the motor.

07-28: Start after external Baseblock

07-28=0: Speed search start: Speed search is executed after base block is removed.

07-28=1: Normal start: Speed search is not enabled.

Notes:

- Set parameter to 1 for the control mode of SLV mode (00-00 = 2) when the external base block active time is longer than the time the motor needs to come to a complete stop. After the external base block command is removed the inverter will accelerate from min. frequency.
- The inverter has no choices but can only normally start when using permanent magnetic motor.

■ Speed search based on current detection

(a) Speed search at starting




Figure 4.4.55 Speed search at starting

(b) Speed search in recovery period of momentary power failure




Figure 4.4.56 Speed search in recovery period of momentary power failure

Notes:

- If the minimum base block time (07-18) is longer than the momentary power failure time, the speed search starts operation after the minimum base block time (07-18).
- If the minimum base block time (07-18) is too short, the speed search operation begins immediately after power has been restored.

Group 08 Protection Parameters

08- 00	Stall Prevention Function
Range	【xxx0b】 : Stall prevention is enabled in acceleration. 【xxx1b】 : Stall prevention is disabled in acceleration. 【xx0xb】 : Stall prevention is enabled in deceleration. 【xx1xb】 : Stall prevention is disabled in deceleration. 【x0xxb】 : Stall prevention is enabled in operation. 【x1xxb】 : Stall prevention is disabled in operation. 【0xxxb】 : Stall prevention in operation decelerates based on deceleration time 1 【1xxxb】 : Stall prevention in operation decelerates based on deceleration time 2
08- 01	Stall Prevention Level in Acceleration
Range	【30~200】 %
08- 02	Stall Prevention Level in Deceleration
Range	【330~410】 V : 200V 【660~820】 V : 400V
08- 03	Stall Prevention Level in Operation
Range	【30~200】 %
08-21	Limit of Stall Prevention in Acc over Base Speed
Range	【0~100】 %
08-22	Stall Prevention Detection Time in Operation
Range	【2~100】 msec

Stall prevention during acceleration (08-00=xxx0b)

Prevents the inverter from faulting (Overcurrent, Motor overload, Inverter overload) when accelerating with heavy loads.

When the inverter output current reaches the level set in parameter 08-01 minus 15% the acceleration rate starts to decrease. When the inverter output current reaches the level set in parameter 08-01 the motor stops accelerating. Refer to Fig.4.4.57 for more information.

Notes:

- Reduce stall prevention level during acceleration (08-01) in case the motor stalls (when the motor power is smaller than the inverter rating).
- The inverter rated output current should be set to 100%.




Figure 4.4.57 Stall prevention during acceleration

If the motor is used in the constant power (CH) region, the stall prevention level (08-01) is automatically reduced to prevent the stall.

Stall prevention level during acceleration (Constant horsepower)

$$\text{Stall Prev. Lev. Acceleration (CH)} = \frac{\text{Stall prevention level in acceleration (08-01)} \times \text{Fbase (01-12)}}{\text{Output frequency}}$$

Parameter 08-21 is the stall prevention limit value in Constant Horsepower region. Refer to Fig.4.4.58.




Figure 4.4.58 Stall prevention level and limit in acceleration

Stall prevention selection during deceleration (08-00=xx0xb)

Stall prevention during deceleration automatically increases the deceleration time according based on the DC-bus voltage to prevent over-voltage during deceleration. Refer to Fig.4.4.59 for stall prevention during deceleration

When the DC-bus voltage exceeds the stall prevention level deceleration will stop and the inverter will wait for the DC-bus voltage to fall below the stall prevention level before continuing deceleration. Stall prevention level can be set by 08-02, see Table 4.4.10.

Table 4.4.10 Stall prevention level

Inverter model	08-02 default value
200V class, 5 to 15HP	395VDC
200V class, 20HP and above	385VDC
400V class, 5 to 20HP	790VDC
400V class, 25 HP and above	770VDC

* If 01-14 < 400V, the default value of parameter 08-02 is 680VDC when the inverter software is V1.3 or below.

Note: When using external braking (braking resistor or braking module) disable stall prevention during deceleration (08-00 to xx1xb).




Figure 4.4.59 Stall prevention selection in deceleration

Stall prevention selection during run (08-00=x0xxb)

Stall prevention during run can only be used in V/F or SLV control mode.

This function prevents the motor from stalling by automatically reducing the output frequency during run.

If the inverter output current rises above the level set in parameter 08-03 for the time specified in parameter 08-22, the inverter output frequency is automatically decreased following deceleration time 1 (00-15) or deceleration time 2 (00-17).

When the inverter output current falls below the level set in parameter (08-03) minus 2%, normal operation continues and the output frequency increases to the frequency reference using the acceleration time 1 or acceleration time 2. Refer to the following Fig.4.4.60.

Note: The stall prevention level during run can be set by using multi-function analog input AI2 (04-05=7).




Figure 4.4.60 Stall prevention selection in operation

08- 05	Selection for Motor Overload Protection (OL1)
Range	【xxx0b】 : Motor Overload Protection is disabled.
	【xxx1b】 : Motor Overload Protection is enabled.
	【xx0xb】 : Cold Start of Motor Overload
	【xx1xb】 : Hot Start of Motor Overload
	【x0xxb】 : Standard Motor
	【x1xxb】 : Special motor
	【0xxxb】 : Reserved
【1xxxb】 : Reserved	

The motor overload protection function estimates the motor overload level based on the output current, output frequency, motor characteristics and time. The motor overload trip time depends on the motor rated current when the output frequency is higher than 60Hz.

On inverter power-up the motor overload protection internal thermal accumulation register is automatically reset.

To use the built-in motor overload protection function parameter 02-01 (motor rated current) has to match the motor rated current on the motor nameplate.

Turn off the motor overload protection when using two or more motors connected to the inverter (set 08-05 = xxx0b), and provide external overload protection for each motor (e.g. thermal overload switch).

With cold start enabled (08-05 = xx0xb), motor overload protection occurs in 5 and a half minutes when operating the motor at 150% of the motor rated current at an output frequency greater than 60Hz.

With hot start enabled (08-05 = xx1xb), motor overload protection occurs in 3 and a half minutes when operating the motor at 150% of the motor rated current at an output frequency greater than 60Hz.

Refer to the following Fig.4.4.61 for an example of motor overload protection standard curve.




Figure 4.4.61 Motor overload protection curve (example: standard motor)

When using force cooled motors (Special inverter motor), thermal characteristics are independent of the motor speed, set 08-05 = x1xxb.

When 08-05 = x1xxb, overload protection function is based on motor rated current for output frequencies between 6 and 60Hz. If the output frequency is lower than 1Hz, the overload protection function uses 83% of the motor rated current to determine an overload condition.

When 08-05 = x0xxb, overload protection function is based on 70% of the motor rated current for an output frequency of 20Hz. If the output frequency is lower than 1Hz, the overload protection function uses 40% of the motor rated current to determine an overload condition.

Refer to Fig.4.4.62 for motor overload rating at different output frequencies.




Figure 4.4.62 Motor overload rating at different output frequencies

08- 06	Start-up mode of overload protection operation (OL1)
Range	[0] : Stop Output after Overload Protection [1] : Continuous Operation after Overload Protection.

08-06=0: When the inverter detects a motor overload the inverter output is turned off and the OL1 fault message will flash on the keypad. Press RESET button on the keypad or activate the reset function through the multi-function inputs to reset the OL1 fault.

08-06=1: When the inverter detects a motor overload the inverter will continue running and the OL1 alarm message will flash on the keypad until the motor current falls within the normal operating range.

08- 08	Automatic Voltage Regulation (AVR)
Range	[0] : AVR is enabled [1] : AVR is disabled

Automatic voltage regulation stabilizes the motor voltage independent of fluctuation to the input voltage.

08-08=0: Automatic voltage regulation is active.

08-08=1: Automatic voltage regulation is not active, motor voltage follows the input voltage fluctuation.

08- 09	Selection of Input Phase Loss Protection
Range	[0] : Disable [1] : Enable

08-09=0: Input phase loss detection is disabled.

08-09=1: Input phase loss detection is enabled. Keypad shows "IPL input Phase Loss" (IPL), when an input phase loss is detected the inverter output is turned off and the fault contact is activated.

Note: The input phase loss detection is disabled when the output current is less than 30% of the inverter rated current.

08- 10	Selection of Output Phase Loss Protection
Range	【0】 : Disable 【1】 : Enable

08-10=0: Output phase loss detection is disabled.

08-10=1: Output phase loss detection is enabled. Keypad shows "OPL Output Phase Loss" (OPL), when an output phase loss is detected and the inverter output is turned off and the fault contact is activated.

Note: The output phase loss detection is disabled when the output current is less than 10% of the inverter rated current.

08- 13	Selection of Over-Torque Detection
Range	【0】 : Over-Torque Detection is Disabled. 【1】 : Start to Detect when Reaching the Set Frequency. 【2】 : Start to Detect when the Operation is Begun.
08- 14	Selection of Over-Torque Operation
Range	【0】 : Deceleration to Stop when Over- Torque is Detected. 【1】 : Display Warning when Over- Torque is Detected. Go on Operation. 【2】 : Coast to Stop when Over Torque is Detected.
08- 15	Level of Over-Torque Detection
Range	【0~300】 %
08- 16	Time of Over-Torque Detection
Range	【0.0~10.0】 Sec
08- 17	Selection of Low-Torque Detection
Range	【0】 : Low-Torque Detection is Disabled. 【1】 : Start to Detect when Reaching the Set Frequency. 【2】 : Start to Detect when the Operation is Begun.
08- 18	Selection of Low-Torque Operation
Range	【0】 : Deceleration to Stop when Low- Torque is Detected. 【1】 : Display Warning when Low- Torque is Detected. Go on Operation. 【2】 : Coast to Stop when Low-Torque is Detected.
08- 19	Level of Low-Torque Detection
Range	【0~300】 %
08- 20	Time of Low-Torque Detection
Range	【0.0~10.0】 Sec

The over torque detection function monitor the inverter output current or motor torque and can be used to detect increase in inverter current or motor torque (e.g. heavy load).

The low torque detection function monitor the inverter output current or motor torque and can be used to detect a decrease in inverter current or motor torque (e.g. belt break).

The torque detection levels (08-15, 08-19) are based on the inverter rated output current (100% = inverter rated output current) when operating the inverter in V/F control mode and motor output torque (100% = motor rated torque) when operating the inverter in SLV control mode.

Over-torque detection

Parameter 08-13 selects over-torque detection function. An over-torque condition is detected when the output current / torque rises above the level set in parameter 08-15 (Over-torque detection level) for the time specified in parameter 08-06 (Over-torque detection time).

08-13=0: Over-torque detection is disabled.

08-13=1: Over-torque detection is enabled when the output frequency reaches the set frequency.

08-13=2: Over-torque detection is enabled during running.

Parameter 08-14 selects the way the inverter acts when an over-torque condition is detected.

08-14=0: When an over-torque condition is detected the inverter displays an over-torque detection fault and the motor decelerates to a stop.

08-14=1: When an over-torque condition is detected the inverter displays an over-torque detection alarm and continues to run.

08-14=2: When an over-torque condition is detected the inverter displays an over-torque detection fault and the motor coasts to a stop.




Figure 4.4.63 Over-torque detection operation

Low-torque detection

Parameter 08-18 selects low-torque detection function. A low-torque condition is detected when the output current / torque falls below the level set in parameter 08-19 (low-torque detection level) for the time specified in parameter 08-20 (Low-torque detection time).

08-17=0: Low-torque detection is disabled.

08-17=1: Low-torque detection is enabled when the output frequency reaches the set frequency.

08-17=2: Low-torque detection is enabled during running.

Parameter 08-18 selects the way the inverter acts when an over-torque condition is detected.

08-18=0: When a low-torque condition is detected the inverter displays a low-torque detection fault and the motor decelerates to a stop.

08-18=1: When a low-torque condition is detected the inverter displays a low-torque detection alarm and continues to run.

08-18=2: When a low-torque condition is detected the inverter displays a low-torque detection fault and the motor coasts to a stop.




Figure 4.4.64 Low torque detection operation

Over and low torque detection condition can be output to the multi-function digital outputs (R1A-R1C, R2A-R2C, R3A-R3C) by setting parameters 03-11, 03-12 and 03-39 to 12 or 25. Refer to Fig. 4.4.65 for more information.




Figure 4.4.65 Over-torque / low torque detection multi-function digital output terminal

08- 23	Ground Fault (GF) Selection
Range	【0】 : Disable 【1】 : Enable

If the inverter leakage current is greater than 50% of inverter rated current and the ground fault function is enabled (08-23), the keypad will display a "GF Ground Fault" (GF), motor will coast to a stop and fault contact is activated.

08- 24	Operation Selection of External Fault
Range	【0】 : Deceleration to Stop 【1】 : Coast to Stop 【2】 : Continuous Operation

When multi-function digital input terminal is set to 25 (the external fault) and this terminal signal is triggered off, parameter 08-24 (Operation Selection of External Fault) can be selected to stop it. The selection of stop modes is the same as 07-09.

08- 25	Detection selection of External Fault
Range	【0】 : Immediately Detect when the Power is Supplied 【1】 : Start to Detect during Operation

The reason for the detection of external faults is determined by parameter 08-25.

- When 08-25=0, faults are immediately detected at power up.
- When 08-25=1, faults are detected when the inverter is running.

08- 30	Selection of Safety Function
Range	【0】 : Deceleration to Stop 【1】 : Coast to Stop

If multi-function digital input terminal is set to 58 (Safety Function), inverter will stop via the set of 08-30 when this function is enabled.

08- 37	Fan Control Function
Range	【0】 : Start at Operation 【1】 : Permanent Start 【2】 : Start at High Temperature
08- 38	Delay Time of Fan Off
Range	【0~600】 Sec

08-37=0: Start at Operation

Fan starts while inverter is running.

If the inverter stops over the delay time of fan off (08-38), fan is off.

08-37=1: Permanent Start

When the inverter is at power on, fan will start permanently.

08-37=2: Start at High Temperature

When the temperature of heatsink is higher than that of internal setting, fan immediately starts.

If the temperature is lower than internal setting value or the delay time of fan off (08-38) is due, fan will be off.

Note: Function of fans on is disabled for the models of 40HP or the above (200V) and 50HP or the above (400V) in IP20 series and is enabled for all the models in IP55 series.

08- 35	Fault Selection of Motor Overheat
Range	【0】 : Disable 【1】 : Deceleration to Stop 【2】 : Coast to Stop
08- 36	Time Coefficient of PTC Input Filter
Range	【0.00 ~ 5.00】
08- 39	Delay Time of Motor Overheat Protection
Range	【1 ~ 300】 Sec

Protection of motor overheating is enabled via the sensor of motor fan with the temperature impedance

characteristics of positive temperature coefficient (PTC).

Thermistor of PTC connects with terminals MT and GND. If motor is overheating, the keypad displays the error code of OH4.

08-35=0: Fault selection of motor overheating is disabled.

08-35=1, 2: Motor stop running while fault of motor overheating occurs.

Protection of motor overheating is enabled at $R_T > 1330\Omega$ of thermistor of PTC and the reach of delay time set by 08-39. The keypad will display an "OH4 Motor overheat" and fault output is active.

When the value of thermistor of PTC is $R_T < 550\Omega$, it can reset "OH4 Motor overheat."

Note: The stop mode of the inverter fault is set by 08-35.

08-35=1: Deceleration to stop when the inverter fault occurs.

08-35=2: Coast to stop when the inverter fault occurs

Notes:

- If thermistor of PTC does not connect with MT and GND, the keypad will display an "OH4 Motor overheat."
- The value of the external thermistor of PTC is in compliance with British National Standard. When T_r is 150°C in class F and 180°C in class H,
 - a. $T_r - 5^\circ\text{C}$: $R_T \leq 550\Omega$
 - b. $T_r + 5^\circ\text{C}$: $R_T \geq 1330\Omega$

Refer to Fig. 4.4.66 for the connecting between the corresponding temperature of thermistor of PTC and terminals.




Figure 4.4.66 Protection of motor overheating

Group 09: Communication Parameters

09- 00	INV Communication Station Address
Range	【1~31】
09- 01	Communication Mode Selection
Range	【0】 : MODBUS 【1】 : BacNET 【2】 : MetaSys 【3】 : PUMP in Parallel Connection 【4】 : PROFIBUS
09- 02	Baud Rate Setting (bps)
Range	【0】 : 1200 【1】 : 2400 【2】 : 4800 【3】 : 9600 【4】 : 19200 【5】 : 38400
09- 03	Stop Bit Selection
Range	【0】 : 1 Stop Bit 【1】 : 2 Stop Bits
09- 04	Parity Selection
Range	【0】 : No Parity 【1】 : Even Bit 【2】 : Odd Bit
09- 06	Communication Error Detection Time
Range	【0.0~25.5】 Sec
09- 07	Fault Stop Selection
Range	【0】 : Deceleration to Stop Based on Deceleration Time 1 【1】 : Coast to Stop when Communication Fault Occurs. 【2】 : Deceleration to Stop Based on Deceleration Time 2 【3】 : Keep Operating when Communication Fault Occurs.
09- 08	Comm. Fault Tolerance Count
Range	【1~20】
09- 09	Waiting Time
Range	【5~65】 msec
09- 10	Device Instance Number
Range	1~254

The Modbus communication port RJ45 (S+, S-) can be used to monitor, control, program and trouble-shoot the inverter. The built-in RS-485 can support the following communication protocol:

- Modbus communication protocol
- BacNet communication protocol (Refer to section 4.7 for more details)
- MetaSys communication protocol (Refer to section 4.8 for more details)
- Pump in Parallel Connection (Refer to parameter group 23 for more details)
- Profibus communication protocol (Refer to section 11.9 Profibus communication option card for more details and this function is required to install Profibus card to be enabled).

Modbus communication can perform the following operations, independent of the frequency command selection (00-05) setting and operation command selection (00-02) setting:

- Monitor inverter signals
- Read and write parameters.
- Reset fault

- Control multi-function inputs

Modbus (RS-485) communication specification:

Items	Specification
Interface	RS-485
Communication type	Asynchronous (start - stop synchronization)
Communication parameters	Baud rate: 1200, 2400, 4800, 9600, 19200 and 38400 bps Data Length: 8 bits (Fixed) Parity: options of none, even and odd bit. For even and odd selection stop bit is fixed at 1 bit.
Communication protocol	Modbus RTU / ASCII
Number of inverters	Maximum 31 units

Communication wiring and setup

- (1) Turn off power to the inverter.
- (2) Connect communication lines of the controller to the inverter (RJ45).
- (3) Turn power on.
- (4) Set the required communication parameters (09-00) via the keypad.
- (5) Turn off power to the inverter and wait until keypad is completely off.
- (6) Turn power on
- (7) Start communication between controller and inverter.

Modbus (485) communication architecture

- (1) Modbus communication configuration uses a master controller (PC, PLC), communicating to a maximum of 31 inverters.
- (2) The master controller is directly connected to the inverter via the RS-485 interface. If the master controller has a RS-232, a converter must be installed to convert signals to RS-485 to connect the master controller to the inverter.
- (3) A maximum 31 inverters can be connected to a network, following the Modbus communication standard.

Communication Parameters:

09-00: Inverter station addresses: Range 1-31

09-02: RS-485 communication baud rate setting

- = 0: 1200 bps (bits / second)
- = 1: 2400 bps
- = 2: 4800 bps
- = 3: 9600 bps
- = 4: 19200 bps
- = 5: 38400 bps

09-03: Stop bit selection

- = 0: 1 stop bit
- = 1: 2 stop bits

09-04: Parity selection of RS-485 communication

- = 0: No parity.
- = 1: even parity.
- = 2: odd parity.

09-06: RS-485 communication error detection time

09-07: Stop selection of RS-485 communication failure

- = 0: Deceleration to stop by deceleration time 00-15
- = 1: Coast to stop
- = 2: Deceleration to stop using the deceleration time of 00-26 (emergency stop time)
- = 3: Continue to operate (only shows a warning message, press the stop button to stop operation)

09-08: Comm. fault tolerance count

When the number of communication errors exceeds the value set in parameter 09-08 the inverter will display the comm. Fault alarm.

09-09: Wait time of inverter transmission

Sets the inverter response delay time. This is the time between the controller message and the start of the inverter response message. Refer to Fig. 4.4.67. Set the controller receive time-out to a greater value than the wait time parameter (09-09).




Figure 4.4.67 Communication Message Timing

Group 10: PID Parameters

10- 00	PID Target Value Source Setting
Range	【0】 : Keypad Given (for PUMP or HVAC mode) 【1】 : AI1 Given 【2】 : AI2 Given 【3】 : Reserved 【4】 : 10-02 Given 【5】 : Reserved

Operation Pressure Setting (23-02) or Target Value of Flow Meters (PUMP or HVAC function selection) can be set as PID's target value only when 10-00=0 and 23-00=1 or 2.

When 10-00=1 or 2, signal source proportional is corresponding to PID target via analog input terminal. For example, 0~10V is corresponding to the target of 0~100% so given 2V is equivalent with the target value of 20%.

For normal use of PID, set 10-00 to 4 and set PID target value in parameter 10-02.

When 10-00=4, in addition to the percentage setting of 10-02 (PID target value), it allows PID setting (12-38) in the main screen monitor. The maximum target value is set via parameter 10-33 (PID maximum feedback value), the decimals are set via parameter 10-34 (PID decimal width) and the unit is set via parameter 10-35 (PID unit). For example:

When 10-33 = 999, 10-34 = 1, 10-35 = 3 and 10-02 = 10%, then 12-38 = 9.9 PSI displayed in the main screen monitor. User can also modify the value of 12-38 in the main screen monitor but the maximum value is 99.9 PSI (depending on the setting value of 10-33).

10- 01	PID Feedback Value Source Setting
Range	【1】 : AI1 Given 【2】 : AI2 Given 【3】 : Reserved

Note: Parameter 10-00 and 10-01 cannot be set to the same source. If both parameters are set to the same source the keypad will show a SE05 alarm.

10- 02	PID Target Value
Range	【0.0~100.0】 %
10- 03	PID Control Mode
Range	【xxx0b】 : PID Disable 【xxx1b】 : PID Enable 【xx0xb】 : PID Positive Characteristic 【xx1xb】 : PID Negative Characteristic 【x0xxb】 : PID Error Value of D Control 【x1xxb】 : PID Feedback Value of D Control 【0xxxb】 : PID Output 【1xxxb】 : PID Output + Target Value

When 10-03 is set to xxx 0b, PID will be disabled; if it is set to xxx1b, PID is enabled.

Note: When 00-02 or 00-03 is set to 5 (the source of PID frequency),

- LCD keypad will be switched automatically (16-00).
- Main Screen Monitoring will be changed to PID Setting (12-38).
- Sub-Screen Monitoring 1 will be changed to PID Feedback (12-39).
- Sub-Screen Monitoring 2 will be changed to Output Frequency (12-17).

At this time, if the setting is disabled, it will be switched automatically back to frequency command as the main page. When switching to PID setting in the LED keypad, it displays the modes selection of parameter 23-05.

Note: when 23-05=0, set the value in the conditions of 10-33 < 1000 and 10-34=1, or the inverter will display the signal of PID setting error (SE05).

When 10-03 is set to xx0xb, PID output occurs forward; if it is set to xx1xb, PID output occurs reversely. If PID feedback value is lower than the target value when PID output is set to be reverse, the output frequency is lower.

When 10-03 is set to x1xxb, PID control for feedback differential value is enabled; if it is set to x0xxb, basic PID control is enabled. Refer to Fig.4.4.69 and Fig.4.4.70.

When 10-03 is set to 0xxxb, PID output is enabled and it is corresponding to the frequency of 01-02 at 100%.

When 10-03 is set to 1xxxb, PID output and target value are enabled. The output percentage of target value (corresponding to the frequency of 01-02) will be cumulated when the inverter starts to run, and PID control starts.

10- 04	Feedback Gain
Range	【0.01~10.00】
10- 05	Proportional Gain (P)

Range	【0.00~10.00】
10- 06	Integral Time (I)
Range	【0.0~100.0】 Sec
10- 07	Differential Time (D)
Range	【0.00~10.00】 Sec
10- 09	PID Bias
Range	【-100~100】 %
10- 10	PID Primary Delay Time
Range	【0.00~10.00】 %
10-14	PID Integral Limit
Range	【0.0~100.0】 %
10-23	PID Limit
Range	【0.00~100.0】 %
10-24	PID Output Gain
Range	【0.0~25.0】
10-25	PID Reversal Output Selection
Range	【0】 : Do not Allow Reversal Output 【1】 : Allow Reversal Output
10-26	PID Target Acceleration/ Deceleration Time
Range	【0.0~25.5】 Sec

PID Adjustments

Gain control: The error signal (deviation) between the input command (set value) and the actual control value (feedback). This error signal or deviation is amplified by the proportional gain (P) to control the offset between the set value and the feedback value.

Integral control: The output of this control is the integral of the error signal (difference between set value and feedback value) and is used to minimize the offset signal that is left over from the gain control. When the integral time (I) is increased, the system response becomes slower.

Differential control: This control is the inverse from integral control and tries to guess the behavior of the error signal by multiplying the error with the differential time. The result is added to the PID input. Differential control slows down the PID controller response and may reduce system oscillation. **Note:** Most applications that PID control (fan and pump) do not require differential control. Refer to Fig. 4.4.68 for PID control operation




Figure 4.4.68 PID Control

PID Control Type

The inverter offers two types of PID control:

(a) PID control with differential feedback: (10-03 = x1xxb)

Make sure to adjust the PID parameters without causing system instability. Refer to Fig. 4.4.69 for PID control for feedback value differential.




Figure 4.4.69 PID control for feedback differential value

(b) Basic PID control: (10-03 = x0xxb)

This is the basic type of PID control. Refer to the Fig. 4.4.70.




Figure 4.4.70 Basic PID control

PID Setup

Enable PID control by setting parameter 10-03, PID target value (10-00) and PID feedback value (10-01).

To use PID control set frequency command selection 00-05 to 4.

10-00: PID target value

- = 0: keypad given
- = 1: analog AI1 given (default)
- = 2: analog AI2 given
- = 3: Reserved
- = 4:10-02

10-01: PID feedback value

- = 1: Analog AI1 given
- = 2: Analog AI2 given
- = 3: Reserved




Figure 4.4.71 PID input selection

PID Control Setting

PID control block diagram.

The following figure shows the PID control block diagram.




Figure 4.4.72 PID control block diagram

PID Tuning

Use the following procedures to start PID control,

- (1) Enable PID control (set 10-03 to a value greater than "xx0b").
- (2) Increase the proportional gain (10-05) to the highest value possible without causing the system to become unstable.
- (3) Decrease the integral time (10-06) to the lowest value possible without causing the system to become unstable.
- (4) Increase the differential time (10-07) to the highest value possible without causing the system to become unstable.

The PID control serves to maintain a given process within certain limits whether it is pressure, flow etc. To do this the feedback signal is compared to the set value and the difference becomes the error signal for the PID control.

The PID control then responds by trying to minimize this error. The error is multiplied times the value of the proportional gain set by parameter **10-05**. An increased gain value results in a larger error. However, in any system as the gain is increased there is a point that the system will become unstable (oscillate).

To correct this instability, the response time of the system may be slowed down by increasing the **Integral time** set by parameter **10-06**. However slowing the system down too much may be unsatisfactory for the process.

The end result is that these two parameters in conjunction with the acceleration time (01-14) and deceleration (**01-15**) times require to be adjusted to achieve optimum performance for a particular application.

PID output polarity can be selected with parameter 10-03 (setting = xx0xb: PID output forward, setting = xx1xb: PID output reversal). When the PID output is set for reverse operation the output frequency decreased when the PID target value increases.

PID feedback value can be adjusted using parameter 10-04 (PID feedback gain) as well as with the analog input gain and bias for terminal AI1 or AI2.

10-14: PID integral limit: Used to limit the integral output to prevent motor stall or damage to the system in case of a rapid change in the feedback signal. Reduce the value of 10-14 to increase the inverter response.

10-23: PID limit: Used to limit the output of the PID control. Maximum output frequency is 100%.

10-10: Primary delay time: Low pass filter situated after the PID limit block that can be used to prevent PID output resonance. Increase the time constant to a value greater than the resonance frequency cycle and reduce time constant to increase the inverter response.

10-09: PID bias: Used to adjust the offset of the PID control. The offset value is added to the frequency reference as compensation. Use parameter 10-24 (PID output gain) to control the amount of compensation.

In case the PID control output value goes negative, parameter 10-25 (PID reversal output selection) can be used to reverse the motor direction.

Note: The PID output remains at zero when reverse operation is disabled.

10-26: PID target SFS: Sets the PID target value acceleration and deceleration ramp time. The PID target SFS can be disabled by setting the multi-function digital inputs 03-00 ~ 03-05 to 36 (PID target SFS is off). Reduce the acceleration / deceleration time in case load resonance or system instability is encountered.


PID Fine Tuning

All PID control parameters are related to each other and require to be adjusted to the appropriate values. Therefore, the procedure achieving the minimum steady-state is shown as following:

- (1) Increase or decrease the proportion (P) gain until the system is stable using the smallest possible control change.
- (2) The integral (I) reduces the system stability which is similar to increasing the gain. Adjust the integral time so that the highest possible proportional gain value can be used without affecting the system stability. An increase in the integral time reduces system response.
- (3) Adjust the differential time if necessary to reduce overshoot on startup. The acceleration / deceleration time can also be used for the same purpose.


Fine-tuning PID control parameters:

- (1) Reduce overshoot




In case overshoot occurs, reduce the derivative time (D) and increase the integral time (I).

- (2) Stabilize PID control




To quickly stabilize the PID control, reduce the integral time (I) and increase the differential time (D) in case overshoot occurs.

- (3) Reduce long-period oscillation



Adjust the integral time (I) in case of long-periodical system oscillation.

- (4) Reduce short-period oscillation



Adjusting the differential time (D) and proportional (P) gain when experiencing short-periodical oscillation.

10-11	PID Feedback Loss Detection Selection
Range	【0】 : Disable 【1】 : Warning 【2】 : Fault
10-12	PID Feedback Loss Detection Level
Range	【0~100】 %
10-13	PID Feedback Loss Detection Time
Range	【0.0~10.0】 Sec

The PID control function provides closed-loop system control. In case PID feedback is lost, the inverter output frequency may be increase to the maximum output frequency.

It is recommended to enable to the PID feedback loss when the PID function is used.

PID feedback loss detection

10-11=0: Disable

10-11=1: Warning

A feedback loss condition is detected when the PID feedback value falls below the value set in parameter 10-12 (PID feedback loss detection level) for the time set in parameter 10-13 (PID feedback loss detection time). PID feedback loss warning message "Pb" will be displayed on the keypad and the inverter will continue to operate.

10-11=2: Fault

A feedback loss condition is detected when the PID feedback value falls below the value set in parameter 10-12 (PID feedback loss detection level) for the time set in parameter 10-13 (PID feedback loss detection time). PID feedback loss fault message "Fb" will be displayed on the keypad, the inverter stops and the fault contact is activated.




Figure 4.4.73 PID feedback loss detection

10-17	Start Frequency of PID Sleep
Range	【0.00~180.00】 Hz
10-18	Delay Time of PID Sleep
Range	【0.0~255.5】 Sec
10-19	Frequency of PID Waking up
Range	【0.00~180.00】 Hz
10-20	Delay Time of PID Waking up
Range	【0.0~255.5】 Sec
10-29	PID Sleep Selection
Range	【0】 : Disable 【1】 : Enable 【2】 : Set by DI

The PID Sleep function is used to stop the inverter when the PID output falls below the PID sleep level (10-17) for the time specified in the PID sleep delay time parameter (10-18).

The inverter wakes up from a sleep condition when the PID output (Reference frequency) rises above the PID wake-up frequency (10-19) for the time specified in the PID wake-up delay time (10-20).

Use parameter 10-29 to enable / disable PID sleep function.

10-29 =0: PID Sleep function is disabled.

10-29 =1: PID sleep operation is based on parameters of 10-17 and 10-18.

10-29 =2: PID sleep mode is enabled by multi-function digital input

Refer to Fig.4.4.74 (a) and (b) for PID sleep / wakeup operation.




Figure 4.4.74: (a) PID control block diagram




Figure 4.4.74: (b) Timing diagram PID sleep / wakeup

Notes:

- The PID sleep timer is enabled when the output frequency (Fout) falls below the PID sleep frequency (10-17). When the sleep timer reaches the set PID sleep delay time (10-18) the inverter will decelerate to a stop and enter the sleep mode.
- While sleep mode is active and the motor has stopped, the internal PID control is still in operating. When the reference frequency increases and exceeds the wakeup frequency parameter 10-19 for the time specified in the wakeup delay time parameter 10-20, the inverter will restart and the output frequency will ramp up to the reference frequency.
- Parameter 10-00 and 10-01 cannot be set to the same source. If both parameters are set to the same source the keypad will show a SE05 alarm.

10-27	PID Feedback Display Bias
Range	【-99.99~99.99】
10-28	PID Feedback Display Gain
Range	【0.00~100.00】

PID Feedback Display Scaling

The PID feedback signal can be scaled to represent actual engineering units. Use parameter 10-28 to set the feedback signal gain for the feedback signal range maximum and parameter 10-27 to the feedback signal minimum.

Example:

Feedback signal is a pressure transducer (4-20mA) with a range of 0 – 200 PSI
 4mA = 0 PSI, 20mA = 200 PSI.

Set parameter 10-27 to 0.0 minimum of transducer range (0%).
 Set parameter 10-28 to 2.0 maximum of transducer range (100%).

Refer to the Fig.4.4.75 for displaying the unit conversion.




Figure 4.4.75 Feedback signal scaling

10-30	Upper Limit of PID Target
Range	【0 ~ 100】 %
10-31	Lower Limit of PID Target
Range	【0 ~ 100】 %

PID target value will be limited to the upper and lower limit range of PID target.

10- 32	PID Switching Function
Range	【0】 : PID1 【1】 : PID2 【2】 : Set by DI 【3】 : Set by RTC

10-32=0: PID 1 function is enabled.

PID target value is set by 10-02 and proportional gain, integral time and differential time are set by 10-05, 10-06 and 10-07.

10-32=1: PID 2 function is enabled.

PID target value is set by 10-02 and proportional gain, integral time and differential time are set by 10-36, 10-37 and 10-38.

10-32=2: Set by Digital Input

If the digital input terminal is enabled (digital multi-function terminal is set to 54), PID1 will switch to PID2.

10-32=3: Set by RTC

When RTC timer is enabled, PID1 will switch to PID2.

10- 33	PID Maximum Feedback Value
Range	【1~10000】

Function of PID maximum feedback value is the 100% corresponding value of 10-02.

10- 34	PID Decimal Width
Range	【0~4】

Function of PID decimal width enables the user to set the decimal point.

For example, if it is set to 1, the keypad displays the first decimal place XXX.X. If it is set to 2, the keypad displays the second decimal place XX.XX.

10- 35	PID Unit
Range	【0~23】

PID unit enables the user to select the unit for PID target value.

When 10-35=0, parameter of 12-38 will be used by the unit of %.

10- 36	PID2 Proportional Gain (P)
Range	【0.00~10.00】
10- 37	PID2 Integral Time (I)
Range	【0.0~100.0】 Sec
10- 38	PID2 Differential Time (D)
Range	【0.00~10.00】 Sec

Refer to the PID function for more details of PID2 description.

10- 39	PID Output Frequency Setting during disconnection	*1
Range	【0~400】 Hz	

*1: It is new added in inverter software V1.4.

When the warning of PID feedback disconnection occurs, frequency command output depends on the parameter 10-39. When the disconnection warning is removed, PID control restores.

Group 11: Auxiliary Parameters

11- 00	Direction Lock Selection
Range	【0】 : Allow Forward and Reverse Rotation 【1】 : Only Allow Forward Rotation 【2】 : Only Allow Reverse Rotation

If motor operation direction is set to 1 or 2, the motor can only operate in that specific direction. Run commands in the opposite direction are not accepted.

Forward or reverse commands can be issued via the control terminals or keypad.

Note: The reverse rotation selection can be used in fan and pump application where reverse rotation is prohibited.

11- 01	Carrier Frequency	
Range	【0】 : Carrier Output Frequency Tuning 【1】 : 1.5 KHz 【2~16】 2~16 KHz	*1

*1: It is reserved in inverter software V1.3

Notes:

- (1) Value 1 to 16 represents KHz.
- (2) When 11-01=0, variable carrier frequency is used see parameter 11-30~11-32.
- (3) For SLV mode, the minimum value of 11-01 is 4 kHz.
- (4) Setting range is determined by the inverter rating (13-00).
- (5) Refer to section 3 inverter derating based on carrier frequency.
- (6) A low carrier frequency increases motor noise but reduces motor losses and temperature.
- (7) A low carrier frequency decreases RFI, EMI interference and motor leakage current.

Refer to the carrier frequency Table 4.4.11.

Table 4.4.11 Carrier frequency settings

Carrier frequency (11-01=1 to 16)	1.5KHz--6K--10K--16KHz	
Motor noise	High -----	low
Output current waveform	Non-sinusoidal -----	sinusoidal (better)
Noise interference	Low -----	high
Leakage current	Low -----	high

If wire length between the inverter and the motor is too long, the high-frequency leakage current will cause an increase in inverter output current, which might affect peripheral devices. Adjust the carrier frequency to avoid this as shown in Table 4.4.12.

Table 4.4.12 Wire length and carrier frequency

Wire length	< 30 Meter (98ft)	up to 50 Meter (164 ft)	up to 100 Meter (328ft)	> 100 Meter > 328ft
Carrier frequency (11-01 value)	Max. value 16KHz (11-01=14KHz)	Max. value 10KHz (11-01=10KHz)	Maxi. value 5KHz (11-01=5KHz)	Max. value 2KHz (11-01=2KHz)

Notes:

- Reduce the carrier frequency if the torque does not match the speed.
- In V/F control mode, the carrier frequency is determined by parameters 11-30 (Carrier frequency max. limit), 11-31 (Carrier frequency lower limit) and 11-32 (Carrier frequency proportional gain).

11- 02	Soft PWM Function Selection
Range	【0】 : Disable 【1】 : Enable

11-02=0: Soft-PWM control disabled.

11-02=1: Soft-PWM control enabled. Soft-PWM control can improve the ‘metal’ noise produced by the motor, more comfortable for the human ear. At the same time, Soft-PWM also limits RFI noise to a minimum level. The default setting of Soft-PWM control is disabled. When Soft-PWM is enabled, the maximum carrier frequency is limited to 8 kHz.

11- 03	Automatic Carrier Lowering Selection
Range	【0】 : Disable 【1】 : Enable

11-03=0: Automatic carrier frequency reduction during an overheat condition is disabled.

11-03=1: Carrier frequency is automatically lowered in case the inverter heatsink overheats and returns to carrier frequency set in parameter 11-01 when the inverter temperature returns to normal. See section 3.5 for more information.

11- 04	S-curve Time Setting at the Start of Acceleration
11- 05	S-curve Time Setting at the End of Acceleration
11- 06	S-curve Time Setting at the Start of Deceleration
11- 07	S-curve Time Setting at the End of Deceleration
Range	【0.00~2.50】 Sec

The S curve function for acceleration / deceleration is used to reduce mechanical impact caused by the load during momentary starting and stopping of the inverter. To use the S curve function set the time for acceleration start point (11-04), acceleration end point (11-05), deceleration start point (11-06) and deceleration end point (11-07). Refer to Fig.4.4.76 for more information.




Figure 4.4.76 S curve characteristic

Total acceleration and deceleration time when the S curve is used:

$$\text{Accelerating time} = \text{Accelerating time 1 (or 2)} + \frac{(11-04) + (11-05)}{2}$$

$$\text{Deceleration time} = \text{Deceleration time 1 (or 2)} + \frac{(11-06) + (11-07)}{2}$$

11- 08	Jump Frequency 1
11- 09	Jump Frequency 2
11-10	Jump Frequency 3
Range	【0.0~400.0】 Hz
11-11	Jump Frequency Width
Range	【0.0~25.5】 Hz

These parameters allow “jumping over” of certain frequencies that can cause unstable operation due to resonance within certain applications.

Note: Prohibit any operation within the jump frequency range. During acceleration and deceleration the frequency is continuous without skipping the jump frequency.

To enable jump frequency 1 – 3 (11-08 – 11-10) set the frequency to a value greater than 0.0 Hz.

Use the jump frequency width (11-11) to create a jump frequency range. Refer to Fig.4.4.77.




Figure 4.4.77 Jump frequency operation

Jump frequency via Analog Input.

Set parameter 04-05 (AI2 function selection) to 9 (frequency jump setting 4) to control the jump frequency via analog input AI2. Refer to Fig. 4.4.38.

Note: When jump frequency overlap the sum of the overlapped jump frequencies will be used as the jump frequency range. Refer to Fig.4.4.78.




Figure 4.4.78 Jump frequency overlap

11- 13	Automatic Return Time
Range	【0~120】 Sec

If the keypad is not pressed within the time set by 11-13, it will automatically return to the mode screen.

When it is set to 0, function of automatic return key is off. Press the return key to return to the previous directory.

11- 12	Manual Energy Saving Gain
Range	【0~100】 %
11- 18	Manual Energy Saving Frequency
Range	【0.00~400.00】 Hz

Manual energy savings reduces the output voltage for the purpose of saving energy.

To enable manual energy savings set one of the multi-function digital input (03-00 to 03-05) to 20 and activate the input or use parameter 11-18 to set the manual energy savings activation frequency.

When the output frequency rises above the value set in parameter 11-18 manual energy savings function is enabled. Setting parameter 11-18 manual energy savings frequency to 0.0 Hz disables the manual energy savings frequency activation function. Refer to figure 4.4.88 for more information.

Note: Only use manual energy savings functions in combination with light loads.

Manual energy saving gain (11-12) determines the output voltage of the inverter when manual energy savings is enabled. Output voltage is percentage gain times the V/F voltage.

Manual energy saving control uses the voltage recovery time (07-23) to change the output voltage




Figure 4.4.79 Manual energy saving operation

11- 19	Automatic Energy Saving Function
Range	【0】 : Automatic Energy Saving is Disabled. 【1】 : Automatic Energy Saving is Enabled.
11- 20	Filter Time of Automatic Energy Saving
Range	【0~200】 msec
11- 21	Voltage Upper Limit of Energy Saving Tuning
Range	【0~100】 %
11- 22	Adjustment Time of Automatic Energy Saving
Range	【0~5000】 msec
11- 23	Detection Level of Automatic Energy Saving
Range	【0~100】 %
11- 24	Coefficient of Automatic Energy Saving
Range	【0.00~655.35】

In the V/F control mode the automatic energy saving (AES) function automatically adjusts the output voltage and reduces the output current of the inverter to optimize energy savings based on the load.

The output power changes proportional to the motor load. Energy savings is minimal when the load exceeds 70% of the output power and savings become greater when the load decreases.

The parameter of automatic energy saving function has been set at the factory before shipment. In general, it is no need to adjust. If the motor characteristic has significant difference from the TECO standard, please refer to the following commands for adjusting parameters:

Enable Automatic Energy Savings Function

- (1) To enable automatic energy saving function set 11-19 to 1.
- (2) Filter time of automatic energy saving (11-20)
- (3) Commissioning parameter of energy saving (11-21 to 11-22)

In AES mode, the optimum voltage value is calculated based on the load power requirement but is also affected by motor temperature and motor characteristic.

In certain applications the optimum AES voltage needs to be adjusted in order to achieve optimum energy savings. Use the following AES parameters for manual adjustment:

11-21: Voltage limit value of AES commissioning operation

Sets the voltage upper limit during automatic energy saving. 100% corresponds to the settings of parameter 01-03 (Maximum Output Voltage) depending on the inverter class used. Refer to the Fig.4.4.80.




Figure 4.4.80 Voltage limit value of commissioning operation

11-22: Adjustment time of automatic energy saving

Set sample time constant for measuring output power.

Reduce the value of 11-22 to increase response when the load changes.

Note: If the value of 11-22 is too low and the load is reduced the motor may become unstable.

11-23: Detection level of automatic energy saving

Set the automatic energy saving output power detection level.

11-24: Coefficient of automatic energy saving

The coefficient is used to tune the automatic energy saving. Adjust the coefficient while running the inverter on light load while monitoring the output power. A lower setting means lower output voltage.

Notes:

- If the coefficient is set to low the motor may stall.
- Coefficient default value is based on the inverter rating. Set parameter 13-00. If the motor power does not match the inverter rating.

11- 29	Auto De-rating Selection
Range	【0】 : Disable 【1】 : Enable

The automatic de-rating function automatically reduces the output frequency by 30% of the nominal motor speed when the inverter detects an overheat condition (heatsink).

Automatic de-rating function depends on the automatic carrier frequency reduction selection (11-03).

If automatic carrier frequency reduction is disabled (11-03=0), the output frequency is reduced by 30% of the nominal motor speed when an overheat condition is detected.

If automatic carrier frequency reduction is enabled (11-03=1), the output frequency is reduced by 30% of the nominal motor speed when the carrier frequency is at its minimum setting.

11-29=0: Auto de-rating selection disabled, carrier frequency is based on 11-01 or 11-03.


11-29=1: Auto de-rating selection is enabled.

11- 30	Variable Carrier Frequency Max. Limit
Range	【0~16】 KHz
11- 31	Variable Carrier Frequency Min. Limit
Range	【0~16】 KHz
11- 32	Variable Carrier Frequency Proportional Gain
Range	【00~99】

Carrier frequency method depends on the selected control mode.

Control Mode	Variable Carrier Frequency (11-01 = 0)	Fixed Carrier Frequency (11-01 = 2-16 kHz)
V/F	Available	Available
SLV	Not available	Available

Variable carrier frequency can be adjust with parameter 11-30 ~ 11-32.



K is a coefficient; the value of K is based on the following based on the maximum carrier frequency:

K=1: when 11-30 < 5 KHz

K=2: when 10 KHz > 11-30 ≥ 5 KHz

K=3: when 11-30 ≥ 10KHz

Notes:

- In V/F control mode if the speed and torque are constant, the variable carrier frequency mode (11-01=0) can be selected to reduce the carrier frequency based on output frequency.
- If the carrier frequency proportional gain (11-32) > 6 and 11-30 < 11-31, error message "SE01" out of range will appear on the keypad.
- If the minimum limit (11-31) is set higher than the maximum limit (11-30), the minimum limit will be ignored and the carrier frequency will be set at the highest limit (11-30).
- In fixed carrier frequency mode (11-01 = 2-16) parameters 11-30, 11-31 and 11-32 are not used.
- In SLV control mode, the maximum limit of the carrier frequency is fixed at 11-30.

11- 41	Reference Frequency Loss Detection
Range	【0】 : Deceleration to Stop when Reference Frequency Disappears 【1】 : Operation is Set by 11-42 when Reference Frequency Disappears
11- 42	Reference Frequency Loss Level
Range	【0.0~100.0】 %

A reference frequency loss is detected when the frequency command falls 90% within 360ms.

When 11-41=1, main frequency command continuously compares with the previous value occurring in 360 ms.

When the frequency loss occurs, inverter will operate depending on the following estimated frequency command.

$$\text{Reference frequency command} = \text{the frequency command prior to frequency loss} \times \text{the level set in parameter 11-42}$$

Descriptions of frequency loss function:

- 1) When inverter is on operation and source of selected analog command disappears, the command acts depending on the setting of parameter 11-42.
- 2) When reference command restores to the level prior to frequency loss, inverter will restore to the previous state.

Notes:

1. Frequency command (11-42) is corresponding to the maximum output frequency of motor 1 (01-02) when reference frequency disappears.
2. The disappearance of reference frequency is only for the use of analog signal (1: AI1; 7:AI2) from the selection of main frequency source (00-05).

Refer to Fig.4.4.81 for the process diagram of multi-function digital output (03-11~03-12) when reference frequency loss occurs.




Figure 4.4.81 Operation for reference frequency loss

11- 43	Hold Frequency at Start
Range	【0.0~400.0】 Hz
11- 44	Frequency Hold Time at Start
Range	【0.0~10.0】 Sec
11- 45	Hold Frequency at Stop
Range	【0.0~400.0】 Hz
11- 46	Frequency Hold Time at Stop
Range	【0.0~10.0】 Sec

The hold function is used to temporarily hold the reference frequency in order to prevent stalling the motor or preventing an over current condition during starting or stopping due to load conditions.

During start the inverter will operate at the hold frequency at start for the time specified in the parameter 11-44 in order to establish the magnetic flux.

Note: The acceleration or deceleration time does not include the start and stop hold time. Refer to the Fig. 4.4.82.




Figure 4.4.82 Reserved function

When the inverter is in stop mode, this function can also be used to prevent wind milling. In addition, it can be used for the purpose of braking using the motor to consume the braking energy resulting in a better controlled stop. Refer to the DC brake parameter 07-16 for DC braking during start.

Notes:

- The hold function at start is inactive when the hold frequency at start (11-43) is set to a value less than Fmin (01-08).
- The hold function at stop is inactive when the hold frequency at stop (11-45) is set to a value less than Fmin (01-08).

11- 47	KEB Deceleration Time
Range	【0.0~25.5】 Sec
11- 48	KEB Detection Level
Range	【190~210】 V : 200V 【380~420】 V : 400V

KEB function can be used to keep the inverter from tripping on a under voltage condition due to a momentary power-loss. To enable the KEB function set parameter 11-47 to a value greater than 0.0 sec.

Upon detection of a power-loss the inverter uses the KEB deceleration time (11-47) to decelerate the

motor and using the regenerative energy from the motor to maintain the DC-bus at a nominal level.

11-48: KEB detection level

If the DC-bus voltage falls below the value set in 11-48, the KEB is activated and the inverter starts decelerating according to the value set in 11-47.

To accelerate back to the original output frequency one of the digital inputs (03-00 to 03-05) set for 48 (KEB acceleration) has to be activated and the DC voltage has to rise above 11-48 + delta V (Delta V = +10V for 200V series, Delta V = +20 V for 400V series).

Refer to the example in Fig.4.4.83.




Figure 4.4.83 KEB operation

11- 51	Braking Selection of Zero Speed
Range	[0] : Disable [1] : Enable

11-51: Operation selection of zero-speed braking

In V/F control mode, the DC braking operation can be used to the motor shaft. Set 11-51 to select zero-speed braking operation to 1 to enable this function.

To use DC braking operation set parameter 00-02 (operation command selection) to 1 and parameter 00-05 (frequency reference selection) to 1, the operation command and frequency reference are now set for external control. When the frequency reference is 0V (or less than 4mA), and the operation command is turned on, the zero-speed 'DC' braking operation is activated and holding torque is generated using DC braking.

Refer to Fig.4.4.84 for more information on zero-speed DC braking operation.

Note: DC braking 07-07 is limited to 20% of the inverter rated current.




Figure 4.4.84 Zero-speed braking operation

11- 54	Initialization of Cumulative Energy
Range	【0】 : Do not Clear Cumulative Energy 【1】 : Clear Cumulative Energy

Reset the cumulative energy (KWhr) (12-67) and the cumulative energy (MWhr) (12-68) via parameter 11-54.

11- 55	STOP Key Selection
Range	【0】 : Stop Key is Disabled when the Operation Command is not Provided by Keypad. 【1】 : Stop Key is Enabled when the Operation Command is not Provided by Keypad.

11-55= 0: Stop button disabled when operation command is set for terminals (00-02=1) or communication (00-02=3).

11-55= 1: Stop button enabled.

11- 56	UP/DOWN Selection
Range	【0】 : When UP/DOWN in Keypad is Disabled, it will be Enabled if Press ENTER after Frequency Modification. 【1】 : When UP/DOWN in Keypad is Enabled, it will be Enabled after Frequency Modification.

11-56= 0: Changing the reference frequency on the keypad in UP/DOWN control requires the ENTER button to be pressed for the inverter to accept the modified reference frequency.

11-56= 1: Changing the reference frequency on the keypad in UP/DOWN control immediately changes the reference frequency and there for the output frequency.

Note: The reference frequency can be changed (up or down) via the keypad or by setting one of multi-functional digital input terminals (03-00 to 03-05) to 8 and 9. Refer to instructions of (03-00 to 03-05 = 8 or 9).

11- 58	Record Reference Frequency
Range	【0】 : Disable 【1】 : Enable

This function is enabled only when one of multi-function digital input terminals (03-00 to 03-05) is set to 11 (ACC / DEC disabled) or to 8 and 9 (up / down). Refer to the figure 4.4.18 for the inhibition of acceleration / deceleration, and figure 4.4.17 for up / down operation.

11- 59	Prevention of Oscillation Gain	*1
Range	【0.01~2.50】	

Gradually increase the setting value with the unit of 0.01 when the motor is driven leading to the occurrence of oscillation under the state of normal duty.

11- 60	Prevention of Oscillation Upper Limit	*1
Range	【0~100】 %	

Function of prevention of oscillation upper limit is required to be within the setting value.


11- 61	Prevention of Oscillation Time Parameters	*1
Range	【0~100】	

Adjust the response of oscillation function. That is, adjust once delay time parameter of prevention oscillation function.

11- 62	Prevention of Oscillation Selection	*1
Range	【0】 : Mode 1 【1】 : Mode 2	

***1: It is new added in inverter software V1.4.**

When 11-62 is set to 0, the response to prevention oscillation is slower.
When 11-62 is set to 1, the response to prevention oscillation is faster.



Group 12: Monitoring Parameters

12- 00	Display Screen Selection (LED)	
Range	Highest bit => 0 0 0 0 <= lowest bit The value range of each bit is 0~7 from the highest bit to the lowest bit,	
	【0】 : No display 【2】 : Output Voltage 【4】 : heatsink Temperature 【6】 : AI1 Value	【1】 : Output Current 【3】 : DC Bus Voltage 【5】 : PID Feedback 【7】 : AI2 Value

Note: The highest bit is used for power-up monitor. The 4 least significant bits can be used to customize the display sequence see section 4.1.3.

12- 01	PID Feedback Display Mode (LED)	
Range	【0】 : Display the Feedback Value by Integer (xxx)	
	【1】 : Display the Feedback Value by the Value with First Decimal Place (xx.x)	
	【2】 : Display the Feedback Value by the Value with Second Decimal Places (x.xx)	
12- 02	PID Feedback Display Unit Setting (LED)	
Range	【0】 : xxxxx(no unit)	
	【1】 : xxxPb(pressure)	
	【2】 : xxxFL(flow)	

12- 03	Line Speed Display (LED)	
Range	【0~65535】 RPM	
12- 04	Line Speed Display Mode (LED)	
Range	【0】 : Display Inverter Output Frequency	
	【1】 : Line Speed Display at Integer.(xxxxx)	
	【2】 : Line Speed Display at One Decimal Place. (xxxx.x)	
	【3】 : Line Speed Display at Two Decimal Places. (xxx.xx)	
	【4】 : Line Speed Display at Three Decimal Places. (xx.xxx)	

12-04=0

Inverter displays the line speed at stop, operation or the modification of frequency.

12-04≠0

12-03 is set to the maximum line speed and corresponds to the maximum output frequency.


For example, if the line speed display of 12-03 is 1800, the keypad display is 900 when frequency output is 30Hz.

12- 05	Status Display of Digital Input Terminal (LED/LCD)
Range	Read-only


Terminals S1-S6 are represented using two segments of each digit. Segment turns on when input is active. The bottom segments of each of the first three digits are used to represent the digital outputs (R1, R2, R3). Segments turn on when output is active.

When operation command is changed to PLC, press RUN key and it will light up.

Example1: S1~S6, R1, R2 and R3 are ON



Example2: S1~S6, R1, R2 and R3 are OFF



Note: Refer to section 4.3 for other monitor parameters 12-11~12-79.

Monitor parameters 12-67 (KWHr) and 12-68 (MWHr) is the display of accumulative energy.

Note: Parameter 11-54 can clear the monitor parameter.

Monitor parameter 12-76 (No-load voltage) is required to refer to the descriptons of parameter 02-09(Motor 1 excitation current) and 17-09 (Motor excitation current).

Group 13 Maintenance Function Group

13- 00	Inverter Rating Selection
Range	00H~FFH

Inverter model	13- 00 display	Inverter model	13- 00 display
F510-2005-XXX	205	F510-4005-XXX	405
F510-2008-XXX	208	F510-4008-XXX	408
F510-2010-XXX	210	F510-4010-XXX	410
F510-2015-XXX	215	F510-4015-XXX	415
F510-2020-XXX	220	F510-4020-XXX	420
F510-2025-XXX	225	F510-4025-XXX	425
F510-2030-XXX	230	F510-4030-XXX	430
F510-2040-XXX	240	F510-4040-XXX	440
F510-2050-XXX	250	F510-4050-XXX	450
F510-2060-XXX	260	F510-4060-XXX	460
F510-2075-XXX	275	F510-4075-XXX	475
F510-2100-XXX	2100	F510-4100-XXX	4100
F510-2125-XXX	2125	F510-4125-XXX	4125
F510-2150-XXX	2150	F510-4150-XXX	4150
F510-2175-XXX	2175	F510-4175-XXX	4175
		F510-4215-XXX	4215
		F510-4250-XXX	4250
		F510-4300-XXX	4300
		F510-4375-XXX	4375
		F510-4425-XXX	4425
		F510-4535-XXX	4535
		F510-4670-XXX	4670
		F510-4800-XXX	4800

13- 01	Software Version
Range	0.0-9.9

13- 03	Cumulative Operation Hours 1
Range	【0~23】 hours
13- 04	Cumulative Operation Hours 2
Range	【0~65535】 days
13- 05	Selection of Accumulative Operation Time
Range	【0】 : Accumulative time in power on 【1】 : Accumulative time in operation

13-05= 0: Inverter logs the time while the inverter is powered-up.

13-05= 1: Inverter logs the time when the inverter is running.

13- 06	Parameters Locked
Range	【0】 : Parameters out of 13-06 are read-only 【1】 : Only user parameter is enabled. 【2】 : All parameters are writable.
13- 07	Parameter Password Function
Range	Reserved

13- 08	Restore Factory Setting
Range	【0】 : No Initialization 【1】 : Reserved 【2】 : 2 Wire Initialization (220/440V, 60Hz) 【3】 : 3 Wire Initialization (220/440V, 60Hz) 【4】 : 2 Wire Initialization (230/415V, 50Hz) 【5】 : 3 Wire Initialization (230/415V, 50Hz) 【6】 : 2 Wire Initialization (200/380V, 50Hz) 【7】 : 3 Wire Initialization (200/380V, 50Hz) 【8】 : PLC Initialization 【9】 : 2 Wire Initialization (230V/460V, 60Hz) 【10】 : 3 Wire Initialization (230V/460V, 60Hz) 【Others】 : Reserved

Use parameter 13-08 to initialize the inverter to factory default. It is recommended to write down the modified parameters before initializing the inverter. After initialization, the value of 13-08 will return to zero automatically.

13-08=2: 2-wire initialization (220V/440V)

Multi-function digital input terminal S1 controls forward operation / stop command, and S2 controls reverse operation / stop command. Refer to Fig.4.4.1.

Inverter input voltage (01-14) is automatically set to 220V (200V class) or 440V (400V class).

Inverter maximum frequency (01-12) is automatically set to 60Hz.

13-08=3: 3-wire initialization (220V/440V)

Multi-function digital input terminal S5 controls the forward / reverse direction, and terminals S1 and S2 are set for 3-wire start operation and stop command. Refer to Figure 4.4.2 and Figure 4.4.3 for 3-wire type operation mode.

Inverter input voltage (01-14) is automatically set to 220V (200V class) or 440V (400V class).

Inverter maximum frequency (01-12) is automatically set to 60Hz.

13-08=4: 2-wire initialization (230V/415V)

Multi-function digital input terminal S1 controls forward operation / stop command, and S2 controls reverse operation / stop command. Refer to Fig.4.4.1.

Inverter input voltage (01-14) is automatically set to 230V (200V class) or 415V (400V class).

Inverter maximum frequency (01-12) is automatically set to 50Hz.

13-08=5: 3-wire initialization (230V/415V)

Multi-function digital input terminal S5 controls the forward / reverse direction, and terminals S1 and S2 are set for 3-wire start operation and stop command.

Inverter input voltage (01-14) is automatically set to 230V (200V class) or 415V (400V class).

Inverter maximum frequency (01-12) is automatically set to 50Hz.

13-08=6: 2-wire initialization (200V/380V)

Multi-function digital input terminal S1 controls forward operation / stop command, and S2 controls reverse operation / stop command. Refer to Fig.4.4.1.

Inverter input voltage (01-14) is automatically set to 200V (200V class) or 380V (400V class).

Inverter maximum frequency (01-12) is automatically set to 50Hz.

13-08=7: 3-wire initialization (200V/380V)

Multi-function digital input terminal S5 controls the forward / reverse direction, and terminals S1 and S2 are set for 3-wire start operation and stop command.

Inverter input voltage (01-14) is automatically set to 200V (200V class) or 380V (400V class).

Inverter maximum frequency (01-12) is automatically set to 50Hz.

13-08=8: PLC initialization

Clear built-in PLC ladder logic and related values.

13-08=9: 2 wire initialization (230V/460V, 60Hz)

It is the same as 2 wire Initialization (13-08=2). The input voltage (01-14) will be set to 230V (200V class) or 460V (400V class) automatically and the maximum frequency of 01-12 will be set to 60Hz automatically.

13-08=10: 3 wire initialization (230V/460V, 60Hz)

It is the same as 3 wire Initialization (13-08=3). The input voltage (01-14) will be set to 230V (200V class) or 460V (400V class) automatically and the maximum frequency of 01-12 will be set to 60Hz automatically.

Note: The default value of 13-08 is 4(230V/415V, 50Hz) in F510 Filter Model (IP20 and IP55).

13- 09	Fault History Clearance Function
Range	【0】 : Do not Clear Fault History 【1】 : Clear Fault History

13-09=1: Clear inverter fault history including (12-11~12-15/12-45~12-64)

13- 10	Password Function 2
Range	0 ~ 9999

13- 11	C/B CPLD Ver.	*1
Range	【0.00~9.99】	

This parameter displays CPLD version on the control board.

13- 12	Option Card Id	*1
Range	【0~255】	

This parameter displays option card Id on the control board and it is enabled only with the option card.

- 【0】 : None**
- 【1】 : PG-L**
- 【2】 : PG-O**
- 【3】 : PG-PM**
- 【4】 : PG-PMS**
- 【5】 : PG-PMR**
- 【6】 : CM-P**
- 【7】 : CM-C**
- 【8】 : IO-8DO**

13- 13	Option Card CPLD Ver.	*1
Range	【0.00~9.99】	

***1: It is new added in inverter software V1.4.**

This parameter displays option card CPLD version on the control board and it is enabled only with option card.

Information
 provided by
EMAG
 Tel: 01902 601403
www.emag-ltd.co.uk

Group 14: PLC Setting Parameters

14-00	T1 Set Value 1
14-01	T1 Set Value 2 (Mode 7)
14-02	T2 Set Value 1
14-03	T2 Set Value 2 (Mode 7)
14-04	T3 Set Value 1
14-05	T3 Set Value 2 (Mode 7)
14-06	T4 Set Value 1
14-07	T4 Set Value 2 (Mode 7)
14-08	T5 Set Value 1
14-09	T5 Set Value 2 (Mode 7)
14-10	T6 Set Value 1
14-11	T6 Set Value 2 (Mode 7)
14-12	T7 Set Value 1
14-13	T7 Set Value 2 (Mode 7)
14-14	T8 Set Value 1
14-15	T8 Set Value 2 (Mode 7)
Range	【0~9999】

14-16	C1 Set Value
14-17	C2 Set Value
14-18	C3 Set Value
14-19	C4 Set Value
14-20	C5 Set Value
14-21	C6 Set Value
14-22	C7 Set Value
14-23	C8 Set Value
Range	【0~65535】

14-24	AS1 Set Value 1
14-25	AS1 Set Value 2
14-26	AS1 Set Value 3
14-27	AS2 Set Value 1
14-28	AS2 Set Value 2
14-29	AS2 Set Value 3
14-30	AS3 Set Value 1
14-31	AS3 Set Value 2
14-32	AS3 Set Value 3
14-33	AS4 Set Value 1
14-34	AS4 Set Value 2
14-35	AS4 Set Value 3
Range	【0~65535】

14-36	MD1 Set Value 1
14-37	MD1 Set Value 2
14-38	MD1 Set Value 3
14-39	MD2 Set Value 1
14-40	MD2 Set Value 2

14-41	MD2 Set Value 3
14-42	MD3 Set Value 1
14-43	MD3 Set Value 2
14-44	MD3 Set Value 3
14-45	MD4 Set Value 1
14-46	MD4 Set Value 2
14-47	MD4 Set Value 3
Range	【0~65535】

Please refer to section 4.5 for more details of built-in PLC function.

Group 15: PLC Monitoring Parameters

15- 00	T1 Current Value 1
15- 01	T1 Current Value 2 (Mode 7)
15- 02	T2 Current Value 1
15- 03	T2 Current Value 2 (Mode 7)
15- 04	T3 Current Value 1
15- 05	T3 Current Value 2 (Mode 7)
15- 06	T4 Current Value 1
15- 07	T4 Current Value 2 (Mode 7)
15- 08	T5 Current Value 1
15- 09	T5 Current Value 2 (Mode 7)
15- 10	T6 Current Value 1
15- 11	T6 Current Value 2 (Mode 7)
15- 12	T7 Current Value 1
15- 13	T7 Current Value 2 (Mode 7)
15- 14	T8 Current Value 1
15- 15	T8 Current Value 2 (Mode 7)
Range	【0~9999】

15-16	C1 Current Value
15-17	C2 Current Value
15-18	C3 Current Value
15-19	C4 Current Value
15-20	C5 Current Value
15-21	C6 Current Value
15-22	C7 Current Value
15-23	C8 Current Value
Range	【0~65535】

15-24	AS1 Results
15-25	AS2 Results
15-26	AS3 Results
15-27	AS4 Results
15-28	MD1 Results
15-29	MD2 Results
15-30	MD3 Results
15-31	MD4 Results
15-32	TD Current Value
Range	【0~65535】

Group 16: LCD Function Parameters

16- 00	Main Screen Monitoring
Range	【5~79】
16- 01	Sub-Screen Monitoring 1
Range	【5~79】
16- 02	Sub-Screen Monitoring 2
Range	【5~79】

At power-up the inverter shows two monitor section on the display, main monitor section and the sub-screen monitor section (smaller font).

Choose the monitor signal to be displayed as the main-screen monitor screen in parameter 16-00, and the monitor signals to be displayed on the sub-screen monitor in parameters 16-01 and 16-02, similar to monitor parameters 12-5 ~ 12-79.

Note: The setting value of 16-00, 16-01 and 16-02 can be modified. It also can reset except PID modes (refer to the setting description of parameter 10-03) and PUMP modes (refer to the setting description of parameter 23-00), but these two modes can be modified in inverter software V1.4.

16- 03	Selection of Display Unit
Range	<p>【0】 : Display unit is Hz (Resolution is 0.01Hz) 【1】 : Display unit is % (Resolution is 0.01%) 【2】 : Rpm display; motor rotation speed is set by the control modes to select IM (02-07)/ PM (22-03) motor poles to calculate. 【40~9999】 : 100% is XXXX with no decimals (integer only) 【10001~19999】 : 100% is XXX.X with 1 decimal 【20001~29999】 : 100% is XX.XX with 2 decimals 【30001~39999】 : 100% is X.XXX with 3 decimals</p>
16- 04	Selection of Engineering Unit
Range	<p>【0】 : No Unit 【1】 : FPM 【2】 : CFM 【3】 : PSI 【4】 : GPH 【5】 : GPM 【6】 : IN 【7】 : FT 【8】 : /s 【9】 : /m 【10】 : /h 【11】 : °F 【12】 : inW 【13】 : HP 【14】 : m/s 【15】 : MPM 【16】 : CMM 【17】 : W 【18】 : KW 【19】 : m 【20】 : °C 【21】 : RPM 【21】 : RPM *1 【22】 : Bar *1 【23】 : Pa *1</p>


*1: It is new added in inverter software V1.4.

16-03: Display unit of digital operator

Set the units of the following items to be displayed, the frequency reference (05-01, 00-18, 06-01~06-15) and the monitoring frequency 12-16, 12-17 (Output frequency)

16-04: Display unit of engineering

When 16-03 = 00040-39999, engineering units are enabled. The displayed set range and the frequency range of unit (05-01, 06-01~06-15) as well as the monitoring frequency (12-16, 12-17) are changed by parameters 16-04 and 16-03.

16-03		Set / displayed contents			
0		0.01 Hz			
1		0.01 % (maximum output frequency 01-02=100%)			
2		RPM (RPM = 120 x reference frequency / numbers of motor pole. The numbers of motor pole is set by 02-07 in the control modes of V/F or SLV and is set by 22-03 in PMSLV.)			
		Set the decimal point by using the fifth place. i.e. $\square \quad \square\square\square\square$  Sets full display scaling excluding decimals Set the number of decimal places 00040 - 09999 : $\square\square\square\square$ (Integer only e.g. 1000) 10001 - 19999 : $\square\square\square.\square$ (1 decimal place e.g. 10.0) 20001 - 29999 : $\square\square.\square\square$ (2 decimal places, e.g. 10.00) 30001 - 39999 : $\square.\square\square\square$ (3 decimal places, e.g. 10.000) <example>			
00040 - 39999	16-03	Display	Display unit	Display example	
	00040 - 09999	$\square\square\square\square$		Example: 100 % speed is 0200 > set 16-03=00200 (from 05-01, 06-01 to 06-15, set range from 0040 to 9999). > set 16-04=0 (no unit)	
	10001 - 19999	$\square\square\square.\square$	use 16-04 setting	Example: 100 % speed is 200.0 CFM > set 16-03=12000 (05-01, 06-01 to 06-15, set range from 0000 to 9999). > set 16-04=2 (CFM) > 60% speed will be displayed as 120.0 CFM	
	20001 - 29999	$\square\square.\square\square$		Example: 100 % speed is 65.00°C > set 16-03=26500 (05-01, 06-01 to 06-15, set range from 0000 to 9999) > set 16-04=20 (°C) > 60% of speed is displayed as 39.00 °C	
	30001 - 39999	$\square.\square\square\square$		Example: 100 % speed is 2.555 m/s > set 16-03=32555 > set 16-04=14 (m/s) > 60% speed is displayed as 1.533 m/s	

16- 05	LCD Backlight
Range	【0~7】

Adjust the screen contrast of the digital operator. If it is set to 0, the screen backlight is turned off.

16- 07	Copy Function Selection
Range	【0】 : Do not copy parameters 【1】 : Read inverter parameters and save to the operator. 【2】 : Write the operator parameters to inverter. 【3】 : Compare parameters of inverter and operator.
16- 08	Selection of Allowing Reading
Range	【0】 : Do not allow to read inverter parameters and save to the operator. 【1】 : Allow to read inverter parameters and save to the operator.

LCD digital operator with built-in memory (EEPROM) can be used to store and retrieve parameters:

- (1) Read: Save inverter parameters to the digital operator (INV → OP).
- (2) Write: Write the parameters from the digital operator to the inverter and save (OP → INV).
- (3) Verify: Compare the inverter parameters against the parameters in the digital operator.

16-07=0: No action

16-07=1: Read (all parameters are copied from the inverter to the keypad).

16-07=2: Write (all parameter are copied from the keypad to the inverter).

16-07=3: Verify (Compare the set value of the inverter to the parameter of the digital operator).

Set 16-08 = 0, to prevent the saved parameter data stored in the digital operator from accidentally being overwritten.

When parameter 16-08=0 and the read operation is executed (16-07=1) a warning message of "RDP Read Prohibited" will be displayed on the keypad and the read operation is cancelled.

Refer to the following steps for copy function operation.

For the write-in operation requires the following items to match.









- (1) Software version
- (2) Control method
- (3) Inverter type
- (4) Inverter rated capacity and voltage

Set one of the parameters 03-00 to 03-05 (multi-function digital input selection) to 49 (Enable the parameter write-in function) to enable or disable the parameter write-in function.





When terminal is active, parameters can be copied from the digital operator to the inverter. When the terminal is not active inverter parameters are prohibited from write-in, excluding the reference frequency (00-05).





Note: Parameter 16-11 (RTC date setting) and 16-12 (RTC time setting) require resetting, after parameter setting in the keypad is written and saved in the inverter (OP→INV).

■ **READ : Copy inverter parameters to the keypad**









Steps	LCD Display (English)	Description
1		Select the copy function group (16) from the group menu.
2		Press the Read / Enter key and select parameter (16-07) copy sel.
3		Press the Read / Enter key to display the data setting / read screen (LCD display is inversed).
4		Change the set value to 1 (read) by using the up arrow key.
5		<ul style="list-style-type: none"> • Use Read / Enter key to enable the read operation, the display is shown as the left. • The bottom of LCD display will show a bar to indicate the read progress s.
6		“READ COMPLETE” will be displayed on the keypad when reading was successful.
		<ul style="list-style-type: none"> • The error message of "RDP Read Prohibited" may occur on the keypad when reading parameters from the inverter is prohibited. • If the error is displayed, press any key to remove the error message and go back to parameter 16-07.
7		When DSP/FUN key is pressed, the display returns to parameter 16-07.

■ **WRITE: Copy Keypad parameters to the Inverter**

Steps	LCD Display (English)	Description
1		Select the copy function group (16) from the group menu.
2		Press the Read / Enter key and select parameter (16-07) copy sel.
3		Press the Read / Enter key to display the data setting / read screen (LCD display is inversed).
4		Change the set value to 2 (write) by using the up arrow key.

Steps	LCD Display (English)	Description
5		<ul style="list-style-type: none"> Use Read / Enter key to enable the read operation, the display is shown as the left. The bottom of LCD display will show a bar to indicate the read progress.
6		<p>“WRITE COMPLETE” will be displayed on the keypad when writing was successful.</p>
		<ul style="list-style-type: none"> The error message of “WRE Write Error ” may occur on the keypad when writing parameters to the inverter is prohibited. If the error is displayed, press any key to remove the error message and go back to parameter 16-07.
7		<p>When DSP/FUN key is pressed, the display returns to parameter 16-07.</p>

■ **Verify: Compare Inverter Parameters against Keypad Parameters.**

Steps	LCD Display (English)	Description
1		<p>Select the copy function group (16) from the group menu.</p>
2		<p>Press the Read / Enter key and select parameter (16-07) copy sel.</p>
3		<p>Press the Read / Enter key to display the data setting / read screen (LCD display is inversed).</p>
4		<p>Change the set value to 3 (verify) by using the up arrow key.</p>
5		<ul style="list-style-type: none"> Use Read / Enter key to enable the read operation, the display is shown as the left. The bottom of LCD display will show a bar to indicate the read progress.
6		<p>“VERIFY COMPLETE” will be displayed on the keypad when writing was successful.</p>
		<ul style="list-style-type: none"> The error message of “VRYE Verify Error ” may occur on the keypad when writing parameters to the inverter is prohibited. If the error is displayed, press any key to remove the error message and go back to parameter 16-07.
7		<p>When DSP/FUN key is pressed, the display returns to parameter 16-07.</p>

16- 09	Selection of Operator Removed (LCD)
Range	【0】 : Keep operating when LCD operator is removed. 【1】 : Display fault to stop when LCD operator is removed

16-09=0: Continue operating when keypad is removed.

16-09=1: Trip inverter when keypad is removed while operating in local mode.

16- 10	RTC Time Display Setting
Range	【0】 : Hide 【1】 : Display
16- 11	RTC Date Setting
Range	【12.01.01 ~ 99.12.31】
16- 12	RTC Time Setting
Range	【00:00 ~ 23:59】

Set the internal clock before using the function of Real Time Clock (RTC).

RTC date setting is determined by parameter 16-11 and RTC time setting is determined by parameter 16-12.

RTC is displayed in the top of the keypad and refer to Fig.4.4.85 for the selection of RTC time display (16-10) is set to 1.

Monitor	00:00
Freq Ref	12-16 = 000.00 Hz
	12-17 = 000.00 Hz
	12-18 = 0000.0A

Figure 4.4.85 RTC Time Display (Example)

Notes:

- RTC is not enabled if keypad does not connect with the inverter.
- The counting time continues running regardless of the function being hide or display in the parameter 16-10 (RTC Time Display Setting).

Users can apply the parameters 12-72 and 12-73 to monitor the specific RTC date and time.

RTC has the following characteristics:

- Four times a day
- Four weeks
- Timer offset function (preset time)
- Timer enables via multi-function digital input
- Selection for constant time and speed
- Timer enables multi-function digital output

16- 13	RTC Timer Function
Range	【0】 : Disable 【1】 : Enable 【2】 : Set by DI
16- 14	P1 Start Time
16- 15	P1 Stop Time
16- 18	P2 Start Time
16- 19	P2 Stop Time
16- 22	P3 Start Time
16- 23	P3 Stop Time
16- 26	P4 Start Time
16- 27	P4 Stop Time
Range	【00:00 ~ 23:59】
16- 16	P1 Start Date
16- 17	P1 Stop Date
16-20	P2 Start Date
16- 21	P2 Stop Date
16- 24	P3 Start Date
16- 25	P3 Stop Date
16- 28	P4 Start Date
16- 29	P4 Stop Date
Range	【1】 : Mon 【2】 : Tue 【3】 : Wed 【4】 : Thu 【5】 : Fri 【6】 : Sat 【7】 : Sun
16- 30	Selection of RTC Offset
Range	【0】 : Disable 【1】 : Enable 【2】 : Set by DI
16- 31	RTC Offset Time Setting
Range	【00:00 ~ 23:59】
16- 32	Source of Timer 1
16- 33	Source of Timer 2
16- 34	Source of Timer 3
16- 35	Source of Timer 4
Range	【0~31】 : Refer to Table 4.4.13
16- 36	Selection of RTC Speed
Range	【0】 : Off 【1】 : By Timer 1 【2】 : By Timer 2 【3】 : By Timer 3 【4】 : By Timer 4 【5】 : By Timer 1+2
16- 37	Selection of RTC Rotation Direction
Range	【xxx0 B】 : RTC Run1 Forward Rotation 【xxx1 B】 : RTC Run1 Reverse Rotation

	【xx0x B】 : RTC Run2 Forward Rotation	【xx1x B】 : RTC Run2 Reverse Rotation
	【x0xx B】 : RTC Run3 Forward Rotation	【x1xx B】 : RTC Run3 Reverse Rotation
	【0xxx B】 : RTC Run4 Forward Rotation	【1xxx B】 : RTC Run4 Reverse Rotation

Source of timer can be selected to link multiple time periods and one time period can be set to multiple timers.

Timer is set by the following steps:

① **Start the timer:**

Timer starts via the setting of RTC timer function (16-13).

② **Set the time period:**

Set the start & stop time and date. If the setting of start time is equal to that of stop time, timing period is off.

③ **The timer is enabled:**

Arrange time period to the specific timer (16-32~16-35).

④ **Link to parameters:**

The timer can be linked to the relay output. One relay output can be only linked to one timer(ex. 03-11, 03-12 and 03-39, 16-36).

Note: If the stop time is set to 12:00, Motor start to stop from 12:01.

Refer to Fig.4.4.86 for RTC structure.




Figure 4.4.86 RTC structure

Refer to the following Table 4.4.13 for the selection of timer operation cycle.

Table 4.4.13 Arrange time period to the timer function

16-32 ~ 16-35	O	P4	P3	P2	P1	Timer Function	Display
0	0	0	0	0	0	Without the selection of timer	None
1	0	0	0	0	1	Time Period 1	P1
2	0	0	0	1	0	Time Period 2	P2
3	0	0	0	1	1	Time Period 1 and 2	P1+P2
4	0	0	1	0	0	Time Period 3	P3
5	0	0	1	0	1	Time Period 1 and 3	P1+P3
6	0	0	1	1	0	Time Period 2 and 3	P2+P3
7	0	0	1	1	1	Time Period 1, 2 and 3	P1+P2+P3
8	0	1	0	0	0	Time Period 4	P4
9	0	1	0	0	1	Time Period 1 and 4	P1+P4
10	0	1	0	1	0	Time Period 2 and 4	P2+P4
11	0	1	0	1	1	Time Period 1, 2 and 4	P1+P2+P4

16-32 ~ 16-35	O	P4	P3	P2	P1	Timer Function	Display
12	0	1	1	0	0	Time Period 3 and 4	P3+P4
13	0	1	1	0	1	Time Period 1, 3 and 4	P1+P3+P4
14	0	1	1	1	0	Time Period 2, 3 and 4	P2+P3+P4
15	0	1	1	1	1	Time Period 1, 2, 3 and 4	P1+P2+P3+P4
16	1	0	0	0	0	Offset selection	Offset (O)
17	1	0	0	0	1	Offset and time period 1	O+P1
18	1	0	0	1	0	Offset and time period 2	O+P2
19	1	0	0	1	1	Offset and time period 1 and 2	O+P1+P2
20	1	0	1	0	0	Offset and time period 3	O+P3
21	1	0	1	0	1	Offset and time period 1 and 3	O+P1+P3
22	1	0	1	1	0	Offset and time period 2 and 3	O+P2+P3
23	1	0	1	1	1	Offset and time period 1, 2 and 3	O+P1+P2+P3
24	1	1	0	0	0	Offset and time period 4	O+P4
25	1	1	0	0	1	Offset and time period 1 and 4	O+P1+P4
26	1	1	0	1	0	Offset and time period 2 and 4	O+P2+P4
27	1	1	0	1	1	Offset and time period 1, 2 and 4	O+P1+P2+P4
28	1	1	1	0	0	Offset and time period 3 and 4	O+P3+P4
29	1	1	1	0	1	Offset and time period 1, 3 and 4	O+P1+P3+P4
30	1	1	1	1	0	Offset and time period 2, 3 and 4	O+P2+P3+P4
31	1	1	1	1	1	Offset and time period 1, 2, 3 and 4	O+P1+P2+P3+P4

Reference frequency and motor rotation direction are controlled by RTC function.

16-36=0: RTC speed selection is disabled.

16-36=1: Timer 1 is enabled.

Reference frequency = Frequency Setting of Speed-Stage 0 (05-01)

16-36=2: Timer 2 is enabled.

Reference frequency = Frequency Setting of Speed-Stage 0 (05-01)

16-36=3: Timer 3 is enabled.

Reference frequency = Frequency Setting of Speed-Stage 0 (05-01)

16-36=4: Timer 4 is enabled.

Reference frequency = Frequency Setting of Speed-Stage 0 (05-01)

16-36=4: Timer 1 and 2 are enabled.

Reference frequency is enabled by the simultaneous operation of timer 1 and 2.

Notes:

- The inverter runs via the start of the specific timer without the influence of other timers.
- The selection of RTC speed setting (16-36) is affected by the action of time period 1 to 4 (P1~P4) which is corresponding to the selection of RTC rotation direction (16-37).

For example:

When the selection of RTC speed is set to 5 (by timer 1+2), source of run command (00-02) and source of frequency command (00-05) are required to set to RTC. Thus, reference frequency is controlled by RTC timer 1 and 2 and the inverter continues running.

Refer to Table 4.4.14 for the control of reference frequency.

Note: Selection of RTC Rotation Direction (16-37) is limited by the Motor Direction Lock Selection(11-00).

Table 4.4.14 Reference frequency is determined by timer 1 and 2

Timer 1	Timer 2	Main Frequency Command Source Selection (00-05)	Source of frequency setting	Selection of rotation direction
0	0	6(RTC)	Set by frequency setting of speed-stage 0 (05-01)	By RTC 1 (16-37)
1	0	6(RTC)	Set by frequency setting of speed-stage 1 (06-01)	By RTC 2 (16-37)
0	1	6(RTC)	Set by frequency setting of speed-stage 2 (06-02)	By RTC 3 (16-37)
1	1	6(RTC)	Set by frequency setting of speed-stage 3 (06-03)	By RTC 4 (16-37)

RTC function can not run normally when:

- When multi-function terminal (03-00~03-05) is set to the fire mode.
- When KEB function is enabled
 - Source of main frequency of RTC function is according to Table 4.4.14 and also can refer to main and alternative frequency command modes (00-07).
 - If main run command source selection (00-02) is set to 0~3 (0: keypad, 1: external terminal, 2: communication control, 3: PLC), refer to Table 4.4.15 for the relationship between main run command and RTC timer status.

Table 4.4.15 Relationship between main run command and RTC timer status

Main run command 00-02	RTC timer x status	Inverter status
0~3	0	Inverter can not run (without run command)
0~3	1	Inverter can not run (without run command)
4	0	Inverter can not run (RTC timer is disabled)
4	1	Inverter runs and rotates depending on the function of 16-37.

Take an example for RTC timer connecting with different parameters:

The work time on Monday is 6:00 AM to 10:00 PM.

The work time on Tuesday to Friday is 8:00 AM to 8:00 PM.

The work time on Saturday is 8:00 AM to 6:00 PM.

The work time on Sunday is 8:00 AM to 12:00 PM.

Motor runs on weekdays (Mon. to Fri.) at speed 1 and on weekends at speed 2.




Figure 4.4.87 RTC timer (example)

- ① **Start up the timer in the parameter group 16** (Set the internal time first to enable this function).
Set the correct date and time in the parameters 16-11 and 16-12 and set parameter 16-13 to 1(enable RTC timer function).
- ② **Set time period 1 (P1)**
Start time 1: 16-14 = 06:00:00 (6:00 AM)
Stop time 1: 16-15 = 22:00:00 (10:00 PM)
Start date 1: 16-16 = 1 (Monday)
Stop date 1: 16-17 = 1 (Monday)
- ③ **Set time period 2 (P2)**
Start time 2: 16-18 = 08:00:00 (8:00 AM)
Stop time 2: 16-19 = 20:00:00 (8:00 PM)
Start date 2: 16-20 = 2 (Tuesday)
Stop date 2: 16-21 = 5 (Friday)
- ④ **Set time period 3 (P3)**
Start time 3: 16-22 = 08:00:00 (8:00 AM)
Stop time 3: 16-23 = 18:00:00 (6:00 PM)
Start date 3: 16-24 = 6 (Saturday)
Stop date 3: 16-25 = 6 (Saturday)
- ⑤ **Set time period 4 (P4)**
Start time 4: 16-26 = 08:00:00 (8:00 AM)
Stop time 4: 16-27 = 12:00:00 (12:00 AM)
Start date 4: 16-28 = 7 (Sunday)
Stop date 4: 16-29 = 7 (Sunday)
- ⑥ **Timer 1 is enabled to set all the time periods (P1, P2, P3, P4)**
16-32 = 15: Source of timer 1 = P1 + P2 + P3 + P4)
- ⑦ **Selection of RTC speed is determined by timer 1**
16-36 = 1: Timer 1 is enabled.
Frequency setting is speed-stage 0 (05-01).
Rotation direction (16-37) is set to 0000b.
Then, the rotation direction of time period 1~4 (P1~P4) is corresponding to the setting of 16-37.
- ⑧ **Choose two constant speeds (speed 1 & speed 2)**
16-36 = 5: Timer 1+2 is enabled.
When timer 1 is enabled, frequency setting is speed-stage 1; while timer 2 is enabled, frequency setting is speed-stage 2.
Rotation direction (16-37) is set to 0000b.
Then, when timer 1 and timer 2 are active, direction of motor rotation is forward rotation.

Note: Select RTC offset (16-30) and set RTC offset time (16-31) to enable the offset time. Inverter runs depending on the arranging time period to timer function. Refer to the following Fig.4.4.88.




Figure 4.4.88 Operation of offset time

For example:

Inverter runs at the time period exclusive P1:

When 16-36=1 (selection of RTC speed is set to timer 1) and 16-32=17 (offset + P1), RTC offset (16-30) is set by DI and the offset time is set via 16-31. Switch on DI and RTC will immediately start up.

If the source of timer is set to 15 (P1+P2+P3+P4), press "STOP" key at the time period 1 (P1). Normally, RTC will start automatically at the next time period (P2) but it can also start via the setting of 16-30 to 2 (set by DI). Inverter re-runs when switching on DI and RTC will immediately start up.

Notes:

- If press "STOP" key at the time period and inverter can re-run at this time, user can:
 - Set the selection of RTC offset (16-30) to 2 (set by DI) and set DI to 56 (RTC Offset Enable).
 - Switch the selection of RTC offset (16-30) to be enabled.

Note:

RTC Accuracy:

Temperature	Deviation
+25°C (77°F)	+/-3 sec./ day
-20 / +50 °C (-4 / 122°F)	+/-6 sec./ day

Group 17: IM Motor Automatic Tuning Parameters

17- 00	Mode Selection of Automatic Tuning
Range	【0】 : Rotation Auto-tune 【1】 : Static Auto-tune 【2】 : Stator Resistance Measurement 【4】 : Loop Tuning
17- 01	Motor Rated Output Power
Range	【0.00~600.00】 KW
17- 02	Motor Rated Current
Range	10%~200% of the inverter rated current in V/F control mode 25%~200% of the inverter rated current in SLV control mode
17- 03	Motor Rated Voltage ^{*1}
Range	【0.0~255.0】 V: 200V 【0.0~510.0】 V: 400V
17- 04	Motor Rated Frequency ^{*2}
Range	【10.0~400.0】 Hz
17- 05	Motor Rated Speed
Range	【0~24000】 rpm
17- 06	Pole Number of Motor
Range	【2~16】 pole (Even)
17- 08	Motor No-load Voltage
Range	【50~240】 V: 220V 【100~480】 V: 440V
17- 09	Motor Excitation Current
Range	【0.01~600.00】 A (15%~70% motor rated current)
17- 10	Automatic Tuning Start
Range	【0】 : Disable 【1】 : Enable
17- 11	Error History of Automatic Tuning
Range	【0】 : No Error 【1】 : Motor Data Error 【2】 : Stator Resistance Tuning Error 【3】 : Leakage Inductance Tuning Error 【4】 : Rotor Resistance Tuning Error 【5】 : Mutual Induction Tuning Error 【6】 : Reserved 【7】 : DT Error 【8】 : Motor Acceleration Error 【9】 : Warning
17-12	Leakage Inductance Ratio
Range	【0.1~15.0】 %
17-13	Slip Frequency
Range	【0.10~20.00】 Hz

*1. Values of motor rated voltage are for 200V class, double the values for 400V class.

*2. The setting range of motor rated frequency is 0.0 to 400.0 Hz.

Auto-tuning

Based on the motor nameplate set the motor rated output power (17-01), motor output rated current (17-02), motor rated voltage (17-03), motor rated frequency (17-04), motor rated speed (17-05) and number of motor poles (17-06) to perform an auto-tune.

- Automatic tuning mode selection (17-00)

17-00=0: Perform rotational auto-tune (High performance auto-tune)

17-00=1: Perform a static non-rotational auto-tune

Motor does not rotate during auto-tuning and this tuning causes lower power at low speed.

17-00=2: Perform stator resistance non-rotational auto-tune (V/F mode) when using long motor leads. This tuning causes lower power at low speed.

17-00=3: Reserved

17-00=4: Performance improvement for in vector control mode

- Motor rated output power (17-01)
Set by inverter capacity (13-00)
- Motor rated current (17-02)
Set by inverter capacity (13-00)
Set the range to 10 %~200 % of the inverter rated current.
- Motor rated voltage (17-03)
- Motor rated frequency (17-04)
- Motor rated speed (17-05)

When tuning a special motor (e.g. constant power motor, high-speed spindle motor), with a motor rated voltage or rated motor frequency that is lower than a standard AC motor, it is necessary to confirm the motor nameplate information or the motor test report.

Prevent the inverter output voltage from saturation when the motor rated voltage is higher than the inverter input voltage (see Example 1).

Example 1: Motor rated voltage (440V/60Hz) is higher than the inverter input voltage (380V/50 Hz).




Figure 4.4.89 Rated voltage and frequency settings

Step 1: Set motor rated voltage, 17-03=440V.

Step 2: Set no-load voltage, 17-08=360V, lower the input voltage by 20V when operating in torque control.

Step 3: Set motor rated frequency:

$$17-04 = (\text{Rated frequency of motor nameplate}) \times \frac{(\text{Inverter input power voltage})}{(\text{Rated frequency of motor nameplate})} = 60\text{Hz} \times \frac{380\text{V}}{440\text{V}} = 51.8\text{Hz}$$

Step 4: Automatically tuning

Parameter 01-12 (Fbase) is automatically set during auto-tuning. Parameter 01-12 (Fbase) is set to the motor rated frequency.

Step 5: Set the 01-12 (Fbase) to the motor rated frequency on the motor nameplate. If the maximum output frequency (01-02, Fmax) and base frequency (01-12, Fbase) are different, set the maximum output frequency when the auto-tuning (01-02, Fmax) is completed.

When the inverter input voltage (or frequency) is higher than the motor rated voltage (or frequency), set the motor rated voltage (17-03) and the motor rated frequency (17-04) to the rated frequency on the motor nameplate.

Example 2: The inverter input voltage and frequency (440V/50Hz) are higher than the motor rated voltage and frequency (380V/33Hz), set 17-03 to 380V (rated motor voltage) and 17-04 to 33Hz (motor rated frequency).

- Number of poles (17-06)
Set the motor pole number with its range is 2, 4, 6, 8 and 16 poles. (It is only 2~8 poles in inverter software V1.3).
 - Motor no-load voltage (17-08)
 - a) Motor no-load voltage is mainly used in SLV mode, set to value 10~50V lower than the input voltage to ensure good torque performance at the motor rated frequency.
 - b) Set to 85 ~ 95% of the motor rated voltage. In general, the no-load voltage can be closer to the motor rated voltage for larger motors, but cannot exceed the motor rated voltage.
 - c) The motor no-load voltage can be set to a value greater than the actual input voltage. In this case, the motor can only operate under relatively low frequency. If the motor operates at the rated frequency an over voltage condition may occur.
 - d) The higher the motor power is, the higher the no-load voltage is.
 - e) A smaller no-load voltage will reduce the no-load current.
 - f) When load is applied the magnetic flux is weakened and the motor current increases.
 - g) A higher no-load voltage results in a higher the no-load current.
 - h) When load is applied the magnetic flux weakens and the motor current increases. Increasing the magnetic flux generates back EMF and results in poor torque control.
 - Motor excitation current (17-09)
 - a) Only the static-type or stator resistance measurement auto-tuning (17-00=1 or 17-00=2) can be set. This data can be obtained by manual tuning. Normally, it does not require adjusting.
 - b) Motor excitation current is used for non-rotational auto-tuning.
 - c) The setting range of motor excitation current is 15%~70% of the motor rated current.
 - d) If this parameter is not set, the inverter calculates the motor related parameters.
 - Automatic tuning start (17-10)
Set parameter 17-10 to 1 and press ENTER the inverter will display "Atrdy" for Auto-tune ready. Next, press RUN key to start the auto-tune procedure. During auto-tuning the keypad will display "Atune" for Auto-tune in progress. When the motor is successfully tuned, the keypad shows "AtEnd".
 - Error history of automatic tuning (17-11)
If auto-tuning fails the keypad will display the "AtErr" message and the auto-tune cause is shown in parameter 17-11. Refer to section 5 for troubleshooting and possible automatic tuning error causes.
- Note:** The motor tuning error history (17-11) shows the tuning result of the last auto-tune. No error is displayed when auto-tune is aborted or when the last auto-tune was successful.
- Motor Leakage Inductance Ratio (17-12)
 - a) Only stator resistance measurement auto-tuning (17-00=2) can be set and this data can be

- obtained by manual tuning. Normally, it does not require adjustment.
 - b) It is mainly for non-rotational auto-tuning. The default setting is 3.4%. It is required to tune to make the adjusted parameter value saved into the group 02-33.
 - c) If this parameter is not set, the inverter calculates the motor related parameters.
- Motor Slip Frequency (17-13)
- a) Only stator resistance measurement auto-tuning (17-00=2) can be set and this data can be obtained by manual tuning. Normally, it does not require adjustment.
 - b) It is mainly for non-rotational auto-tuning. The default setting is 1Hz. It is required to tune to make the adjusted parameter value saved into the group 02-34.
 - c) If this parameter is not set, the inverter calculates the motor related parameters.

Notes:

- Perform the "Stator resistance measurement" (17-00=2) auto-tune if the inverter/motor leads are longer than 167ft (50m).
- For the best performance in vector control perform the rotary-type automatic tune (17-00=0) first (using short motor leads between the inverter and motor) and a "Stator resistance measurement" (17-00=2) next.
- If a rotary auto-tune (17-00=0) cannot be performed, manually enter the mutual induction (02-18), excitation current (02-09), core saturation compensation factor 1-3 (02-11 - 02-13).
- Perform the "Stator resistance measurement" (17-00=2) in V/F control when inverter/motor leads are longer than 167ft (50m).

Information
provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk

Group 18: Slip Compensation Parameters

18- 00	Slip Compensation Gain at Low Speed
Range	【0.00~2.50】
18- 01	Slip Compensation Gain at High Speed
Range	【-1.00~1.00】
18- 02	Slip Compensation Limit
Range	【0~250】 %
18- 03	Slip Compensation Filter Time
Range	【0.0~10.0】 sec
18- 04	Regenerative Slip Compensation Selection
Range	【0】 : Disable 【1】 : Enable
18- 05	FOC Delay Time
Range	【1~1000】 msec
18- 06	FOC Gain
Range	【0.00~2.00】

Slip compensation automatically adjusts the output frequency based on the motor load to improve the speed accuracy of the motor mainly in V/F mode.

The slip compensation function compensates for the motor slip to match the actual motor speed to the reference frequency.

Slip compensation adjustment in V/F mode

18-00: Slip compensation gain at low speed

The adjustment of slip compensation gain at low speed follows the below procedure:

1. Set the rated slip and the motor no-load current (02-00).
2. Set the slip compensation (18-00) to 1.0 (factory default setting is 0.0 in V / F control mode)
3. For the operation with a load attached, measure the speed and adjust the slip gain (18-00) accordingly (increase in steps of 0.1).
 - If the motor speed is lower than frequency reference, increase the value of 18-00.
 - If the motor speed is higher than frequency reference, decrease the value of 18-00.

When the output current is greater than the no-load current (02-00), the slip compensation is enabled and the output frequency increases from f1 to f2. Refer to Fig.4.4.90., the slip compensation value is calculated as follows:

$$\text{Slip compensation value} = \text{Motor rated sync induction rotation difference} \times \frac{[\text{Output current (12-08)} - \text{motor no-load current (02-00)}]}{[\text{Motor output rated current (02-01)} - \text{motor no-load current (02-00)}]}$$




Figure 4.4.90 Slip compensation output frequency

18-02: Slip compensation limit

Sets slip compensation limit in constant torque and the constant power operation (Fig.4.4.91).

If 18-02 is 0%, the slip compensation limit is disabled.




Figure 4.4.91 Slip compensation limit

When the slip compensation gain 18-00 at low speed is adjusted, and the actual motor speed is still lower than the reference frequency, the motor may be limited by the slip compensation limit.

Note: Make sure that the slip compensation limit 18-02 does not exceed the maximum allowed system limit.

18-03: Slip compensation filter

Set slip compensation filter time in V/F mode

18-04: Regenerating slip compensation selection

The selections to enable or disable the slip compensation function during regeneration.

To enable slip compensation during regeneration caused by deceleration (SLV mode), set 18-04 to 1 in case speed accuracy is required. When the slip compensation function is used regenerative energy might increase temporarily (18-04= 1) therefore a braking module might be required.

SLV mode adjustment

18-00: Slip compensation gain

- Slip compensation can be used to control the full range speed accuracy under load condition.
- If the speed is lower than 2 Hz and the motor speed decreases, increase the value of 18-00.
- If the speed is lower than 2 Hz and the motor speed increases, reduce the value of 18-00.

Slip compensation gain uses a single value for the whole speed range. As a result the slip compensation accuracy at low speed is high but slight inaccuracies might occur at high speeds.

Adjust parameter 18-02 together with the compensation value or continue to adjust 18-00 if the speed accuracy at higher speed is not acceptable. Please note adjusting these parameters might impact the accuracy at lower speeds.

The impact of 18-00 on the torque and the speed are shown in Fig.4.4.92.




Figure 4.4.92 18-00 Effect on the torque and speed

18-01: Slip compensation gain at high speed

It is not required to adjust the Slip compensation gain at high speed if the motor is loaded. After adjusting parameter 18-00 it is recommended to increase the reference frequency and check the motor speed. In case of a speed error increase the value of 18-01 to adjust the compensation. Increase the motor rated frequency (01-12 base frequency) and increase the value of 18-01 to reduce the speed error. If the speed accuracy becomes worse due to an increase in motor temperature it is recommended to use a combination of 18-00 and 18-01 for adjustment.

Compared to 18-00, 18-01 serves as a variable gain for the full speed range. Parameter 18-01 determines the slip compensation at the motor rated speed and is calculated follows:

$$\text{Slip compensation gain} = \text{Slip compensation gain at low speed} + \frac{[\text{Slip compensation gain at high speed} \times \text{frequency reference}]}{[\text{Motor rated frequency}]}$$




Figure 4.4.93 18-00/18-01 Slip compensation gain versus frequency reference




Figure 4.4.94 18-01 Effect on torque speed curve

18-05: FOC (Flux Orient Control) delay time

In the SLV mode, the slip compensation of the magnetic flux depends on the torque current and excitation current. If the motor load rises above 100% while running at the motor rated frequency, the motor voltage and resistance drops sharply, which may cause the inverter output to saturate and current jitter occur. The magnetic flux slip compensation will independently control the torque current and the excitation current to prevent current jitter. For slow speed or fixed speed operation, 18-05 may be increased. For fast operation adjust 18-06.

18-06: Slip compensation gain

If the motor is jittering at the rated frequency under full load, the value of 18-06 may gradually be reduced to zero to reduce current jitter.

Group 20 Speed Control Parameters

20- 00	ASR Gain 1
Range	【0.00~250.00】
20- 01	ASR Integral Time 1
Range	【0.001~10.000】 Sec
20- 02	ASR Gain 2
Range	【0.00~250.00】
20- 03	ASR Integral Time 2
Range	【0.001~10.000】 Sec
20- 04	ASR Integral Time Limit
Range	【0~300】 %
20- 07	Selection of Acceleration and Deceleration of P/PI
Range	<p>【0】 : PI speed control will be enabled only in constant speed. For accel/decel, only use P control.</p> <p>【1】 : Speed control is enabled either in constant speed or accel/decal.</p>
20- 08	ASR Delay Time
Range	【0.000~0.500】 Sec
20- 09	Speed Observer Proportional (P) Gain 1
Range	【0.00~2.55】
20- 10	Speed Observer Integral(I) Time 1
Range	【0.01~10.00】 Sec
20- 11	Speed Observer Proportional (P) Gain 2
Range	【0.00~2.55】
20- 12	Speed Observer Integral(I) Time 2
Range	【0.01~10.00】 Sec
20- 13	Low-pass Filter Time Constant of Speed Feedback 1
Range	【1~1000】 mSec
20- 14	Low-pass Filter Time Constant of Speed Feedback 2
Range	【1~1000】 mSec
20- 15	ASR Gain Change Frequency 1
Range	【0.0~400.0】 Hz
20- 16	ASR Gain Change Frequency 2
	【0.0~400.0】 Hz
20- 17	Torque Compensation Gain at Low Speed
Range	【0.00~2.50】
20- 18	Torque Compensation Gain at High Speed
Range	【-10~10】 %
20-33	Constant Speed Detection Level
Range	【0.1~5.0】 %

The following figure an overview of the automatic speed regulator (ASR) block.

SLV control mode:

The ASR function adjusts the output frequency to control the motor speed to minimize the difference between the frequency reference and actual motor speed.

The ASR controller in SLV mode uses a speed estimator to estimate the motor speed. In order to reduce speed feedback signal interference, a low-pass filter and speed feedback compensator can be enabled.

The ASR integrator output can be disabled or limited. The ASR output is passed through a low-pass filter.




Figure 4.4.95 ASR block diagram (SLV mode)

ASR setting (SLV control mode)

In SLV mode the ASR gain is divided into a high-speed and low-speed section. The speed controller has a high-speed gain 20-00/20-01 and a low-speed gain 20-02/20-03 that can be set independently.

- The high/low switch frequency can be set with parameter 20-15 and 20-16. Similar to the ASR gain, the speed estimator has a high-speed gain 20-09/20-10 and a low-speed gain 20-11/20-12.
- The speed estimator has a low-pass filter to reduce the speed feedback interference, parameter 20-13 and 20-14 are active at high speed as well as low speed. The switch between the high-speed and the low-speed is set by parameter 20-15 and 20-16.
- 20-17 sets the low-speed compensation gain of the speed feedback.
- 20-18 sets the high-speed compensation gain of the speed feedback.
- When the frequency reference rises above the value set in 20-16, the ASR gain used is set by parameters 20-00 and 20-01.
- When the frequency reference falls below the value set in 20-15, the ASR gain used is set by parameters 20-02 and 20-03.
- Gain time constant is adjusted linearly when the speed command falls within the range of 20-15 to 20-16, for a smooth operation.




Figure 4.4.96 ASR gain setting (SLV mode)

Tune the speed control gain

Refer to the following steps:

- a. Gain adjustment of minimum output frequency
 - Motor running is at minimum output frequency (F_{min} , 01-08).
 - Maximum ASR proportional gain 2 (20-02) will not lead to instability.
 - Minimum ASR integration time 2 (20-03) will not lead to instability.
 - Ensure the output current is lower than 50% of inverter rated current. If the output current is over than 50% of inverter rated current, decrease the setting value of parameter 20-02 and increase that of 20-03.
- b. Gain adjustment of maximum output frequency
 - Motor running is at maximum output frequency (F_{max} , 01-02).
 - Maximum ASR proportional gain 1 (20-00) will not lead to instability.
 - Minimum ASR integration time 1 (20-02) will not lead to instability.
- c. Gain adjustment of accel./ decel. integral control
 - When 20-07=1, start integral control if PI speed control is enabled both at constant speed and accel./ decel..
 - Integral control makes the motor speed as quickly as possible reach to the target speed but may cause overshooting or oscillation. Refer to Fig. 4.4.97 & Fig.4.4.98.

When 20-07=1, start ASR Proportion (P) and Integer (I) control during accel/ decel. and steady state

When 20-07=0, start ASR Proportion (P) and Integer (I) control **only** during steady state and use ASR P control during accel/ decel..

Parameter 20-33 (Constant Speed Detection Level) is active mainly for the setting value of 20-07 to be 0 and frequency command source to be analog input because there will be problems occur in analog input signal if the noise causes the system judgment in not reaching the constant speed. Thus, adjust the setting value of parameter 20-33 to avoid the occurrence of the problems.

During ASR gain tuning, the multi-function analog output (AO1 and AO2 terminal) can be used to monitor the output frequency and motor speed (as shown in Fig.4.4.96).

SLV mode gain tuning (20-00~20-03, 20-09~20-18)

- a) Complete the parameter tuning in normal operation.
- b) Increase ASR proportional gain 1 (20-00), ASR proportional gain 2 (20-02), carefully monitor system stability.

Use parameter 20-00 and 20-02 to adjust the speed response for each cycle. Tuning the settings of 20-00, 20-02 can increase system response, but may cause system instability. See Fig.4.4.97.




Figure 4.4.97 System response of ASR proportion gain

- a) Reduce ASR integral time 1 (20-01), ASR integral time 2 (20-02) and carefully monitor system stability.
 1. A long integral time will result in poor system response.
 2. If the integral time setting is too short, the system may become unstable Refer to the following figure.

While tuning ASR P and I gain the system may overshoot and an over voltage condition can occur. A braking unit (braking resistor) can be used to avoid an over voltage condition.




Figure 4.4.98 The response of ASR integral time

Both low-speed ASR gain and the high-speed gain can be set to the same values and only require to be adjusted in case of system instability.

In case tuning of the ASR P and I gain 20-00~20-03 does not improve the system response, reduce the low-pass filter time constant 20-13~20-14 to increase the bandwidth of the feedback system and re-tune the ASR gain.

- Tune low-speed low-pass filter time constant 20-14, make sure the reference frequency is below parameter 20-15 value.
- Tune high-speed low-pass filter time constant 20-13 at frequency reference, make sure the reference frequency is above parameter 20-16 value.
- Increasing the low-pass filter time constant can limit the bandwidth of the speed feedback system and may reduce the system response. Increasing the low-pass time reduces the speed feedback signal interference but may results in sluggish system response when the load suddenly changes. Adjust the low-pass filter time if the load stays fairly constant during normal operation. The low bandwidth of the speed feedback must be supported by the low gain of ASR to ensure the stable operation.
- Decreasing the low-pass filter time constant may increase the bandwidth of the speed feedback and the system response. Decreasing the low-pass time may increase the speed feedback interference resulting in system instability when the load suddenly changes. Decrease the low-pass filter time is a quick system response is required for rapidly changing loads. The high bandwidth of the speed feedback allows for a relative high ASR gain.
- In case tuning 20-00 ~ 20-03 and the low-pass filter time constant 20-13 do not improve the system response time, tuning the PI gain 20-09 ~ 20-12 of the speed estimator may be required.
- Setting a high gain for the speed estimator (high proportion (P) gain and small integral (I) time) increases the bandwidth of the speed feedback, but may cause speed feedback interference resulting in system instability.
- Setting a low gain for the speed estimator (small proportion (P) gain and high integral (I) time) decreases the bandwidth of the speed feedback, may improve speed feedback interference resulting in a more stable system.
- The default values for the ASR can be used in most applications, no adjustment is required. Adjusting the low-pass filter time and speed estimator gains requires a good understanding of the overall system.
- Parameter 20-15 sets the gain switch frequency at low-speed and parameter 20-16 sets the gain switch frequency at high-speed.
- Operating at a speed below 20-15 will result in a larger excitation current for low-speed operation accuracy. When the frequency reference rises above 20-16, the inverter will output the rated excitation current at the no-load voltage (02-19).
- For general purpose applications parameter 20-15 should be set to a value of 5 ~ 50% of the motor base frequency.
- If this value is too high, the inverter output may saturate. Parameter 20-16 should be set to a value of

4Hz or more above the value of 20-08.

- When experiencing speed jitter at high speed and stable operation during mid-range speed while operating a heavy load (>100%), it is recommended to reduce the no-load voltage (02-19) or tune the FOC parameters (18-05 ~ 18-06).
- Parameter 20-17 and 20-18 are for compensating speed feedback at low speed and high speed.
- Use parameter 20-17 to adjust the torque compensation gain for the low speed range. By tuning 20-17 an offset is added to the torque-speed curve. Increase 20-17 when the no-load speed is lower than the frequency reference. Decrease 20-17 when the no-load speed is higher than the frequency reference. The effect on the torque-speed curve from 20-17 is shown as the following figure:




Figure 4.4.99 Effect on the torque-speed curve from 20-17

- Use parameter 20-18 to adjust the torque compensation gain for middle to high speed range. For most general purpose applications it is not necessary to adjust the 20-18. By tuning 20-18 an offset is added to the torque-speed curve. Increase 20-18 when the no-load speed is lower than the frequency reference. Decrease 20-18 when the no-load speed is higher than the frequency reference. The effect on the torque-speed curve from 20-18 is shown as the following Fig.4.4.100.




Figure 4.4.100 Effect on the torque-speed curve from 20-17

- ASR main delay time (20-08).
 - a) Does not required to be adjusted for general purpose applications
 - b) When the set value of 20-08 is set high, the speed response will and therefore system response will decrease improving system stability.
- ASR Integral Time Limit (20-04)
 - a) Setting a small value may prevent system response when the load suddenly changes.

Note:

- Response specifications of no-load speed circuit bandwidth at vector control:
 1. 50 Hz is at the control modes of SV / PMSV.
 2. 10 Hz is at the control modes of SLV / PMSLV.
- Speed response will be affected by k_p adjustment, inertia, load and motor temperature, etc. so that the bandwidth decrease slightly in application.

20- 34	Derating of Compensation Gain
Range	【0.00~25600】
20- 35	Derating of Compensation Time
Range	【0~30000】 mSec

Derating of torque compensation function can reduce derating effect of ASR at shock load. Refer to Fig. 4.4.97 & Fig. 4.4.98.

20-34 Derating of Compensation Gain:

This gain effect is the same as the proportional gain of ASR (20-00, 20-02), but it is required to be with the derating compensation time (20-35) of larger speed tolerance to prevent the inverter from oscillation.

20-35 Derating of Compensation Time:

This time constant is used for the inhibition of oscillation caused from parameter 20-34, but excessive compensation time constant leading to slower output response is unfavorable to derating compensation.

The recommended setting value of 20-34 is 30~50 and that of 20-35 is 50~100ms.

Group 21 Torque Control Parameters

21- 05	Positive Torque Limit
Range	【0~160】 %
21- 06	Negative Torque Limit
Range	【0~160】 %
21- 07	Forward Regenerative Torque Limit
Range	【0~160】 %
21- 08	Reversal Regenerative Torque Limit
Range	【0~160】 %

Torque limit can be set in two ways:

- Use torque limit parameters (21-05 to 21-08) to set a fixed torque limit.
- Set the torque limit by using the multi-function analog input (AI2).

There are four torque limits that can be set separately, one for each quadrant:

- (I) Positive torque limit in forward direction (21-05 positive torque limit)
- (II) Positive torque limit of reverse direction (21-08 negative torque limit)
- (III) Negative torque limit in reverse direction (21-06 forward regenerating torque limit)
- (IV) Negative torque limit in forward direction (21-07 reversal regenerating torque limit)

Refer to Fig.4.4.101.




Figure 4.4.101 Torque limit setting

Torque limit setting by using multi-function analog input AI2 (04-05)

Table 4.4.16 Torque limit analog input

04-05 (AI2)	Function
11	Positive torque limit
12	Negative torque limit
13	Regenerative torque limit (for both forward and reversal directions).
14	Positive/negative torque limit (positive and negative detection torque limit)

Set the analog input terminal (AI2) signal level (04-00), gain (04-07) and bias (04-08)

The default setting for the analog input AI2 is 0 -10V representing 0 – 100% of the motor rated torque).

Fig.4.4.102 shows the relationship between the output torque and the torque limit.




Figure 4.4.102 Analog input torque limit (AI2)

When the analog input is set to positive torque limit (value = 11) the torque limit is active in the third and fourth quadrant.in the reverse direction (regenerative torque in the second quadrant).

When the analog input is set to negative torque limit (value = 12) the torque limit is active in the third and fourth quadrant.

When the analog input is set to regenerative torque limit (value = 13) the torque limit is active in the second and fourth quadrant can be controlled.

When the analog input is set to positive/negative torque limit (value = 14) the torque limit is active in all four quadrants.

When the analog input is at maximum (10V or 20mA), the torque limit is 100% of the motor rated torque. In order to increase the torque limit above 100% the analog input gain (04-07) has to set to a value greater than 100%. For example: 160.0% of the gain will result in the torque limit of 160% of motor rated torque at 10V (20mA) analog input level.

**Group 22: PM Motor Parameters-
only available when PM Control Mode is selected**

22- 00	Rated Power of PM Motor	
Range	【0.00~600.00】 Kw	
22- 01	Rated Voltage of PM Motor	
Range	【50~240】 V: 200V 【100~480】 V: 400V	
22- 02	Rated Current of PM Motor	
Range	25%~200% of inverter's rated current	
22- 03	Pole Number of PM Motor	
Range	【2~96】 Poles	
22- 04	Rated Rotation Speed of PM Motor	
Range	【1~60000】 rpm	
22- 05	Maximum Rotation Speed of PM Motor	
Range	【1~60000】 rpm	
22- 06	PM Motor Rated Frequency	
Range	【0.0~400.0】 Hz	
22- 10	PM SLV Start Current	
Range	【0.0 ~ 120.0】 %	
22- 11	DC Injection Current	
Range	【0.0 ~ 100.0】 %	
22- 12	Speed Estimation kp Value	
Range	【1 ~ 10000】	
22- 13	Speed Estimation kl Value	
Range	【1 ~ 1024】	
22- 14	PM Armature Resistance	
Range	【0.001 ~ 32.767】 Ω	
22- 15	PM Motor D-axis Inductance	
Range	【0.001 ~ 32.767】 mH	
22- 16	PM Motor Q-axis Inductance	
Range	【0.001 ~ 32.767】 mH	
22- 17	Reserved	*2
Range	Reserved	

*2: It is reserved in inverter software V1.4.

The PM parameter group can be restored to factory default by initializing the inverter (13-08).

PM motor rated power (22-00)

Set the motor power according to the motor nameplate.

PM motor rated voltage (22-01)

Set the motor voltage according to the motor nameplate.

PM motor rated current (22-02)

Set the motor full load according to the motor nameplate.

PM motor pole number (22-03)

Set the number of motor poles according to the motor nameplate.

PM motor rated speed (22-04)

Set parameter 22-04 or 22-06, the inverter will automatically calculate the one or the other.

Set the motor rated speed in rpm according to the motor nameplate.

Note:

Only set parameter 22-04 or 22-06, the inverter will automatically calculate the other one.

Formula: $n(22-04) = 120 * f(22-06) / P(22-03)$

PM motor maximum rotation speed (22-05)

Set the maximum motor rated speed in rpm according to the motor nameplate.

PM motor rated frequency (22-06)

Set the motor rated frequency according to the motor nameplate.

PM SLV Start Current (22-10)

Set the torque current at start up and the unit is % of motor rated current.

DC Injection Current (22-11)

Set the auto-tuning DC injection current of the permanent magnet (PM) motor and the unit is % of motor rated current.

Speed Estimation kp Value (22-12) & Speed Estimation ki Value (22-13)

Performance of speed response adjustment:

The higher the setting value is, the faster the motor response becomes; but it may cause the jittering of the controlled object.

The lower the setting value is, the larger the speed deviation becomes. So, please adjust the proper setting value depending on the field apparatus.

PM Armature Resistance (22-14)

Set the motor resistance per phase in unit of 0.001Ω. This parameter is automatically set under the motor auto-tuning (22-21).

Note: The motor resistance is different from the line resistance.

PM Motor D-axis Inductance (22-15)

Set motor D-axis inductance in unit of 0.001mH. This parameter is automatically set under the motor auto-tuning (22-21).

PM Motor Q-axis Inductance (22-16)

Set motor Q-axis inductance in unit of 0.001mH. This parameter is automatically set under the motor auto-tuning (22-21).

22- 21	SLV PM Motor Tuning
Range	【0】 : Disable 【1】 : Enable
22- 22	Fault History of SLV PM Motor Tuning
Range	【0】 : No Error 【1】 ~ 【4】 : Reserved 【5】 : Circuit tuning time out 【6】 : Reserved 【7】 : Other motor tuning errors 【8】 : Reserved 【9】 : Current Abnormity Occurs while Loop Adjustment 【10】 : Reserved 【11】 : Stator Resistance Measurement is Timeout 【12】 : Reserved

SLV PM Motor Tuning (22-21)

WARNING!

Sudden start: The inverter and motor may start unexpectedly during Auto-Tuning, which could result in death or serious injury. Make sure the area surrounding of the motor and load are clear before proceeding with Auto-Tuning.

WARNING! Electric Shock Hazard

High voltage is supplied to the motor when performing an auto-tune, even when the motor is stopped, which could result in death or serious injury. Do not touch the motor before performing the auto-tuning procedure is completed.

WARNING! Holding Brake

Do not perform an auto-tuning procedure when the motor is connected to a brake this may result in incorrect motor data calculation. Disconnect the motor and the load and confirm that the motor can freely run.

- a) Use parameter 22-21 to select tuning mode.
- b) Next press the enter key to go to the PM motor tuning screen. The keypad will display the message of "IPrdy" (Ready to Tune).
- c) Press run to start the PM motor tuning. The keypad will display the "IPtun" message during auto-tune.
- d) If the motor is successfully tuned, the message of "IPEnd " will be displayed. If auto-tune is aborted with the stop key, the operator will display the message of " IPbrd " (PM motor tuning aborted).

Fault History of SLV PM Motor Tuning (22-22)

Parameter 22-22 shows the PM motor tuning fault history. If PM motor tuning has failed, the "IPErr" message is shown on the keypad (PM motor tuning failure). Refer to section 10 for the possible error causes and trouble shooting.

PM motor tuning fault history (22-22) only stores the result of the last auto-tune performed .If auto-tuning was successful or aborted no error will be displayed.

Group 23 Pump & HVAC Function Parameters

23- 00	Function Selection
Range	【0】 : Disable 【1】 : Pump 【2】 : HVAC 【3】 : Compressor

*1

*1: It is new added in inverter software.

Select function of pump or HVAC via parameter 23-00. This function is enabled if the source of reference frequency (00-05) is set to 5 (PID given) and PID control mode (10-03) is enabled. Function of pump or HVAC affects PID target value and if parameter group 23 are enabled.

When 23-00=1, LCD keypad switches automatically the main screen monitoring (16-00) to operating pressure setting (12-74), the sub-screen monitoring 1 (16-01) to pressure feedback value (12-75) and sub-screen monitoring 2 (16-02) to output frequency (12-17).

When 23-00=2, LCD keypad switches automatically the main screen monitoring (16-00) to flow meter target setting (12-77), the sub-screen monitoring 1 (16-01) to flow meter feedback (12-71) and sub-screen monitoring 2 (16-02) to output frequency (12-17).

When 23-00=3, selection of main frequency command source (00-05) can be set except PID mode and V/F curve is limited to F (01-00). Middle output voltage (01-07) is automatically set to the half of maximum output voltage and parameter 01-00 will be hidden.

Notes:

- It is required to set parameters 00-05 and 10-03 in inverter software V1.3.
- It is disabled in switching display setting in inverter software V1.3.
- Refer to the setting value of parameter 23-05 for the display of LED keypad.
- When the control mode 00-00 ≠ 0 ((V/F mode), the selection of 23-00=1 (Pump) or 3 (Compressor) is disabled. (It is new added in inverter software V1.4.)

23- 01	Setting of Single & Multiple Pumps and Master & Alternative
Range	【0】 : Single Pump 【1】 : Master 【2】 : Slave 1 【3】 : Slave 2 【4】 : Slave 3

Set the inverter as the Master or Slave 1~3 via parameter 23-01. Refer to Fig.4.4.111 for the functional process of dual pump start to enable multiple pumps in parallel. It is required to reconnect to write in the parameter after it is set.

23- 02	Operation Pressure Setting
Range	【0.10 ~ 650.00】 PSI

Set the pressure value depending on the pressure transmitter of pump system after setting 10-00 to 0 (keypad given).

23- 03	Maximum Pressure Setting
Range	【0.10 ~ 650.00】 PSI

Set the maximum pressure value depending on the pressure transmitter of pump system. Parameter 23-02 is limited to this maximum value.

23- 04	Pump Pressure Command Source
Range	【0】 : Set by 23-02 【1】 : Set by AI

Pressure command source is given the value set by 23-02 (Operation Pressure Setting) or AI.

Note: Refer to section 3.3.4.1 for single/ Multi-pump wiring diagram.

23- 05	Display Mode Selection	*2
Range	【0】 : Display of Target and Pressure Feedback 【1】 : Only Display Target Pressure 【2】 : Only Display Pressure Feedback	

***2: HVAC and function of this display mode are disabled in inverter software V1.3.**

This function can have the common display of target and feedback pressure or display separately.

① when 23-05=0000 : Led keypad displays pressure setting value and pressure feedback value.

Two-digit in the left is the pressure value setting and two-digit in the right is the pressure feedback value in the seven-segment monitor.

Note: When 23-00=2 (HVAC), the unit will be multiplied by 1000 times. If the display value is 5.0, it means 5000GPM (It is only displayed in inverter software V1.4.)

② when 23-05=0001 : Led keypad only displays the pressure setting value.

③ when 23-05=0002 : Led keypad only displays the pressure feedback value.

Notes:

- Once the target value is bigger than 10, the target value is only shown as "an integer" instead of "a decimal." 10-33 is lower than 1000 and 10-34=1 in the PID modes.
- If Pump mode is used in inverter software V1.3, parameter 23-03 is required to set to <= 9.9 PSI.

23- 06	Proportion Gain (P)
Range	【0.00~10.00】
23- 07	Integral Time (I)
Range	【0.0~100.0】 Sec
23- 08	Differential Time (D)
Range	【0.0~100.0】 Sec




Figure 4.4.103 Diagram of pressure feedback value

Table 4.4.17 Guide for PID parameter adjustment

	Increase Setting Value	Decrease Setting Value	Main Feature
Proportional Gain (P)	(Pros) Increase response time (Cons) Might cause pump jittering	(Pros) Reduce jittering (Cons) Slow down response	Increase stabilized time
Integral Time (I)	(Pros) Smooth output frequency (Cons) Slow down response	(Pros) Fast response (Cons) Change rapidly output frequency	For smooth feedback variations
Differential Time (D)	(Pros) Avoid overshooting (Cons) System instability or motor jittering	(Pros) System stability (Cons) Overshooting easily	Respond to system rapid variations

Notes:

- PID parameters can be modified during the inverter is running.
- Cons: disadvantage, Pros: advantage.




Figure 4.4.104 Diagram for PID parameter adjustment

23- 09	Tolerance Range of Constant Pressure
Range	【0.10~650.00】 PSI

When pressure feedback value is larger than 23-02 (operation pressure setting) , inverter output frequency will decrease downward into sleep status. PID starts (output frequency will increase) when pressure feedback value is less than (23-02) – (23-09).

23- 10	Sleep Frequency of Constant Pressure
Range	【0.0~180.0】 Hz

When inverter output frequency falls below 23-10 (sleep frequency of constant pressure), it starts to count the sleep time (23-11).

23- 11	Sleep Time of Constant Pressure
Range	【0.0~255.5】 Sec

When the inverter finishes counting the sleep time (23-11), the output frequency falls downward at the deceleration time (00-15) and gets into sleep status.




Figure 4.4.105 Diagram for stop time of constant pressure

Note: The purpose of stop time of constant pressure is energy saving.

23- 12	Maximum Pressure Limit
Range	【0.10 ~ 650.00】 PSI

It is convenient for user to limit maximum pressure. When pressure feedback value is higher than maximum pressure limit, the inverter displays warning signal and then stops.

23- 15	Minimum Pressure Limit
Range	【0.10 ~650.00】 PSI

It is convenient for user to limit minimum pressure. When pressure feedback value is lower than minimum pressure limit, the inverter displays warning signal and then stops.




Figure 4.4.106 Diagram for pressure feedback limit

Note: The pressure under the control of PID is between the maximum pressure limit (23-12) and minimum pressure limit (23-15).

23- 13	Warning Time of High Pressure
Range	【0.1 ~ 255.0】 Sec

When pressure feedback value is higher than maximum pressure limit, warning time of high pressure starts to count. If pressure feedback value is lower than maximum pressure limit during counting time, the warning time will recount and the inverter will display the warning signal of HIPb when the warning time ends.

23- 14	Stop Time of High Pressure
Range	【0.1 ~ 255.0】 Sec

When the warning signal of high pressure occurs and pressure feedback value is higher than maximum pressure limit, stop time of high pressure starts to count. If pressure feedback value is lower than maximum pressure limit during counting time, the stop time will recount and the inverter will display stop error signal of OPbFt when the stop time ends.

Note: When user does not want the inverter to be restricted by the maximum pressure, set the warning time of high pressure to zero to disable the function of high pressure limit.




Figure 4.4.107 Diagram for warning to stop under the limit of high pressure

23- 16	Warning Time of Low Pressure
Range	【0.1 ~ 255.0】 Sec

When pressure feedback value is lower than minimum pressure limit, warning time of low pressure starts to count. If pressure feedback value is higher than minimum pressure limit during counting time, the warning time will recount and the inverter will display the warning signal of LoPb when the warning time ends.

23- 17	Fault Stop Time of Low Pressure
Range	【0.0 ~ 600.0】 Sec

When the warning signal of low pressure occurs and pressure feedback value is lower than minimum pressure limit, stop time of low pressure starts to count. If pressure feedback value is higher than minimum pressure limit during counting time, the stop time will recount and the inverter will display stop error signal of LPbFt when the stop time ends.

Note: When user does not want the inverter to be restricted by the minimum pressure, set the warning time of low pressure to zero to disable the function of low pressure limit.




Figure 4.4.108 Diagram for warning to stop under the limit of low pressure

23- 18	Detection Time of Loss Pressure
Range	【0.0 ~ 600.0】 Sec
23- 19	Detection Proportion of Loss Pressure
Range	【0 ~ 100.0】 %

23-19 = 0: Disable

23-19 > 0: If the feedback pressure value is lower than the value of 【(23-02) x (23-19)】 and the detection time of loss pressure (23-18) pass, the inverter jumps fault signal (FBLSS).

23-20	Percentage of Pressure Level	*4
Range	【0】 Pressure Unit Setting 【1】 Pressure Percentage Setting	

*4: It is new added in inverter software V1.5.

23-20=0:

Parameters 23-02 (Operation Pressure Setting), 23-09 (Tolerance Range of Constant Pressure), 23-12 (Maximum Pressure Limit), 23-15 (Minimum Pressure Limit), 23-24 (Range of Water Pressure Detection), 23-38 (Pressure Variation of Leakage Detection Restart) and 23-39 (Tolerance Range of Leakage Detection Restart) are set values with pressure unit.

23-20=1:

The above parameters are set values with the maximum pressure setting (23-03) as the base of percentage in proportionality.

23-23	Direction of Water Pressure Detection
Range	【0】 : Upward Detection 【1】 : Downward Detection
23- 24	Range of Water Preesure Detection

Range	【0.0 ~ 65.00】 PSI
23- 25	Period of Water Pressure Detection
Range	【0.0 ~ 200.0】 Sec
23- 26	Acceleration Time of Water Pressure Detection
Range	【0.0 ~ 600.0】 Sec
23- 27	Deceleration Time of Water Pressure Detection
Range	【0.0 ~ 600.0】 Sec

Acceleration time of water pressure detection (23-26) and deceleration time of water pressure detection (23-27) are corresponding to the acceleration time 2 (00-16) and the deceleration time 2 (00-17), so the setting of 23-26 changed with the setting of 00-16. Thus, avoid using multi-speed application function while using PUMP function.




Figure 4.4.109 Diagram for upward detection of water pressure

23-25 = 0.0 (sec) means to disable the function of water pressure detection.

When function of water pressure detection is enabled, it can shorten the time of jumping into sleep when user stops using water or uses a small amount of water.

If user frequently continues using water, to avoid the occurrence of fluttering or instability extending the cycle of water pressure detection is suggested to reduce detection times.

When function of upward detection of water pressure starts, it will slightly increase the pressure. It may cause shortly pressure fluttering or instability under the situation of continuing using water. It is recommended to reduce the range of water pressure detection (23-24) but it will extend the time of inverter jumping into sleep status when user stops using water or uses a small amount of water.




Figure 4.4.110 Diagram for downward detection of water pressure

23-25 = 0.0 (sec) means to disable the function of water pressure detection.

When function of water pressure detection is enabled, it can shorten the time of inverter jumping into sleep when user stops using water or uses a small amount of water.

If user frequently continues using water, to avoid the occurrence of fluttering or instability extending the cycle of water pressure detection is suggested to reduce detection times.

When functions of upward detection of water pressure start, output frequency will decelerate depending on the deceleration time of water pressure detection (23-27). It may cause shortly pressure fluttering or instability when pressure decreases with the reduced speed and then increase to the target pressure value with the increased speed under the situation of continuing using water. It depends on the pressure feedback value being lower than the gap between the target pressure value (23-02) and range of water pressure detection (23-24).

Range of water pressure detection (23-24) should have appropriate adjustment to prevent pressure from fluttering too much.

For example, when a trace of water-leaking leads to pressure decreasing during deceleration, the inverter jumps to sleep status or reacceleration depending on the first reach of sleep frequency or the pressure being first lower than the gap between the target pressure value (23-02) and range of water pressure detection (23-24).

Table 4.4.18 Guide for comparison of water pressure detection direction

	Pros	Cons
Upward detection of water pressure	<ul style="list-style-type: none"> Keep the pressure above the target pressure during this process. For strict and precise applications 	<ul style="list-style-type: none"> Operating frequency is higher caused from too high "Head" under the situation of stopping using water or using a small amount of water. So this detection effect is restricted to be more difficult to sleep. Energy-saving of water used is not obvious and Slave is not easy to sleep under the multiple pumps in parallel.
Downward detection of water pressure	<ul style="list-style-type: none"> Jump into sleep status under the situation of stopping using water or using a small amount of water. For energy-saving purpose, under the multiple pumps in parallel regulate the pumps to the optimum operation state during this process. Startup sequency is by Master, Slave 1, Slave 2, and Slave 3. Sleep sequency is by Slave 1, Slave 2, and Slave 3 and Master. After the switching time is allowable, alternate Master and Slave reach the average of life expectancy. 	<ul style="list-style-type: none"> Pressure fluctuations may occur during this process if user inappropriately regulates the range of water pressure detection (23-24) and the deceleration time of water pressure detection (23-27).

23- 28	Forecd Run Command
Range	【0.0 ~ 200.0】 Hz

This function is enabled when the source of frequency command (00-05) is set to 5 (PID given) and PID mode (10-03) is enabled.

Pump will not depend on the feedback to make any PID output adjustment when multi-function digital input (S1~S6) is set to 16 (PID control disable).

And when the other digital input is set to 57(forced frequency run), inverter sets the frequency run depending on the parameter 23-28 (forced run command). If DI is removed, the inverter sops output.

It is applied to the situation when pressure sensor disconnects, control inverter output via the external pressure sensor (ex. differential pressure switch).

23-29	Switching Time of Multiple Pumps in Parallel
Range	【0 ~ 240】 hour

If function of multiple pumps in parallel is enabled, the switching way is Master→Slave1→ Slave2→Slave3 → Master → ... and the switching time is set via parameter 23-29.

23- 30	Detection Time of Multiple Pumps in Parallel Running Start
Range	【0.0 ~ 30.0】 Sec

When parameter 23-31 is set to 1 or 3, detection time of multiple pumps in parallel running start is enabled. If water pressure can not reach the error range of constant pressure and water flow time is over the detection time (23-30), Master will inform Slave of running start.

23- 31	Synchronous Selection of Multiple Pumps in Parallel
Range	【0】 : Disable 【1】 : Pressure Setting and Run/ Stop 【2】 : Pressure Setting 【3】 : Run/Stop

23-31=0: Disabled.

23-31=1: Pressure Setting and Run/ Stop

Set 23-01 to 1, Pressure setting and Run/ Stop command are modified by Master and Slave follows Master's command. Run/Stop command from Slave can be regarded as the emergency stop command with the highest priority.

23-31=2: Pressure Setting

Set 23-01 to 2, Pressure setting is modified by Master and Slave follows Master's command to update synchronously.

23-31=3: Run/Stop

Set 23-01 to 3, Run/ Stop command is set by Master and Slave follows Master's command. Run/Stop command from Slave can be regarded as the emergency stop command with the highest priority.

Note: When Master modifies the pressure setting, it requires pressing ENTER key to modify the pressure setting of Slave.




Figure 4.4.111 Dual pumps start up process

A : When dual pumps are enabled, Master starts up first and Slave is in standby to enter constant-pressure operation.

B : Higher water flow results in the higher operation frequency of Master. If water pressure is not lower than

the tolerance range of constant-pressure and the operation time is not over the detection time (23-30), Slave is still in standby.

C : If it is over the detection time (23-30), Master informs Slave of auxiliary kicking water. After Slave operates, the operation frequency of Master and Slave reduces to the operation of constant-pressure if water flow is stable.

D : If water flow is lower, the operation frequency of Master and Slave reduces. Because the water flow is less than that of the operation of dual pumps, Slave stops to sleep and only Master runs to reach constant-pressure operation.


Note: Slave sleep conditions under the operation of dual pumps requires the output frequency of Slave decreasing to zero after the setting time of 23-30 ends.

Notes:


- If the operation time is over the switching time (23-29) under the operation of dual pumps, the dominance between Master and Slave will exchange to operate.
- When 23-01≠0, the parameter 23-01 of these two inverters can not be simultaneously set to 1 or 2. That is, the parameter 23-01 of one inverter is set to 1 and that of the other inverter should be set to 2 and vice versa.

23-37	Leakage Detection Time	*3
Range	【0.0~100.0】	
23-38	Pressure Variation of Leakage Detection Restart	*3
Range	【0.01~65.00】	
23-39	Pressure Tolerance Range of Leakage Detection Restart	*3
Range	【0.01~65.00】	

*3: It is new added in inverter software V1.4.



Leakage Detection Case1: Pressure Variation > 23-38



Pressure Variation of Leakage Detection Restart


$\Delta P1 < 23-38$

$\Delta P2 > 23-38$

Notes:

- When 23-37 = 0.0 (sec), switch off this function.
- When pump is at shutdown state, pressure will drop over time if pipeline leaks. Pump will restart if pressure variation is larger than the value of parameter 23-38 in every detection time (23-37).

Leakage Detection Case2: Pressure Variation <23-38



Notes:

- When 23-37 = 0.0 (sec), switch off this function.
- When pump is at shutdown state, pressure will drop over time if pipeline leaks. Inverter will keep sleep state if pressure variation is lower than the value of parameter 23-38 in every detection time (23-37) and pump will restart if pressure variation is larger than that of 23-38 or pressure tolerance range is over the value of parameter 23-39 in the detection time.
- Properly adjust the relevant leakage detection parameters 23-37, 23-38 and 23-39 to improve the condition of frequent pump start and stop caused from the dropping pressure of water system due to leakage.
- Function of leakage detection is enabled only in the setting of single pump.

23-41	Local/ Remote Key
Range	[0] : Disable [1] : Enable

User can switch reference frequency of the inverter and give the run command in the local or remote mode.

Input source selection is determined by the source of frequency command (00-05) and the operation modes (00-02).

23-41=0: Disable

Frequency command is controlled by terminal AI1 and AI2 when SEQ and REFsignal light up and run command is controlled by terminal S1, S2 or RS485.

23-41=1: Enable

User can control FWD/REV key for the switch of Local / Remote key.

Frequency command is controlled by the keypad when SEQ and REF signal light off.

Note: Local mode is controlled by the keypad and remote mode is controlled by control circuit terminals or RS485 connection.

23-42	Energy Recaculating
Range	【0】 : Disable (Energy Accumulating) 【1】 : Enable
23-43	Electricity Price per kWh
Range	【0.000~5.000】

When the inverter starts up, user can learn the motor accumulative output energy from parameter 12-67 (unit: kWhr) and 12-68 (unit: MWhr). User recalculates energy via the setting of parameter 23-42 to 1.

User caculates electricity price via the setting of electricity price per kWh (23-43) and learn the accumulative electricity price from parameter 12-69 and 12-70.

23-44	Selection of Accumulative Electricity Pulse Output Unit
Range	【0】 : Disable 【1】 : Unit for 0.1kWh 【2】 : Unit for 1kWh 【3】 : Unit for 10kWh 【4】 : Unit for 100kWh 【5】 : Unit for 1000kWh

Unit of accumulative electricity pulse output signal (23-44) is for kWh. When accumulating the electricity to the setting unit of parameter 23-44, the pulse output signal of the electric meter or PLC is on lasting 200 msec.




Figure 4.4.112 Diagram for accumulative electricity pulse output

23-45	Given Modes of Flow Meters Feedback
Range	【0】 : Disable 【1】 : Analog Input 【2】 : Pulse Input
23- 46	Maximum Value of Flow Meters
Range	【1~50000】 GPM
23- 47	Target Value of Flow Meters
Range	【1~50000】 GPM

23-00=2: HVAC

HVAC is enabled when the source of main frequency command (00-05) is set to 5 (PID given) and PID mode is enabled (10-03).

23-45: Given Modes of Flow Meters Feedback

Modes of flow meters feedback is given by analog input (AI) or pulse input (PI) and flow meter (12-71) displays feedback value.

23-46: Maximum Value of Flow Meters

Maximum value of flow meters is the maximum value set by the target value of flow meters for HVAC system.

23-47: Target Value of Flow Meters

This function sets the target value of flow meters for HVAC system depending on the setting of 10-00 to 0 (PID target value source is set by keypad.)

23-48	Maximum Flow Value of Feedback
Range	【0.01~99.00】 %

It is convenient for user to limit the maximum flow value depending on the different situations. When flow feedback value is higher than the maximum flow value, the inverter will display warning signal and then stops.

23- 49	Maximum Flow Warning Time of Feedback
Range	【0~255】 Sec

When flow feedback is higher than the maximum flow limit, warning time of high flow starts to count. If the flow feedback is lower than the maximum flow limit during counting time, the warning time will recount and the inverter will display the warning signal of HFPb when the warning time ends.

23- 50	Maximum Flow Stop Time of Feedback
Range	【0~255】 Sec

When the warning signal of high flow occurs and flow feedback is higher than maximum flow limit, stop time of high flow starts to count. If flow feedback is lower than maximum flow limit during counting time, the stop time will recount and the inverter will display stop error signal of HIbFt when the stop time ends.

Note: When user does not want the inverter to be restricted by the maximum flow, set the warning time of high flow to zero to disable the function of high flow limit.




Figure 4.4.113 Diagram for high flow limited warning of stop

23-51	Minimum Flow Value of Feedback
Range	【0.01~99.00】 %

It is convenient for user to limit the minimum flow value depending on the different situations. When flow feedback value is lower than the minimum flow value, the inverter will display warning signal and then stops.


23- 52	Minimum Flow Warning Time of Feedback
Range	【0~255】 Sec

When flow feedback is lower than the minimum flow limit, warning time of low flow starts to count. If the flow feedback is higher than the minimum flow limit during counting time, the warning time will recount and the inverter will display the warning signal of LFPb when the warning time ends.

23- 53	Minimum Flow Stop Time of Feedback
Range	【0~255】 Sec

When the warning signal of low flow occurs and flow feedback is lower than minimum flow limit, stop time of low flow starts to count. If flow feedback is higher than minimum flow limit during counting time, the stop time will recount and the inverter will display stop error signal of LObFt when the stop time ends.

Note: When user does not want the inverter to be restricted by the minimum flow, set the warning time of low flow to zero to disable the function of low flow limit.



T1 < (23-52): Recounting after T1.
 T2 = (23-52): Keypad flashes and displays LFPb
 T3 = (23-53): Keypad flashes and displays LOPbt

Figure 4.4.114 Diagram for low flow limited warning of stop

23-54	Detection Function of Low Suction
Range	【0】 : Disable 【1】 : PID Error Value 【2】 : Current 【3】 : Current and PID Error Value
23- 55	Detection Time of Low Suction
Range	【0~30.0】 Sec
23- 56	PID Error Level of Low Suction
Range	【0 ~ 30】 %
23- 57	Current Level of Low Suction (Motor Rated Current)
Range	【0 ~ 100】 %
23- 58	Reaction of Low Suction
Range	【0】 : Disable 【1】 : Warning 【2】 : Fault 【3】 : Fault & Restart

The hydraulic application can detect insufficient water in the tank resulting in low suction via HVAC function. User can select the reaction of low suction (23-58) to run command. Low suction is detected by parameter 23-54. Refer to Fig.4.4.115 for the process of low suction.




Figure 4.4.115 Diagram for the process of low suction

When 23-54=0, detection function of low suction is disabled.

And refer to Table 4.4.19 for the detection logic of parameter 23-54 to select PID error of output current as the detection signal.

Table 4.4.19 the detection logic of low suction

23-54	Detection Signal	
	PID Error	Output Current
1	1	0
2	0	1
3	1	1

The detection level is required to be set by PID error level of low suction (23-56) and output current signal (23-57) after selecting the detection signal.

The state of low suction experiences the detection time of low suction (23-55); when it is over the detection time, low suction is active.

The reaction of low suction (23-58) is set by user to act. Refer to Table 4.4.20 for the detection signal of water used.

Table 4.4.20 Detection signal of water used

23-58	Inverter Status	Keypad Signal	Error Signal
0	Continuous Running	None	None
1	Continuous Running	LSCFT(Flash)	Warning of Low Suction
2	Stop	LSCFT	Jump to Error for Low Suction
3	Stop and Restart	LSCFT	Jump to Error for Low Suction and Restart

Note: Low suction state is detected by if the signal is higher than PID error level or lower than output current.

23-59	Source of HVAC Pressure Command	*3
Range	【0】 : Set by 23-47 【1】 : Set by AI	

*3: It is new added in inverter software V1.4.

23-59=0: Target value depends on parameter 23-47.

23-59=1: Convert the proportional target value of flow meters via AI1 input voltage value.

23- 66	Derating of Current Level (for Compressor Current)	*3
Range	【10 ~ 200】 %	
24- 67	Derating of Delay Time	*3
Range	【1.0 ~ 20.0】 Sec	
23- 68	Derating of Frequency Gain	*3
Range	【1~100】 %	
23- 69	OL4 Current Level	*3
Range	【10~200】 %	
23-70	OL4 Delay Time	*3
Range	【0.0 ~ 20.0】 Sec	

***3: It is new added in inverter software V1.4.**

The application of water-cooled chiller is when the rated current of compressor operates for 1 to 2 minutes easily to cause damage to compressor so the inverter is required to be set two- stage protection to protect the compressor.

Protection of first stage:

When the inverter is at constant speed and the current is higher than the derating of current level (23-66) (this is the percentage for the rated current of compressor), it will start to count the derating of delay time (23-67). After the counting time is over the delay one, frequency command can reach the derating of output frequency and reduce the current load via being multiplied by the derating of frequency gain (23-68). When the current is lower than the derating of current level, output frequency will be restored to the frequency command. The action of derating to restore is counted one time. When it repeats more than three times, the output frequency will stop at the last derating frequency until the current is lower than the derating of current level (23-66).

For example: Set 23-66=80%, 23-67=10sec, 23-68=90%, the frequency command=60Hz and the rated current of compressor=30A, then, when the output current=27A, higher than 24A (30A*80%); 10 sec (the derating of delay time) passes, and the output frequency=54Hz (frequency command 60Hz*90%), the output current decreases to 25A, also higher than 24A; then another 10 sec passes, 60Hz*81%=48.6Hz, the output current decreases to 23A, lower than 24A, so the output frequency is restored to 60Hz and the current rises to 27A. When it repeats more than three times, the output frequency will stop at 48.6Hz and the output current decreases to 23A.

Protection of second stage:

After the current reaches OL4 current level (23-69), the inverter will count the time at the setting value of OL4 delay time (23-70). When the counting time ends, it will decelerate to stop automatically and display the warning signal (fault signal, OL4 Compressor Overload).

If fault occurs, PLC can read if the inverter is running from the digital output terminals. If the inverter stops, terminate the RUN command. If 00-02=0, user can press Reset key; if 00-02=1, terminate the RUN command of digital input terminal to reach the effect of Reset. Then PLC can be restored to give RUN command.

Note: It is recommended that the rated current of compressor is required to be lower than that of inverter.

Group 24 Pump Control Function Parameters

24- 00	Selection of Pump Control Function
Range	<p>【0】 : Function of 1 to 8 Pump Card is Disabled.</p> <p>【1】 : Fixed Modes of Inverter Pump: First on and Last off; then Stop All.</p> <p>【2】 : Fixed Modes of Inverter Pump: Only Stop Inverter Pump.</p> <p>【3】 : Fixed Modes of Inverter Pump: First on and First Off; then Stop All.</p> <p>【4】 : Cycle Modes of Inverter Pump: First on and First Off; then Stop All.</p> <p>【5】 : Cycle Modes of Inverter Pump: Only Stop Inverter Pump.</p> <p>【6】 : 1 to 3 Relay of Cycle Modes of Inverter Pump: First on and First off; then Stop All.</p>

The inverter with built-in PID controller and simple programmable logic controller (PLC) is widely applied to water supply industry. 1 to 8 pump card, mainly applied to the situation of water supply of constant pressure, dispenses the inverter from the need of an external controller.

The inverter provides the power supply of variable frequency for pump to implement the continuously variable transmission (CRT) and makes the water pressure being satbly controlled via the built-in PID controller.

There are two basic operation modes in 1 to 8 pump card:

① **Fixed modes of inverter pump:**

Pump driven by the inverter is fixed to 1 set and maximum to 8 sets.




Figure 4.4.116 Fixed modes of inverter pump

② Cycle modes of inverter pump:

Pump driven by the inverter is not fixed to 1 set and maximum to 4 sets.




Figure 4.4.117 Cycle modes of inverter pump

In addition to the two basic operation modes provided from 1 to 8 pump card, it can only use the Relay in the control board to enable the cycle modes of inverter pump.

*** Cycle modes of inverter pump in the control board:** Run via a Relay with a pump to start the cycle modes of inverter pump.




Figure 4.4.118 Cycle modes of inverter pump in the control board

24-00=0: Function of 1 to 8 pump card is disabled.

24-00 = 1: in the fixed modes of inverter pump, first on and last off; then stop all.

Pump (motor) driven by the inverter is fixed. Switching off the pump (motor) is by the sequence of the last on and this mode is applicable to different pump (motor) ratings.

24-00=2: only inverter pump stops in the fixed modes of inverter pump.

When the inverter sends the stop command, only the pump (motor) stops but the Relay keeps on.

24-00=3: in the fixed modes of inverter pump, first on and first off; then stop all.

Switching off the pump (motor) is by the sequence of the first on (longer operation time) to make the pump (motor) be used for the equal frequency and this mode is applicable to the same pump (motor) ratings.

24-00=4: in the cycle modes of inverter pump, first on and first off; then stop all.

All the motors besides the pump are driven by the inverter and switching off the pump (motor) is by the sequence of the first on.

24-00=5: only inverter pump stops in the cycle modes of inverter pump.

When the inverter sends the stop command, only the pump (motor) stops but the Relay keeps on.

24-00=6 : 1 to 3 Relay of Cycle Modes of Inverter Pump: First on and First off; then Stop All.

This mode runs via a Relay with a pump in the cycle modes of inverter pumps. If 24-07=1, only Relay in the control board is enabled in 1 to 3 Relay of cycle modes and can switch the drive sequence of every pump.

Notes:

- When 1 to 8 pump card is not installed, it is forced to be disabled (24-00=0).
- Set 24-07=1 to enable the Relay in the control board to provide the function selection of 1 to 8 pump cards, or it is still forced to be disabled.
- 1 to 8 pump cards enabled or disabled and the selection modes of water supply are determined by parameter 24-00.
- PID Setting:
PID function is enabled via the setting of the frequency reference source (00-05) to 5 (PID given) and PID control mode (10-03) to xxx1b (PID enable). Set PID target value source (10-00) to 4 (10-02 given) and the target value is determined by 10-02. If the feedback value source (10-01) is set to 2 (AI2 given) and AI input signal type (04-00) is set to 0 (AI2: 0~10V), it requires SW2 switching to V in the control board.

24- 01	Selection of Relay 2-4 Function
Range	【xxx0b】 : Reserved 【xxx1b】 : Reserved 【xx0xb】 : Relay 2 Disable 【xx1xb】 : Relay 2 Enable 【x0xxb】 : Relay 3 Disable 【x1xxb】 : Relay 3 Enable 【0xxxb】 : Relay 4 Disable 【1xxxb】 : Relay 4 Enable
24- 02	Selection of Relay 5-8 Function
Range	【xxx0b】 : Relay 5 Disable 【xxx1b】 : Relay 5 Enable 【xx0xb】 : Relay 6 Disable 【xx1xb】 : Relay 6 Enable 【x0xxb】 : Relay 7 Disable 【x1xxb】 : Relay 7 Enable 【0xxxb】 : Relay 8 Disable 【1xxxb】 : Relay 8 Enable

Fixed modes of inverter pump:

In the fixed modes of inverter pump, RY1 is permanently used and RY2~RY8 is arbitrarily selected to be used.

Inverter decelerates/ accelerates to lower/ upper limit frequency when user increases/ decreases pumps and function of PID is temporarily disabled. When the inverter reaches lower/ upper limit frequency, function of PID restores and the inverter output is determined by the feedback.

Cycle modes of inverter pump:

In the cycle modes of inverter pump, RY2 and RY1 are always used. The rest (RY3~RY8) is a group of two, RY3/RY4, RY5/RY6, and RY7/RY8. If any one of the group is set to be disabled, this group is disabled.

The inverter output disconnects when user increases pumps. When a motor originally driven by the inverter is switched by commercial AC power supply, it requires the switching time of magnetic contactor

(24-05) to allow the AC power supply input. Then the inverter output drives the next motor, which is determined by the feedback.

Switch off the motor of the first on when user decreases pumps to make the pump (motor) be the equal using frequency.

Cycle modes of inverter pump in the control board:

In the cycle modes of inverter pump, RY1 is permanently used and RY2~RY3 is arbitrarily selected to be used. 24-01 can only set 0xxx (Relay 4 can not be set.) and 24-02 can only set 0000 (Relay 5-8 can not be set.) so this parameter will be hidden.

24- 03	Duration of Upper Limit Frequency
Range	【1.0 ~ 600.0】 Sec

Set the inverter output frequency controlled by PID reaches the upper limit frequency (the proportion setting by parameter 00-12) via parameter 24-03. 1 to 8 pump card controls the time required for increasing pumps.

The setting value of duration of upper limit frequency (24-03) is determined by the changing time speed of system pressure. The setting value of 24-03 is the fewer the better in the range without producing oscillation of system pressure.

24- 04	Duration of Lower Limit Frequency
Range	【1.0 ~ 600.0】 Sec

Set the inverter output frequency controlled by PID reaches the lower limit frequency (the proportion setting by parameter 00-13) via parameter 24-04. 1 to 8 pump card controls the time required for decreasing pumps.

The setting value of duration of lower limit frequency (24-04) is determined by the changing time speed of system pressure. The setting value of 24-04 is the fewer the better in the range without producing oscillation of system pressure.

24- 05	Switching Time of Magnetic Contactor
Range	【0.1~2.00】 Sec

When a motor originally driven by the inverter is switched by the commercial AC power supply or originally driven by the commercial AC power supply is switched by the inverter, function of parameter 24-05 is used to avoid the delay of external magnetic contactor resulting in a short circuit of the inverter output and AC power supply.

The setting value of 24-05 requires being larger than the time from the switch of the inverter Relay signal to the action of external magnetic contactor. Generally, the off to on time of magnetic contactor is longer than the on to off time. Set parameter 24-05 depending on the longer time.




Figure 4.4.119 Diagram for the single cycle modes of inverter pump

24-06	Allowable Bias of Pump Switch
Range	【0.0~20.0】%

When increasing or decreasing pumps with PID control to operate in coordination with Relay card, user has to determine if it is required to increase or decrease allowable value of pump in the situation of inverter output frequency being closed to upper limit frequency (00-12) or lower limit frequency (00-13).

The setting unit is 0.1% and if the setting is 0.0%, inverter output frequency needs to reach the upper limit or lower limit value to increase or decrease pump (motor).

For example, 00-12 = 80%, and 00-13 = 20%, then:

- If 24-06 = 0%, the output frequency needs to reach 80% of the maximum frequency to increase the pump (motor); the output frequency needs to reach 20% of the minimum frequency to decrease the pump (motor).
- If 24-06 = 5%, the output frequency needs to reach 75% of the maximum frequency to increase the pump (motor); the output frequency needs to reach 25% of the minimum frequency to decrease the pump (motor).

24-07	Pump Control Source Selection
Range	【0】 : 1 to 8 Pump Card 【1】 : Built-in 1 to 3 Control Mode

24-07 = 0: 1 to 8 Pump Card

It is Relay in the 1 to 8 pump card used for function of inverter pump.

24-07 = 1: Built-in 1 to 3 Control Mode

It is Relay in the control board used for function of inverter pump.

Only R1A~R3A in the control board can be used and Relay in 1 to 8 pump card cannot be used.

It is required for the following conditions to enable this control mode.

- ① 24-00 is only set to 1~3 and 6.
- ② 24-01 is only set to 0xxx (Relay 4 is disabled).
- ③ 24-02 is only set to 0000 (Relay 5~8 are disabled).

Note: If user does not follow the above requirements (24-00, 24-01, 24-02, and 24-07), errors will occur when user give commands to the inverter.

Refer to the following table for controlling the maximum value of pump under the different setting values of 24-00 and 24-07.

Setting value of 24-00	Inverter pump Modes	One pump with Relay	24-07=0 (Relay in 1 to 8 pump card)	24-07=1 (Relay in the control board)
1-3	Fixed Modes	1	8 PUMP	3 PUMP
4,5	Cycle Modes	2	4 PUMP	None
6	Cycle Modes	1	8 PUMP	3 PUMP

- If 24-07=1, R1A is fixed to support Relay 1 controlled by pump and function of parameter 03-11 is disabled.
- If 24-07=1 and 24-01= xx1x, R2A supports Relay 2 controlled by pump and function of parameter 03-12 is disabled.
- If 24-07 = 1 · 24-01 = x1xx, R3A supports Relay 3 controlled by pump and function of parameter 03-39 is disabled.

The following examples are for the actions of increasing / decreasing pumps in the fixed modes of inverter pump. Relay 1~Relay 4 in 1 to 8 pump card is set to be enabled. Motor 1 is connected to inverter and motor 2~4 are connected to AC power supply. MC of AC power supply is mainly controlled by the external circuit control. Refer to Fig. 4.4.126.

When 24-00=1, 24-06=0 and depending on the above PID setting, the following status occurs.

- ◇ Output frequency (Fout) reaches the upper limit frequency (00-12) and Fout time is over than the duration of upper limit frequency (24-03). Then Relay 2 is power on and the connected motor starts to accelerate.




Figure 4.4.120 Diagram of increasing pump in the fixed modes of inverter pump

- ◇ Output frequency (F_{out}) decreases to the lower limit frequency (00-13) and the F_{out} time is over than the duration of lower limit frequency (24-04). Then Relay 4 is power off and the inverter accelerates to the upper limit frequency (00-12).
- ◇ When F_{out} reaches to the upper limit frequency (00-12), the inverter starts to decelerate.




Figure 4.4.121 Diagram of decreasing pump in the fixed modes of inverter pump

The following examples are for the actions of increasing / decreasing pumps in the cycle modes of inverter pump. Relay 1~Relay 4 in 1 to 8 pump card is set to be enabled. Refer to Fig.4.4.119 for switching of the motor connected to the inverter or AC power supply. MC of AC power supply is mainly controlled by the external circuit control. Refer to Fig.4.4.127.

When 24-00=1, 24-06=0 and depending on the above PID setting, the following status occurs.

- ◇ Output frequency (F_{out}) reaches the upper limit frequency (00-12) and F_{out} time is over than the duration of upper limit frequency (24-03). Then Relay 1 is power off and output frequency of the inverter does not occur.
- ◇ Relay 1 and Relay 2 is power on and the inverter starts to accelerate after the switching time of MC (24-05) ends.




Figure 4.4.122 Diagram of increasing pump in the cycle modes of inverter pump

- ✧ Output frequency (Fout) reaches the lower limit frequency (00-13) and Fout time is over than the duration of lower limit frequency (24-04). Then Relay 1 and Relay 2 is power off
- ✧ Relay 1 is power on and the inverter starts to decelerate after the switching time of MC (24-05) ends.




Figure 4.4.123 Diagram of decreasing pump in the fixed modes of inverter pump

The following examples are for the actions of increasing / decreasing pumps in 1 to 3 Relay modes. Relay 1~Relay 3 is corresponding to R1A-R3A. Refer to Fig.4.4.118 for switching of the motor connected to the inverter or AC power supply. MC of AC power supply is mainly controlled by the external circuit control. Refer to Fig.4.4.128.

When 24-00=1, 24-06=0 and depending on the above PID setting, the following status occurs.

- ✧ Output frequency (Fout) reaches the upper limit frequency (00-12) and Fout time is over than the duration of upper limit frequency (24-03). Then Relay 1 is power off and output frequency of the inverter does not occur.
- ✧ Relay 2 is power on and output frequency of the inverter does not still occur after the switching time of MC (24-05) ends.
- ✧ Relay 1 is power on and the inverter starts to accelerate after the switching time of MC (24-05) ends.




Figure 4.4.124 Diagram of increasing pump in 1 to 3 Relay modes

- ✧ When pressure feedback value is larger than the target value, output frequency (F_{out}) decreases. Relay 1 is power off when the output frequency reaches to the lower limit frequency (00-13) and F_{out} time is over than the duration of lower limit frequency (24-04).




Figure 4.4.125 Diagram of decreasing pump in 1 to 3 Relay modes

■ Wiring for 1 to 8 Pump Card and 1 to 3 Relay Modes




Figure 4.4.126 Wiring for the fixed modes of inverter pump




Figure 4.4.127 Wiring for the cycle modes of inverter pump




Figure 4.4.128 Wiring for the cycle modes of inverter pump in the control board

4.5 Built-in PLC Function

The PLC ladder logic can be created and downloaded using the TECO drive link software.

4.5.1 Basic Command

	[∧	∨	P	— —	— / —	NO / NC
Inputs					I	i	I1~I6 / i1~i6
Outputs	Q	Q	Q	Q	Q	q	Q1~Q2 / q1~q2
Auxiliary command	M	M	M	M	M	m	M1~MF / m1~mF
Special registers							V1~V7
Counter function	C				C	c	C1~C8 / c1~c8
Timer function	T				T	t	T1~T8 / t1~t8
Analog comparison function	G				G	g	G1~G8 / g1~g8
Operation control function	F				F	f	F1~F8 / f1~f8
summation and subtraction function	AS						AS1~4
Multiplication and division function	MD						MD1~4

Description of registers

V1 : Set frequency	Range : 0.1~400.0Hz
V2 : Operation frequency	Range : 0.1~400.0Hz
V3 : AI1 input value	Range : 0~1000
V4 : AI2 input value	Range : 0~1000
V5 : Keypad input value	Range : 0~1000
V6 : Operation current	Range : 0.1~999.9A
V7 : Torque value	Range : 0.1~200.0%

Command	Upper Differential	Lower Differential	Other command symbol
Differential command	D	d	
SET command			∧
RESET command			∨
P command			P


Open circuit	“ ”	
Short circuit	“_”	

Connection symbol	Definition
—	Connect components on the left and right side
⊥	Connects components on the left , right and top side
⊕	Connects components on the left , right , top and bottom side
⊔	Connects components on the left , right and bottom side


4.5.2 Basic Command Function

◎ D (d) command function

Example 1 : I1-D — [Q1



Example 2 : i1-d — [Q1



◎ NORMAL (-) output

I1 — [Q1




◎ SET (^) output

I1 — ^ Q1




◎ RESET (v) output

I1 — v Q1




◎ P output

i1 — PQ1



4.5.3 Application Functions

1: Counter Function



Symbol	Description
①	Counter mode (1 ~ 4)
②	UP/Down counting modes can be set by (I1 ~ f8).
	OFF: Count up (0, 1, 2, 3...) ON: Count down (...3,2,1,0)
③	Use (I1~f8) to reset counting value
	ON: Internal count value is reset and counter output ⑥ is OFF
	OFF: Internal counter value retained
④	Internal counter value
⑤	Counter compare value (AS1~AS4,MD1~MD4,T1~T8,C1~C8,V1~V7,constant)
⑥	Counter output (C1 to C8, there are a total of 8 counters)

Counter modes:

Mode 1: Counter value is locked to the set value. The value will not be retained when the power is cut off.


Mode 2: Counter value is not locked. The value will not be retained when the power is cut off.

Mode 3: Counter value is locked. The value will be retained when the power is cut off.


Mode 4: Counter value is not locked. The value will be retained when the power is cut off.

Counter mode 1


Example:




Input from ladder program



Input from the function program




Counter mode 2




Note: In this mode the internal counter may increase past the counter compare value, unlike mode 1 where the internal counter value is limited to the counter compare value.

- (1) Counter mode 3 is similar to the counter mode 1, with the exception that the counter value is saved when the drive is powered down and reloaded at power up.
- (2) Counter mode 4 is similar to the counter mode 2, with the exception that the counter value is saved when the drive is powered down and reloaded at power up.

5	20		
4	Mode 1 & 2	1 1 2 2	0 1 1 2 2
4	Mode 3 & 4	1 1 2 2 3	3 4 4 5 5




2: Timer Function




Symbol	Description
①	Timer mode (1-7)
②	Timing unit: 1:0.0~999.9 second
	2:0~9999 second
	3:0~9999 minute
③	Use (I1~f8) to reset timing value
	ON: Internal timing value is reset and timer output ⑥ is OFF OFF: Internal timer stays running
④	Internal timer value
⑤	Timer set value (AS1~AS4, MD1~MD4, T1~T8, C1~C8, V1~V7, constant)
⑥	Timer output (T1 to T8, there are a total of 8 timers)

Timer mode description :


(1) Timer mode 1 (ON-delay Timer mode 1)





Example:




(2) Timer mode 2 (ON-delay Timer mode 2)




(3) Timer mode 3 (OFF-delay Timer mode 1)




(4) Timer mode 4 (OFF-delay Timer mode 2)




(5) Timer mode 5 (FLASH Timer mode 1)




(6) Timer mode 6 (FLASH Timer mode 2)



(7) Timer mode 7 (FLASH Timer mode 3)



3: Analog comparator function



Symbol	Description
①	Analog comparator mode (1~3)
②	Input comparison value selection (AS1~AS4,MD1~MD4,T1~T8,C1~C8,V1~V7)
③	Current analog input value
④	Set the reference comparison value (Upper limit) (AS1~AS4,MD1~MD4,T1~T8,C1~C8,V1~V7, constant)
⑤	Set the reference comparison value (lower limit) (AS1~AS4,MD1~MD4,T1~T8,C1~C8,V1~V7, constant)
⑥	Comparator output (G1 to G8, there are a total of 8 comparators)

The description of analog comparison mode:


- (1) Analog comparison mode 1 (③ ≤ ⑤, ⑥ ON)
- (2) Analog comparison mode 2 (③ ≥ ④, ⑥ ON)
- (3) Analog comparison mode 3 (⑤ ≤ ③ ≤ ④, ⑥ ON)

Input comparison value selection (V1~V7)

- (1) Input comparison value selection = V1: Set frequency
- (2) Input comparison value selection = V2: Operation frequency

- (3) Input comparison value selection = V3: AI1 input value
- (4) Input comparison value selection = V4: AI2 input value
- (5) Input comparison value selection = V5: Keypad input value
- (6) Input comparison value selection = V6: Operation current
- (7) Input comparison value selection = V7: Torque value


4: Operation control function




Symbol	Description
①	Forward /Reversal control can be set by (I1~f8) OFF: Forward(FWD) ON: Reversal(REV)
②	Speed terminal control can be set by (I1~f8) OFF: Operation based on ③ set frequency ON: Operation based on frequency of speed ④
③	Set frequency (can be constant or V3 · V4 · V5)
④	Speed frequency (can be constant or V3 · V4 · V5)
⑤	Acceleration time (ACC Time)
⑥	Deceleration time (DEC Time)
⑦	Operation command output (F1 to F8, there are a total of 8 operation control functions)

Example:


Input from the Ladder Program



Input from Function Program




5: Summation and subtraction functions



RESULT (calculation result) = V1+ V2- V3

Symbol	Description
①	Calculation result : RESULT
②	Addend V1(AS1~AS4,MD1~MD4,T1~T8,C1~C8,V1~V7, constant)
③	Addend V2(AS1~AS4,MD1~MD4,T1~T8,C1~C8,V1~V7, constant)
④	Subtrahend V3(AS1~AS4,MD1~MD4,T1~T8,C1~C8,V1~V7, constant)
⑤	Coil output of error signal (M1~MF)
⑥	Addition and subtraction modes number (AS1~AS4)

6: Multiplication and division modes



RESULT (calculation result) =V1*V2/V3


Symbol	Description
①	Calculation result : RESULT
②	Multiplier V1(AS1~AS4,MD1~MD4,T1~T8,C1~C8,V1~V7, constant)
③	Multiplier V2(AS1~AS4,MD1~MD4,T1~T8,C1~C8,V1~V7, constant)
④	Divisor V3(AS1~AS4,MD1~MD4,T1~T8,C1~C8,V1~V7, constant)
⑤	Coil output of error signal (M1~MF)
⑥	Multiplication and division modes number (MD1~ MD4)

4.6 Modbus Protocol Descriptions

4.6.1 Communication Connection and Data Frame


The inverter can communicate with a PC or PLC via RS485 or RS232 using the Modbus RTU or Modbus ACSII protocol. The maximum frame length is 80 bytes.

• Network Connection



**The distance of communication line with above 200m should have terminal resistors, which ought to be placed at both ends, so as to eliminate reflection phenomenon. **

- Use S (+) and S (-) terminals (only for RS-485) or CN6 connector to connect.
- ◆ CN6 Connector:



Pin	Signal	Pin	Signal
1	RS-485 S+ signal	5	Tx signal
2	RS-485 S- signal	6	RS-485 S- signal
3	RS-485 S+ signal	7	VCC of isolated 5V power supply
4	Rx signal	8	GND of isolated 5V power supply

- ◆ For RS-485 communication, use pin 1 or pin 3 for S (+) and pin 2 or pin 6 for S (-).

• **Data Format Frame**

■ **Data Frame for ASCII Mode**

STX(3AH)	Start Bit = 3AH
Address Hi	Communication Address (Station): 2-digit ASCII Code
Address Lo	
Function Hi	Function Code (command): 2-digit ASCII Code
Function Lo	
Command Start Address	Command Start Byte: 4-digit ASCII Code
Command Start Address	
Command Start Address	
Command Start Address	
Data length	The length of the command: 4-digit ASCII Code
Data length	
Data length	
Data length	
LRC Check Hi	LRC Check Code: 2-digit ASCII Code
LRC Check Lo	
END Hi	End Bit:
END Lo	END Hi = CR(0DH) , END Li = LF(0AH)

■ **Data Frame for RTU Mode**

Master (PLC etc.) sends request to follower (inverter), and the follower sends a response to the master (PC, PLC). The data received is illustrated here.

The data length varies depending on the command (Function).

Node Address
Function Code
DATA
CRC CHECK
Signal Interval

** The inverter response time is 10ms.

• **Node Address**

00H: Broadcast to all the drivers

01H: to the No. 01 inverter

0FH: to the No.15 inverter

10H: to the No.16 inverter and so on....., max to No. 254 (FEH)

• **Function Code**

03H: Read the register contents

06H: Write a WORD to register

08H: Loop test

10H: Write several data to register (complex number register write)

• Checksum Calculation

■ LRC

ex. NODE ADDRESS	01H
FUNCTION	03H
COMMAND	01H
	00H
+ DATA LENGTH	0AH

	0FH-----2's complement
Checksum =	F1H
CS(H) =	46H (ASCII)
CS(L) =	31H (ASCII)

■ CRC

CRC Check: CRC code covers the content from Slave address to DATA. Please calculate it according to the following methods.

- (1) Load a 16-bit register with FFFF hex (all 1's). Call this CRC register.
- (2) Exclusive OR the first 8-bit byte of the message, the low-order byte of the 16-bit CRC register, putting the result in the CRC register.
- (3) Shift the CRC register one bit to the right (toward the LSB), Zero-filling the MSB, Extract and examines the LSB.
- (4) (If the LSB was 0): Repeat Steps (3) (another shift)
(If the LSB was 1): Exclusive OR the CRC register with the polynomial value A001 hex (1010 0000 0000 0001), putting the result in CRC register.
- (5) Repeat Steps (3) and (4) until 8 shifts been performed. When this is done, a complete 8-bit byte will be processed.
- (6) Repeat Steps (2) through (5) for next 8-bit byte of the message, Continue doing this until all bytes have been processed. The final content in the CRC register is the CRC value. When sending the CRC value, the Low-order byte should be sent firstly, then the High-order byte. For example, CRC value: 1241 Hex, the high-order byte should be set to 41hex and low-order byte 12hex.

• CRC Calculate Program (C language)

```

UWORD ch_sum (UBYTE long , UBYTE *rxdbuf ) {
    BYTE i = 0;
    UWORD wkg = 0xFFFF;
    while ( long-- ) {
        wkg ^= rxdbuf++;
        for ( i = 0 ; i < 8; i++ ) {
            if ( wkg & 0x0001 ) {
                wkg = ( wkg >> 1 ) ^ 0xa001;
            }
            else {
                wkg = wkg >> 1;
            }
        }
    }
    return( wkg );
}

```

• **Exception Code**

ASCII Mode	
STX	‘.’
Address	‘0’
	‘1’
Function	‘8’
	‘6’
Exception code	‘5’
	‘1’
LRC Check	‘2’
	‘8’
END	‘CR’
	‘LF’

RTU Mode		
SLAVE Address		02H
Function		83H
Exception code		52H
CRC-16	High	C0H
	Low	CDH

During a communication error, the inverter will respond with an Exception Code and send a message back to the main system consisting of a Function Code that is “ANDED (and 80h)” with 80 Hex.

Exception Code	Content
01	Function code error
02	Register number error
03	Number error
04	DATA setting error

Information provided by **EMAG**
 Tel: 01902 601403
 www.emag-ltd.co.uk

4.6.2 Register and Data Format

• Command Data (Read / Write)

Register No.	Bit	Content
2500H	Reserved	
2501H	0	Operation Command 1 : Run 0 : Stop
	1	Reverse Command 1 : Reverse 0 : Forward
	2	External Fault 1 : Fault
	3	Fault Reset 1 : Reset
	4	Reserved
	5	Reserved
	6	Multi-function Comm S1 1 : "ON"
	7	Multi-function Comm S2 1 : "ON"
	8	Multi-function Comm S3 1 : "ON"
	9	Multi-function Comm S4 1 : "ON"
	A	Multi-function Comm S5 1 : "ON"
	B	Multi-function Comm S6 1 : "ON"
	C	Reserved
	D	Reserved
	E	Controller Mode 1 : "ON"
F	Reserved	
2502H	Frequency Command (Unit: 0.01Hz)	
2503H	Reserved	
2504H	Reserved	
2505H	AO1 (0 ~ 1000): Voltage (0.00V ~ 10.00V); Current (4mA~20mA)	
2506H	AO2 (0 ~ 1000): Voltage (0.00~10.00V); Current (4mA~20mA)	
2507H	DO	
2508H	Reserved	
2509H	Reserved	
250AH	Reserved	
250BH	Reserved	
250CH	Reserved	
250DH	Reserved	
250EH	Reserved	
250FH	Reserved	
2510H	G12-00 H-WORD	
2511H	G12-00 L-WORD	

Note: Write a zero into the register for not used bit; do not write data to a reserved register.

• Monitor Data (Read only)

Register No.	Bit	Content
2520H	0	Operation 1 : Run 0 : Stop
	1	Direction 1 : Reverse 0 : Forward
	2	Inverter ready 1 : Ready 0 : Unready
	3	Fault 1 : Abnormal
	4	Warning 1 : "ON"
	5	Zero Speed 1 : "ON"
	6	Ls 440 1 : "ON"
	7	Frequency Agree 1 : "ON"
	8	Set Frequency Agree 1 : "ON"
	9	Frequency Detection 1 1 : "ON"
	A	Frequency Detection 2 1 : "ON"
	B	Under Voltage 1 : "ON"
	C	Baseblock 1 : "ON"
	D	Freq Ref. not from Comm. 1 : "ON"
	E	Seq. not from Comm. 1 : "ON"
	F	Over Torque 1 : "ON"
2521H	0	30 Reserved
	1	UV 31 Reserved
	2	OC 32 Reserved
	3	OV 33 Reserved
	4	OH1 34 Reserved
	5	OL1 35 Reserved
	6	OL2 36 Low Suction Fault
	7	OT 37 Low Suction Fault (with retry)
	8	UT 38 CF07
	9	SC 39 Low Flow Fault
	10	Ground OC 40 High Flow Fault
	11	Fuse broken 41 Reserved
	12	Input Phase Loss 42 Low Pressure Fault
	13	Output Phase Loss 43 High Pressure Fault
	14	Reserved 44 Feedback Loss
	15	Reserved 45 Reserved
	16	Reserved 46 Motor Overheat (OH4)
	17	External Fault 01
	18	External Fault 02
	19	External Fault 03
	20	External Fault 04
	21	External Fault 05
	22	External Fault 06
	23	Reserved
	24	Reserved
	25	Feedback Fault
	26	Keypad Removed
	27	Modbus External Fault
	28	CE
	29	STO

Register No.	Bit	Content						
2522H	0	Multi-function Comm S1						
	1	Multi-function Comm S2						
	2	Multi-function Comm S3						
	3	Multi-function Comm S4						
	4	Multi-function Comm S5						
	5	Multi-function Comm S6						
	6	Reserved						
	7	Reserved						
	8	Reserved						
	9	Reserved						
	A	Reserved						
	B	Reserved						
	C	Reserved						
	D	Reserved						
	E	Reserved						
	F	Reserved						
2523H	Frequency Command							
2524H	Output Frequency							
2525H	Reserved							
2526H	DC Voltage Command							
2527H	Output Current							
2528H	0	No alarm	18	EF2	36	SE03	54	BB6
	1	OV	19	EF3	37	SE04	55	Reserved
	2	UV	20	EF4	38	SE05	56	Reserved
	3	OL2	21	EF5	39	HPERR	57	LOPb
	4	OH2	22	EF6	40	EF	58	HIPb
	5	Reserved	23	Reserved	41	CTRL	59	LSCFT
	6	OT	24	Reserved	42	SUME	60	LOPb
	7	Reserved	25	CLA	43	RDP	61	RETRY
	8	Reserved	26	CLB	44	Reserved	62	SE07
	9	UT	27	Reserved	45	OL1	63	SE08
	10	Reserved	28	Reserved	46	Reserved	64	HIPb
	11	Reserved	29	USP	47	SE10	65	OH1
	12	Reserved	30	RDE	48	Reserved	66	FIRE
	13	CE	31	WRE	49	BB1		
	14	Reserved	32	FB	50	BB2		
	15	Reserved	33	VRYE	51	BB3		
	16	EF0	34	SE01	52	BB4		
	17	EF1	35	SE02	53	BB5		
2529H	DO State							
252AH	AO1 (0 ~ 1000): Voltage (0.00V ~ 10.00V); Current (4mA~20mA)							
252BH	AO2 (0 ~ 1000): Voltage (0.00~10.00V); Current (4mA~20mA)							
252CH	Analog Input 1							
252DH	Analog Input 2							
252EH	Reserved							
252FH	F510/A510/L510/E510 Check							

Note: Do not write data to a reserved register.

• **Read Holding Register [03H]**

Read consecutive holding registers. The address of the first holding register is specified in the protocol.

Example: Read frequency command from the inverter with node address 1.

■ **ASCII Mode**

Command message		Response Message (Normal)		Response Message (Error)		
3AH	STX	3AH	STX	3AH	STX	
30H	Node Address	30H	Node Address	30H	Node Address	
31H		31H		31H		
30H	Function Code	30H	Function Code	38H	Function Code	
33H		33H		33H		
30H	Starting Register	30H	DATA Length	30H	Exception Code	
43H		32H		34H		
31H		Data	31H	LRC CHECK	34H	LRC CHECK
30H			37H		30H	
30H	Number of Registers	37H	LRC CHECK	0DH	END	
30H		30H		0AH		
30H	LRC CHECK	0DH	END	0AH	END	
46H		0AH		0AH		
0DH	END					
0AH						

■ **RTU Mode**

Command Message			Response Message (Normal)			Response Message (Error)		
Node Address		01 H	Node Address		01H	Node Address		01H
Function Code		03H	Function Code		03H	Function Code		83H
Starting Register	High	0CH	DATA Length		02H	Exception Code		04H
	Low	10H	Data	High	17H	CRC-16	High	40H
Number of Registers	High	00H		Low	70H		Low	F3H
	CRC-16	High	86H	CRC-16	High	B6H		
Low		9FH	Low		50H			

• **Loop Back Test [08H]**

Check the communication between the master and the follower (inverter). The data used can be arbitrary.

■ **ASCII Mode**

Command Message		Response Message (Normal)		Response Message (Error)	
3AH	STX	3AH	STX	3AH	STX
30H	Node Address	30H	Node Address	30H	Node Address
31H		31H		31H	
30H	Function Code	30H	Function Code	38H	Function Code
38H		38H		38H	
30H	Test Code	30H	Test Code	30H	Exception Code
30H		30H		33H	
30H		30H		30H	LRC CHECK
30H		30H		36H	
41H	DATA	41H	DATA	0DH	END
35H		35H		0AH	
33H		33H			
37H		37H			
31H	LRC CHECK	31H	LRC CHECK		
42H		42H			
0DH	END	0DH	END		
0AH		0AH			

■ **RTU Mode**

Command Message			Response Message (Normal)			Response Message (Error)		
Node Address		01 H	Node Address		01H	Node Address		01H
Function Code		08H	Function Code		08H	Function Code		88H
Test Code	High	00H	Test Code	High	00H	Exception Code		03H
	Low	00H		Low	00H	CRC-16	High	06H
DATA	High	A5H	DATA	High	A5H		Low	01H
	Low	37H		Low	37H			
CRC-16	High	DAH	CRC-16	High	DAH			
	Low	8DH		Low	8DH			

• **Write Single Holding Register [06H]**

Write single holding register. The register address of the holding register is specified in the message.

Example: Write a 60.00Hz frequency command to node address 1.

■ **ASCII Mode**

Command Message		Response Message (Normal)		Response Message (Error)	
3AH	STX	3AH	STX	3AH	STX
30H	Node Address	30H	Node Address	30H	Node Address
31H		31H		31H	
30H	Function Code	30H	Function Code	38H	Function Code
36H		36H		36H	
32H	Starting Register	32H	Starting Register	30H	Exception Code
35H		35H		33H	
30H		30H		30H	LRC CHECK
32H		32H		32H	
31H	DATA	31H	DATA	0DH	END
37H		37H		0AH	
37H		37H			
30H		30H			
34H		LRC CHECK		34H	LRC CHECK
42H	42H				
0DH	END	0DH	END		
0AH		0AH			

■ **RTU Mode**

Command Message			Response Message (Normal)			Response Message (Error)		
Node Address	01 H		Node Address	01H		Node Address	01H	
Function Code	06H		Function Code	06H		Function Code	86H	
Starting Register	High	25H	Starting Register	High	25H	Exception Code	03H	
	Low	02H		Low	02H	CRC-16	High	02H
DATA	High	17H	DATA	High	17H		Low	61H
	Low	70H		Low	70H			
CRC-16	High	2DH	CRC-16	High	2DH			
	Low	12H		Low	12H			

• **Write Multiple Holding Register [10H]**

Write multiple holding registers. The address of the first holding register is specified in the message.

Example: Write a 60.00Hz frequency command to node address 1 and enable FWD run command.

■ **ASCII Mode**

Command Message		Response Message (Normal)		Response Message (Error)	
3AH	STX	3AH	STX	3AH	STX
30H	Node Address	30H	Node Address	30H	Node Address
31H		31H		31H	
31H	Function Code	31H	Function Code	39H	Function Code
30H		30H		30H	
32H	Starting Register	32H	Starting Register	30H	Exception Code
35H		35H		33H	
30H		30H		30H	LRC CHECK
31H	31H	43H			
30H	Number of Registers	30H	Number of Registers	0DH	END
30H		30H		0AH	
30H		30H			
32H		32H			
30H	Number of Bytes *	43H	LRC CHECK		
34H		37H			
30H	DATA 1	0DH	END		
30H		0AH			
30H					
31H					
31H	DATA 2				
37H					
37H					
30H	LRC CHECK				
33H					
42H					
0DH	END				
0AH					

* Number of bytes is register amount x 2.

■ RTU Mode

Command Message

Node Address		01H
Function Code		10H
Starting Register	High	25H
	Low	01H
Number of Registers	High	00H
	Low	02H
Number of Bytes *		04H
DATA 1	High	00H
	Low	01H
DATA 2	High	17H
	Low	70H
CRC-16	High	60H
	Low	27H

Response Message (Normal)

Node Address		01H
Function Code		10H
Starting Register	High	25H
	Low	01H
Number of Registers	High	00H
	Low	02H
CRC-16	High	1BH
	下位	04H

Response Message (Error)

Node Address		01H
Function Code		90H
Exception Code		03H
CRC-16	High	0CH
	Low	01H

* Number of bytes is register amount x 2.

Information provided by
EMAG
 Tel: 01902 601403
 www.emag-ltd.co.uk

• Parameter Data and Corresponding Register No.

Function Code	Register No.	Function Code	Register No.	Function Code	Register No.
Group 0		Group 0		Group 1	
0 – 00	0000H	0 – 45	002DH	1 – 00	0100H
0 – 01	0001H	0 – 46	002EH	1 – 01	0101H
0 – 02	0002H	0 – 47	002FH	1 – 02	0102H
0 – 03	0003H	0 – 48	0030H	1 – 03	0103H
0 – 04	0004H	0 – 49	0031H	1 – 04	0104H
0 – 05	0005H	0 – 50	0032H	1 – 05	0105H
0 – 06	0006H	0 – 51	0033H	1 – 06	0106H
0 – 07	0007H	0 – 52	0034H	1 – 07	0107H
0 – 08	0008H	0 – 53	0035H	1 – 08	0108H
0 – 09	0009H	0 – 54	0036H	1 – 09	0109H
0 – 10	000AH	0 – 55	0037H	1 – 10	010AH
0 – 11	000BH	0 – 56	0038H	1 – 11	010BH
0 – 12	000CH			1 – 12	010CH
0 – 13	000DH			1 – 13	010DH
0 – 14	000EH			1 – 14	010EH
0 – 15	000FH			1 – 15	010FH
0 – 16	0010H				
0 – 17	0011H				
0 – 18	0012H				
0 – 19	0013H				
0 – 20	0014H				
0 – 21	0015H				
0 – 22	0016H				
0 – 23	0017H				
0 – 24	0018H				
0 – 25	0019H				
0 – 26	001AH				
0 – 27	001BH				
0 – 28	001CH				
0 – 29	001DH				
0 – 30	001EH				
0 – 31	001FH				
0 – 32	0020H				
0 – 33	0021H				
0 – 34	0022H				
0 – 35	0023H				
0 – 36	0024H				
0 – 37	0025H				
0 – 38	0026H				
0 – 39	0027H				
0 – 40	0028H				
0 – 41	0029H				
0 – 42	002AH				
0 – 43	002BH				
0 – 44	002CH				

Function Code	Register No.	Function Code	Register No.	Function Code	Register No.
Group 2		Group 3		Group 3	
2 – 00	0200H	3 – 00	0300H	3 – 33	0321H
2 – 01	0201H	3 – 01	0301H	3 – 34	0322H
2 – 02	0202H	3 – 02	0302H	3 – 35	0323H
2 – 03	0203H	3 – 03	0303H	3 – 36	0324H
2 – 04	0204H	3 – 04	0304H	3 – 37	0325H
2 – 05	0205H	3 – 05	0305H	3 – 38	0326H
2 – 06	0206H	3 – 06	0306H	3 – 39	0327H
2 – 07	0207H	3 – 07	0307H	3 – 40	0328H
2 – 08	0208H	3 – 08	0308H		
2 – 09	0209H	3 – 09	0309H		
2 – 10	020AH	3 – 10	030AH		
2 – 11	020BH	3 – 11	030BH		
2 – 12	020CH	3 – 12	030CH		
2 – 13	020DH	3 – 13	030DH		
2 – 14	020EH	3 – 14	030EH		
2 – 15	020FH	3 – 15	030FH		
2 – 16	0210H	3 – 16	0310H		
2 – 17	0211H	3 – 17	0311H		
2 – 18	0212H	3 – 18	0312H		
2 – 19	0213H	3 – 19	0313H		
2 – 33	0221H	3 – 20	0314H		
2 – 34	0222H	3 – 21	0315H		
		3 – 22	0316H		
		3 – 23	0317H		
		3 – 24	0318H		
		3 – 25	0319H		
		3 – 26	031AH		
		3 – 27	031BH		
		3 – 28	031CH		
		3 – 29	031DH		
		3 – 30	031EH		
		3 – 31	031FH		
		3 – 32	0320H		

Function Code	Register No.	Function Code	Register No.	Function Code	Register No.
Group 4		Group 5		Group 5	
4-00	0400H	5-00	0500H	5-33	0521H
4-01	0401H	5-01	0501H	5-34	0522H
4-02	0402H	5-02	0502H	5-35	0523H
4-03	0403H	5-03	0503H	5-36	0524H
4-04	0404H	5-04	0504H	5-37	0525H
4-05	0405H	5-05	0505H	5-38	0526H
4-06	0406H	5-06	0506H	5-39	0527H
4-07	0407H	5-07	0507H	5-40	0528H
4-08	0408H	5-08	0508H	5-41	0529H
4-09	0409H	5-09	0509H	5-42	052AH
4-10	040AH	5-10	050AH	5-43	052BH
4-11	040BH	5-11	050BH	5-44	052CH
4-12	040CH	5-12	050CH	5-45	052DH
4-13	040DH	5-13	050DH	5-46	052EH
4-14	040EH	5-14	050EH	5-47	052FH
4-15	040FH	5-15	050FH	5-48	0530H
4-16	0410H	5-16	0510H		
4-17	0411H	5-17	0511H		
4-18	0412H	5-18	0512H		
4-19	0413H	5-19	0513H		
4-20	0414H	5-20	0514H		
		5-21	0515H		
		5-22	0516H		
		5-23	0517H		
		5-24	0518H		
		5-25	0519H		
		5-26	051AH		
		5-27	051BH		
		5-28	051CH		
		5-29	051DH		
		5-30	051EH		
		5-31	051FH		
		5-32	0520H		

Function Code	Register No.	Function Code	Register No.	Function Code	Register No.
Group 6		Group 6		Group 7	
6-00	0600H	6-33	0621H	7-00	0700H
6-01	0601H	6-34	0622H	7-01	0701H
6-02	0602H	6-35	0623H	7-02	0702H
6-03	0603H	6-36	0624H	7-03	0703H
6-04	0604H	6-37	0625H	7-04	0704H
6-05	0605H	6-38	0626H	7-05	0705H
6-06	0606H	6-39	0627H	7-06	0706H
6-07	0607H	6-40	0628H	7-07	0707H
6-08	0608H	6-41	0629H	7-08	0708H
6-09	0609H	6-42	062AH	7-09	0709H
6-10	060AH	6-43	062BH	7-10	070AH
6-11	060BH	6-44	062CH	7-11	070BH
6-12	060CH	6-45	062DH	7-12	070CH
6-13	060DH	6-46	062EH	7-13	070DH
6-14	060EH	6-47	062FH	7-14	070EH
6-15	060FH			7-15	070FH
6-16	0610H			7-16	0710H
6-17	0611H			7-17	0711H
6-18	0612H			7-18	0712H
6-19	0613H			7-19	0713H
6-20	0614H			7-20	0714H
6-21	0615H			7-21	0715H
6-22	0616H			7-22	0716H
6-23	0617H			7-23	0717H
6-24	0618H			7-24	0718H
6-25	0619H			7-25	0719H
6-26	061AH			7-26	071AH
6-27	061BH			7-27	071BH
6-28	061CH			7-28	071CH
6-29	061DH				
6-30	061EH				
6-31	061FH				
6-32	0620H				

Function Code	Register No.	Function Code	Register No.	Function Code	Register No.
Group 8		Group 9		Group 10	
8- 00	0800H	9- 00	0900H	10- 00	0A00H
8 - 01	0801H	9 - 01	0901H	10 - 01	0A01H
8 - 02	0802H	9 - 02	0902H	10 - 02	0A02H
8 - 03	0803H	9 - 03	0903H	10 - 03	0A03H
8 - 04	0804H	9 - 04	0904H	10 - 04	0A04H
8 - 05	0805H	9 - 05	0905H	10 - 05	0A05H
8 - 06	0806H	9 - 06	0906H	10 - 06	0A06H
8 - 07	0807H	9 - 07	0907H	10 - 07	0A07H
8 - 08	0808H	9 - 08	0908H	10 - 08	0A08H
8 - 09	0809H	9 - 09	0909H	10 - 09	0A09H
8 - 10	080AH	9 - 10	090AH	10 - 10	0A0AH
8 - 11	080BH			10 - 11	0A0BH
8 - 12	080CH			10 - 12	0A0CH
8 - 13	080DH			10 - 13	0A0DH
8 - 14	080EH			10 - 14	0A0EH
8 - 15	080FH			10 - 15	0A0FH
8 - 16	0810H			10 - 16	0A10H
8 - 17	0811H			10 - 17	0A11H
8 - 18	0812H			10 - 18	0A12H
8 - 19	0813H			10 - 19	0A13H
8 - 20	0814H			10 - 20	0A14H
8 - 21	0815H			10 - 21	0A15H
8 - 22	0816H			10 - 22	0A16H
8 - 23	0817H			10 - 23	0A17H
8 - 24	0818H			10 - 24	0A18H
8 - 25	0819H			10 - 25	0A19H
8 - 26	081AH			10 - 26	0A1AH
8 - 27	081BH			10 - 27	0A1BH
8 - 28	081CH			10 - 28	0A1CH
8 - 29	081DH			10 - 29	0A1DH
8 - 30	081EH			10 - 30	0A1EH
8 - 31	081FH			10 - 31	0A1FH
8 - 32	0820H			10 - 32	0A20H
8 - 33	0821H			10 - 33	0A21H
8 - 34	0822H			10 - 34	0A22H
8 - 35	0823H			10 - 35	0A23H
8 - 36	0824H			10 - 36	0A24H
8 - 37	0825H			10 - 37	0A25H
8 - 38	0826H			10 - 38	0A26H
8 - 39	0827H			10 - 39	0A27H

Function Code	Register No.	Function Code	Register No.	Function Code	Register No.
Group 11		Group 11		Group 12	
11- 00	0B00H	11- 33	0B21H	12- 00	0C00H
11 - 01	0B01H	11 - 34	0B22H	12 - 01	0C01H
11 - 02	0B02H	11 - 35	0B23H	12 - 02	0C02H
11 - 03	0B03H	11- 36	0B24H	12 - 03	0C03H
11 - 04	0B04H	11 - 37	0B25H	12 - 04	0C04H
11 - 05	0B05H	11 - 38	0B26H	12 - 05	0C05H
11 - 06	0B06H	11- 39	0B27H	12 - 06	0C06H
11 - 07	0B07H	11 - 40	0B28H	12 - 07	0C07H
11 - 08	0B08H	11 - 41	0B29H	12 - 08	0C08H
11 - 09	0B09H	11- 42	0B2AH	12 - 09	0C09H
11 - 10	0B0AH	11 - 43	0B2BH	12 - 10	0C0AH
11 - 11	0B0BH	11 - 44	0B2CH	12 - 11	0C0BH
11 - 12	0B0CH	11- 45	0B2DH	12 - 12	0C0CH
11 - 13	0B0DH	11 - 46	0B2EH	12 - 13	0C0DH
11 - 14	0B0EH	11 - 47	0B2FH	12 - 14	0C0EH
11 - 15	0B0FH	11 - 48	0B30H	12 - 15	0C0FH
11 - 16	0B10H	11 - 49	0B31H	12 - 16	0C10H
11 - 17	0B11H	11 - 50	0B32H	12 - 17	0C11H
11 - 18	0B12H	11 - 51	0B33H	12 - 18	0C12H
11 - 19	0B13H	11 - 52	0B34H	12 - 19	0C13H
11 - 20	0B14H	11 - 53	0B35H	12 - 20	0C14H
11 - 21	0B15H	11 - 54	0B36H	12 - 21	0C15H
11 - 22	0B16H	11 - 55	0B37H	12 - 22	0C16H
11 - 23	0B17H	11 - 56	0B38H	12 - 23	0C17H
11 - 24	0B18H	11 - 57	0B39H	12 - 24	0C18H
11 - 25	0B19H	11 - 58	0B3AH	12 - 25	0C19H
11 - 26	0B1AH	11 - 59	0B3BH	12 - 26	0C1AH
11 - 27	0B1BH	11 - 60	0B3CH	12 - 27	0C1BH
11 - 28	0B1CH	11 - 61	0B3DH	12 - 28	0C1CH
11 - 29	0B1DH	11 - 62	0B3EH	12 - 29	0C1DH
11 - 30	0B1EH	11 - 63	0B3FH	12 - 30	0C1EH
11 - 31	0B1FH	11 - 64	0B40H	12 - 31	0C1FH
11 - 32	0B20H	11 - 65	0B41H	12 - 32	0C20H
		11 - 66	0B42H		

Function Code	Register No.	Function Code	Register No.	Function Code	Register No.
Group 12		Group 13		Group 14	
12- 33	0C21H	13- 00	0D00H	14- 00	0E00H
12 - 34	0C22H	13 - 01	0D01H	14 - 01	0E01H
12 - 35	0C23H	13 - 02	0D02H	14 - 02	0E02H
12- 36	0C24H	13 - 03	0D03H	14 - 03	0E03H
12 - 37	0C25H	13 - 04	0D04H	14 - 04	0E04H
12 - 38	0C26H	13 - 05	0D05H	14 - 05	0E05H
12- 39	0C27H	13 - 06	0D06H	14 - 06	0E06H
12 - 40	0C28H	13 - 07	0D07H	14 - 07	0E07H
12 - 41	0C29H	13 - 08	0D08H	14 - 08	0E08H
12- 42	0C2AH	13 - 09	0D09H	14 - 09	0E09H
12 - 43	0C2BH	13 - 10	0D0AH	14 - 10	0E0AH
12 - 44	0C2CH	13 - 11	0D0BH	14 - 11	0E0BH
12- 45	0C2DH	13 - 12	0D0CH	14 - 12	0E0CH
12 - 46	0C2EH	13 - 13	0D0DH	14 - 13	0E0DH
12 - 47	0C2FH			14 - 14	0E0EH
12 - 48	0C30H			14 - 15	0E0FH
12 - 49	0C31H			14 - 16	0E10H
12 - 50	0C32H			14 - 17	0E11H
12 - 51	0C33H			14 - 18	0E12H
12 - 52	0C34H			14 - 19	0E13H
12 - 53	0C35H			14 - 20	0E14H
12 - 54	0C36H			14 - 21	0E15H
12 - 55	0C37H			14 - 22	0E16H
12 - 56	0C38H			14 - 23	0E17H
12 - 57	0C39H			14 - 24	0E18H
12 - 58	0C3AH			14 - 25	0E19H
12 - 59	0C3BH			14 - 26	0E1AH
12 - 60	0C3CH			14 - 27	0E1BH
12 - 61	0C3DH			14 - 28	0E1CH
12 - 62	0C3EH			14 - 29	0E1DH
12 - 63	0C3FH			14 - 30	0E1EH
12 - 64	0C40H			14 - 31	0E1FH
12 - 65	0C41H			14 - 32	0E20H
12 - 66	0C42H			14 - 33	0E21H
12 - 67	0C43H				
12 - 68	0C44H				
12 - 69	0C45H				
12 - 70	0C46H				
12 - 71	0C47H				
12 - 72	0C48H				
12 - 73	0C49H				
12 - 70	0C46H				
12 - 71	0C47H				
12 - 72	0C48H				
12 - 73	0C49H				
12 - 74	0C4AH				
12 - 75	0C4BH				
12 - 76	0C4CH				

Function Code	Register No.	Function Code	Register No.	Function Code	Register No.
Group 14		Group 15		Group 16	
14 – 34	0E22H	15 – 00	0F00H	16 – 00	1000H
14 – 35	0E23H	15 – 01	0F01H	16 – 01	1001H
14 – 36	0E24H	15 – 02	0F02H	16 – 02	1002H
14 – 37	0E25H	15 – 03	0F03H	16 – 03	1003H
14 – 38	0E26H	15 – 04	0F04H	16 – 04	1004H
14 – 39	0E27H	15 – 05	0F05H	16 – 05	1005H
14 – 40	0E28H	15 – 06	0F06H	16 – 06	1006H
14 – 41	0E29H	15 – 07	0F07H	16 – 07	1007H
14 – 42	0E2AH	15 – 08	0F08H	16 – 08	1008H
14 – 43	0E2BH	15 – 09	0F09H	16 – 09	1009H
14 – 44	0E2CH	15 – 10	0F0AH	16 – 10	100AH
14 – 45	0E2DH	15 – 11	0F0BH	16 – 11	100BH
14 – 46	0E2EH	15 – 12	0F0CH	16 – 12	100CH
14 – 47	0E2FH	15 – 13	0F0DH	16 – 13	100DH
		15 – 14	0F0EH	16 – 14	100EH
		15 – 15	0F0FH	16 – 15	100FH
		15 – 16	0F10H	16 – 16	1010H
		15 – 17	0F11H	16 – 17	1011H
		15 – 18	0F12H	16 – 18	1012H
		15 – 19	0F13H	16 – 19	1013H
		15 – 20	0F14H	16 – 20	1014H
		15 – 21	0F15H	16 – 21	1015H
		15 – 22	0F16H	16 – 22	1016H
		15 – 23	0F17H	16 – 23	1017H
		15 – 24	0F18H	16 – 24	1018H
		15 – 25	0F19H	16 – 25	1019H
		15 – 26	0F1AH	16 – 26	101AH
		15 – 27	0F1BH	16 – 27	101BH
		15 – 28	0F1CH	16 – 28	101CH
		15 – 29	0F1DH	16 – 29	101DH
		15 – 30	0F1EH	16 – 30	101EH
		15 – 31	0F1FH	16 – 31	101FH
		15 – 32	0F20H	16 – 32	1020H
				16 – 33	1021H
				16 – 34	1022H
				16 – 35	1023H
				16 – 36	1024H
				16 – 37	1025H

Function Code	Register No.	Function Code	Register No.	Function Code	Register No.
Group 17		Group 18			
17- 00	1100H	18- 00	1200H		
17 - 01	1101H	18 - 01	1201H		
17 - 02	1102H	18 - 02	1202H		
17 - 03	1103H	18 - 03	1203H		
17 - 04	1104H	18 - 04	1204H		
17 - 05	1105H	18 - 05	1205H		
17 - 06	1106H	18 - 06	1206H		
17 - 07	1107H				
17 - 08	1108H				
17- 09	1109H				
17 - 10	110AH				
17 - 11	110BH				
17 - 12	110CH				
17 - 13	110DH				

Information
 provided by


 Tel: 01902 607403
www.emag-ld.co.uk

Function Code	Register No.	Function Code	Register No.	Function Code	Register No.
Group 20		Group 21		Group 22	
20- 00	1400H	21- 00	1500H	22 - 00	1600H
20 - 01	1401H	21 - 01	1501H	22 - 01	1601H
20 - 02	1402H	21 - 02	1502H	22 - 02	1602H
20 - 03	1403H	21 - 03	1503H	22 - 03	1603H
20 - 04	1404H	21 - 04	1504H	22 - 04	1604H
20 - 05	1405H	21 - 05	1505H	22 - 05	1605H
20 - 06	1406H	21 - 06	1506H	22 - 06	1606H
20 - 07	1407H	21 - 07	1507H	22 - 07	1607H
20 - 08	1408H	21 - 08	1508H	22 - 08	1608H
20 - 09	1409H			22 - 09	1609H
20 - 10	140AH			22 - 10	160AH
20 - 11	140BH			22 - 11	160BH
20 - 12	140CH			22 - 12	160CH
20 - 13	140DH			22 - 13	160DH
20 - 14	140EH			22 - 14	160EH
20 - 15	140FH			22 - 15	160FH
20 - 16	1410H			22 - 16	1610H
20 - 17	1411H			22 - 17	1611H
20 - 18	1412H			22 - 18	1612H
20 - 33	1421H			22 - 19	1613H
20 - 34	1422H			22 - 20	1614H
20 - 35	1423H			22 - 21	1615H
				22 - 22	1616H

Function Code	Register No.	Function Code	Register No.	Function Code	Register No.
Group 23		Group 23		Group 24	
23 – 00	1700H	23 – 47	172FH	24 – 00	1800H
23 – 01	1701H	23 – 48	1730H	24 – 01	1801H
23 – 02	1702H	23 – 49	1731H	24 – 02	1802H
23 – 03	1703H	23 – 50	1732H	24 – 03	1803H
23 – 04	1704H	23 – 51	1733H	24 – 04	1804H
23 – 05	1705H	23 – 52	1734H	24 – 05	1805H
23 – 06	1706H	23 – 53	1735H	24 – 06	1806H
23 – 07	1707H	23 – 54	1736H		
23 – 08	1708H	23 – 55	1737H		
23 – 09	1709H	23 – 56	1738H		
23 – 10	170AH	23 – 57	1739H		
23 – 11	170BH	23 – 58	173AH		
23 – 12	170CH				
23 – 13	170DH				
23 – 14	170EH				
23 – 15	170FH				
23 – 16	1710H				
23 – 17	1711H				
23 – 18	1712H				
23 – 19	1713H				
23 – 20	1714H				
23 – 21	1715H				
23 – 22	1716H				
23 – 23	1717H				
23 – 24	1718H				
23 – 25	1719H				
23 – 26	171AH				
23 – 27	171BH				
23 – 28	171CH				
23 – 29	171DH				
23 – 30	171EH				
23 – 31	171FH				
23 – 32	1720H				
23 – 33	1721H				
23 – 34	1722H				
23 – 35	1723H				
23 – 36	1724H				
23 – 37	1725H				
23 – 38	1726H				
23 – 39	1727H				
23 – 40	1728H				
23 – 41	1729H				
23 – 42	172AH				
23 – 43	172BH				
23 – 44	172CH				
23 – 45	172DH				
23 – 46	172EH				


4.7 BacNET Protocol Descriptions

BACnet is in compliance with four-layer of seven-layer structure models in OSI (Open Systems Interconnection) of International Standard Organization (ISO). These four-layer structure models are application layer, network layer, data link layer and physical layer. Besides, BACnet is defined by the view of standard “object” and “property.” All BACnet devices are controlled via the property of objects. Every controller with BACnet devices is considered an object collector so that every controller device can execute different kinds of functions of objects to achieve the communication control and monitor control.




4.7.1 BACnet Services

Services provide some commands to save or control information and some functions to achieve the purpose of monitoring and control. Namely, one BACnet device receive certain information or command to complete specific work from other BACnet device so the two devices need to support the same service to complete communication. To complete the exchange of these service messages, these communication requirements are specified in the communication protocol of application layer by BACnet. Thus, services are parts of the communication protocol data unit (PDU) in the application layer and build the communication modes via the relationship of Server – Client. Client will send the message of service requirements to Server and Server needs to respond to Client to execute this service. Refer to the following figure.




All BACnet devices have the application programs to manage the requirements of device motion and executing services. Take work station for example, the application program needs to keep the display value of every input so it requires sending the service request to the object of other device to update the display value of input. The application program of the device needs to respond to the service requirements. Refer to the following figure.



4.7.2 BACnet Protocol Structure

BACnet is the communication protocol by way of protocol stack so the packet is composed of stacked layer types. Refer to the following figure.



When application program sends the BACnet service request for the packet, it requires requesting for executing BACnet request program in the application layer via application program interface. The requirements of the program are sent to the application layer and application protocol data unit (APDU) consists of Application Protocol Control Information (APCI) and Service Data of application program. Then APDU passes its messages downward to BACnet request program in the network layer. APDU becomes Network Layer Protocol Data Unit (NPDU) composed of Network Service Data Unit (NSDU) and Network Protocol Control Information (NPCI). And so forth for the data link layer and physical layer to complete the full service for the packet.

4.7.3 BACnet Specifications

Inverter F510 model is built-in standard BACnet MS/TP communication protocol structure to meet the demand of automatic communication equipment. Control or monitor F510 via BACnet to be allowable to read and modify specific parameter. F510 includes the following supports of standard objects:

- Inverter Objects
- Analog Input ■ Analog Output ■ Analog Value
- Digital Input ■ Digital Output ■ Digital Value

Refer to Table 4.7.3.1 for F510 supporting the property information of object classification. User can collect related properties of objects required via the dedicated communication software of BACnet to give control or monitor command for each object.

Table 4.7.3.1 Object and property supporting list

Proerty	Inverter (DEV)	Analog Input (AI)	Analog Output (AO)	Analog Value (AV)	Digital Input (BI)	Digital Output (BO)	Digital Value (BV)
Object_Identifier	V	V	V	V	V	V	V
Object_Name	V	V	V	V	V	V	V
Object_Type	V	V	V	V	V	V	V
System_Status	V						
Vendor_Name	V						
Vendor_Identifier	V						
Model_Name	V						
Firmware_Revision	V						
Applocation_Software_Supported	V						
Protocol_Version	V						
Protocol_Revision	V						
Protocol_Services_Supported	V						
Protocol_Object_Type_Supported	V						
Object_List	V						
Max_APDU_Length_Accepted							
Segmentation_Supported							
APDU_Timeout							
Number_Of_APDU_Retries							
Max_Masters	V						
Max_Info_Frames	V						
Device_Address_Binding							
Location	V						
Presnent_Value		V	V	V	V	V	V
Status_Flags							
Event_State							
Reliability							
Out_Of_Service							
Units		V	V	V			
Priority_Array							
Relinquish_Default							
Polarity							
Inactive_Text							
Active_Text							

4.7.4 BACnet Object Properties

This section provides the predetermined configuration of the inverter. User can achieve the optimized situation at any necessary modification.

Refer to Table 4.7.4.1 for the property information of inverter objects and user can learn the inverter messages from the inverter objects.

Refer to Table 4.7.4.2 ~ Table 4.7.4.7 for the related object information that inverter supports. User can control/ read each object with the application requirements.

Table 4.7.4.1 – Inverter property list

Property	Inverter
Object_Identifier	DEV
Object_Name	TECO F510
Object_Type	8
System_Status	0
Vendor_Name	TECO F510
Vendor_Identifier	461
Model_Name	TECO.Inc
Firmware_Revision	0.14
Applcation_Software_Supported	0.14
Protocol_Version	1
Protocol_Revision	5
Protocol_Services_Supported	{ readProperty , writeProperty , who is }
Protocol_Object_Type_Supported	{ Analog_Input , Analog_Output, Analog_Value Binary_Input, Binary_Output, Binary_Value, Device}
Max_Masters	127
Max_Info_Frames	1
Location	R.O.C

Table 4.7.4.2 Analog input property list (READ)

No.	Object Name	Description	Unit	Classification	Range
AI0	TM2 AIN	AI1 inpur	Volt	R	0 - 10
AI1	TM2 AIN2	AI2 input	Volt	R	0 - 10
AI2	Error code	Recent fault message	No Units	R	0 – 45
AI3	Freq cmd	Frequency command	HZ	R	0 - 60
AI4	Frequency	Output frequency	HZ	R	0 - 60
AI5	Current	Output current	Amps	R	
AI6	Control Mode	Control mode	No Units	R	0 - 2
AI7	Motor R-Volt	Motor rated voltage	Volt	R	
AI8	Motor R-HP	Motor rated power	horsepower	R	
AI9	Motor R-RPM	Motor rated rotation speed	No Units	R	
AI10	Motor R-Hz	Motor rated frequency	HZ	R	
AI11	CarrierFreq	Carrier frequency	KiloHertz	R	4 - 16
AI12	Comm Station	INV communication station	No Units	R	1 - 254
AI13	BaudRate	Baudrate setting	No Units	R	0 - 3
AI14	BacnetSel	Communication mode selection	No Units	R	0 - 1
AI15	DevInstance	Inverter number	No Units	R	1 - 254

Table 4.7.4.3 – Analog output property list (READ/ WRITE)

No.	Object Name	Description	Unit	Classification	Range
AO0	Set frequency	Frequency command	HZ	R/W	0 - 60
AO1	FM+	Output voltage	Volt	R	0 - 10
AO2	Motor R-Amp	Motor rated current	Amps	R/W	0-65535
AO3	PwrL Sel	Momentary stop and restart selection	No Units	R	0 - 2
AO4	RestartSel	Number of Fault Auto-Restart Attempts	No Units	R	0 – 10
AO5	RestartDelay	Fault Auto-Restart Time	seconds	R	0 - 800
AO6	FreqCommand1	Speed frequency setting-stage 0	HZ	R/W	0 - 400
AO7	FreqCommand2	Speed frequency setting-stage 1	HZ	R/W	0 - 400
AO8	FreqCommand3	Speed frequency setting-stage 2	HZ	R/W	0 - 400
AO9	FreqCommand4	Speed frequency setting-stage 3	HZ	R/W	0 - 400
AO10	FreqCommand5	Speed frequency setting-stage 4	HZ	R/W	0 - 400
AO11	FreqCommand6	Speed frequency setting-stage 5	HZ	R/W	0 - 400
AO12	FreqCommand7	Speed frequency setting-stage 6	HZ	R/W	0 - 400
AO13	FreqCommand8	Speed frequency setting-stage 7	HZ	R/W	0 - 400
AO14	FreqCommand9	Speed frequency setting-stage 8	HZ	R/W	0 - 400
AO15	FreqCommand10	Speed frequency setting-stage 9	HZ	R/W	0 - 400
AO16	FreqCommand11	Speed frequency setting-stage 10	HZ	R/W	0 - 400
AO17	FreqCommand12	Speed frequency setting-stage 11	HZ	R/W	0 - 400
AO18	FreqCommand13	Speed frequency setting-stage 12	HZ	R/W	0 - 400
AO19	FreqCommand14	Speed frequency setting-stage 13	HZ	R/W	0 - 400
AO20	FreqCommand15	Speed frequency setting-stage 14	HZ	R/W	0 - 400
AO21	FreqCommand16	Speed frequency setting-stage 15	HZ	R/W	0 - 400
AO22	RunSource	Main run command source selection	No Units	R/W	0 - 2
AO23	ReverseOper	Direction locked command	No Units	R/W	0 - 1
AO24	StoppingSel	Stop modes selection	No Units	R/W	0 - 1
AO25	FrequenceComm	Main frequency command source	No Units	R/W	0 - 5

No.	Object Name	Description	Unit	Classification	Range
		selection			
AO26	FreqUpperLim	Upper limit frequency	HZ	R/W	0 - 400
AO27	FreqLowerLim	Lower limit frequency	HZ	R/W	0 - 400
AO28	Acc Time1	Acceleration time 1	seconds	R/W	0 - 3600
AO29	Dec Time1	Deceleration time 1	seconds	R/W	0 - 3600

Table 4.7.4.4 Analog value property list (READ/ WRITE)

No.	Object Name	Description	Unit	Classification	Range
AV0	PID – P Gain	Proportional gain (P)	No Units	R/W	0 - 10
AV1	PID – I Time	Integral time (I)	No Units	R/W	0 - 100
AV2	PID – D Time	Differential time (D)	No Units	R/W	0 - 10

Table 4.7.4.5 Digital input property list (READ)

No.	Object Name	Description	Unit	Classification	Range
BI0	Run/Stop	Operation status	Stop / Run	R	0 - 1
BI1	Direction	Operation direction	FWD/REV	R	0 - 1
BI2	ststus	Inverter status	OK/Fault	R	0 - 1
BI3	Abnormal	Error occurs	Close/ Open	R	0 - 1
BI4	DI_1 status	S1 status	Close/ Open	R	0 - 1
BI5	DI_2 status	S2 status	Close/ Open	R	0 - 1
BI6	DI_3 status	S3 status	Close/ Open	R	0 - 1
BI7	DI_4 status	S4 status	Close/ Open	R	0 - 1
BI8	DI_5 status	S5 status	Close/ Open	R	0 - 1
BI9	DI_6 status	S6 status	Close/ Open	R	0 - 1

Table 4.7.4.6 Digital output property list (READ/ WRITE)

No.	Object Name	Description	Unit	Classification	Range
BO0	RY1 status	Relay output 1 status	Close/Open	R	0 - 1
BO1	RY2 status	Relay output 2 status	Close/Open	R	0 - 1
BO2	RY3 status	Relay output 3 status	Close/Open	R	0 - 1

Table 4.7.4.7 Digital value property list (READ/ WRITE)

No.	Object Name	Description	Unit	Classification	Range
BV0	RUN/STOP	RUN/STOP	Stop / Run	R/W	0 - 1
BV1	FWD/REV	FWD/REV	FWD/REV	R/W	0 - 1

4.8 MetaSys N2 Communication Protocol

4.8.1 Introduction and Setting

This section mainly describes the communication modes of MetaSys N2 communication protocol. Connect terminal S+ and S- of hardware line RS485 and check if Baudrate setting of parameter 09-02 is 9600bps. If not, inverter requires reconnecting after the communication mode selection of parameter 09-01 is set to 2 (MetaSys).

4.8.2 MetaSys N2 Specification

Serial Communication Interface	RS-485
Maximum Numbers of Connection	255 MetaSys N2 slave standard
Communication Speed	9600 (BPS)
Data Format	<ul style="list-style-type: none"> • Data byte: 8 byte • Stop byte: 1 byte • No parity
Access to Data	<ul style="list-style-type: none"> • 15 Analog input • 10 Digital input • 34 Analog Output • 5 Digital output
Supporting Command	<p>Support the following command</p> <p>0/0 : Time Setting Command</p> <p>0/4, 0/5 : Poll Command</p> <p>0/8 : Warm Reset Command</p> <p>1 : Read Command</p> <p>2 : Write Command</p> <p>F : Identify Device Command</p> <ul style="list-style-type: none"> • The following Override command is enabled but it will not clear automatically after 10 minutes. <ul style="list-style-type: none"> 7/2/3 : AO Override command 7/2/4 : BO Override command • The following command will respond but not execute this action. <ul style="list-style-type: none"> 7/3 : Remove Override command 7/2/1 : AI Override command 7/2/2 : BI Override command


4.8.3 Definition of MetaSys N2 Communication Protocol

MetaSys N2 is the communication protocol developed by Johnson Control Company. MetaSys N2 communication protocol uses the configuration of Master/ Slave. Every N2 Slave device can set N2 address and the range is 1-255.

The data of N2 Slave is displayed by the object and Network Point Type (NPT) is classified to seven kinds of objects:

No.	NPT Name	NPT (abbreviation)	Description
1	Analog input	AI	32-bit, IEEE- Standard floating-point
2	Binary input	BI	1-bit
3	Analog output	AO	32-bit, IEEE- Standard floating-point
4	Binary output	BO	1-bit
5	Internal floating-point	ADF	32-bit, IEEE- Standard floating-point
6	Internal integer	ADI	16-bit
7	Internal Bytes	DB	8-bit

The input and output are mainly for N2 network. The input is the data from N2 Slave to N2 network and the output is the data from N2 network to N2 Slave.



The object of N2 Slave has grouping and every group data can set the address of 0-255, abbreviated for NPA (Network Point Address).

Every object has its property which includes data contents (AI and AO object), object status (BI and BO object data), planning approach (if COS can respond or not) and so on. The property can read or write command but the data value of analog output and digital output requires the Override command to write in.

The object of N2 support function of COS (output in the change of status) and if COS starts, object of AO, BI, and BO will automatically record under the data change and respond under the poll.

N2 Slave device waits for the identify command after the inverter starts and starts for the communication with network after receiving the identify command.

4.8.4. MetaSys N2 Communication Protocol in F510 Model

F510 models support four NPT, AI, AO, BI and BO but DO NOT support the following functions:

- Do not support only for the property or field that JCI used.
- Do not support functions of Analog Alarm and Analog Warning in AI. The related fields can read or write but do not have corresponding action.
- Do not support functions of OverRide in AI and BI. The inverter does not have error message for giving the OverRide command in AI and BI but do not have corresponding action.
- Support functions of OverRide in AO and BO but values of AO and BO do not restore to default value when removing OverRide function.

The followings are the supporting properties list in AI, AO, BI and BO for F510 models:

(1) AI Property List

No.	Data Type	Description	Notes
1	Byte	Object Configuration	READ/ WRITE
2	Byte	Object Status	Only READ
3	Float	Analog Input Value	Only READ

(2) BI Property List

No.	Data Type	Description	Notes
1	Byte	Object Configuration	READ/ WRITE
2	Byte	Object Status	Only READ

(3) AO Property List

No.	Data Type	Description	Notes
1	Byte	Object Configuration	READ/ WRITE
2	Byte	Object Status	Only READ
3	Float	Current Value	READ/ OverRide

(4) BO Property List

No.	Data Type	Description	Notes
1	Byte	Object Configuration	READ/ WRITE
2	Byte	Object Status	READ/ OverRide
3	Integer	Minimum On-time	READ/ WRITE
4	Integer	Minimum On-time	READ/ WRITE
5	Integer	Maximum Cycles/Hour	READ/ WRITE

The followings are parameters F510 models can read and write via MetaSys communication.

Analog input property list (READ)

No.	Object Name	F510 Parameters	Unit	Classification	Range
AI1	Motor R-RPM	02-03 Motor Rated Rotation Speed	No Units	R	0 ~ 60000
AI2	Motor R-Volt	02-04 Motor Rated Voltage	Volt	R	0~240.0/0~480.0
AI3	Motor R-HP	02-05 Motor Rated Power	horsepower	R	0~600.00
AI4	Motor R-Hz	02-06 Motor Rated Frequency	HZ	R	0.00 ~ 400.00
AI5	Comm Station	09-00 INV Communication Station Address	No Units	R	1 - 254
AI6	CommSel	09-01 Communication Mode Selection	No Units	R	0 ~ 3
AI7	BaudRate	09-02 Baud Rate Setting	No Units	R	0 ~ 5
AI8	CarrierFreq	11-01 Carrier Frequency	KiloHertz	R	0 ~ 16
AI9	Freq cmd	12-16 Frequency Command	HZ	R	0.00 ~ 400.00
AI10	Frequency	12-17 Output Frequency	HZ	R	0.00 ~ 400.00
AI11	Current	12-18 Output Current	Amps	R	0.0~6553.5
AI12	Control Mode	12-24 Control Mode	No Units	R	0 ~ 5
AI13	TM2 AIN	12-25 AI1 Input	Volt	R	0 ~ 100.0
AI14	TM2 AIN2	12-26 AI2 Input	Volt	R	0 ~ 100.0
AI15	Error code	12-45 Recent Fault Message	No Units	R	0 ~ 45

Analog output property list (READ/ Write)

No.	Object Name	F510 Parameters	Unit	Classification	Range
AO1	Set frequency	Register 2502H	HZ	R/W	0 ~ 400.00
AO2	AO1	Register 2505H	Volt/ Amps	R	0.00 ~ 100.00
AO3	AO2	Register 2506H	Volt/ Amps	R	0.00 ~ 100.00
AO4	RunSource	00-02 Main Run Command Source Selection	No Units	R/W	0 ~ 4
AO5	FreqComm	00-05 Main Frequency Command Source Selection	No Units	R/W	0 ~ 6
AO6	FreqUpperLim	00-12 Upper Limit Frequency	HZ	R/W	0 - 109
AO7	FreqLowerLim	00-13 Lower Limit Frequency	HZ	R/W	0 - 109
AO8	Acc Time1	00-14 Acceleration Time 1	seconds	R/W	0 ~ 6000.0
AO9	Dec Time1	00-15 Deceleration Time 1	seconds	R/W	0 ~ 6000.0
AO10	Motor R-Amp	02-01 Motor Rated Current	Amps	R/W	1 ~ 999.9
AO11	FreqCommand1	05-01 Frequency Setting of Speed-Stage 0	HZ	R/W	0 ~ 400.00
AO12	FreqCommand2	06-01 Frequency Setting of Speed-Stage 1	HZ	R/W	0 ~ 400.00
AO13	FreqCommand3	06-02 Frequency Setting of Speed-Stage 2	HZ	R/W	0 ~ 400.00
AO14	FreqCommand4	06-03 Frequency Setting of	HZ	R/W	0 ~ 400.00

No.	Object Name	F510 Parameters	Unit	Classification	Range
		Speed-Stage 3			
AO15	FreqCommand5	06-04 Frequency Setting of Speed-Stage 4	HZ	R/W	0 ~ 400.00
AO16	FreqCommand6	06-05 Frequency Setting of Speed-Stage 5	HZ	R/W	0 ~ 400.00
AO17	FreqCommand7	06-06 Frequency Setting of Speed-Stage 6	HZ	R/W	0 ~ 400.00
AO18	FreqCommand8	06-07 Frequency Setting of Speed-Stage 7	HZ	R/W	0 ~ 400.00
AO19	FreqCommand9	06-08 Frequency Setting of Speed-Stage 8	HZ	R/W	0 ~ 400.00
AO20	FreqCommand10	06-09 Frequency Setting of Speed-Stage 9	HZ	R/W	0 ~ 400.00
AO21	FreqCommand11	06-10 Frequency Setting of Speed-Stage 10	HZ	R/W	0 ~ 400.00
AO22	FreqCommand12	06-11 Frequency Setting of Speed-Stage 11	HZ	R/W	0 ~ 400.00
AO23	FreqCommand13	06-12 Frequency Setting of Speed-Stage 12	HZ	R/W	0 ~ 400.00
AO24	FreqCommand14	06-13 Frequency Setting of Speed-Stage 13	HZ	R/W	0 ~ 400.00
AO25	FreqCommand15	06-14 Frequency Setting of Speed-Stage 14	HZ	R/W	0 ~ 400.00
AO26	FreqCommand16	06-15 Frequency Setting of Speed-Stage 15	HZ	R/W	0 ~ 400.00
AO27	PwrL Sel	07-00 Momentary Power Loss/Fault Restart Selection	No Units	R	0 ~ 1
AO28	RestartDelay	07-01 Fault Auto-Restart Time	seconds	R	0 ~ 7200
AO29	RestartSel	07-02 Number of Fault Auto-Restart Attempts	No Units	R	0 ~ 10
AO30	StoppingSel	07-09 Stop Mode Selection	No Units	R/W	0 - 1
AO31	PID – P Gain	10-05 Proportional Gain (P)	No Units	R/W	0 ~ 10.00
AO32	PID – I Time	10-06 Integral Time (I)	No Units	R/W	0 ~ 100.00
AO33	PID – D Time	10-07 Differential Time (D)	No Units	R/W	0 – 10.00
AO34	ReverseOper	11-00 Direction Lock Selection	No Units	R/W	0 ~ 2

Binary input property list (READ)

No.	Object Name	No Action / Action	Classification	Range
BI1	Run/ Stop	Stop/ Run	R	0 - 1
BI2	Direction	Forward/ Reverse	R	0 - 1
BI3	Status	OK/ Fault	R	0 - 1
BI4	Abnormal	Off/ On	R	0 - 1
BI5	DI_1 Status	Off/ On	R	0 - 1
BI6	DI_2 Status	Off/ On	R	0 - 1
BI7	DI_3 Status	Off/ On	R	0 - 1
BI8	DI_4 Status	Off/ On	R	0 - 1
BI9	DI_5 Status	Off/ On	R	0 - 1
BI10	DI_6 Status	Off/ On	R	0 - 1

Binary output property list (READ/ WRITE)

No.	Object Name	No Action / Action	Classification	Range
BO1	Run/ Stop	Stop/ Run	R/W	0 - 1
BO2	Forward/ Reverse	Forward/ Reverse	R/W	0 - 1
BO3	RY1 Status	Off/ On	R	0 - 1
BO4	RY2 Status	Off/ On	R	0 - 1
BO5	RY3 Status	Off/ On	R	0 - 1

MetaSys N2 Error Code List

Error Code	Cause
00	Without receiving Identify command at power up
01	Receive the non-support command
02	Check Code occurs error
03	Receive the data of more than 256 bits
05	Incorrect command length
10	Data is out of the range
11	Save the undefined fields or the fields that JCI dedicated
12	The parameter position is only for read command.

Chapter 5 Check Motor Rotation and Direction

This test is to be performed solely from the inverter keypad. Apply power to the inverter after all the electrical connections have been made and protective covers have been re-attached.

Important: Motor rotation and direction only applies to standard AC motors with a base frequency of 60Hz. For 50Hz or other frequency AC motors please set the max frequency and base frequency in group 01 accordingly before running the motors.

◆ LED Keypad Display

At this point, **DO NOT RUN THE MOTOR**, the LED keypad should display as shown below in Fig. 5.1 and all LEDs are flashing. Next press the **RUN** key, all LEDs light on. See Fig 5.2. The motor should now be operating at low speed running in forward (clockwise) direction. The value shown in the screen will change from 000.00Hz to 005.00Hz. Next press **STOP** key to stop the motor.



Fig 5.1: LED Keypad (Stopped)



Fig 5.2: LED Keypad (Running)

◆ LCD Keypad Display

At this point, **DO NOT RUN THE MOTOR**, the LCD keypad should display as shown below in Fig. 5.3 and the speed reference 12-16=005.00Hz should be blinking at the parameter code "12-16". Next press the **RUN** key, see Fig 5.4. The motor should now be operating at low speed running in forward (clockwise) direction. The parameter code 12-17 shown at the bottom left corner of the screen will change from 12-17=000.00Hz to 12-17=005.00Hz. Next press **STOP** key to stop the motor.



Fig 5.3: Keypad (Stopped)



Fig 5.4: Keypad (Running)

Notes:

- If the motor rotation is incorrect, power down the inverter.
- After the power has been turned OFF, wait at least ten minutes until the charge indicator extinguishes completely before touching any wiring, circuit boards or components.
- Using Safety precaution, and referring to section 3.8 exchange any two of the three output leads to the motor (U/T1, V/T2 and W/T3). After the wiring change, repeat this step and recheck motor direction.

Chapter 6 Speed Reference Command Configuration

The inverter offers users several choices to set the speed reference source. The most commonly used methods are described in the next sections.

Frequency reference command is selected with parameter 00-05.

00-05: Main Frequency Command (Frequency Source)

This function sets the frequency command source.

Setting Range: 0 to 5

To set parameter 00-05:

- After power-up press the **DSP/FUN** key
- Select **00 Basic Fun**
- Press **READ/ ENTER** key
- Select parameter -05 with the **UP/DOWN ▲** and **▼** keys and press the **READ/ ENTER** key.

In the parameter list move cursor to 00-05 with the **UP/DOWN** keys and press **READ/ ENTER** key to select.


00-05	Main Frequency Command Source Selection
Range	0: Keypad 1: External control (analog) 2: Terminal UP / DOWN 3: Communication control 4: Pulse input 5: PID

6.1 Reference from Keypad


Speed reference from the keypad is the default setting. Press the **READ/ ENTER** key first and use the **</RESET**, **▲** and **▼** keys to change the speed reference.

6.2 Reference from External Analog Signal (0-10V / 4-20mA)


Analog Reference: 0 – 10 V (Setting 00-05 = 1)



Analog Reference: Potentiometer / Speed Pot (Setting 00-05 = 1)




Analog Reference: 4 – 20mA (Setting 00-05 = 1)



Information provided by
EMAG
 Tel: 01902 601403
 www.emag-ltd.co.uk

6.3 Reference from Serial Communication RS485 (00-05=3)



To set the speed reference for the inverter via serial communication parameter 00-05 has be set to “3” for frequency command via serial communication.

Default Communication Setting is: Address “1”, 9600 Bits/sec, 1 Start Bit, 1 Stop Bit, and No Parity

The serial communication link function uses RS485 Modbus RTU protocol and allows for:

- 1) Monitoring (data monitoring, function data check).
- 2) Frequency setting.
- 3) Operation command (FWD, REV, and other commands for digital input).
- 4) Write function data.

Frequency Reference Command Register

Inverter Frequency Reference Register: 2502 (Hexadecimal) - Bit 0 – Bit 15: 0.00 ~ 400.00 Hz

Examples:

Frequency Reference Command: 10.00 Hz (Inverter Node Address: 01)

Command String (hexadecimal): 01 06 25 02 03 E8 23 B8

To set the frequency reference to 10.00, a value of '1000' (03E8h) has to be send to the inverter.

Frequency Reference Command: 30.00 Hz (Inverter Node Address: 01)

Command String (hexadecimal): 01 06 25 02 0B B8 24 44


To set the frequency reference to 30.00, a value of '3000' (0BB8h) has to be send to the inverter.

Frequency Reference Command: 60.00 Hz (Inverter Node Address: 01)

Command String (hexadecimal): 01 06 25 02 17 70 2D 12

To set the frequency reference to 60.00, a value of '6000' (1770h) has to be send to the inverter

Note: The last 2 bytes of the command strings consist of a CRC16 checksum, please refer to section 4.5 of the instruction manual for additional information.




6.4 Reference from two Analog Inputs

Analog input AI1 is used as master frequency reference and analog input AI2 is used as auxiliary frequency reference.

Analog Reference AI1: 0 – 10 V (Setting 00-05 = 1)

Analog Reference AI2: 0 – 10 V (Setting 00-06 = 1, 04-05 = 1)

AI1 – Analog Input 1	AI2 – Analog Input 2	04-00 Setting (Default = 1)	Dipswitch SW2 (Default 'V')
0 ~ 10V	0 ~ 10V	0	Set to 'V'
0 ~ 10V	4 ~ 20mA	1	Set to 'I'



6.5 Change Frequency Unit from Hz to rpm

Enter the number of motor poles in 16-03 to change the display units from Hz to rpm.

16-03	Display unit
Range	<p>0: Display unit is Hz (Resolution is 0.01Hz)</p> <p>1: Display unit is % (Resolution is 0.01%)</p> <p>2~38: Display unit rpm, (uses number of motor poles to calculate)</p> <p>40~9999: 100% is XXXX with no decimals (integer only)</p> <p>10001~19999: 100% is XXX.X with 1 decimal</p> <p>20001~29999: 100% is XX.XX with 2 decimals</p> <p>30001~39999: 100% is X.XXX with 3 decimals</p>

Example: Motor poles 4, 16-03 = 4.

Chapter 7 Operation Method Configuration (Run / Stop)

The inverter offers users several choices to run and stop from different sources. The most commonly used methods are described in the next sections.

Operation command is selected with parameter 00-02.

00-02: Run Command Selection

This function sets the frequency command source.

Setting Range: 0 to 3

To set parameter 00-01:

- After power-up press the **DSP/FUN** key
- Select **00 Basic Fun**
- Press **READ/ ENTER** key
- Select parameter -01 with the **UP/DOWN ▲** and **▼** keys and press the **READ/ ENTER** key.

In the parameter list move cursor to 00-01 with the **UP/DOWN** keys and press **READ/ ENTER** key to select.

00-02	Run Command Selection
Range	0: Keypad control 1: External terminal control 2: Communication control 3: PLC

7.1 Run/Stop from the Keypad (00-02=0) – Default Setting

Use the **RUN** key to run the drive in forward direction and the **FWD/REV** key to change the motor direction. (Note: to disable reverse direction set parameter 11-01 to 1)


Press **STOP** key to stop the inverter. (Note: Stop method can be set with parameter 07-09, default is **deceleration to stop**).




7.2 Run/Stop from External Switch / Contact or Pushbutton (00-02=1)

Use an external contact or switch to Run and Stop the inverter.

Permanent Switch / Contact



7.3 Run/Stop from Serial Communication RS485 (00-02=3)



To control (Run/Stop) the inverter via serial communication parameter 00-02 has to be set to either a “3” for communication control.

Default Communication Setting is: Address “1”, 9600 Bits/sec, 1 Start Bit, 1 Stop Bit, and No Parity

The serial communication link function uses RS485 Modbus RTU protocol and allows for:

- 1) Monitoring (data monitoring, function data check).
- 2) Frequency setting.
- 3) Operation command (FWD, REV, and other commands for digital input).
- 4) Write function data.

Command Register

Inverter Command Register: 2501 (Hexadecimal)

Bit 0: Run Forward

Bit 1: Run Reverse

Bit 2 ~ Bit 15: Refer to the chapter XX of this manual

Examples:

Run Forward Command (Inverter Node Address: 01)

Command String (hexadecimal): 01 06 25 01 00 01 12 C6

Run Reverse Command (Inverter Node Address: 01)

Command String (hexadecimal): 01 06 25 01 00 03 93 07

Stop Command (Inverter Node Address: 01)

Command String (hexadecimal): 01 06 25 01 00 00 D3 06

Note: The last 2 bytes of the command strings consist of a CRC16 checksum, please refer to section 4.5 of the instruction manual for additional information.

Information
provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk

Chapter 8 Motor and Application Specific Settings

It is essential that before running the motor, the motor nameplate data matches the motor data in the inverter.

8.1 Set Motor Nameplate Data (02-01, 02-05)

02-05 Rated power of motor 1

The nominal motor rated capacity is set at the factory. Please verify that the motor name plate data matches the motor rated capacity shown in parameter 02-05. The setting should only be changed when driving a motor with a different capacity.

Range: 0.00 to 600.00 kW (1HP = 0.746 kW)

To set parameter 02-05:

- After power-up press the **DSP/FUN** key
- Select **02 Motor Parameter**
- Press **READ/ ENTER** key
- Select parameter -01 with the **UP/DOWN ▲** and **▼** keys and press the **READ/ ENTER** key.

Default values vary based on the inverter model.

02-01 Rated current of motor 1

The motor rated current is set at the factory based on the inverter model. Enter the motor rated current from the motor nameplate if it does not match the value shown in parameter 02-01.

Setting range: 0.01 to 600.00A

To set parameter 02-01:

- After power-up press the **DSP/FUN** key
 - Select **02 Motor Parameter**
 - Press **READ/ ENTER** key
 - Select parameter -01 with the **UP/DOWN ▲** and **▼** keys and press the **READ/ ENTER** key.
-

8.2 Acceleration and Deceleration Time (00-14, 00-15)

Acceleration and Deceleration times directly control the system dynamic response. In general, the longer the acceleration and deceleration time, the slower the system response, and the shorter time, the faster the response. An excessive amount of time can result in sluggish system performance while too short of a time may result in system instability.

The default values suggested normally result in good system performance for the majority of general purpose applications. If the values need to be adjusted, caution should be exercised, and the changes should be in small increments to avoid system instability.

00-14 Acceleration time 1


00-15 Deceleration time 1

These parameters set the acceleration and deceleration times of the output frequency from 0 to maximum frequency and from maximum frequency to 0.

To set parameter 00-14 or 00-15:

- After power-up press the **DSP/FUN** key
- Select **00 Basic Fun**
- Press **READ/ ENTER** key
- Select parameter -14 or -15 with the **UP/DOWN ▲** and **▼** keys and press the **READ/ ENTER** key.

Acceleration and deceleration times are represented by the three most significant (high order) digits. Set acceleration and deceleration times with respect to maximum frequency. The relationship between the set frequency value and acceleration/deceleration times is as follows:



Note: If the set acceleration and deceleration times are set too low, the torque limiting function or stall prevention function can become activated if the load torque and or inertia are relatively high. This will prolong the acceleration and or deceleration times and not allow the set times to be followed. In this case the acceleration and or the deceleration times should be adjusted.

8.3 Torque Compensation Gain (01-10)

This parameter sets the relationship between output frequency and output voltage. Constant torque applications have the same torque requirements at low speed as well as at high speed.

Initial Setup

For Variable Torque / Normal Duty applications set parameter 01-10 to an initial value of 0.5.

For Constant Torque / Heavy Duty applications set parameter 01-10 to an initial value of 1.0.

01-10 Torque compensation gain

This parameter sets the torque boost for motor 1.

Setting range: 0.0 to 2.0

To set parameter 01-10:

- After power-up press the **DSP/FUN** key
- Select **01 V/F Pattern**
- Press **READ/ ENTER** key
- Select parameter -10 with the **UP/DOWN ▲** and **▼** keys and press the **READ/ ENTER** key.

Increase value when:

- The wiring between the inverter and the motor very too long
- The motor size is smaller than the inverter size

Note: Gradually increase the torque compensation value and make sure the output current does not exceed inverter rated current.

Reduce value when:

- Experiencing motor vibration
- Over Current Fault
- Overload Fault

Important: Confirm that the output current at low speed does not exceed the rated output current of the inverter.



Warning: A larger than required torque compensation gain value creates over-excitation at low speeds, continued operation may cause the motor to overheat. Check the characteristics of the motor for additional information.

8.4 Automatic Energy Savings Function (11-19)

In the V/F control mode the automatic energy saving (AES) function automatically adjusts the output voltage and reduces the output current of the inverter to optimize energy savings based on the load.

The output power changes proportional to the motor load. Energy savings is minimal when the load exceeds 70% of the output power and savings become greater when the load decreases.

The parameter of automatic energy saving function has been set at the factory before shipment. In general, it is no need to adjust. If the motor characteristic has significant difference from TECO standard, please refer to the following commands for adjusting parameters:

Enable Automatic Energy Savings Function

To set parameters 11-19 to 11-24:

- After power-up press the **DSP/FUN** key
- Select **11 Auxiliary Function Group**
- Press **READ/ ENTER** key
- Select parameter -19 to -24 with the **UP/DOWN ▲** and **▼** keys and press the **READ/ ENTER** key.


- (1) To enable automatic energy saving function set 11-19 to 1.
- (2) Filter time of automatic energy saving (11-20)
- (3) Commissioning parameter of energy saving (11-21 to 11-22)

In AES mode, the optimum voltage value is calculated based on the load power requirement but is also affected by motor temperature and motor characteristic.

In certain applications the optimum AES voltage needs to be adjusted in order to achieve optimum energy savings. Use the following AES parameters for manual adjustment:

11-21: Voltage limit value of AES commissioning operation

Sets the voltage upper limit during automatic energy saving. 100% corresponds to 230V or 460V depending on the inverter class used.



Voltage limit value of commissioning operation

11-22: Adjustment time of automatic energy saving

Sets sample time constant for measuring output power.

Reduce the value of 11-22 to increase response when the load changes.

Note: If the value of 11-22 is too low and the load is reduced the motor may become unstable.

11-23: Detection level of automatic energy saving

Sets the automatic energy saving output power detection level.

11-24: Coefficient of automatic energy saving

The coefficient is used to tune the automatic energy saving. Adjust the coefficient while running the inverter on light load while monitoring the output power. A lower setting means lower output voltage.

Notes:

- If the coefficient is set to low the motor may stall.
- Coefficient default value is based on the inverter rating. Set parameter 13-00. If the motor power does not match the inverter rating.


Information
provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk

8.5 Emergency Stop

The emergency stop time is used in combination with multi-function digital input function #14 (Emergency stop). When emergency stop input is activated the inverter will decelerate to a stop using the Emergency stop time (00-26) and display the [EM STOP] condition on the keypad.

Note: To cancel the emergency stop condition the run command has to be removed and emergency stop input deactivated.


Example: Emergency Stop Switch set for input terminal S5 (03-04 = 14).



00-26	Emergency stop time
Range	0.0~6000.0 Sec

8.6 Direct / Unattended Startup

The unattended startup function prevents the inverter from starting automatically when a run command is present at time of power-up. To use USP command set one of the multi-function digital input functions to #50 (USP Startup).



Unattended Startup Protection

Information provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk


8.7 Analog Output Setup

Signal: Use parameter 04-11 to select the analog output signal for AO1 and parameter 04-16 to select the analog output signal for AO2.

Gain: Use parameter 04-12 to adjust the gain for AO1 and parameter 04-17 to adjust the gain for AO2. Adjust the gain so that the analog output (10V/20mA) matches 100% of the selected analog output signal (04-11 for AO1 and 04-16 for AO2).

Bias: Use parameter 04-13 to adjust the bias for AO1 and parameter 04-18 to adjust the bias for AO2. Adjust the bias so that the analog output (0V/4mA) matches 0% of the selected analog output signal (04-11 for AO1 and 04-16 for AO2).

Example: Analog Output 1 Wiring



04-11	AO1 function Setting	
Range	0: Output frequency	14: Reserved
	1: Frequency command	15: ASR output
	2: Output voltage	16: Reserved
	3: DC voltage	17: q-axis voltage
	4: Output current	18: d-axis voltage
	5: Output power	19: Reserved
	6: Motor speed	20: Reserved
	7: Output power factor	21: PID input
	8: AI1 input	22: PID output
	9: AI2 input	23: PID target value
	10: Torque command	24: PID feedback value
	11: q -axis current	25: Output frequency of the soft starter
	12: d-axis current	26: PG feedback
	13: Speed deviation	27: PG compensation amount


04-12	AO1 gain value
Range	0.0~1000.0%

04-13	AO1 bias-voltage value
Range	-100.0~100.0%

04-16	AO2 function Setting
Range	See parameter 04-11

04-17	AO2 gain value
Range	0.0~1000.0%

04-18	AO2 bias-voltage value
Range	-100.0~100.0%




Analog output level adjustment

Chapter 9 Using PID Control for Constant Flow / Pressure Applications

9.1 What is PID Control?

The PID function in the inverter can be used to maintain a constant process variable such as pressure, flow, temperature by regulating the output frequency (motor speed). A feedback device (transducer) signal is used to compare the actual process variable to a specified setpoint. The difference between the set-point and feedback signal is called the error signal.

The PID control tries to minimize this error to maintain a constant process variable by regulating the output frequency (motor speed).



The amplitude of the error can be adjusted with the Proportional Gain parameter 10-05 and is directly related to the output of the PID controller, so the larger the gain the larger the output correction.

Example 1:

Gain = 1.0

Set-Point = 80%

Feedback = 78%

Error = Set-point - Feedback = 2%

Control Error = Gain x Error = 2%

Example 2:

Gain = 2.0

Set-Point = 80%

Feedback = 78%

Error = Set-point - Feedback = 2%

Control Error = Gain x Error = 4%

Please note that an excessive gain can make the system unstable and oscillation may occur.

The response time of the system can be adjusted with the Integral Gain set by parameter 10-06. Increasing the Integral Time will make the system less responsive and decreasing the Integral Gain Time will increase response but may result in instability of the total system.

Slowing the system down too much may be unsatisfactory for the process. The end result is that these two parameters in conjunction with the acceleration (00-14) and deceleration (00-15) times are adjusted to achieve optimum performance for a particular application.

For typical fan and pump applications a Proportional Gain (10-05) of 2.0 and an Integral Time (10-06) of 5.0 sec is recommended.

10-03 PID control mode

PID control can be enabled by setting parameter 10-03 to 'xxx1b'

10-03	PID control mode
Range	xxx0b: PID disable xxx1b: PID enable xx0xb: PID positive characteristic xx1xb: PID negative characteristic x0xxb: PID error value of D control x1xxb: PID feedback value of D control 0xxxb: PID output 1xxxb: PID output +target value

Commonly used PID control modes

0001b: Forward operation: PID operation enabled, motor speeds increases when feedback signal is smaller than set-point (most fan and pump applications)

0011b: Reverse operation: PID operation enabled, motor slows down when feedback signal is smaller than set-point (e.g. level control applications)

To set parameter 10-03:

- After power-up press the **DSP/FUN** key
- Select **10 PID Control**
- Press **READ/ ENTER** key
- Select parameter -03 with the **UP/DOWN ▲** and **▼** keys and press the **READ/ ENTER** key.


Important: To use the PID function parameter 00-05 (Main Frequency Command Source Selection) has to be set to 5 for PID reference.

9.2 Connect Transducer Feedback Signal (10-01)


The PID function in the inverter

Depending on the type of feedback transducer used, the inverter can be setup for either 0-10V or a 4-20mA feedback transducer.

Feedback Signal 4 – 20mA (10-01 = 2) – SW2 = I



Feedback Signal 0 – 10V (10-01 = 1) – SW2 = V



9.3 Engineering Units

The PID setpoint scaling can be selected with parameter 16-03 and 16-04.

Example: 0 – 200.0 PSI Setpoint, set 16-03 to 12000 (1 decimal, range 0 – 200) and 16-04 to 2 (PSI).

9.4 Sleep / Wakeup Function

The PID Sleep function can be used to prevent a system from running at low speeds and is frequently used in pumping application. The PID Sleep function is turned on by parameter 10-29 set to 1. The inverter output turns off when the PID output falls below the PID sleep level (10-17) for the time specified in the PID sleep delay time parameter (10-18).



The inverter wakes up from a sleep condition when the PID output (Reference frequency) rises above the PID wake-up frequency (10-19) for the time specified in the PID wake-up delay time (10-20).

10-29 =0: PID Sleep function is disabled.

10-29 =1: PID sleep operation is based on parameters of 10-17 and 10-18.

10-29 =2: PID sleep mode is enabled by multi-function digital input

Refer to figure 4.4.74 (a) and (b) for PID sleep / wakeup operation.



PID Sleep Function

Chapter 10 Troubleshooting and Fault Diagnostics

10.1 General

Inverter fault detection and early warning / self-diagnosis function. When the inverter detects a fault, a fault message is displayed on the keypad. The fault contact output energizes and the motor will coast to stop (The stop method can be selected for specific faults).

When the inverter detects a warning / self-diagnostics error, the digital operator will display a warning or self-diagnostic code, the fault output does not energize in this case. Once the warning is removed, the system will automatically return to its original state.

10.2 Fault Detection Function





When a fault occurs, please refer to Table 10.2.1 for possible causes and take appropriate measures.









Use one of the following methods to restart:

1. Set one of multi-function digital input terminals (03-00, 03-05) to 17 (Fault reset); activate input
2. Press the reset button on the keypad and clear fault message.
3. Power down inverter wait until keypad goes blank and power-up the inverter again.

When a fault occurs, the fault message is stored in the fault history (see group 12 parameters).

Table 10.2.1 Fault information and possible solutions

LED display	Description	Cause	Possible solutions
OC over current	The inverter output current exceeds the overcurrent level (around 200% of the inverter rated current).	<ul style="list-style-type: none"> • Acceleration time is too short. • Contactor at the inverter output side. • A special motor or applicable capacity is greater than the inverter rated value. • Short circuit or ground fault. 	<ul style="list-style-type: none"> • Extend acceleration time. • Check the motor wiring. • Disconnect motor and try running inverter.
			
SC short circuit	Inverter output short circuit or ground fault.	<ul style="list-style-type: none"> • Short circuit or ground fault (08-23 = 1). • Motor damaged (insulation). • Wire damage or deterioration. 	<ul style="list-style-type: none"> • Check the motor wiring. • Disconnect motor and try running inverter.
			
GF Ground fault	The current to ground exceeds 50% of the inverter rated output current (08-23 = 1, GF function is enabled).	<ul style="list-style-type: none"> • Motor damaged (insulation). • Wire damage or deterioration. • Inverter DCCT sensors defect. 	<ul style="list-style-type: none"> • Replace motor. • Check the motor wiring. • Disconnect motor and try running inverter. • Check resistance between cables and ground. • Reduce carrier frequency.
			
OV Over voltage	DC bus voltage exceeds the OV detection level: 410Vdc: 200V class 820Vdc: 400V class (For 400V class, if input voltage 01-14 is set lower than 400V, the OV detection value will be decreased to 730Vdc).	<ul style="list-style-type: none"> • Deceleration time set too short, resulting in regenerative energy flowing back from motor to the inverter. • The inverter input voltage is too high. • Use of power factor correction capacitors. • Excessive braking load. • Braking transistor or resistor defective. • Speed search parameters set incorrectly. 	<ul style="list-style-type: none"> • Increase deceleration time • Reduce input voltage to comply with the input voltage requirements or install an AC line reactor to lower the input voltage. • Remove the power factor correction capacitor. • Use dynamic braking unit. • Replace braking transistor or resistor. • Adjust speed search parameters.
			

LED display	Description	Cause	Possible solutions
UV Under voltage	DC bus voltage is lower than the UV detection level or the pre-charge contactor is not active while the inverter is running. 190Vdc: 200V class; 380Vdc: 400V class (The detection value can be adjusted by 07-13).	<ul style="list-style-type: none"> The input voltage is too low. Input phase loss. Input voltage fluctuation. Pre-charge contactor damaged. DC bus voltage feedback signal value not incorrect. 	<ul style="list-style-type: none"> Check the input voltage. Check input wiring. Check power source Replace pre-charge contactor Replace control board or complete inverter.
			
IPL input phase loss	Phase loss at the input side of the inverter or input voltage imbalance, active when 08-09 = 1 (enabled).	<ul style="list-style-type: none"> IPL occurs. Terminal screws of R/L1, S/L2 or T/L3 are loose or lost. Input voltage fluctuation is too big. Input Voltage is imbalance per phase Aging of the capacity on main circuit inside inverter 	<ul style="list-style-type: none"> Check if the main wiring connection is correct. Check if the terminal screw gets loose. Make sure having stable input voltage or turn off IPL detection function. Replace the circuit board or inverter
			
OPL output phase loss	Phase loss at the output side of the inverter, active when 08-10 = 1 (enabled).	<ul style="list-style-type: none"> Wiring loose in inverter output terminal. Motor rated current is less than 10% of the inverter rated current. 	<ul style="list-style-type: none"> Check output wiring / faster screws. Check motor & inverter rating.
			
OH1 Heatsink overheat	The temperature of the heat sink is too high.	<ul style="list-style-type: none"> Ambient temperature too high. cooling fan failed Carrier frequency set too high. Load too heavy. 	<ul style="list-style-type: none"> Install fan or AC to cool surroundings. Replace cooling fan. Reduce carrier frequency. Reduce load / Measure output current
	Note: when OH1 fault occurs three times within five minutes, it is required to wait 10 minutes before resetting the fault.		
OH4 Motor overheating	Motor overheating : The input of PTC (Positive Temperature Coefficient) exceeds the overheat protection level	<ul style="list-style-type: none"> The surrounding temperature of motor is too high. The input of PTC (Positive Temperature Coefficient) exceeds the overheat protection level. 	<ul style="list-style-type: none"> Check the surrounding temperature of motor. Check MT and GND terminal wiring be correct.
			
OL1 Motor overload	Internal motor overload protection tripped, active when protection curve 08-05 = xxx1.	<ul style="list-style-type: none"> Voltage setting V/F mode too high, resulting in over-excitation of the motor. Motor rated current (02-01) set incorrectly. Load too heavy. 	<ul style="list-style-type: none"> Check V/f curve. Check motor rated current Check and reduce motor load, check and operation duty cycle.
			
OL2 Inverter overload	Inverter thermal overload protection tripped. If an inverter overload occurs 4 times in five minutes, it is required to wait 4 minutes before resetting the fault.	<ul style="list-style-type: none"> Voltage setting V/F mode too high, resulting in over-excitation of the motor. Inverter rating too small. Load too heavy. 	<ul style="list-style-type: none"> Check V/f curve. Replace inverter with larger rating. Check and reduce motor load, check and operation duty cycle.
			
OT Over torque detection	Inverter output torque is higher than 08-15 (over torque detection level) for the time specified in 08-16. Parameter 08-14 = 0 or 2 to activate.	<ul style="list-style-type: none"> Load too heavy. 	<ul style="list-style-type: none"> Check over torque detection parameters (08-15 / 08-16). Check and reduce motor load, check and operation duty cycle.
			
UT Under torque detection	Inverter output torque is lower than 08-19 (under	<ul style="list-style-type: none"> Sudden drop in load. Belt break. 	<ul style="list-style-type: none"> Check under torque detection parameters (08-19 / 08-20).

LED display	Description	Cause	Possible solutions
UL	torque detection level) for the time specified in 08-20. Parameter 08-18 = 0 or 2 to activate.		<ul style="list-style-type: none"> Check load / application.
CE CE communication error	No Modbus communication received in for the time specified in 09-06 (communication error detection time). Active when 09-07(= 0 to 2).	<ul style="list-style-type: none"> Connection lost or wire broken. Host stopped communicating. 	<ul style="list-style-type: none"> Check connection Check host computer / software.
FB PID feedback loss	PID feedback signal falls below level specified in 10-12 (PID feedback loss detection level) for the time specified in 10-13 (Feedback loss detection time). Active when parameter (10-11 = 2).	<ul style="list-style-type: none"> Feedback signal wire broken Feedback sensor broken. 	<ul style="list-style-type: none"> Check feedback wiring Replace feedback sensor.
STO Safety switch	Inverter safety switches open.	<ul style="list-style-type: none"> Terminal board Input F1 and F2 are not connected. 08-30 is set to 1: Coast to stop, and digital terminal switch (58) is turned on. 	<ul style="list-style-type: none"> Check F1 and F2 connection Check digital terminal(58) is turned on
SS1 Safety switch	Inverter safety switches open.	<ul style="list-style-type: none"> When 08-30 is set to 0: Deceleration to stop, and digital terminal switch(58) is turned on. 	<ul style="list-style-type: none"> Check digital terminal(58) is turned on.

LED display	Description	Cause	Possible solutions
EF1 External fault (S1)	External fault (Terminal S1) Active when 03-00= 25, and Inverter external fault selection 08-24=0 or 1.	<ul style="list-style-type: none"> Multifunction digital input external fault active. 	<ul style="list-style-type: none"> Multi-function input function set incorrectly. Check wiring
EF1			
EF2 External fault (S2)	External fault (Terminal S2) Active when 03-01= 25, and Inverter external fault selection 08-24=0 or 1.		
EF2			
EF3 External fault (S3)	External fault (Terminal S3) Active when 03-02= 25, and Inverter external fault selection 08-24=0 or 1.		
EF3			
EF4 External fault (S4)	External fault (Terminal S4) Active when 03-03= 25, and Inverter external fault selection 08-24=0 or 1.		
EF4			
EF5 External fault (S5)	External fault (Terminal S5) Active when 03-04= 25, and Inverter external fault selection 08-24=0 or 1.		
EF5			

LED display	Description	Cause	Possible solutions
EF6 External fault (S6)	External fault (Terminal S6) Active when 03-05= 25, and Inverter external fault selection 08-24=0 or 1.	<ul style="list-style-type: none"> Multifunction digital input external fault active. 	<ul style="list-style-type: none"> Multi-function input function set incorrectly. Check wiring
EF6			
CF07 Motor control fault	Motor control fault	<ul style="list-style-type: none"> SLV mode is unable to run motor. 	<ul style="list-style-type: none"> Perform rotational or stationary auto-tune Increase minimum output frequency (01-08)
CF07			
FU fuse open	DC bus fuse blown DC fuse (Models 230V 50HP and above, 460V 75HP and above) open circuit.	<ul style="list-style-type: none"> IGBT damaged. Short circuit output terminals. 	<ul style="list-style-type: none"> Check IGBTs Check for short circuit at inverter output. Replace inverter.
Fu			
LOPBT Low flow fault	Low flow fault	<ul style="list-style-type: none"> The feedback signal is not connected. Due to HVAC feedback value is lower than limit of minimum flow. 	<ul style="list-style-type: none"> Check feedback signal is correct and with right connection. Check if feedback value is lower than limit of minimum flow (23-51).
LOPbt			
HIPBT High flow fault	High flow fault	<ul style="list-style-type: none"> Due to HVAC feedback value is lower than limit of maximum flow. 	<ul style="list-style-type: none"> Check feedback signal is correct. Check if feedback value is lower than limit of maximum flow (23-48).
HI Pbt			
LPBFT Low pressure fault	Low pressure fault	<ul style="list-style-type: none"> The feedback signal is not connected. Due to feedback value of pump pressure is lower than limit of minimum flow. 	<ul style="list-style-type: none"> Check feedback signal is correct and with connection. Check if feedback value of pressure is lower than limit of minimum pressure (23-15).
LPbft			
OPBFT High pressure fault	High pressure fault	<ul style="list-style-type: none"> Due to feedback value of pump pressure is lower than limit of maximum flow. 	<ul style="list-style-type: none"> Check feedback signal is correct. Check if feedback value of pressure is lower than limit of maximum pressure (23-12).
OPbft			
LSCFT Low suction fault	Low suction fault	<ul style="list-style-type: none"> Insufficient water supply of effluent channel leads to insufficient suction PID difference is higher than its level or current is lower than output current level 	<ul style="list-style-type: none"> Check if water of effluent channel is enough, and water supply is regular. Check PID difference is higher than its level or current is lower than output current level
LSCft			
CF00 Operator Communication Error	Errors of data transmission occur in LCD keypad	<ul style="list-style-type: none"> LCD keypad and inverter cannot transmit data after power on 5 seconds 	<ul style="list-style-type: none"> Disconnect the operator and then reconnect. Replace the control board
LCD display only*			
CF01 Operator Communication Error 2	Errors of data transmission occur in LCD keypad	<ul style="list-style-type: none"> LCD keypad and inverter can transmit data but transmission error occurs for more than 2 seconds 	<ul style="list-style-type: none"> Disconnect the operator and then reconnect. Replace the control board
LCD display only*			
CT Fault	Fault occurs in voltage level of three-phase input	<ul style="list-style-type: none"> Abnormal input voltage, too much noise or malfunctioning control board 	<ul style="list-style-type: none"> Check input voltage signal and the voltage on the control board.
CTEr			
Double Communication Error	Redundant Profibus and Modbus protocol	<ul style="list-style-type: none"> User may use two communication mechanisms simultaneously 	<ul style="list-style-type: none"> Check only one communication mechanism is used.
CF20			

* When the communication errors occur in LED keypad, the LED will stay the screen and stop action.

10.3 Warning / Self-diagnosis Detection Function

When the inverter detects a warning, the keypad displays a warning code (flash).

Note: The fault contact output does not energize on a warning and the inverter continues operation. When the warning is no longer active the keypad will return to its original state.




When the inverter detected a programming error (for example two parameters contradict each other or are set to an invalid setting), the keypad displays a self-diagnostics code.









Note: The fault contact output does not energize on a self-diagnostics error. While a self-diagnostics code is active the inverter does not accept a run command until the programming error is corrected.










Note: When a warning or self- diagnostic error is active the warning or error code will flash on the keypad.







Refer to Table 10.3.1 for and overview, cause and corrective action for inverter warnings and self-diagnostic errors.









Table 10.3.1 Warning / self-diagnosis and corrective actions









LED display	Description	Cause	Possible solutions
OV (flash) Over voltage 	DC bus voltage exceeds the OV detection level: 410Vdc: 200V class 820Vdc: 400V class (for 440V class, if input voltage 01-14 is set lower than 400V, the OV detection value will be decreased to 700Vdc)	<ul style="list-style-type: none"> Deceleration time set too short, resulting in regenerative energy flowing back from motor to the inverter. The inverter input voltage is too high. Use of power factor correction capacitors. Excessive braking load. Braking transistor or resistor defective. Speed search parameters set incorrectly. 	<ul style="list-style-type: none"> Increase deceleration time Reduce input voltage to comply with the input voltage requirements or install an AC line reactor to lower the input voltage. Remove the power factor correction capacitor. Use dynamic braking unit. Replace braking transistor or resistor. Adjust speed search parameters.
UV (flash) under voltage 	DC bus voltage is lower than the UV detection level or the pre-charge contactor is not active while the inverter is running. 190Vdc: 200V class; 380Vdc: 400V class (the detection value can be adjusted by 07-13)	<ul style="list-style-type: none"> The input voltage is too low. Input phase loss. Input voltage fluctuation. Magnetic contactor damaged. DC bus voltage feedback signal value not incorrect. 	<ul style="list-style-type: none"> Check the input voltage. Check input wiring. Check power source Replace magnetic contactor Replace control board or complete inverter.
OH1 Heat sink overheating 	Heat sink is overheating : The temperature of the heat sink is too high. If heat sink overheating fault has occurred with three times in five minutes, it is required to wait for 10 minutes before resetting the fault.	<ul style="list-style-type: none"> Ambient temperature is too high. The cooling fan has stopped. Carrier frequency setting is too high. 	<ul style="list-style-type: none"> Check the ambient temperature of the inverter. Check the fan or dust and dirt in the heat sink. Check the carrier frequency setting.

LED display	Description	Cause	Possible solutions
OH2 (flash) Inverter over heating warning	Inverter overheat warning: Multi-function digital input set to 32. (Terminal S1 ~ S6) Active when 03-00 ~ 03-05 =31).	<ul style="list-style-type: none"> • Multifunction digital input overheat warning active. 	<ul style="list-style-type: none"> • Multi-function input function set incorrectly. • Check wiring
			
OT (flash) over torque detection	Inverter output torque is higher than 08-15 (over torque detection level) for the time specified in 08-16. Parameter 08-14 = 0 to activate.	<ul style="list-style-type: none"> • Load too heavy. 	<ul style="list-style-type: none"> • Check over torque detection parameters (08-15 / 08-16). • Check and reduce motor load, check and operation duty cycle.
			
UT (flash) under torque detection	Inverter output torque is lower than 08-19 (under torque detection level) for the time specified in 08-20. Parameter 08-18 = 0 to activate.	<ul style="list-style-type: none"> • Sudden drop in load. • Belt break. 	<ul style="list-style-type: none"> • Check under torque detection parameters (08-19 / 08-20). • Check load / application.
			
bb1 (flash) External baseblock	External base block (Terminal S1)	<ul style="list-style-type: none"> • Multifunction digital input external baseblock active. 	<ul style="list-style-type: none"> • Multi-function input function set incorrectly. • Check wiring
			
bb2 (flash) External baseblock	External base block (Terminal S2)		
			
bb3 (flash) External baseblock	External base block (Terminal S3)		
			
bb4 (flash) External baseblock	External base block (Terminal S4)		
			
bb5 (flash) External baseblock	External base block (Terminal S5)		
			

LED display	Description	Cause	Possible solutions
bb6 (flash) External baseblock 	External base block (Terminal S6)	<ul style="list-style-type: none"> Multifunction digital input external baseblock active. 	<ul style="list-style-type: none"> Multi-function input function set incorrectly. Check wiring
OL1 Motor overload 			
OL2 Inverter overload 	Inverter thermal overload protection tripped. If an inverter overload occurs 4 times in five minutes, it is required to wait 4 minutes before resetting the fault	<ul style="list-style-type: none"> Voltage setting V/F mode too high, resulting in over-excitation of the motor. Motor rated current (02-01) set incorrectly. Load too heavy. Voltage setting V/F mode too high, resulting in over-excitation of the motor. Inverter rating too small. Load too heavy. 	<ul style="list-style-type: none"> Check V/f curve. Check motor rated current Check and reduce motor load, check and operation duty cycle. Check V/f curve. Replace inverter with larger rating. Check and reduce motor load, check and operation duty cycle
CE (flash) communication error 			
CLB over current protection level B 	Inverter current reaches the current protection level B.	<ul style="list-style-type: none"> Inverter current too high. Load too heavy. 	<ul style="list-style-type: none"> Check load and duty cycle operation.
Retry (flash) retry 			
EF1 (flash) External fault (S1) 	External fault (Terminal S1) Active when 03-00= 25, and Inverter external fault selection 08-24=2.	<ul style="list-style-type: none"> Multifunction digital input external fault active and parameter 08-24 = 2 for operation to continue. 	<ul style="list-style-type: none"> Multi-function input function set incorrectly. Check wiring Multi-function input function set incorrectly. Check wiring
EF2 (flash) External fault (S2) 			
EF3 (flash) External fault (S3) 	External fault (Terminal S3) Active when 03-02= 25, and Inverter external fault selection 08-24=2.		

LED display	Description	Cause	Possible solutions
EF4 (flash) External fault (S4)	External fault (Terminal S4) Active when 03-03= 25, and Inverter external fault selection 08-24=2.		
			
EF5 (flash) External fault (S5)			
	External fault (Terminal S5) Active when 03-04= 25, and Inverter external fault selection 08-24=2.	<ul style="list-style-type: none"> • Multifunction digital input external fault active and parameter 08-24 = 2 for operation to continue. 	<ul style="list-style-type: none"> • Multi-function input function set incorrectly. • Check wiring • Multi-function input function set incorrectly. • Check wiring
EF6 (flash) External fault (S6)			
	External fault (Terminal S6) Active when 03-05= 25, and Inverter external fault selection 08-24=2.		
EF9 (flash) error of forward/reversal rotation			
	Forward run and reverse run are active within 0.5 sec of each other. Stop method set by parameter 07-09.	<ul style="list-style-type: none"> • Forward run and reverse run active (see 2-wire control). 	<ul style="list-style-type: none"> • Check run command wiring
SE01 Rang setting error			
	Parameter setting falls outside the allowed range.	<ul style="list-style-type: none"> • Some parameter ranges are determined by other inverter parameters which could cause an out of range warning when the dependency parameter is adjusted. For example: 02-00>02-01, 00-12<00-13 or when 00-07 = 1, 00-05 is the same with 00-06 or 20-16 <= 20-15. 	<ul style="list-style-type: none"> • Check parameter setting.
SE02 Digital input terminal error			
	Multi-function input setting error.	<ul style="list-style-type: none"> • Multi-function digital input terminals (03-00 to 03-07) are set to the same function (not including ext. fault and not used.) or ①UP/DOWN commands are not set at the same time(they must be used together). ②UP/DOWN commands (08 and 09) and ACC/DEC commands (11) are set at the same time. ③Speed search 1(19 · maximum frequency) and Speed search 2 (34 · from the set frequency) are set at the same time. 	<ul style="list-style-type: none"> • Check multi-function input setting.

LED display	Description	Cause	Possible solutions
SE03 V/f curve error	V/f curve setting error.	<ul style="list-style-type: none"> V/F curve setting error. ① 01-02 > 01-12 > 01-06 > 01-08; (Fmax) (Fbase) (Fmid1) (Fmin) ② 01-16 > 01-24 > 01-20 > 01-22; (Fmax2) (Fbase2)(Fmid1) (Fmin2) 	<ul style="list-style-type: none"> Check V/F parameters
			
SE05 PID selection error	PID selection error.	<ul style="list-style-type: none"> 10-00 and 10-01 are set to 1 (AI1) or 2 (AI2) simultaneously. When 23-05=0 and 10-33>= 1000 or 10-34≠1. 	<ul style="list-style-type: none"> Check the setting value of parameters 10-00 and 10-01. Check the setting value of 10-33, 10-34 and 23-05.
			
HPErr Model selection error	Inverter capacity setting error: Inverter capacity setting 13-00 does not match the rated voltage.	<ul style="list-style-type: none"> Inverter capacity setting does not match voltage class (13-00). 	<ul style="list-style-type: none"> Check inverter capacity setting 13-00.
			
SE09 PI setting error	Inverter PI setting error	<ul style="list-style-type: none"> Inverter pulse input selection (03-30) selection conflicts with PID source (10-00 and 10-01). 	<ul style="list-style-type: none"> Check pulse input selection (03-30) and PID source (10-00 and 10-01).
			
FB (flash) PID feedback breaking	PID feedback signal falls below level specified in 10-12 (PID feedback loss detection level) for the time specified in 10-13 (Feedback loss detection time). Active when parameter (10-11 = 1).	<ul style="list-style-type: none"> Feedback signal wire broken Feedback sensor broken. 	<ul style="list-style-type: none"> Check feedback wiring Replace feedback sensor.
			
USP (flash) Unattended Start Protection	Unattended Start Protection (USP) is enabled (enabled at power-up.)	<ul style="list-style-type: none"> USP at power-up (activated by multi-function digital input) is enabled. The inverter will not accept a run command. While the warning is active the inverter does not accept a run command. (See parameter 03-00 - 03-05 = 50). 	<ul style="list-style-type: none"> Remove run command or reset inverter via multi-function digital input (03-00 to 03-07 = 17) or use the RESET key on the keypad to reset inverter. Activate USP input and re-apply the power.
			
LFPB Low flow error	Low flow error	<ul style="list-style-type: none"> The feedback signal is not connected. Due to HVAC feedback value is lower than limit of minimum flow. 	<ul style="list-style-type: none"> Check feedback signal is correct and with right connection. Check if feedback value is lower than limit of minimum flow.
			
HFPB High flow error	High flow error	<ul style="list-style-type: none"> Due to HVAC feedback value is lower than limit of maximum flow. 	<ul style="list-style-type: none"> Check feedback signal is correct. Check if feedback value is lower than limit of maximum flow.
			

LED display	Description	Cause	Possible solutions
LPBFT Low pressure error	Low pressure error	<ul style="list-style-type: none"> The feedback signal is not connected. Due to feedback value of pump pressure is lower than limit of minimum flow. 	<ul style="list-style-type: none"> Check feedback signal is correct and with connection. Check if feedback value of pressure is lower than limit of minimum pressure.
			
OPBFT High pressure error	High pressure error	<ul style="list-style-type: none"> Due to feedback value of pump pressure is lower than limit of maximum flow. 	<ul style="list-style-type: none"> Check feedback signal is correct. Check if feedback value of pressure is lower than limit of maximum pressure.
			
LSCFT Low suction error	Inadequate suction error	<ul style="list-style-type: none"> Insufficient water of supply tank leads to insufficient suction. PID difference is higher than its level or current is lower than output current level. 	<ul style="list-style-type: none"> Check if water of supply tank is enough, and water supply is regular. Check PID difference is higher than its level or current is lower than output current level
			
FIRE Fire override mode	Fire override mode	<ul style="list-style-type: none"> Fire override mode is active 	<ul style="list-style-type: none"> None (Fire override mode is not a kind of warning).
			
SE10 PUMP/HVAC Setting error	PUMP/HVAC settings of inverter error	<ul style="list-style-type: none"> PUMP selection of inverter (23-02)> (23-03). HVAC selection of inverter (23-46)> (23-47). 	<ul style="list-style-type: none"> Check pump selection of inverter (23-02) and (23-03) settings. Check HVAC selection of inverter (23-02) and (23-03) settings.
			
COPUP PUMP communication breaking error	Breaking error of multiple pumps communication	<ul style="list-style-type: none"> Communication breaking or disconnection of pump cascade control. 	<ul style="list-style-type: none"> Check if it has setting issue or is not properly connected.
			
Parameter Setting Error	Parameter setting error	<ul style="list-style-type: none"> Error of Parameter setting occurs. 	<ul style="list-style-type: none"> Refer to the instruction manual or this parameter is selected to be disabled.
			
Warning of Direct Start	When 07-04 is set to 1, the inverter can not start directly but displays the warning signal.	<ul style="list-style-type: none"> Set the digital input terminal (S1~S6) to run and simultaneously set 07-04=1. 	<ul style="list-style-type: none"> Check the digital input terminal and disconnect it. Then reconnect the DI terminal after the setting delay time (07-05) ends.
			

LED display	Description	Cause	Possible solutions
ADC Voltage Error ▲▼▼▼▼▲ AdCEr	Abnormal voltage level on the control board	<ul style="list-style-type: none"> Abnormal input voltage, too much noise or malfunctioning control board. 	<ul style="list-style-type: none"> Check the input voltage signal and the voltage on the control board.
EEPROM Archiving Error ▲▼▼▼▼▲ EPErr			
Control Board Error ▲▼▼▼▼▲ bdErr	The control board is not correspondent with the program.	<ul style="list-style-type: none"> The control board is not correspondent with the program. 	<ul style="list-style-type: none"> Replace the control board.
EEPROM Archiving Error ▲▼▼▼▼▲ EPErr			

Information provided by
EMAG
 Tel: 01902 601403
www.emag-ltd.co.uk

10.4 Auto-tuning Error

When a fault occurs during auto-tuning of a standard AC motor, the display will show the “AtErr” fault and the motor stops. The fault information is displayed in parameter 17-11.

Note: The fault contact output does not energize with an auto-tuning fault. Refer to Table 10.4.1, for fault information during tuning, cause and corrective action.

Table 10.4.1 Auto-tuning fault and corrective actions

Error	Description	Cause	Corrective action
01	Motor data input error.	<ul style="list-style-type: none"> Motor Input data error during auto-tuning. Inverter output current does not match motor rated current. 	<ul style="list-style-type: none"> Check the motor tuning data (17-00 to 17-09). Check inverter capacity
02	Motor lead to lead resistance R1 tuning error.	<ul style="list-style-type: none"> Auto-tuning is not completed within the specified time Auto-tuning results fall outside parameter setting range. Motor rated current exceeded. Motor was disconnected. 	<ul style="list-style-type: none"> Check the motor tuning data (17-00 to 17-09). Check motor connection. Disconnect motor load. Check inverter current detection circuit and DCCTs. Check motor installation.
03	Motor leakage inductance tuning error.		
04	Motor rotor resistance R2 tuning error.		
05	Motor mutual inductance Lm tuning error.		
07	Deadtime compensation detection error		
08	Motor acceleration error (Rotational type auto-tuning only).	<ul style="list-style-type: none"> Motor fails to accelerate in the specified time (00-14=20sec). 	<ul style="list-style-type: none"> Increase acceleration time (00-14). Disconnect motor load.
09	Other auto-tuning errors	<ul style="list-style-type: none"> No load current is higher than 70% of the motor rated current. Torque reference exceeds 100%. Errors other than ATE01~ATE08. 	<ul style="list-style-type: none"> Check the motor tuning data (17-00 to 17-09). Check motor connection.

10.5 PM Motor Auto-tuning Error

When a fault occurs during auto-tuning of a PM motor, the display will show the “IPErr” fault and the motor stops. The fault information is displayed in parameter 22-22.

Note: The fault contact output does not energize with an auto-tuning fault. Refer to Table 10.5.1, for fault information during tuning, cause and corrective action.

Table 10.5.1 Auto-tuning fault and corrective actions for PM motor

Error	Description	Cause	Corrective action
01	Magnetic pole alignment tuning failure (static).	<ul style="list-style-type: none"> Inverter output current does not match motor current. 	<ul style="list-style-type: none"> Check the motor tuning data (22-02). Check inverter capacity
02~04	Reserved		
05	Circuit tuning time out.	<ul style="list-style-type: none"> System abnormality during circuit tuning. 	<ul style="list-style-type: none"> Check for active protection functions preventing auto-tuning.
06	Reserved		
07	Other motor tuning errors.	<ul style="list-style-type: none"> Other tuning errors. 	<ul style="list-style-type: none"> Check the motor tuning data (22-02). Check motor connection.
08	Reserved		
09	Current out of range during circuit tuning.	<ul style="list-style-type: none"> Inverter output current does not match motor current. 	<ul style="list-style-type: none"> Check the motor tuning data (22-02). Check inverter capacity
10	Reserved		
11	Parameter tuning and detecting time out.	<ul style="list-style-type: none"> Error relationship between voltage and current. 	<ul style="list-style-type: none"> Check if the setting value of parameter 22-11 is too low, but its value cannot exceed 100% of the inverter. Check motor connection.

Chapter 11 Inverter Peripheral devices and Options

11.1 Braking Resistors and Braking Units

Inverters ratings 200V 5~30HP/400V 5~40HP (IP20) and 400V 5~25HP (IP55) have a built-in braking transistor. For applications requiring a greater braking torque an external braking resistor can be connected to terminals B1 / P and B2 in protection level of IP20 and to terminals B1 and B2 in protection level of IP55; for inverter ratings above 200V 40HP/400V 50HP (IP20) or 400V 30HP (IP55), external braking units (connected to ⊕ - ⊖ of the inverter) and braking resistors (connected to two ends of the detection module B-P0) are required.

Table 11.1.1 List of braking resistors and braking units (IP20)

Inverter			Braking unit		Braking resistor				Braking torque (Peak / Continues)	Minimum resistance	
V	HP	Rated Current (A)	Model	Qty Req	Part Number	Resistor specification	Qty Req.	Resistor dimensions (L*W*H)mm		(Ω)	(W)
3φ 200V	5	14.5	-	-	JNBR-390W40	390W/40Ω	1	395*34*78	126%,10%ED	25	680
	7.5	21	-	-	JNBR-520W30	520W/30Ω	1	400*40*100	114%,10%ED	21	800
	10	30	-	-	JNBR-780W20	780W/20Ω	1	400*40*100	126%,10%ED	18	900
	15	40	-	-	JNBR-2R4KW13R6	2400W/13.6Ω	1	535*50*110 (*2 pcs)	124%, 10%ED	11	1500
	20	56	-	-	JNBR-3KW10	3000W/10Ω	1	615*50*110 (*2 pcs)	126%, 10%ED	9.5	1800
	25	69	-	-	JNBR-4R8KW8	4800W/8Ω	1	535*50*110 (*4 pcs)	126%, 10%ED	7.2	2400
	30	79	-	-	JNBR-4R8KW6R8	4800W/6.8Ω	1	535*50*110 (*4 pcs)	124%, 10%ED	6.5	2400
	40	110	JNTBU-230	2	JNBR-3KW10	3000W/10Ω	2	615*50*110 (*4 pcs)	126%, 10%ED	2.7	3000
	50	138	JNTBU-230	2	JNBR-3KW10	3000W/10Ω	2	615*50*110 (*4 pcs)	105%, 10%ED	2.7	3000
	60	169	JNTBU-230	2	JNBR-4R8KW6R8	4800W/6.8Ω	2	535*50*110 (*8 pcs)	124%, 10%ED	*note1	
	75	200	JNTBU-230	3	JNBR-4R8KW8	4800W/8Ω	3	535*50*110 (*12 pcs)	124%, 10%ED	*note1	
	100	250	JNTBU-230	3	JNBR-4R8KW6R8	4800W/6.8Ω	3	535*50*110 (*12 pcs)	116%, 10%ED	*note1	
	125	312	JNTBU-230	4	JNBR-4R8KW6R8	4800W/6.8Ω	4	535*50*110 (*16 pcs)	119%,10%ED	*note1	
	150	400	JNTBU-230	5	JNBR-4R8KW8	4800W/8Ω	5	535*50*110 (*20 pcs)	108%, 10%ED	*note1	
	175	450	JNTBU-230	6	JNBR-4R8KW8	4800W/8Ω	6	535*50*110 (*24 pcs)	113%, 10%ED	*note1	

Inverter			Braking unit		Braking resistor				Braking torque (Peak / Continues)	Minimum resistance	
V	HP	Rated Current (A)	Model	Qty Req	Part Number	Resistor specification	Qty Req.	Resistor dimensions (L*W*H)mm		(Ω)	(W)
3φ 400V	5	9.2	-	-	JNBR-400W150	400W/150Ω	1	395*34*78	133%, 10%ED	60	1200
	7.5	11.1	-	-	JNBR-600W130	600W/130Ω	1	400*40*100	107%, 10%ED	60	1200
	10	17.5	-	-	JNBR-800W100	800W/100Ω	1	535*50*110	105%, 10%ED	43	1600
	15	23	-	-	JNBR-1R6KW50	1600W/50Ω	1	615*50*110	133%, 10%ED	43	1600
	20	31	-	-	JNBR-1R5KW40	1500W/40Ω	1	615*50*110	126%, 10%ED	39	1600
	25	38	-	-	JNBR-4R8KW32	4800W/32Ω	1	535*50*110 (*4 pcs)	126%, 10%ED	22	3000
	30	44	-	-	JNBR-4R8KW27R2	4800W/27.2Ω	1	535*50*110 (*4 pcs)	124%, 10%ED	13.5	4800
	40	54	-	-	JNBR-6KW20	6000W/20Ω	1	615*50*110 (*4 pcs)	124%, 10%ED	13.5	4800
	50	72	JNTBU-430	2	JNBR-4R8KW32	4800W/32Ω	2	535*50*110 (*8 pcs)	126%, 10%ED	11	3000
	60	88	JNTBU-430	2	JNBR-4R8KW27R2	4800W/27.2Ω	2	535*50*110 (*8 pcs)	124%, 10%ED	11	3000
	75	103	JNTBU-430	2	JNBR-6KW20	6000W/20Ω	2	615*50*110 (*8 pcs)	133%, 10%ED	11	3000
	100	145	JNTBU-430	3	JNBR-4R8KW27R2	4800W/27.2Ω	3	535*50*110 (*12 pcs)	113%, 10%ED	*note1	
	125	165	JNTBU-430	3	JNBR-6KW20	6000W/20Ω	3	615*50*110 (*12 pcs)	121%, 10%ED	*note1	
	150	208	JNTBU-430	3	JNBR-6KW20	6000W/20Ω	3	615*50*110 (*12 pcs)	104%, 10%ED	*note1	
	175	250	JNTBU-430	5	JNBR-4R8KW27R2	4800W/27.2Ω	5	535*50*110 (*20 pcs)	109%, 10%ED	*note1	
	215	296	JNTBU-430	6	JNBR-4R8KW27R2	4800W/27.2Ω	6	535*50*110 (*24 pcs)	107%, 10%ED	*note1	
	250	328	JNTBU-430	5	JNBR-6KW20	6000W/20Ω	5	615*50*110 (*20 pcs)	105%, 10%ED	*note1	
	300	435	JNTBU-430	6	JNBR-6KW20	6000W/20Ω	6	615*50*110 (*24 pcs)	105%, 10%ED	*note1	
	375	515	JNTBU-430	7	JNBR-6KW20	6000W/20Ω	7	615*50*110 (*28 pcs)	100%, 10%ED	*note1	
	425	585	JNTBU-430	8	JNBR-6KW20	6000W/20Ω	8	615*50*110 (*32 pcs)	100%, 10%ED	*note1	
535	690	JNTBU-430	10	JNBR-6KW20	6000W/20Ω	10	615*50*110 (*40 pcs)	99%, 10%ED	*note1		
670	840	JNTBU-430	11	JNBR-6KW20	6000W/20Ω	11	615*50*110 (*44 pcs)	90%, 10%ED	*note1		
800	960	JNTBU-430	13	JNBR-6KW20	6000W/20Ω	13	615*50*110 (*52 pcs)	90%, 10%ED	*note1		

*note1: Refer to the recommended value in the instruction brochure of braking unit JNBTU-230/JNBTU-430.

Table 11.1.2 List of braking resistors and braking units (IP55)

Inverter			Braking unit		Braking resistor				Braking torque (Peak / Continues)	Minimum resistance	
V	HP	Rated Current (A)	Model	Qty Req	Part Number	Resistor specification	Qty Req.	Resistor dimensions (L*W*H)mm		(Ω)	(W)
3φ 400V	5	9.2	-	-	JNBR-400W150	400W/150Ω	1	395*34*78	133%, 10%ED	65	1000
	7.5	11.1	-	-	JNBR-600W130	600W/130Ω	1	400*40*100	107% ,10%ED	65	1000
	10	17.5	-	-	JNBR-800W100	800W/100Ω	1	535*50*110	105% ,10%ED	39	1600
	15	23	-	-	JNBR-1R6KW50	1600W/50Ω	1	615*50*110	133% ,10%ED	39	1600
	20	31	-	-	JNBR-1R5KW40	1500W/40Ω	1	615*50*110	126% ,10%ED	20	3000
	25	38	-	-	JNBR-4R8KW32	4800W/32Ω	1	535*50*110 (*4 pcs)	126% ,10%ED	20	3000
	30	44	JNTBU-430	1	JNBR-4R8KW27R2	4800W/27.2Ω	1	535*50*110 (*4 pcs)	124% ,10%ED	20	3000
	40	54	JNTBU-430	1	JNBR-6KW20	6000W/20Ω	1	615*50*110 (*4 pcs)	126% ,10%ED	19	3600
	50	72	JNTBU-430	2	JNBR-4R8KW32	4800W/32Ω	2	535*50*110 (*8 pcs)	126%, 10%ED	10	3000
	60	88	JNTBU-430	2	JNBR-4R8KW27R2	4800W/27.2Ω	2	535*50*110 (*8 pcs)	124%, 10%ED	10	3000
	75	103	JNTBU-430	2	JNBR-6KW20	6000W/20Ω	2	615*50*110 (*8 pcs)	133%, 10%ED	9	3600
	100	145	JNTBU-430	3	JNBR-4R8KW27R2	4800W/27.2Ω	3	535*50*110 (*12 pcs)	113%, 10%ED	6.5	3000

Note 1: Options: 400V 50HP :(JUVPHV-0060+JNBR-9R6KW16) x 1,
400V 60HP: (JUVPHV-0060+JNBR-9R6KW13R6) x 1

Note 2: JUVPHV-0060 is not certified for UL

Note 3: Keep sufficient space between inverter, braking unit and braking resistor and ensure proper cooling is provided for.

11.2 AC Line Reactors

An AC line reactor can be used for any of the following:

- Capacity of power system is much larger than the inverter rating.
- Inverter mounted close to the power system (in 33ft / 10 meters).
- Reduce harmonic contribution (improve power factor) back to the power line.
- Protect inverter input diode front-end by reducing short-circuit current.
- Minimize overvoltage trips due to voltage transients.

Please select the AC line reactor based on the inverter rating according to the following table.


Table11.2.1 List of AC Line Reactors

Model		AC reactor		
Voltage	HP	Part Number	Inductance Value (mH)	Rated Current (A)
3 ϕ 200V	5	JNACL0P71M15A2	0.71mH	15A
	7.5	JNACL0P53M20A2	0.53mH	20A
	10	JNACL0P35M30A2	0.35mH	30A
	15	JNACL0P265M40A2	0.265mH	40A
	20	JNACL0P18M60A2	0.18mH	60A
	25	JNACL0P13M80A2	0.13mH	80A
	30	JNACL0P12M90A2	0.12mH	90A
	40	JNACL0P09M120A2	0.09mH	120A
	50	JNACL0P07M160A2	0.07mH	160A
	60	JNACL0P05M200A2	0.05mH	200A
	75	JNACL0P044M240A2	0.044mH	240A
	100	JNACL0P038M280A2	0.038mH	280A
	125	JNACL0P026M360A2	0.026mH	360A
	150	JNACL0P02M500A2	0.02mH	500A
175	JNACL0P02M560A2	0.02mH	560A	
3 ϕ 400V	5/7.5	JNACL2P2M10A4	2.2mH	10A
	10	JNACL1P42M15A4	1.42mH	15A
	15	JNACL1P06M20A4	1.06mH	20A
	20	JNACL0P7M30A4	0.7mH	30A
	25	JNACL0P53M40A4	0.53mH	40A
	30	JNACL0P42M50A4	0.42mH	50A
	40	JNACL0P36M60A4	0.36mH	60A
	50	JNACL0P26M80A4	0.26mH	80A
	60	JNACL0P24M90A4	0.24mH	90A
	75	JNACL0P18M120A4	0.18mH	120A
	100	JNACL0P15M150A4	0.15mH	150A
	125	JNACL0P11M200A4	0.11mH	200A
	150	JNACL0P09M250A4	0.09mH	250A
	175/215	JNACL0P06M330A4	0.06mH	330A
	250	JNACL0P05M400A4	0.05mH	400A
	300	JNACL0P04M500A4	0.04mH	500A
	375/425	JNACL0P032M670A4	0.032mH	670A
	535	JNACL0P02M862A4	0.02mH	862A
670	JNACL0P02M1050A4	0.02mH	1050A	
800	JNACL0P02M1200A4	0.02mH	1200A	

Note: AC reactors listed in this table can only be used for the inverter input side. Do not connect AC reactor to the inverter output side. Both 200V class 60HP~125HP (IP20) and 400V class 100HP~425HP (IP20) and 5HP~100HP (IP55) have built-in DC reactors. If required by the application an AC reactor may be added.

11.2.1 200V Class AC Reactor Dimensions

1. Standard: In Compliance with JEC-2210 (Ver. 1990)
2. Insulation Level: H Level
3. Phase: 3-phase
4. Voltage: 200~240V
5. Insulation Resistance: below 0.2~1.1KV, AC4000V/1Min
6. Type: MR-DL (for input terminal)
7. Dimensions:



Voltage (V)	Inductance Value (mH)	Rated Current (A)	Dimensions (mm)						Figure	NW (Kg)
			A	B	C	D	E	F		
3 ϕ 200V	0.71mH	15A	150	145	85	6	60	65	Figure 2	3.5
	0.53mH	20A	150	145	85	6	60	65	Figure 2	3.5
	0.35mH	30A	150	125	120	6	60	65	Figure 1	3.5
	0.265mH	40A	150	125	130	6	60	75	Figure 1	4.5
	0.18mH	60A	150	125	130	6	60	75	Figure 1	4.5
	0.13mH	80A	180	150	150	6	90	75	Figure 1	7
	0.12mH	90A	180	150	150	6	90	75	Figure 1	7
	0.09mH	120A	180	150	160	6	90	85	Figure 1	8
	0.07mH	160A	230	180	170	10	160	90	Figure 1	16
	0.05mH	200A	230	180	180	10	160	100	Figure 1	18
	0.044mH	240A	230	180	190	10	160	110	Figure 1	23
	0.038mH	280A	230	180	200	10	160	120	Figure 1	25
	0.026mH	360A	280	250	230	10	160	135	Figure 1	30
	0.02mH	500A	280	250	250	10	160	140	Figure 1	35
	0.02mH	560A	320	280	250	10	170	140	Figure 1	40

11.2.2 400V Class AC Resistor Dimensions

1. Standard: In Compliance with JEC-2210 (Ver. 1990)
2. Insulation Level: H Level
3. Phase: 3-phase
4. Voltage: 380~600V
5. Insulation Resistance: below 0.2~1.1KV, AC4000V/1Min
6. Type: MR-DL (for input terminal)
7. Dimensions




Figure 1

Figure 2

Voltage (V)	Inductance Value (mH)	Rated Current (A)	Dimensions (mm)						Figure	NW (Kg)
			A	B	C	D	E	F		
3 ϕ 400V	2.2mH	10A	150	145	85	6	60	65	Figure 2	3.5
	1.42mH	15A	150	145	85	6	60	65	Figure 2	3.5
	1.06mH	20A	150	145	95	6	60	75	Figure 2	4.5
	0.7mH	30A	150	125	130	6	60	75	Figure 1	4.5
	0.53mH	40A	180	150	150	6	90	75	Figure 1	7
	0.42mH	50A	180	150	160	6	90	85	Figure 1	8
	0.36mH	60A	180	150	160	6	90	85	Figure 1	8.5
	0.26mH	80A	230	190	170	8	160	85	Figure 1	12
	0.24mH	90A	230	190	180	8	160	95	Figure 1	15
	0.18mH	120A	230	190	190	8	160	105	Figure 1	18
	0.15mH	150A	230	180	200	10	160	120	Figure 1	25
	0.11mH	200A	280	250	230	10	160	135	Figure 1	30
	0.09mH	250A	280	250	230	10	160	135	Figure 1	33
	0.06mH	330A	320	260	240	10	170	140	Figure 1	42
	0.05mH	400A	320	260	240	10	170	140	Figure 1	45
	0.04mH	500A	320	260	250	10	170	150	Figure 1	48
	0.032mH	670A	380	320	260	10	220	145	Figure 1	63
	0.02mH	862A	380	320	300	10	220	165	Figure 1	70
0.02mH	1050A	420	400	300	12	260	160	Figure 1	125	
0.02mH	1200A	420	400	320	12	260	170	Figure 1	150	

11.3 Input Noise Filters

A. Input Noise Filter on Specifications & Ratings

Install a noise filter on power supply side to eliminate noise transmitted between the power line and the inverter. The inverter noise filter shown in Table 11.3.1 and Table 11.3.2 below meets the EN61800-3 class A specification. 400V inverter class models can be ordered with integrated noise filter.

Table 11.3.1 Input Noise Filter Specifications and Ratings (IP20)

Inverter size		Noise filter		
Input voltage	HP	Model	Rated current	Dimension
3 ϕ 200V	5HP/7.5HP	FS32124-23-99	23	290*50*85
	10HP/15HP	FS32123-42-99	42	330*85*90
	20HP	FS32125-61-99	61	318*80*135
	25HP/30HP	FS32125-86-99	86	360*95*90
	40HP/50HP	FS32125-150-99	150	320*226.5*86
	60HP/75HP	FS32125-232-99	232	320*226.5*86
	100HP/125HP	FS32125-343-99	343	320*226.5*86
	150HP/175HP	FN3270H-600-99	600A	
3 ϕ 400V	5HP/7.5HP/10HP	JN5-FLT-19A	19	123*141*92
	15HP/20HP	JN5-FLT-33A	33	132*206*124
	25HP/30HP/40HP	JN5-FLT-63A	63	127*260*131
	50HP/60HP/75HP	JN5-FLT-112A	112	186*284*128
	100HP/125HP	FS32126-181-99	181	320*226.5*86
	150HP/175HP/215HP/250HP	FS32126-361-99	361	320*226.5*86
	300HP/375HP/425HP	FN3270H-800-99	800A	
	535HP/670HP/800HP			

Table 11.3.2 Input Noise Filter Specifications and Ratings (IP55)

Inverter size			Noise filter of Input Terminal		
Input voltage	HP	Output Rated current(A)	Rated current	Model	Type
3 ϕ 400V	10	17.5	30A	FS29040-30-99	External
	15	23	30A	FS29040-30-99	External
	75	103	42A		External
	100	145	42A		External

B. Input or Output Noise Filter (EMI Suppression Zero Phase Core)

- Part Number: 4H000D0250001
- Select a matched ferrite core to suppress EMI noise according to the required power rating and wire size.
- The ferrite core can attenuate high frequencies in the range of 100 kHz to 50 MHz, as shown in figure 11.4.1 below, and therefore should minimize the RFI generated by the inverter.
- The zero-sequence noise ferrite core can be installed either on the input side or on the output side. The wire around the core for each phase should be wound by following the same convention and in one direction. The more turns without resulting in saturation the better the attenuation. If the wire size is too large to be wound, all the wiring can be grouped and put through several cores together in one direction.




Figure 11.3.1 Frequency attenuation characteristics (10 windings case)




Figure 11.3.2 Example of EMI Suppression Zero Phase Core Application

Note: All the wiring of phases U/T1, V/T2, W/T3 must pass through the same zero-phase core without crossing over.

11.4 Input Current and Fuse Specifications

IP20 200V class

Model	Horse power	KVA	100% of rated output current	Rated input current	Fuse rating
F510-2005-H3	5	5.5	14.5	16	30
F510-2008-H3	7.5	8.0	21	22.3	45
F510-2010-H3	10	11.4	30	31.6	60
F510-2015-H3	15	15	40	41.7	80
F510-2020-H3	20	21	56	60.9	125
F510-2025-H3	25	26	69	75	150
F510-2030-H3	30	30	79	85.9	175
F510-2040-H3	40	42	110	119.6	225
F510-2050-H3	50	53	138	150	275
F510-2060-H3	60	64	169	186	325
F510-2075-H3	75	76	200	232	400
F510-2100-H3	100	95	250	275	500
F510-2125-H3	125	119	312	343	600
F510-2150-H3	150	152	400	440	800
F510-2175-H3	175	172	450	495	1000

IP20 400V class

Model	Horse power	KVA	100% of rated output current	Rated input current	Fuse rating
F510-4005-H3(F)	5	7.0	9.2	9.6	20
F510-4008-H3(F)	7.5	8.5	11.1	11.6	20
F510-4010-H3(F)	10	13.3	17.5	18.2	30
F510-4015-H3(F)	15	18	23	24	40
F510-4020-H3(F)	20	24	31	32.3	50
F510-4025-H3(F)	25	29	38	41.3	70
F510-4030-H3(F)	30	34	44	47.8	80
F510-4040-H3(F)	40	41	54	58.7	100
F510-4050-H3(F)	50	55	72	75	125
F510-4060-H3(F)	60	67	88	95.7	150
F510-4075-H3(F)	75	79	103	112	200
F510-4100-H3(F)	100	111	145	141	250
F510-4125-H3(F)	125	126	165	181	300
F510-4150-H3(F)	150	159	208	229	350
F510-4175-H3(F)	175	191	250	275	500
F510-4215-H3(F)	215	226	296	325	600
F510-4250-H3(F)	250	250	328	360	700
F510-4300-H3(F)	300	332	435	478	800
F510-4375-H3(F)	375	393	515	566	1000
F510-4425-H3(F)	425	446	585	643	1200
F510-4535-H3(F)	535	526	690	750	1400
F510-4670-H3(F)	670	640	840	913	1800
F510-4800-H3(F)	800	732	960	1044	2200

IP55 400V class

Model	Horse power	KVA	100% of rated output current	Rated input current	Fuse rating
F510-4005-H3(F)N4	5	7.0	9.2	9.6	20
F510-4008-H3(F)N4	7.5	8.5	11.1	11.6	20
F510-4010-H3(F)N4	10	13.3	17.5	18.2	30
F510-4015-H3(F)N4	15	18	23	24	40
F510-4020-H3(F)N4	20	24	31	34	50
F510-4025-H3(F)N4	25	29	38	41	70
F510-4030-H3(F)N4	30	34	44	48	80
F510-4040-H3(F)N4	40	41	54	59	100
F510-4050-H3(F)N4	50	55	72	68	125
F510-4060-H3(F)N4	60	67	88	96	150
F510-4075-H3(F)N4	75	79	103	112	200
F510-4100-H3(F)N4	100	111	145	140	250

Fuse type: Choose semiconductor fuse to comply with UL.

Class: CC, J, T, RK1 or RK5

Voltage Range:

For 200V class inverter, use 300V class fuse.

For 400V class inverter, use 500V class fuse.

Information
provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk

11.5 Other options


A. JN5-OP-F02 LCD keypad

LED keypad is standard for F510 IP20 model and it is optional for LCD keypad. Refer to the following figure.



B. Analog keypad

In addition to LCD & LED keypad and optional HOA LCD keypad for this inverter model (IP20), analog operation panel (JNEP-16), which can be pulled outside to be removable, is optional for installation. Refer to Fig.11.7.1 for the keypad exterior and inverter wiring diagram.




(a) Exterior

(b) Wiring diagram

Figure 11.5.1 Analog keypad

C. LED/ LCD keypad

LED keypad can be pulled out to operate and select different specifications of extension cables depending on needs.



L	Extension Cable *1
1m	JN5-CB-01M
2m	JN5-CB-02M
3m	JN5-CB-03M
5m	JN5-CB-05M

- *1 : inclusive of dedicatedly isolated wiring extension cable, blank cover, screws and instruction manuals.
- *2 : inclusive of a dedicatedly isolated wiring extension cable.
- *3 : Install blank cover to the position of digital keypad to avoid the unknown objects falling.

Dimensions of LED keypad (IP20):




Figure 11.5.2 Dimensions of LED keypad

Dimensions of LCD keypad (IP55):




Figure 11.5.3 Dimensions of LCD keypad (IP55)

D. 1 to 8 Pump Card



Refer to instruction manual of the option card to install.

JN5-IO-8DO Card: 8 Relay Output Card.

Terminals of JN5-IO-8DO:


Terminal	Description
RY1~RY8	Relay1~Relay8 A terminal output
CM1~CM4	Common terminal output

Wiring of JN5-IO-8DO (Example):




E. Copy Unit (JN5-CU)

The copy unit is used to copy an inverter parameter setup to another inverter.



F. Copy Module (JN5-CU-M)


The copy module is used to copy multiple (128 sets) inverters parameters setup to another inverter.




G. RJ45 to USB connecting Cable (1.8m)

JN5-CM-USB has the function of converting USB communication format to RS485 to achieve the inverter communication control being similar with PC or other control equipment with USB port.

- Exterior:



- Connecting:



Information
provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk

11.6 Communication Options

(a) PROFIBUS communication interface module (JN5-CM-PDP)

For wiring example and communication setup refer to JN5-CM-PDP communication option manual.

(b) DEVICENET communication interface module (JN5-CM-DNET)

For wiring example and communication setup refer to JN5-CM-DNET communication option manual.

(c) CANopen communication interface module (JN5-CM-CAN)

For wiring example and communication setup refer to JN5-CM-VAN communication option manual.

(d) TCP-IP communication interface module (JN5-CM-TCPIP)

For wiring example and communication setup refer to JN5-CM-TCPIP communication option manual.

Information
provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk

11.7 Profibus Communication Option Card

11.7.1 Introduction


It is the detailed descriptions and applications for F510 Profibus DP communication option card (JN5-CM-PMUS).

11.7.2 Specification of JN5-CM-PBUS

When Profibus-DP Communication card works, the RS-485 ports are not available for communication, An error would occur if you use both Profibus-DP communication card and RS-485 communication port at the same time.

Specification	Content									
Main Function	Connect F510 inverter with Profibus-DP network									
Suitable Inverter	F510 Series									
Mounting Base	Connector on F510 Control Board									
Maximum Connection	32 DP-Slave nodes									
Auto-Baud Search(bit/Sec)	9.6K	19.2K	93.75K	187.5K	500K	1.5M	3M	6M	12M	
Transmission Distance(m)	1200	1200	1200	1000	400	200	100	100	100	
Connection Medium	Profibus Layer2 Cable									
Optic Coupler Isolation	Common Mode Rejection $V_{cm}=50V, dV/dt=5000V/\mu Sec$									
Access Parameter	16 Words in, 16 Words out									
Terminal Resistor	DIP Switch Setting On Board									
LED Indication	Operation, Profibus communication									
Dimension	101 mm x 40.5 mm									

11.7.3 Wiring Diagram of JN5-CM-PBUS




Terminals of JN5-CM-PBUS

Terminal	Function
B+	Profibus sends and receives signals (Positive)
A-	Profibus sends and receives signals (Negative)
E	Connect to the isolation layer of Profibus Cable


11.7.4 Installation

- (1) Turn on the inverter and check the Software version in parameter 13-01.
In order to support functions of Profibus-DP communication card, it is necessary to use F510 inverter with software version 1.2 or newer version.
- (2) Set parameters 09-02、00-02、00-05. Please refer to section 11.9.6 for the setting of related communication parameters. Then turn off the inverter.
- (3) Remove the Digital Operator and front cover / terminal cover. Please also refer to Section 3.2.4 for the installation process to remove operator and covers for avoiding damage to the inverter.
- (4) Turn off the inverter and check the CHARGE indicator is OFF.
- (5) Mount the Profibus-DP communication card to the control board, with the hole aligned to the locking supports, and the connector CN1 aligned to CN3 (36pin) of control board. Please refer to the following figure.
- (6) Connect the Profibus Layer 2 Cable to TB1 on Profibus-DP Optio Card.
(The green line is for A-, and the red one is for B+)
- (7) Set Profibus Address and terminal resistor via SW1 and SW2. (please refer to section 11.9.5 for the setting of SW1 and SW2.)
- (8) Turn On the F510 Inverter.




Information
provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk

(1) For IP00/ IP20 models




- ① Loosen the fixing screw on the terminal cover.
- ② Press the latch on both sides of the terminal cover, and then pull it out.
- ③ Press the latch on the side of digital operator to remove it.
- ④ Disconnect the RJ45 cable of digital operator.
- ⑤ Press the latch on both sides of the front cover, and then pull it out.
- ⑥ Install the option card.
- ⑦ Follow the instructions above in a reverse order to re-assemble the machine.

(2) For IP55 models



- ① Loosen the fixing screw on the digital operator.
- ② Press the latch on the bottom of digital operator, and then pull it out.
- ③ Disconnect the RJ45 cable of digital operator.
- ④ Loosen the fixing screw (6pcs) on the front cover.
- ⑤ Remove the front cover (be careful not to drop waterproof gasket).
- ⑥ Install the option card.
- ⑦ Follow the instructions above in a reverse order to re-assemble the machine.

11.7.5 Descriptions of Terminals, LEDs and DIP switch



(1) Terminals

Terminals	Description
B+	Profibus Signal (Positive)
A-	Profibus Signal (Negative)
E	Connect to shield of Profibus Cable

(2) LED

LED	Description
LED1 (Red)	LED lights during the Profibus-DP communication.
LED2 (Red)	LED lights while the option card operates without error.

(3) DIP Switch

A. SW1 (Profibus Address. Please set the SW1-6, 1-7, 1-8 to OFF)

Address	SW1-5	SW1-4	SW1-3	SW1-2	SW1-1
1	OFF	OFF	OFF	OFF	OFF
2	OFF	OFF	OFF	OFF	ON
⋮	⋮				
30	ON	ON	ON	OFF	ON
31	ON	ON	ON	ON	OFF

B. SW2 (Terminal Resistor)

SW2	Description
ON	Enable terminal resistor between B+ and A-
OFF	Disable terminal resistor between B+ and A-

11.7.6 Related Parameters for Communication

PLC can monitor the status of F510 via Profibus DP option card while parameter 09-01 is set to 4(Profibus), and the operating command and frequency command are enabled by the setting of 00-02 to 2/ 00-05 to 3 (communication control) . Please refer to the following table:

Group	Parameter Name	Setting Range	Default
09-01	Communication Selection	4:Profibus	0
00-02	Main Run Command Source Selection	2:Communication Control	1
00-05	Main Frequency Command Source Selection	3:Communication Control	1

11.7.7 Profibus I/O List

Hardware configuration of PLC can define the Profibus I/O address as 400~431, with the correspondence to Profibus address and related parameters shown in below list.

(1) Data input (Data is received by PLC)

No.	Profibus address	Bit	Description
1	PIW400	0	Inverter status 1 : Running 0 : Stop
		1	Direction status 1 : Reverse 0 : Forward
		2	Inverter ready status 1 : Inverter ready 0 : Preparing
		3	Error 1 : Abnormal
		4	Alarm 1 : "ON"
		5	Zero Speed 1 : "ON"
		6	440 class type 1 : "ON"
		7	Frequency agree 1 : "ON"
		8	Setting frequency agree 1 : "ON"
		9	Frequency detection 1 1 : "ON"
		A	Frequency detection 2 1 : "ON"
		B	Under voltage 1 : "ON"
		C	Base Block 1 : "ON"
		D	Frequency command source 1 : From Profibus protocol
		E	SeqNotFromComm 1 : "ON"
		F	Over torque 1 : "ON"

No.	Profibus address		Bit	Description
2	PIW402	Fault Content	0	Reserved
			1	UV
			2	OC
			3	OV
			4	OH1
			5	OL1
			6	OL2
			7	OT
			8	UT
			9	SC
			10	GF
			11	FU
			12	IPL
			13	OPL
			14	Reserved
			15	Reserved
			16	Reserved
			17	EF1
			18	EF2
			19	EF3
			20	EF4
			21	EF5
			22	EF6
			23	Reserved
			24	Reserved
			25	PID Feedback Fault
			26	Keypad Removed
			27	Modbus External Fault
			28	CE
			29	STO
3	PIW404	DI Status	0	Programmable digital Input S1
			1	Programmable digital Input S2
			2	Programmable digital Input S3
			3	Programmable digital Input S4
			4	Programmable digital Input S5
			5	Programmable digital Input S6
			6	Reserved
			7	Reserved
			8	Reserved
			9	Reserved
			A	Reserved
			B	Reserved
			C	Reserved
			D	Reserved
			E	Reserved
			F	Reserved

No.	Profibus address		Bit	Description						
4	PIW406			Frequency command (6000/60Hz)						
5	PIW408			Output frequency (6000/60Hz)						
6	PIW410			Reserved						
7	PIW412			Voltage command (1/0.1V)						
8	PIW414			Output current (1/0.1A)						
9	PIW416	Alarm Content	0	No alarm	19	EF3	38	SE05	57	LOPb
			1	OV	20	EF4	39	HPERR	58	HIPb
			2	UV	21	EF5	40	EF	59	LSCFT
			3	OL2	22	EF6	41	Reserved	60	LOPb
			4	OH2	23	Reserved	42	Reserved	61	RETRY
			5	Reserved	24	Reserved	43	RDP	62	Reserved
			6	OT	25	Reserved	44	Reserved	63	Reserved
			7	Reserved	26	CLB	45	OL1	64	HIPb
			8	Reserved	27	Reserved	46	Reserved	65	OH1
			9	UT	28	Reserved	47	SE10	66	FIRE
			10	Reserved	29	USP	48	Reserved		
			11	Reserved	30	RDE	49	BB1		
			12	Reserved	31	WRE	50	BB2		
			13	CE	32	FB	51	BB3		
			14	Reserved	33	VRYE	52	BB4		
			15	Reserved	34	SE01	53	BB5		
			16	Reserved	35	SE02	54	BB6		
			17	EF1	36	SE03	55	Reserved		
			18	EF2	37	Reserved	56	Reserved		
10	PIW418	DO Status	0	R1A-R1C output 0: No action 1: output						
			1	R2A-R2C output 0: No action 1: output						
			2	R3A-R3C output 0: No action 1: output						
			3-1	Reserved						
			5							
11	PIW420			AO1 (0.00V ~ 10.00V)						
12	PIW422			AO2 (0.00V ~ 10.00V)						
13	PIW424			Analog input 1 (1/0.1%)						
14	PIW426			Analog input 2 (1/0.1%)						
15	PIW428			Reserved						
16	PIW430			Reserved						

(2) Data output (Data is sent by PLC)

No.	Profibus address		Bit	Description
1	PQW400	Operating signal	0	Operating command 1 : Run 0 : Stop
			1	Direction command 1 : Reversed 0 : Forward (User can prohibit the direction via parameter 11-00, 0: Allow FWD/REV 1: Allow FWD only 2: Allow REV only)
			2	External fault 1 : Fault
			3	Fault reset 1 : Reset
			4	Reserved
			5	Reserved
			6	Programmable digital Input S1 1 :“ON”
			7	Programmable digital Input S2 1 :“ON”
			8	Programmable digital Input S3 1 :“ON”
			9	Programmable digital Input S4 1 :“ON”
			A	Programmable digital Input S5 1 :“ON”
			B	Programmable digital Input S6 1 :“ON”
			C	Reserved
			D	Reserved
			E	Controller mode 1 : “ON”
F	Reserved			
2	PQW402			Frequency command(6000/60Hz)
3	PQW404			Reserved
4	PQW406			Reserved
5	PQW408			AO1 (0.00V ~ 10.00V)
6	PQW410			AO2 (0.00V ~ 10.00V)
7	PQW412	DO Status	0	R1A-R1C output(0: No action 1: output) (It is enabled while 03-11=32)
			1	R2A-R2C output (0: No action 1: output) (It is enabled while 03-12=32)
			2	R3A-R3C output (0:No action 1: output) (It is enabled while 03-39=32)
			3-1 5	Reserved
8	PQW414			Reserved
9	PQW416			
10	PQW418			
11	PQW420			
12	PQW422			
13	PQW424			
14	PQW426			
15	PQW428			
16	PQW430			

11.7.8 Error Message

If Profibus DP option card is unable to communicate with Profibus network or F510, or the circuit is defective, the F510 will display error message in the digital operator. For most of the errors, the LED1 in communication option card will flash or be off, showing that the option card is unable to work properly.

Message in Operator	Option card LED Status	Content	Description
Communication error 1	LED1 Flash	Communication Time-out	Profibus DP option card does not receive any data from Profibus network in specified period.
Communication error 2	LED2 Flash	Dual port RAM Fault	Dual-port RAM Fault.
Communication error 3	LED2 Flash	Dual port RAM Checksum Error	Dual-port RAM Checksum Error while data is being exchanged in Dual-port RAM.
Communication error 4	LED2 Flash	Dual port RAM data error	Dual-port RAM data Error while data is being exchanged in Dual-port RAM

11.7.9 GSD File

```

;*****/
;/* Filename:   F510-P.GSD
;/* ModelName:  TECO AC DRIVES F510
;/* CreateDate: 2012.12.18
;*****/
#Profibus_DP
GSD_Revision      = 1
Vendor_Name       = "TECO"
Model_Name        = "F510-P"
Revision          = "Version0.0"
Ident_Number      = 0xF510
Protocol_Ident    = 0                ;Profibus-DP
Station_Type      = 0                ;DP Slaver
FMS_supp          = 0                ;Pure DP Device
Hardware_Release  = "HW_V1.0"
Software_Release  = "SW_V1.0"
;
9.6_supp          = 1
19.2_supp         = 1
93.75_supp       = 1
187.5_supp       = 1
500_supp         = 1
1.5M_supp        = 1
3M_supp          = 1
6M_supp          = 1
12M_supp         = 1

```

```


MaxTsdr_9.6      = 60
MaxTsdr_19.2    = 60
MaxTsdr_93.75   = 60
MaxTsdr_187.5   = 60
MaxTsdr_500     = 100
MaxTsdr_1.5M    = 150
MaxTsdr_3M      = 250
MaxTsdr_6M      = 450
MaxTsdr_12M     = 800
Redundancy       = 0                ;Not Redundancy Supported
Repeater_Ctrl_Sig = 2                ;TTL
24V_Pins         = 0                ;Not Connected
;
Implementation_Type = "VPC3"
Bitmap_Device     = "DP_NORM"
Bitmap_Diag      = "bmpdia"
Bitmap_SF        = "bmpsf"
;
Freeze_Mode_supp = 1                ;Supported
Sync_Mode_supp   = 1                ;Supported
Auto_Baud_supp   = 1                ;Supported
Set_Slave_Add_supp = 0              ;can not change via profibus
;
Fail_Safe        = 0
Slave_Family     = 1                ;Drives Family
Min_Slave_Intervall = 10            ;PollingCycle:10*100uS=1mS
;
Max_Diag_Data_Len = 16
Max_User_Prm_Data_Len = 5
Modul_Offset     = 255
Ext_User_Prm_Data_Const(0) = 0x00,0x00,0x00,0x00,0x00
;
Modular_Station = 1                ;Modular Device
Max_Module      = 1                ;Only 1 Module can be inserted
Max_Input_Len   = 32
Max_Output_Len  = 32
Max_Data_Len    = 64
Module="16 Word In,16 Word Out" 0x7f
EndModule

```

11.8 Protective Cover

If inverter is around the environment of dust or metal shavings, it is recommended to purchase the protective covers positioned on both sides of the inverter to prevent unknown objects from invading.

Frame	Model
1	JN5-CR-A01
2	JN5-CR-A02
4	JN5-CR-A04



Protective Cover

Installation of Protective Cover

Inverter with Protective Cover

Appendix-A Instructions for UL

◆ Safety Precautions

DANGER

Electrical Shock Hazard

Do not connect or disconnect wiring while the power is on.

Failure to comply will result in death or serious injury.

WARNING

Electrical Shock Hazard

Do not operate equipment with covers removed.

Failure to comply could result in death or serious injury.

The diagrams in this section may show drives without covers or safety shields to show details. Be sure to reinstall covers or shields before operating the drives and run the drives according to the instructions described in this manual.

Always ground the motor-side grounding terminal.

Improper equipment grounding could result in death or serious injury by contacting the motor case.

Do not touch any terminals before the capacitors have fully discharged.

Failure to comply could result in death or serious injury.

Before wiring terminals, disconnect all power to the equipment. The internal capacitor remains charged even after the power supply is turned off. After shutting off the power, wait for at least the amount of time specified on the drive before touching any components.

Do not allow unqualified personnel to perform work on the drive.

Failure to comply could result in death or serious injury.

Installation, maintenance, inspection, and servicing must be performed only by authorized personnel familiar with installation, adjustment, and maintenance of AC drives.

Do not perform work on the drive while wearing loose clothing, jewelry, or lack of eye protection.

Failure to comply could result in death or serious injury.

Remove all metal objects such as watches and rings, secure loose clothing, and wear eye protection before beginning work on the drive.

Do not remove covers or touch circuit boards while the power is on.

Failure to comply could result in death or serious injury.

Fire Hazard

Tighten all terminal screws to the specified tightening torque.

Loose electrical connections could result in death or serious injury by fire due to overheating of electrical connections.

Do not use an improper voltage source.

Failure to comply could result in death or serious injury by fire.

Verify that the rated voltage of the drive matches the voltage of the incoming power supply before applying power.

Do not use improper combustible materials.

Failure to comply could result in death or serious injury by fire.

Attach the drive to metal or other noncombustible material.

NOTICE

Observe proper electrostatic discharge procedures (ESD) when handling the drive and circuit boards.

Failure to comply may result in ESD damage to the drive circuitry.

Never connect or disconnect the motor from the drive while the drive is outputting voltage.

Improper equipment sequencing could result in damage to the drive.

Do not use unshielded cable for control wiring.

Failure to comply may cause electrical interference resulting in poor system performance. Use shielded twisted-pair wires and ground the shield to the ground terminal of the drive.

NOTICE

Do not modify the drive circuitry.

Failure to comply could result in damage to the drive and will void warranty.

Teco is not responsible for any modification of the product made by the user. This product must not be modified.

Check all the wiring to ensure that all connections are correct after installing the drive and connecting any other devices.

Failure to comply could result in damage to the drive.

◆ **UL Standards**

The UL/cUL mark applies to products in the United States and Canada and it means that UL has performed product testing and evaluation and determined that their stringent standards for product safety have been met. For a product to receive UL certification, all components inside that product must also receive UL certification.

◆ **UL Standards Compliance**

This drive is tested in accordance with UL standard UL508C and complies with UL requirements. To ensure continued compliance when using this drive in combination with other equipment, meet the following conditions:

■ **Installation Area**

Do not install the drive to an area greater than pollution severity 2 (UL standard).

■ **Main Circuit Terminal Wiring**

UL approval requires crimp terminals when wiring the drive's main circuit terminals. Use crimping tools as specified by the crimp terminal manufacturer. Teco recommends crimp terminals made by NICHIFU for the insulation cap.

The table below matches drives models with crimp terminals and insulation caps. Orders can be placed with a Teco representative or directly with the Teco sales department.

Closed-Loop Crimp Terminal Size

Drive Model F510	Wire Gauge mm ² , (AWG)						Terminal	Crimp Terminal	Tool	Insulation Cap
	R/L1	S/L2	T/L3	U/T1	V/T2	W/T3	Screws	Model No.	Machine No.	Model No.
2008				5.5 (10)			M4	R5.5-4	Nichifu NH 1 / 9	TIC 5.5
2015				14 (6)			M4	R14-6	Nichifu NOP 60	TIC 8
2030				38 (2)			M6	R38-6	Nichifu NOP 60 / 150H	TIC 22
2050				80 (3/0)			M8	R80-8	Nichifu NOP 60 / 150H	TIC 60
2075				150 (4/0)			M8	R150-8	Nichifu NOP 150H	TIC 80
2125				300 (4/0)*2			M10	R150-10	Nichifu NOP 150H	TIC 100
4010				5.5 (10)			M4	R5.5-4	Nichifu NH 1 / 9	TIC 5.5
4020				8 (8)			M6	R8-6	Nichifu NOP 60	TIC 8
4040				22 (6)			M6	R22-6	Nichifu NOP 60 / 150H	TIC 14
4075				60 (2)			M8	R60-8	Nichifu NOP 60 / 150H	TIC 38
4125				150 (3/0)			M8	R150-8	Nichifu NOP 150H	TIC 80
4250				300 (4/0)*2			M10	R150-10	Nichifu NOP 150H	TIC 100

◆ **Type 1**

During installation, all conduit hole plugs shall be removed, and all conduit holes shall be used.

PS : About 2175 and 4300~4425, please see additional data page.

Recommended Input Fuse Selection

Drive Model F510	Fuse Type	
	Manufacturer: Bussmann / FERRAZ SHAWMUT	
	Model	Fuse Ampere Rating (A)
200 V Class Three-Phase Drives		
2002		
2003		
2005	Bussmann 50FE	690V 50A
2008	Bussmann 50FE	690V 50A
2010	Bussmann 63FE	690V 63A
2015	FERRAZ SHAWMUT A50QS100-4	500V 100A
2020	Bussmann 120FEE / FERRAZ A50QS150-4	690V 120A / 500V 150A
2025	FERRAZ SHAWMUT A50QS150-4	500V 150A
2030	FERRAZ SHAWMUT A50QS200-4	500V 200A
2040	FERRAZ SHAWMUT A50QS250-4	500V 250A
2050	FERRAZ SHAWMUT A50QS300-4	500V 300A
2060	FERRAZ SHAWMUT A50QS400-4	500V 400A
2075	FERRAZ SHAWMUT A50QS500-4	500V 500A
2100	FERRAZ SHAWMUT A50QS600-4	500V 600A
2125	FERRAZ SHAWMUT A50QS700-4	500V 700A

Drive Model F510	Fuse Type	
	Manufacturer: Bussmann / FERRAZ SHAWMUT	
	Model	Fuse Ampere Rating (A)
400 V Class Three-Phase Drives		
4002		
4003		
4005	Bussmann 16CT	690V 16A
4008	Bussmann 25ET	690V 25A
4010	Bussmann 40FE	690V 40A
4015	Bussmann 50FE	690V 50A
4020	Bussmann 63FE	690V 63A
4025	Bussmann 80FE	690V 80A
4030	Bussmann 100FE / FERRAZ A50QS100-4	690V 100A / 500V 100A
4040	Bussmann 120FEE	690V 120A
4050	FERRAZ SHAWMUT A50QS150-4	500V 150A
4060	FERRAZ SHAWMUT A50QS200-4	500V 200A
4075	FERRAZ SHAWMUT A50QS250-4	500V 250A
4100	FERRAZ SHAWMUT A50QS300-4	500V 300A
4125	FERRAZ SHAWMUT A50QS400-4	500V 400A
4150	FERRAZ SHAWMUT A50QS500-4	500V 500A
4175	FERRAZ SHAWMUT A50QS600-4	500V 600A
4215	FERRAZ SHAWMUT A50QS700-4	500V 700A
4250	FERRAZ SHAWMUT A50QS700-4	500V 700A

◆ Motor Overtemperature Protection

Motor overtemperature protection shall be provided in the end use application.

■ Field Wiring Terminals

All input and output field wiring terminals not located within the motor circuit shall be marked to indicate the proper connections that are to be made to each terminal and indicate that copper conductors, rated 75°C are to be used.

■ Drive Short-Circuit Rating

This drive has undergone the UL short-circuit test, which certifies that during a short circuit in the power supply the current flow will not rise above value. Please see electrical ratings for maximum voltage and table below for current.

- The MCCB and breaker protection and fuse ratings (refer to the preceding table) shall be equal to or greater than the short-circuit tolerance of the power supply being used.
- Suitable for use on a circuit capable of delivering not more than (A) RMS symmetrical amperes for (Hp) Hp in 240 / 480 V class drives motor overload protection.

Horse Power (Hp)	Current (A)	Voltage (V)
1 - 50	5,000	240 / 480
51 - 200	10,000	240 / 480
201 - 400	18,000	240 / 480
401 - 600	30,000	240 / 480

◆ **Drive Motor Overload Protection**

Set parameter 02-01 (motor rated current) to the appropriate value to enable motor overload protection. The internal motor overload protection is UL listed and in accordance with the NEC and CEC.

■ **02-01 Motor Rated Current**

Setting Range: Model Dependent
 Factory Default: Model Dependent

The motor rated current parameter (02-01) protects the motor and allows for proper vector control when using open loop vector or flux vector control methods (00-00 = 2 or 3). The motor protection parameter 08-05 is set as factory default. Set 02-01 to the full load amps (FLA) stamped on the nameplate of the motor.

The operator must enter the rated current of the motor (17-02) in the menu during auto-tuning. If the auto-tuning operation completes successfully (17-00 = 0), the value entered into 17-02 will automatically write into 02-01.

■ **08-05 Motor Overload Protection Selection**

The drive has an electronic overload protection function (OL1) based on time, output current, and output frequency, which protects the motor from overheating. The electronic thermal overload function is UL-recognized, so it does not require an external thermal overload relay for single motor operation.

This parameter selects the motor overload curve used according to the type of motor applied.

Overload Protection Settings

Setting	Description
---0B	Motor Overload Protection is disabled
---1B	Motor Overload Protection is enabled
--0-B	Cold Start of Motor Overload
--1-B	Hot Start of Motor Overload
-0--B	Standard Motor
-1--B	Special motor

Sets the motor overload protection function in 08-05 according to the applicable motor.


Setting 08-05 = ---0B. Disables the motor overload protection function when two or more motors are connected to a single inverter. Use an alternative method to provide separate overload protection for each motor such as connecting a thermal overload relay to the power line of each motor.

Setting 08-05 = --1-B. The motor overload protection function should be set to hot start protection characteristic curve when the power supply is turned on and off frequently, because the thermal values are reset each time when the power is turned off.

Setting 08-05 = -0--B. For motors without a forced cooling fan (general purpose standard motor), the heat dissipation capability is lower when in low speed operation.

Setting 08-05 = -1--B. For motors with a forced cooling fan (inverter duty or V/F motor), the heat dissipation capability is not dependent upon the rotating speed.

To protect the motor from overload by using electronic overload protection, be sure to set parameter 02-01 according to the rated current value shown on the motor nameplate. Refer to the following "Motor Overload Protection Time" for the standard motor overload protection curve example : Setting 08-05 = -0--B.



Motor Overload Protection Time

■ **08-06 Start-up mode of overload protection operation**

Setting	Description
0	Stop Output after Overload Protection
1	Continuous Operation after Overload Protection

Appendix-A Instructions for UL- Additional Data

08-06=0: When the inverter detects a motor overload the inverter output is turned off and the OL1 fault message will flash on the keypad. Press RESET button on the keypad or activate the reset function through the multi-function inputs to reset the OL1 fault.

08-06=1: When the inverter detects a motor overload the inverter will continue running and the OL1 alarm message will flash on the keypad until the motor current falls within the normal operating range.

Motor overtemperature protection shall be provided in the end use application.

Closed-Loop Crimp Terminal Size

Drive Model F510	Wire Gauge mm ² , (AWG)					Terminal	Crimp Terminal	Tool	Insulation Cap	
	R/L1	S/L2	T/L3	U/T1	V/T2	W/T3	Screws	Model No.	Machine No.	Model No.
2175	152 (300)*2					M12	R150-12*2	Nichifu NOP 150H	TIC 150	
4300	203 (400)*2					M12	R200-12S*2	Nichifu NOH 300K	TIC 200	
4375	253 (500)*2					M12	R325-12S*2	Nichifu NOH 300K	TIC 325	
4425	253 (500)*2					M12	R325-12S*2	Nichifu NOH 300K	TIC 325	

◆Type 1

During installation, all conduit hole plugs shall be removed, and all conduit holes shall be used.

Recommended Input Fuse Selection

Drive Model F510	Fuse Type	
	Manufacturer: Bussmann / FERRAZ SHAWMUT	
	Model	Fuse Ampere Rating (A)
200 V Class Three-Phase Drives		
2150	Bussmann 170M5464	690V 800A
2175	Bussmann 170M5464	690V 800A

Drive Model A510	Fuse Type	
	Manufacturer: Bussmann / FERRAZ SHAWMUT	
	Model	Fuse Ampere Rating (A)
400 V Class Three-Phase Drives		
4300	Bussmann 170M5464	690V 800A
4375	Bussmann 170M5464	690V 800A
4425	Bussmann 170M5466	690V 1000A
4425		

Information
provided by
EMAG
Tel: 01902 601403
www.emag-ltd.co.uk



TECO Electric & Machinery Co., Ltd.

10F., No.3-1, Yuancyu St., Nangang District,
Taipei City 115, Taiwan
Tel : +886-2-6615-9111
Fax : +886-2-6615-0933

<http://globalsa.teco.com.tw/tw>

Distributor

Ver:02 2014.01

This manual may be modified when necessary because of improvement of the product, modification, or changes in specifications, This manual is subject to change without notice.